

CADILLAC


MOTOR CARS




1927

CADILLAC MOTOR CAR COMPANY

DETROIT



Public preference for the Cadillac is pronounced only because public confidence in Cadillac mechanism, coachwork, and policies has never been betrayed. Year after year, this car has maintained its position, well in the van of engineering thought and practice; year after year, it has accorded its owners an excess measure of travel comfort. Its leadership has become traditional. Its worth is acknowledged, and everywhere the public mind is firmly settled in the conviction that ultimate degrees of motoring satisfaction may be attained only with the Cadillac



THE NEW CADILLAC

HOW IT EMPHASIZES ANEW THE FUNDAMENTAL REASONS
FOR CADILLAC OWNERSHIP

So widespread is the desire to own a Cadillac car that the reasons supporting it are often taken for granted. Frequently they become obscured.

They are, in reality, clear-cut and conclusive. Based on definite, demonstrable facts about the car itself and about the character of the organization building the car, they constitute an unanswerable argument.

The fact cannot be overemphasized that the Cadillac is a fundamentally fine, remarkably sturdy, amazingly versatile mechanism. Not only does it meet every demand imposed upon it; it does so with a smoothness, a silence, an easy grace of performance that kindles the enthusiastic loyalty of its owners and commands the honest respect of its competitors. It excels, without at any time directing attention to its extraordinary ability—excels in a quiet, restrained way eloquent of ability borne gracefully as heritage from a long and exceptional lineage.

So long has Cadillac thus stood as the acknowledged leader in the field of eight-cylinder fine cars that passing notice to this mechanical excellence will suffice. For twenty-three years this car has retained its position as Standard of the World. For eleven years, Cadillac has led the world in perfecting eight-cylinder design—led so capably and upon such sound authority that the type of construction it inaugurated at that early date prevails today in these newest and most modern Cadillacs. Such is the proud record of builders who first made sure that they were right.

Because they built at that time on correct engineering principles, there has never arisen need for veering from one type of construction to another, for throwing over past achievements and setting out anew on untried paths. Cadillac's whole history has been one of consistent, consecutive progress toward one ideal.

CADILLAC MOTOR CARS

For eleven years every Cadillac car has been powered with a 90° V-type, eight-cylinder engine. Changes have from time to time been introduced, until this power plant stands today an unparalleled engineering achievement. It is compact, sturdy, efficient, delivering a flow of power so abundant, so pliant, and so docile as to amaze even the most seasoned motorist.

This identical type of engine powers the new Cadillac because its performance cannot be excelled by any other. And probably the most impressive single fact about this superb car is precisely this—that its power plant has been perfected through eleven years of use and of test under the guidance of a single, progressive, able engineering organization.

With this masterful engine, Cadillac combines a chassis strong and rigid against every strain and perfectly balanced in every part, incorporating the most advanced type of mechanical four-wheel brakes.

It is the surpassing performance of this

operating mechanism that has continued year after year to hold the confidence of motor-dom to a degree unparalleled in an industry where competition is incessant and keen.

Against this background of phenomenal ability and long life, new mechanical features, however imposing they may in themselves be, are seen in their correct proportions, as refinements—additional reasons, but not the basic cause, for Cadillac ownership.

Recent refinements in the Cadillac chassis aptly illustrate the truth of these statements. They embrace a number of advancements in design that make the car more alert in get-away and fleetier in action and that simplify service procedure, together with an effective method for preventing crankcase dilution. This last utilizes the pressure built up normally in the crankcase by the revolving crankshaft to expel all gasoline and water vapors before they reach the engine oil. Long life for oil is further assured by an effective oil filter.


COACHWORK

Cadillac cars have always enjoyed the hearty endorsement of the public, not only for their mechanical supremacy, but also for the substantial dignity of their appearance and the luxurious comfort they accord their passengers. Their sound engineering is matched by a quality of coachcraft that gains the instant and abiding approval of those motorists who insist upon the genuinely fine and beautiful.

In these cars, this traditional leadership in fine coachwork is asserted more emphatically than ever before. All are Fisher-built upon plans and specifications of Cadillac engineers working in conjunction with the technical staff of the Fisher Body Corporation.

In this union of expert forces lies the ultimate secret of their intrinsic merit and consummate beauty.

CADILLAC MOTOR CARS



1. One-piece, VV windshield on all closed models
2. Note the rich inset panel
3. Controls are closely, conveniently grouped

4. The glass partition may be raised or lowered
5. Grace, strength, and impressive dignity
6. The trunk rack is of distinctive Cadillac design

CADILLAC MOTOR CARS

At every step unusual precautions are taken in building and finishing these bodies. They are constructed in a special division of the Fisher factories, where Cadillac standards are rigidly maintained. They are finished, upholstered, and appointed in the Cadillac factory itself by craftsmen of long Cadillac experience under the direction of able Cadillac executives.

The pleasing symmetry and proportions of these bodies are enhanced by new fenders of graceful, oval contour, a longer hood, and a narrower, higher radiator encased in a nickel shell of impressive and simple design. At every point there is evidence of true artistic taste, practical engineering ability, intimate knowledge of the requirements of travel comfort, and expert mastery of the means by which that comfort is to be made grateful and lasting.

The Standard line embodies Cadillac's highest ideals of travel comfort and of

beauty. Furnished in Duco finish in various color treatments, they are cars of distinctive charm.

Arm rests in closed cars, for example, are of patented construction, built up of coiled springs, covered with curled hair and upholstered. Doors of all closed cars are trimmed plain with garnished walnut mouldings around the windows. The doors are of unusually sturdy construction, with patented dovetails encased in metal. All are equipped with outside door handles and double safety catches. A unique development is a combination interior door and pull-to-handle. The instrument board in all models is especially rich, with inset panels finished in walnut.

The battery is located in a special metal case inset into the left-hand front fender, where it is fully accessible. Road tools are carried in a similar case on the right-hand side. Both boxes are locked.

THE ORGANIZATION

Of even greater significance than these facts about Cadillac cars themselves are the history and record of the Cadillac Motor Car Company, the organization that gives these cars being and determines their character. About the comparative worth of divergent types of mechanical construction competent authorities may and do differ; about the importance of seasoned experience there can be no question. And here

Cadillac stands well-nigh alone in the entire automotive industry, wholly alone in its specific fine car field.

The history of Cadillac goes back to the days when the mere ability of automobiles to run was often subject to doubt; it extends in a continuous development down to the present moment, when mechanisms have been refined to the point of perfection and when lavish provision for travel comfort is

CADILLAC MOTOR CARS

expected and supplied. Cadillac contributions to the industry during that period are notable.

Notable Achievements

Instances of that history are a matter of public knowledge; Cadillac is known as the car that introduced electric starting and lighting; as the one that first built a really standardized car, with absolutely interchangeable parts; as the first high-speed, V-type engine; as the American car which twice won the coveted Dewar Trophy, England's symbol of mechanical supremacy; as the car which first utilized thermostatic control of engine temperature and thermostatic control of carburetion; as the first American manufacturing company to adopt as factory equipment the world-famous Johansson gauges, accurate to the hundred-thousandth part of an inch.

Cadillac Precision

In the precision with which parts are machined and the accuracy with which they are assembled, Cadillac has long been known to be the leader.

In the exhaustive analysis of materials and rigid inspections of work in process, Cadillac standards are respected and emulated throughout the industry.

In addition to the betterments it has introduced in motor cars, Cadillac has also consistently been a leader in inaugurating those incidental services which enable the car owner to derive the maximum enjoyment from motoring.

Wherever the Cadillac owner may care to travel with his car, he will find service facilities which, when both quality and quantity are taken into account, are second to none.

THE MECHANISM


The Cadillac performs brilliantly because its mechanism is fine. Details of mechanical design that may, in themselves, be of absolutely no interest to the car owner, are in it developed with patient care into a chassis that operates with unmatched smoothness, responsiveness, efficiency, and endurance. The owner may operate his Cadillac for years without needing to know the details of its construction. Yet in the details of its design must be found the reason why year after year it can serve him capably and with only such slight interruptions as are

incidental to essential maintenance attentions—why, year after year, this car continues to win and retain the enthusiastic loyalty of the most exacting motorists.

Consistent Development

The fundamental features of that design have long remained unchanged because no superior type of construction for a fine passenger vehicle has yet been developed. Those features have been tried and approved by eleven years of use in the hands of more than 200,000 motorists.

CADILLAC MOTOR CARS



1. Why Cadillac's V-eight engine is inherently smooth
2. Hand brake does not require adjustment
3. Transmission gears specially ground for silence
4. Semi-elliptic rear springs are universally mounted
5. Rear signal light unit is on rear fender
6. How Cadillac prevents crankcase contamination
7. Full floating rear axle, Cadillac made, with special alloy steel shafts, gears and housing tubes

Refinements upon these features have, of course, been introduced from time to time in keeping with the vigorous development of the Cadillac. An unusual number are incorporated in the new Cadillac. And they are especially significant to the car owner because they make his Cadillac more alert in action, simpler to care for, and, therefore, capable of a finer quality of uninterrupted performance than even Cadillacs have rendered in the past.

Compact, Simple, Sturdy

Cadillac's 90° V-type, eight-cylinder engine is notable among automobile power plants primarily for its ability, and next for the inherent compactness, simplicity, and sturdiness of its construction. It is the shortest automobile engine of four or more cylinders and of equal displacement ever produced. And in the new Cadillac its fundamental simplicity is evidenced in a high degree of accessibility.

Note the unusual vertical mounting of the starting motor, and just forward from it the timer-distributor which, in this position at the extreme rear of the engine, is protected from water in all weathers. Notable points in maintenance attentions are that the timer-distributor is driven by automatically-lubricated gears, and that it can be removed by taking out only one screw. It can be removed and replaced without making it necessary to retime the engine. All this means a shorter stop if this unit should require attention.

There is only one water pump, whose capacity exceeds that of the two formerly

used. A reduction in the number of water connections is thereby effected. Upper hose connections need never be loosened because an outlet elbow with gasket forms the attachment to the cylinder head.


An added feature of the cooling system is the thermostatic control of engine temperature through radiator shutters. Operating automatically, these promote efficient performance and help to counteract all tendency to crankcase dilution in cold weather. These shutters are vertical and, with the new nickel radiator shell, add impressive height to the front of the car.

Keeping the Oil Pure

Particularly significant among improvements in the engine is the Cadillac system of crankcase ventilation which prevents the contamination of engine oil by water vapors and unburned gas. Ever since the earliest development of internal combustion engines, the leakage of these vapors from the combustion chambers into the crankcase has presented a difficult problem. The finest possible manufacturing practice cannot wholly prevent this leakage. Devices which have been attempted for curing its ill effects have failed to prove satisfactory, and the only solution heretofore available has been to change the lubricating oil frequently.

Cadillac now perfects the superior method of preventing this pollution of oil. The air pressure normally built up in the crankcase by the rotation of the crankshaft is utilized to blow these vapors through special ports in the cylinder walls into the valve com-

CADILLAC MOTOR CARS



Cadillac's powerful, smooth-running, efficient and compact engine—the famous 90° V-type

partments before they can cool enough to condense.

The oil supply is still further guarded by an oil filter which effectively removes any impurities in solid form which may be in the oil. So effectively do these safeguards maintain the lubricating qualities of the oil that far more than the usual mileage can be had before draining the crankcase.


Automatic lubrication of the valve stems eliminates the possibility of annoyance from sticking valves. This improvement is brought about by drilling two $\frac{1}{8}$ -inch holes in each

cylinder wall opposite the two nearest valves, and at such distance from the bottom of the cylinder that when the piston is at the bottom of its stroke these holes register with a groove in the piston between the second and third piston rings.

When the piston descends on the power stroke, oil collects in this groove and as soon as the groove registers with the two small holes in the cylinder wall, the pressure of the gases above the piston forces a fine spray out through each hole upon the adjacent valve stem.

Excess oil collects in the bottom of the valve chamber, whence it is returned through ducts into the crankcase.

Valve adjustment screws are locked in the valve lifters by means of a split collar and clamping screw. Adjusting the valve stem clearance has been reduced to its sim-



The unique, positive, pressure-feed fuel system


plest terms, and is effected by loosening the clamping screw with a screw driver, setting the adjustment with a wrench and retightening the screw.

Fuel Distribution

The greatest possible uniformity in distribution of fuel gas and simpler servicing attention are assured by the construction of the intake manifold. A very short, exhaust-heated induction pipe conducts fuel from the carburetor to the intake passage. Instead of being cast in the cylinder block itself, as is common practice, this passage is now a separate casting bolted on the face of the cylinder block. The induction pipe has a single cover on top and is attached to the intake manifolds and the exhaust pipes by four cap screws in each flange. The whole can be simply and quickly disassembled whenever necessary for service attentions.

Smoother Riding

A signal improvement is incorporated in the rear spring suspension, which now em-



Note the convenient location for road tools



Every driving convenience at a touch

ploys a semi-elliptic spring 60 inches long. The advantages of the former platform type are retained through the method of attaching the rear shackle which is universally mounted to the frame through a shackle of tension type with ball and socket connection. This design protects the body from strain because it does not transmit the twists which result from the body riding level while the wheels are aligning themselves with the road.

An improved joint connects the front end of the torque arm to the frame. It employs three plies of heavy fabric to absorb the braking and torque reactions.

This construction completely eliminates wearing surfaces at this point, giving silent operation throughout the life of the car without necessity for adjustment or lubrication.

CONDENSED SPECIFICATIONS

Engine—Compensated eight-cylinder V-type, 90-degree angle between the cylinder blocks. Piston displacement 314 cubic inches, bore $3\frac{1}{8}$ ", stroke $5\frac{1}{8}$ ". Engine and transmission in unit, three-point suspension with spherical trunnion support on front cross member. Cylinders cast in blocks of four, with detachable cylinder heads and internally machined combustion chambers.

Silico-chrome valves, intake $1\frac{1}{8}$ ", exhaust $1\frac{3}{8}$ ", opening, $\frac{5}{16}$ " lift. Valve mechanism enclosed. Crankshaft $2\frac{3}{8}$ " diameter, supported on three main bearings, and provided with compensators.


Single hollow camshaft with 16 cams, supported on six bearings. The camshaft is driven from the crankshaft by a silent chain. The fan and generator are driven by a belt from the camshaft. The chain is automatically adjusted by mechanism contained in idle sprocket.

Horsepower—S. A. E. rating 31.25 H. P. actually more than 80.

Cooling—Total capacity of cooling system $5\frac{1}{2}$ gallons. One large water pump with capacity of 1200 gal. per hour at 300 R. P. M. Both cylinder blocks are interconnected by a brass tube cast in crankcase insuring circulation. Temperature of the engine is controlled by a thermostatically controlled radiator shutter with vertical balanced shutter blades.

One drain valve for entire cooling system at bottom of water pump. Radiator, copper, cellular type.

Electrical System—Source of current—four-pole Cadillac—Delco generator driven by belt from camshaft.



No abrasives pass this oil filter

Automatic charging current regulation by third brush. Single wire system with ground return. Storage battery Cadillac—Exide 130 A. H. 3 cells 6 volts. Automatic circuit breakers (no fuses).

Ignition—Cadillac—Delco high tension system with two timer contact arms actuated by four-lobed cam. Current supplied by generator and battery. Automatic spark advance with auxiliary hand control. Enclosed wiring.

Lighting—Headlamps with tiltable light beam controlled from dash. The lamps are equipped with fluted lenses, with 21 c. p. double filament bulbs and also 4-candle parking bulbs. Additional feature is a special metal cap over lamp bulb to prevent dazzling reflection from fog. Tail lamp in unit with back-up lamp and traffic signal lamp. Back-up light operated by reverse gear shift. Traffic signal controlled by brake pedal. Combination inspection lamp and cigar lighter with 21 c. p. bulb, 12-foot extension cord on reel. Standard line closed cars have dome lights only, except Two Passenger Coupe, which has quarter lights only. Custom closed cars have dome lights and rear quarter lights. Dome lights on custom cars light automatically with opening of door. There is also a controlling switch on inside of car, accessible to all passengers.

The electric gasoline gauge on instrument board operates from storage battery.

Starter—Cadillac—Delco separate unit. Special design and exclusive on Cadillac cars, unusual stalling torque.

Lubrication—Pressure system with gear pump conveys oil under pressure to all main bearings, connecting rod bearings and camshaft bearings and is controlled by an automatic pressure regulator. The oil level indicator gauge is located on right-hand side of crankcase.

Cadillac Crankcase Ventilating System—In our new engine an exclusive system is introduced which prevents pollution of lubricating oil by products of combustion and water condensate.

Carburetor—Cadillac design and manufacture. Uniform distribution with maximum efficiency and economy. Carburetor enriching control on dash to facilitate starting. Intake manifold exhaust heated. One adjustment. Automatic thermostatic control for compensation of changes in atmosphere and engine temperatures. Large accessible strainer at carburetor. Carburetor overflow drained to ground.

CADILLAC MOTOR CARS

Clutch—Multiple disc dry plate—fifteen carbon steel plates, seven of which are driven by gear teeth in the flywheel clutch ring and are covered on both sides with compressed asbestos fabric disc $7\frac{3}{4}$ " diameter. The eight driven discs are carried on steel clutch hub and drive the hub through 45 gear teeth.

Transmission—Transmission mechanism contained in aluminum alloy case. Selective type with three speeds forward and reverse. Chrome nickel steel gears and shafts. The faces of gear teeth are ground on special grinding machines to obtain silent operation. Speedometer drive inside transmission case. The built-in transmission lock located in oil and dust-proof compartment is operated by same key as the switch, tool compartment and tire lock.

Axle—Rear axle, Cadillac make, full floating with special alloy steel axle shafts, gears and axle housing tubes. Spiral type of bevel gears mounted on large ball bearings. Pinion forward bearing has a double row of balls.

Front axle Reverse Elliot Type, drop-forged, special alloy steel, beam section with integral spring perches; drop-forged steering spindles and steering arms; the

steering spindles have tapered roller bearings at upper ends. The straight steering cross rod with ball and socket connections at ends.


Gear Ratios—4.91 to 1, 4.5 to 1, 4.15 to 1.

Drive—Tubular drive shaft 3" diameter transmits the power from the transmission to the rear axle and is fitted with an enclosed universal joint at each end. Grease gun connections for lubrication of universal joints.

Brakes—Two independent braking systems. Foot brakes on all four wheels. Front foot brake internal expanding, rear external contracting. Division of pedal pull automatically proportioned between front and rear systems. Front brakes thermally equalized when straight ahead, outer brake released on turn. 17" brake drums on all wheels.

Hand brakes operated by hand lever on rear wheels, internal expanding type, and will not require adjustment during life of brake lining.

Steering Gear—Cadillac patented gear sector type adjustable with ball thrust bearings. Steering wheel and spokes of walnut, 18" diameter. Steering column angle.



Large radiator and vertical shutters for efficiency; compensating brakes and sturdy axle for safety

CADILLAC MOTOR CARS

Standard Line—

Coupe 2 pass.....	39°
Brougham.....	41°30'
Victoria.....	41°30'
Sedan 5 pass.....	39°
Sedan 7 pass.....	41°30'
Touring.....	41°30'
Phaeton.....	39°
Roadster.....	39°

Frame—Slide bars channel section with wide top flange, carbon steel, maximum depth 7", width 30" in front, 33" in rear, 4 channel cross members and 2 tubular cross members.

Wheels—Artillery type, 12 spokes 1 $\frac{3}{4}$ " side, hickory with steel felloes. Roller bearings, demountable split type rim and six lugs, large steel hub flange with 12 bolts.

Tires—Straight side 33 x 6.75 cord balloon.

Wheelbases—132"—138"—(150" chassis only).

Tread—56".

Springs—Universally suspended semi-elliptic system of suspension. Rear shackle, tension type, with ball and socket connection to frame.

Front Springs 42 x 2".

Rear Springs 60 x 2 $\frac{1}{4}$ ".

Control—Center gear shift and hand brake control, left-hand steering. Service brake foot pedal, clutch pedal, throttle accelerator pedal with foot rest. Throttle, spark lever, and horn button at center of steering wheel. Carburetor enriching control and tilting beam control on instrument board.

Gasoline System—Twenty-gallon tank with electric gasoline gauge on dash (16.67 Imperial Gallons, 75.70 liters). Fuel forced to carburetor by air pressure supplied by air compressor on front of engine, air pressure relief valve in left-hand side of frame, under front floor boards, air gauge, and auxiliary compressor on instrument board.

Top—Open cars—Touring Car five-bow, Phaeton four-bow, Roadster three-bow top. The Touring top is covered with heavy black leatherized fabric with full head lining covering the wood bows. The Phaeton and Roadster are of white nickel slat iron construction with walnut stain wood bows. The headlining is attached above the wood bows. Rain-tight curtains patented construction, with large transparent lights; tagged to facilitate attaching, upper panel opens for ventilation and signalling, plate glass win-

dow in rear curtain, curtains open with doors. Curtains carried in special container bag with inserts to protect lights.

Upholstering—All open cars upholstered in soft finished hand-buffed leather. Closed cars are finished in selected Mohair Velvet or cloth fabrics. The cushions and back springs are of special design. They are encased in fabric. Cotton bats in plain pleats are used in the standard jobs.

Running Boards—Rigid metal construction covered with ribbed rubber matting and white metal binding with black facing. On Custom cars running boards are covered with special molded rubber mat including raised step plates.

Ventilator—All open cars provided with large cowl ventilator flush type operated from underneath the instrument board by quick acting lever. All closed cars are ventilated by means of louvre back of vertically operated windshield, air passes beneath the raised windshield and down in front of instrument board to floor boards.

Tool Compartment—Rain-proof tool box contained in box just forward of right-hand running board. Cylinder lock. Provision made to hold individual tools in place in special fabric holder.

Horn—Motor driven horn carried on left-head lamp bracket in front of radiator. Horn control button at center of steering wheel.

Tire Carrier—Supported by three forged brackets on rear cross tube. Approved tire carrier lock.

Universal Key—Universal key for switch, tool box, tire carrier, gearshift lever and door locks on enclosed models.

Equipment—Closed cars are equipped with the special Fisher VV windshield.

Open cars have one-piece ventilating windshield with windshield wings. Combination cigar lighter and inspection lamp with 12 feet of cord. Eight-day clocks on dash of all cars. Speedometer with figures legible from tonneau, trip reset. Ammeter, air pressure gauge, gasoline quantity gauge, and oil gauge.

Foot rail in all models except Coupes. Electric motor horn, power air compressor for tires, robe rail, license tag holders, rear view mirror, automatic windshield cleaner on all cars. Tire carrier for two spare tires with approved lock. Brougham, Phaeton and Five-Passenger Sedans are equipped with trunk rack. Vanity cases in closed cars.

We reserve the right to make changes in specifications or equipment without notice

CADILLAC MOTOR CAR COMPANY · DETROIT, MICHIGAN

CADILLAC MOTOR CAR CO.
Miscellaneous

C.1

1926-27 The Cadillac line for 1926-
1927.

The Cadillac Line
for
1926 - 1927



LIBRARY REFERENCE COPY
NOT TO CIRCULATE

THE purpose of this booklet is to supply the Cadillac distributing organization with information regarding the Cadillac line for 1926-27. It is not intended as a catalogue, but as a means of providing the necessary information pending the publication of the catalogue.

It contains illustrations of the full line of Cadillac Standard and Custom cars, together with prices and information as to standard and optional equipment.

A few of the illustrations do not reveal the cars to the best advantage, but in order to expedite the printing of this booklet we have used photographs available rather than waiting until better ones could be obtained.

The Cadillac Line For 1926-27

THE Cadillac 1926-27 line includes the finest group of fine cars the automobile industry has ever seen—50 body styles and types and 500 color and upholstery combinations.

Included in this line are 21 Standard and Custom Fisher-built bodies. The remaining 29 include Fleetwood and Brunn Custom-built bodies and Cadillac semi-commercial vehicles.

Four new body models have been added. They are: Standard Two-Passenger Sport Coupe; Standard Five-Passenger Sport Sedan, 132-inch wheelbase; Custom Two-Passenger Convertible Coupe, and Sport Phaeton with double cowl.

In addition, the Standard Victoria has been made a five-passenger model by the removal of the parcel compartment back of the driver's seat. And the Standard Imperial Sedan has been lengthened to 138-inch wheelbase. These, in effect, constitute new models.

Furthermore, the Custom Five-Passenger Coupe, Custom Five-Passenger Sedan, Custom Suburban and Custom Seven-Passenger Imperial are also available in Cabriolet style.

Thus the line really numbers ten models that are new this year.

Cadillac's achievement in producing the most extensive line of fine cars in the history of the industry is one that is surpassed only by the introduction of the Cadillac ninety-degree V-type Eight. And in providing the distributing organization with such a splendid line-up for the ensuing twelve months, Cadillac has provided a still greater opportunity for every distributor, dealer and salesman.

The Cadillac now being produced in such a wide range of body styles and types is essentially the same car as the New Cadillac introduced in August, 1925—the car that met with such universal favor as to cause Cadillac to break all production and sales records in the twelve months following its introduction.

Since it is Cadillac's policy to refine and improve continually, incorporated in the car now offered are a number of improvements. Among these are a new radiator casing, radiator emblem, steering wheel with light control,

and a handsome new instrument board panel. In addition, a number of minor chassis changes have been made.

Though these changes effect an improvement in the car's appearance they are not sufficiently radical as to cause the present car to appear to be a new model. As was stated before, the car is essentially the same, but it is now manufactured in a range of body types and styles and color and upholstery combinations so extensive as to enable Cadillac to cater to the ever-growing demand for individuality in the fine car field.

This booklet includes only illustrations of the Fisher-built bodies in the Standard and Custom line.

Prices

Following are the prices that became effective August 1:

Standard Line

Five-Passenger Brougham.....	\$2995
Two-Passenger Coupe.....	3100
Five-Passenger Victoria.....	3195

Five-Passenger Sedan.....	3250
Seven-Passenger Sedan.....	3350
Seven-Passenger Imperial.....	3535
Sport Two-Passenger Coupe.....	3500
Sport Five-Passenger Sedan.....	3650

Custom Line

Roadster.....	\$3350
Touring Car.....	3450
Phaeton.....	3450
Sport Phaeton.....	3975
Two-Passenger Convertible Coupe.....	3450
Five-Passenger Coupe.....	3855
Five-Passenger Sedan.....	3995
Seven-Passenger Suburban.....	4125
Seven-Passenger Imperial.....	4350

F. O. B., Detroit. Tax Extra.

A number of the cars illustrated in this booklet have equipment added for display purposes. The fact that equipment is shown in the illustration does not necessarily mean that it is standard equipment. Therefore, consult the information in this booklet for guidance in the matter of equipment.

Equipment for All Models

FOLLOWING is information regarding equipment for both Custom and Standard line models, together with information as to optional equipment.

Wheelbase Lengths

Open cars: Touring—138", Phaeton—138", Roadster—132".

Standard closed cars are all on 132" chassis except the Standard Imperial. It is on the 138" chassis, which makes possible a comfortable chauffeur's compartment and gives ample leg-room to passengers in the wide auxiliary seats.

Sport Two-Passenger Coupe and Sport Five-Passenger Sedan are also on 132" chassis.

All Custom closed models are on the 138" chassis, with the exception of the Convertible Two-Passenger Coupe which is on 132" wheelbase.

Gear Ratio

On all models, both Standard and Custom, the gear ratio is 5 to 1.

Tire Equipment

Standard size for all models is 33 x 6.75

Balloon. Makes: Goodyear, Royal, Firestone, and Ajax.

So far as possible distributors' preference for tires will be observed, but the factory reserves the right to supply at its option, any standard make of tire without respect to distributors' specifications.

High-pressure cord tires, size 33x5, optional at no extra charge, can be supplied with wood wheel equipment only on Standard or Custom models.

Wheels

Wood wheels, artillery type, standard equipment on all except Sport models.

Budd-Michelin disc wheels optional, no charge, per set of 5.

Budd-Michelin disc wheels, per set of 6—on other than Standard Sport models, additional charge \$25.00; two spares mounted on rear tire carrier.

The "Buffalo" type wire wheel, made by the Wire Wheel Corporation of America, is continued as special equipment on all except Sport

Phaeton which takes 6 wire wheels as regular equipment. Additional charge, set of 5—\$140.00; set of 6—\$175.00.

Fender Wells

Extra tires may be carried forward in fender wells. Special combination prices are quoted which include the tires, since it would be impossible to carry spare wheels or rims unless they were so equipped.

Six wire wheels, fender wells and two spare tires, \$350.00, on all models except Sport Phaeton on which this is regular equipment. Six disc wheels, fender wells and two spare tires, \$240.00 on all models except Sport Two-Passenger Coupe and Five-Passenger Sport Sedan on which this is regular equipment.

Wood wheels, fender wells, two spare tires and rims, \$200.00.

Collapsible Trunk Rack

A practical convenience for touring and the finishing touch for cars equipped with fender wells is a collapsible trunk rack, supplied as standard equipment on Sport Phaeton (Custom), Sport Two-Passenger Coupe (Standard), and Sport Five-Passenger Sedan (Standard) only. Available on other Standard or Custom models at extra charge of \$50.00.

Special Trunk to fit folding trunk rack is not supplied as standard equipment on any model, but is available for factory equipment at \$100.00. This trunk is designed to Cadillac standards and is of sound, dust-proof construction.

Radiator Casing

The radiator casing on all models is standard finish white nickel; black enamel optional.

It will also be supplied in special Duco color to match fenders at no additional charge on Custom models only. Extra charge for special color on Standard models, \$12.50.

Headlamps

Drum type with 10 $\frac{1}{4}$ " lens on all models. Custom headlamps have brass shell finished in white nickel. Black enamel optional at no extra charge. Will also be furnished in Duco to match special color fenders if specified.

Standard headlamps have steel shell, black enamel finish with nickel rims. Custom headlamps or Standard lamps in full nickel finish will not be furnished on Standard body styles except Sport Coupe and Sport Sedan, on which they are regular equipment.

Extra charge for special color lamps on Standard cars with black fenders—\$10.00.

When special color fenders are ordered, lamp drums will be finished to match fenders at no additional charge unless otherwise specified.

Drum type sidelamps mounted on a nickel cowl band are standard equipment on Custom open and closed and Standard Sport models. Finish will match headlamps.

Cowl lamps on other Standard models, \$75.00 extra.

Running Board Mats

All Standard and Sport models take ribbed rubber matting. Custom cars take molded rubber mats with raised step pads. Standard cars will not be supplied with Custom mats.

Spring Covers, Bumpers and Fender Guards

Front Bumper and Rear Fender Guards of U. S. E. make, and DeLuxe Motometer are supplied as standard equipment on Custom open and closed body styles and Standard Sport models.

Spring Covers of leather are also supplied on Custom models.

These items are available as factory equipment on other body styles at following extra charges:

Front Bumper and Rear Fender Guards—\$50.00.

Motometer—\$10.00.

Spring Covers—\$25.00.

Tire Covers

"Double-wrap Spring type" cover (covers both tire and rim) for cars equipped with wood wheels. Patent finish (Black), \$8.25. Satin finish (Black), \$8.00.

When ordering cars with special color fender sets, tire cover should be ordered to harmonize. Double-wrap spring covers made of duPont Fabricoid, Ducoed any color—\$20.00.

"No. 2 Rim-Type" cover for wire or disc wheels covers the tire only. A spring on the inner edge insures a close fit and neat appearance at all times. Black Patent or Satin finish, \$6.25.

"Drum type special" cover for wire wheels covers the tire and outer surface of the wheel and has a spring on the inner edge. Black Patent or Satin finish, \$6.25.

Both "No. 2 Rim-Type" and "Drum type special" covers can be furnished in duPont Fabricoid material, Ducoed any color, \$17.00.

For open cars a very attractive cover can be furnished in drab duck material to match the top at following charges:

"Double-wrap Spring type," \$17.00; "No. 2 Rim-type" and "Drum type special," \$14.00.

All covers carry the Cadillac crest in colors.

ALL SPECIFICATIONS AND PRICES SUBJECT TO CHANGE WITHOUT NOTICE.

Standard Closed Body Styles

THE 1927 series of Standard closed body styles has been refined to keep pace with improvements in the Custom line.

The pleated and tufted style of trimming used in Custom closed cars during the 1926 season has been adopted for the Standard bodies. Double-decked Marshall spring construction provides an even greater degree of comfort in cushions.

Trimming

Optional trimmings for the Standard line include: 34-T-127, Taupe mohair; 36-T-127, Blue-Gray mohair; 35-T-127, Taupe cloth; 37-T-127, Blue-Gray cloth.

The additional charge for special mohair, cloth, and leather trims will be announced in an early bulletin.

Front pillars have been narrowed one inch, giving greater visibility.

A new type sun visor is supported at each side by nickel bars.

Window recesses similar to the Custom closed cars have been adopted, giving a dash of color

to the conventional black upper panels, and a lighter appearance to the entire car.

Color Options

Standard color options for August and September are as follows:

August—Adjutant Gray, Norse Blue, Argyle Brown, Normandy Blue.

September—Adjutant Gray, Norse Blue, Brentwood Brown, Normandy Blue.

Four colors will be offered on the Standard line each month. To provide variety, these colors will run four months only, one color being dropped and another substituted each month.

Special colors will be supplied at the following charges:

Center panel (between mouldings), \$20.00;
Lower panel (below lower mouldings), \$20.00.

Upper panels, fenders, and chassis are finished black. Charge for special color:

Upper panel, \$20.00; Fenders, Dust-shields, etc., \$75.00; Chassis, \$20.00.

Roof and sun visor are finished black unless otherwise specified. Charge for special color, \$25.00.

Special color orders must reach the factory not later than the 10th of month preceding that in which shipment is to be made.

All above prices refer to Duco colors only.

No orders accepted for Standard body styles in varnish finish.

Wheels

Wheels, unless otherwise specified, are finished the same color as lower panel. Special color wheels on standard job, \$10.00. Contrasting color wheels on special color job, no charge. Natural wood wheels on standard or special job, \$10.00.

Mouldings

Mouldings are finished in the same color as fenders unless otherwise specified. Charge for special color, \$10.00.

Striping

Striping for all standard colors is a double hairline of Antique Ivory on upper and lower mouldings.

Charge for special color stripe in standard

location on standard color jobs, \$15.00. Stripe color optional on special color jobs.

Charge for standard or special color stripe in other than standard location on standard and special color jobs, \$15.00.

Radiator Shutters

Radiator shutters are finished in same color as lower panels. Nickel radiator shutters cannot be supplied.


Other Details

Vanity Cases are leather covered to match trimming and are made in two sizes.


The larger, supplied on Seven-Passenger Sedan, Victoria Coupe and Standard Imperial, have for equipment in the ladies' case, a compact, memo pad and pencil and small ash receiver; in the smoking set, a match box holder and large ash receiver.

The smaller, supplied on Brougham and Five-Passenger Sedan, are equipped with compact and memo pad with pencil in the ladies' case and match box holder and small ash receiver in the smoking set. No cases are furnished with Two-Passenger Coupe.


Interior Hardware is die casting, nickel-plated in Butler's silver finish.




Standard Two-Passenger Coupe




Standard Brougham




Standard Five-Passenger Victoria



Standard Five-Passenger Sedan



Standard Seven-Passenger Sedan



Standard Imperial

Sport Models—Standard Line

TWO new Standard Sport models are introduced: the Two-Passenger Sport Coupe and the Five-Passenger Sport Sedan. Both are on the 132" chassis.

The appeal of these models is to the less conservative prospect, as the name implies.

The Coupe top is non-collapsible, but is dressed with a Burbank covering. Landau bows have a graceful sweep.

The Sedan has leather quarter panels and landau bows. Rear quarter windows of a practical as well as novel design give full vision to the occupants of the rear seat, and lower for ventilation.

Tops on both models are cut down slightly at the rear, giving a racy appearance without infringing on head room.

Special mohair of an entirely new design has been selected for trimming.

Standard Equipment

The following standard equipment on both models is included at the quoted prices:

Nickel headlamps. Nickel cowl band with side lamps. Six disc wheels. Fender wells. Collapsible trunk rack. Two spare tires. Bumpers, front and rear. Motometer.


Colors

Distinctive colors have been selected for these models, the Coupe being available in two, and the Sedan in four. Options during August and September are as follows:


Coupe: 1, R. & M. Maroon with Sumach Red disc wheels; 2, Entire Black with Cream or Vermillion disc wheels.

Sedan: 1, Vineyard Lake with Mountain Ash Scarlet disc wheels; 2, Aulay Gray with disc wheels finished Chasseur Red; 3, Safari Blue with Linden Cream disc wheels; 4, Upper panels, fenders, chassis—Ardsley Green, Center and lower panels and disc wheels—Canoe Brook Green. (Extra charge for special color roof, fenders and chassis—\$120.)

Interior hardware, vanity cases, running board mats, etc., are the same as on Standard closed types.



Two-Passenger Sport Coupe



Five-Passenger Sport Sedan

Custom Closed Body Styles

THE Custom line of closed cars for 1927 far surpasses anything Cadillac has heretofore produced.

The plain style of trimming with the disappearing arm rest in the rear seat will appeal to the most discriminating buyer.

The special spring construction in the cushions is the latest development of Cadillac and Fisher engineers, the effect produced being a comfort which equals, if it does not exceed, down cushions, at the same time retaining a neat appearance.

Standard Equipment

Bumpers, front and rear, DeLuxe motometer, and spring covers are retained as standard equipment. In addition, Custom cars are equipped with sidelamps, attached to a nickel cowl band, to match the headlamps.

Trimmings

Optional trimmings include four highest quality mohair materials and eight cloth patterns.

- 17-T-127, Blue-Gray mohair
- 18-T-127, Taupe mohair
- 19-T-127, Blue mohair
- 20-T-127, Green mohair
- 21-T-127, Gray Bedford Cord cloth
- 22-T-127, Striped Gray broadcloth
- 23-T-127, Blue-Gray broadcloth—vine pattern
- 25-T-127, Blue-Gray broadcloth—basketweave pattern
- 26-T-127, Tan broadcloth—chain pattern
- 28-T-127, Tan broadcloth—basketweave pattern
- 30-T-127, Green broadcloth—chain pattern
- 32-T-127, Tan broadcloth—vine pattern

All of the cloths selected are the most recent developments, and are notable for their beauty and richness. Plain headlining to harmonize is used with the pattern seat material.

Color

Although color is optional on Custom bodies, standard colors carried in stock at the factory

will be listed in monthly schedule letters to assist distributors in ordering attractive cars for stock with the least delay.

Upper panels, roof, sun visor, fenders, and chassis are finished black unless otherwise specified.

No charge is made for special color on upper panels, roof, or sun visor.

Fenders and chassis will be finished in special color Duco at an extra charge of \$95.00.

Instrument Board is finished in same color as center panels.

Equipment

Vanity Cases surpass in beauty and fittings any heretofore supplied. Imported German Calfskin in colors harmonizing with upholstery, is used for covering the cases.

Equipment in the ladies' case in the Five-Passenger Coupe includes a compact, combination note book and card case with pencil, and a small ash tray. The smoking set contains an electric cigar lighter, attractive cigarette case and two square ash receivers.

Equipment in the Sedan, Suburban and Imperial Suburban includes: Ladies' Case—combination compact and cigarette case, combination note book and card case with pencil;

two square ash receivers, and Hunter 30-hour clock of novel design with Radium numerals and hands; Smoking Set—electric cigar lighter and large ash receiver.

Interior Hardware is bronze forging edged in white nickel and enameled in Pyralin in shades to harmonize with upholstery. Inside toggle-action door locks are of new attractive design.

Dome lights and step lights on both sides operate with the opening of rear doors. A separate switch on the right pillar also controls the dome light. Rear quarter lights are controlled by a switch on the left pillar.

Gear shift and hand-brake levers are nickel-plated.

Outside door handles are of offset hand-grip type, rubber covered with nickel ends.

Running Boards are covered with molded rubber matting.

Cabriolet Types

The Custom Five-Passenger Sedan, Custom Five-Passenger Coupe, Custom Suburban and Custom Imperial are now available in leather-back, or Cabriolet style. The extra charge for this type is \$100. In addition, there is the regular extra charge for fender wells, spare tires and folding trunk rack.

Convertible Two-Passenger Coupe

A welcome addition to the Custom line is the convertible Two-Passenger Coupe, with a rumble seat in the rear deck.

The door and window construction is a new idea in convertible body design, being exceptionally rigid and rattle-proof. Contrary to usual trend, the pleasing appearance of the car is improved rather than destroyed, by lowering the top.

The windshield is hinged at the top and is easily and rigidly held outward in any position up to 5½ inches, measuring at the bottom from the cowl. A cowl ventilator provides ample air passage to cool the lower part of the body.

When the rumble seat is in use, and the top is up, the back panel of the top folds up against the roof, providing the same easy companionship in this model that prevails in the Phaeton or the Five-Passenger Coupe.

Trimming and Equipment

Special selected glove finish leather has been

adopted and trimming is done in plain style. Any of the custom mohair or cloth materials can be supplied if desired, although the leather has been selected for its practicability as well as its neat and durable appearance.


Regular Custom equipment includes bumpers, spring covers, motometer, molded rubber running board mats, and nickel cowl band and side lamps.

The top is covered with neat, waterproof non-cracking and non-fading Burbank.


Color

The body color is optional as on other Custom models, and light attractive shades in durable Duco will be recommended each month for stock purposes. Special color fenders and chassis available at the regular charge of \$95.00, probably add more to the appearance of this model than any other in the entire line.


Six wire wheels, fender wells, and two spare tires are offered at a combination price of \$350.00, and a collapsible trunk rack at \$50.00.




Convertible Coupe




Five-Passenger Custom Coupe




Five-Passenger Custom Sedan




Custom Suburban




Custom Imperial



Cabriolet Coupe



Cabriolet Five-Passenger Sedan



Cabriolet Imperial

Custom Open Body Styles

THE 1927 series of Custom open cars has been refined to a point never before approached.

The most noticeable feature is the plain style of trimming, with the disappearing arm rest as standard equipment in both the front and rear seats of the Touring car and Phaeton.

Sidelamps to match the headlamps are mounted on a nickel band which goes across the front of the cowl on all open bodies.

Monogram Panel

A change in the monogram panel on the Touring car and Phaeton to take effect about October 1st, is incorporated in the cars illustrated here.

This panel, heretofore placed only on the rear doors, has been extended across the center panel and the front doors and the vertical moulding in front of the rear door has been moved back of the door.

The effect of this change is to give a much longer and lower appearance to the car, which may be emphasized by the use of contrasting colors in this panel. Cane wicker monogram

panels will be supplied at extra charge of \$50.00 on Touring and Phaeton, and \$20.00 on Roadster.

Seat Construction

The seat construction of the Roadster is a departure from ordinary practice and a convenience which will be greatly appreciated by the trade, the movable seat being easily adapted to suit the requirements of either the tall or the short passenger.

The driver of average height will also find a welcome convenience in this easily adjustable seat as he can move closer to the steering wheel and controls in heavy traffic and find perfect relaxation in the far position for country driving.

Windshields and Tops

Phaetons and Roadsters are equipped with a specially designed windshield which can be folded forward when the top is lowered. Windshield wings have been omitted.

Tops are newly designed to fold compactly, carrying out the straight line of the lowered windshield.

Trimming

Trimming options remain unchanged. Four colors of leather are offered:

36-GX, Green

36-JX, Blue

36-CX, Brown

36-N, Gray

Charge for special trim materials will be announced in an early bulletin.

Equipment

Standard equipment includes front bumper and rear fender guards, spring covers and motometer. Trunk is supplied with the Phaeton.

The Roadster is continued on the 132" chassis, the Touring and Phaeton remaining 138" wheel-base.

The addition of special color fenders and chassis adds greatly to the appearance of the open models. Extra charges of \$75.00 for

special colored fender sets and \$20.00 for special colored chassis are made.

Six wire wheels with extras mounted forward in fender wells and two spare tires are offered at a special combination price of \$350.00. A full rear bumper is substituted for the rear fender guards when fender wells are supplied.


Fender wells, wood wheels, including two spare tires—\$200.00. Fender wells, six disc wheels, including two spare tires—\$240.00.

A practical, collapsible trunk rack on the rear adds the finishing touch to cars so equipped, at a nominal extra charge of \$50.00.


Sport Phaeton

This model, in production this fall, is an adaptation of the Custom Phaeton, with the addition of double cowl and tonneau windshield.


Six wire wheels, two spare tires, fender wells and collapsible trunk rack are added to the regular Custom equipment and included in the quoted price.




Roadster



Touring Car



Phaeton



Sport Phaeton

FILE COPY
DO NOT REMOVE

W. J. Schantz
LA SALLE

Operator's
Manual



CADILLAC MOTOR CAR COMPANY
DETROIT

**FILE COPY
DO NOT REMOVE**

COPYRIGHT 1927 BY
CADILLAC MOTOR CAR COMPANY

To the New Car Owner—

Parts I and II of this Manual contain information that you must know in order to operate and care for your car properly. This section should be read carefully as soon as possible after taking delivery of the car.

Part III contains information that you will not need until occasion arises. We suggest that you do not read this part at once, but keep the book in the cowl pocket or tool compartment for use when you need it.

EDITION No. 303-3
*In ordering a duplicate of this Manual specify the
above number or the engine number of the car*

FILE COPY
DO NOT REMOVE

Contents

Part I—Operation

CHAPTER I—Controls and Instruments	9
Locks—Ignition switch lock—Gasoline gauge—Temperature indicator—Throttle control—Spark control lever—Carburetor enriching control—Carburetor heat control—Starter pedal—Oil pressure gauge—Clutch pedal—Transmission control—Brakes—Speedometer—Ammeter—Lighting switch.	
CHAPTER II—Driving	21
Driving speed when car is new—Danger of running engine in closed garage—Coasting—High compression cylinder heads—General driving suggestions—Don'ts for general operation.	
CHAPTER III—Equipment	26
Windshield and ventilation—Windshield cleaner—Rear vision mirror—Cigar lighter—Clock—TOP AND SIDE CURTAINS—Top—Side curtains on open cars—Curtain fasteners—TOOLS—TIRES—Tire valve caps—Inflation pressure—Tire carrier—Wire wheel carrier—Disc wheel carrier—Lock for spare tires on fenders—Truing up rim—Use of jack in changing tires—Changing tires.	
CHAPTER IV—Cold Weather Operation	38
PREPARING FOR COLD WEATHER—Anti-freezing solutions—Capacity of cooling system—Effect of alcohol on finish—Winter lubrication—Thinning engine oil—Thinning chassis lubricant—Storage battery—Gasoline system—STARTING THE ENGINE—Carburetor enriching button—Priming the carburetor—Position of throttle hand lever—Position of spark control lever—Use of starter—Use of accelerator before engine is warm.	

Part II—Lubrication and Care

CHAPTER I—Systematic Lubrication	45
Necessity for lubrication—Lubrication schedule—LUBRICANTS—Engine oil—Chassis lubricant—Wheel bearing and cup grease—Fiber grease.	
CHAPTER II—Engine Lubrication	48
Oil circulating system—Oil level—Oil pressure—Crankcase ventilating system—Oil filter—Replacing engine oil—Generator oil cups—Timer-Distributor oil cup—Fan—Water pump—Engine rear supports.	
CHAPTER III—General Lubrication	55
Grease gun connections—Clutch thrust bearing—Transmission—Rear axle—Front wheels—Rear wheels—Steering gear—Speedometer flexible drive shaft—Springs—Door hardware—Cooling system—Storage battery—Shock absorbers.	
CHAPTER IV—Care of Body	58
Care of finish when new—Washing varnished cars—Washing Duco—Cleaning windows—Cleaning upholstery.	

CHAPTER V— <i>Care of Tires</i>	61
Result of under-inflation—Result of improperly aligned front wheels—Neglect of small cuts—Result of improperly adjusted tire chains—Result of sudden application of the brakes—Additional suggestions.	

CHAPTER VI— <i>Storing Car</i>	64
Engine—Storage battery—Tires—Body and top—Taking car out of storage.	

Part III—General Information

CHAPTER I— <i>Engine</i>	68
Important features of construction—Firing order—Main and connecting rod bearings—Cylinder heads and removal of carbon—Adjustment of valve stem clearance—Grinding valves—Chains.	

CHAPTER II— <i>Gasoline System</i>	73
General description—Operation of vacuum tank—Gasoline filter—Adjustment of carburetor—Gasoline tank gauge.	

CHAPTER III— <i>Cooling System</i>	79
Water circulation—Adjustment of fan belt—Radiator and shutters—Radiator thermostat—Water pump—Filling and draining the cooling system—Cleaning the cooling system.	

CHAPTER IV— <i>Electrical System</i>	82
GENERATION OF CURRENT—Generator—Ammeter—Thermostatic control of charging rate—Adjustment of charging rate—STORAGE BATTERY—Adding water to storage battery—Specific gravity of battery solution—Disconnecting battery—Exide depots and sales offices—STARTING MOTOR—Operation of starter—IGNITION—General description—Timer-distributor—Adjustment of contact points—Timing ignition—Spark plugs—LIGHTING SYSTEM—Lamp bulbs—Cleaning headlamp reflectors—Official approval of headlamps—Adjustment of headlamps.	

CHAPTER V— <i>Clutch and Transmission</i>	98
Clutch—Adjustment of clutch release rod—Transmission.	

CHAPTER VI— <i>Steering Gear</i>	100
Description—Adjustment of worm and sector—Adjustment of worm thrust bearings—Adjustment of sector shaft—Steering connecting rod.	

CHAPTER VII— <i>Front Axle</i>	103
Description—Stop screws—Alignment of front wheels.	

CHAPTER VIII— <i>Rear Axle and Torsion Tube</i>	106
---	-----

CHAPTER IX— <i>Wheels</i>	106
Tire balancing marks—Removing front wheel—Installing wheel—Rear wheels.	

CHAPTER X— <i>Brakes</i>	108
General description—Brake adjustment—Temporary adjustment—Adjustment of rear wheel brakes.	

CHAPTER XI— <i>Repair Parts</i>	111
Genuine La Salle parts—Uniform parts prices—Ordering new parts—Returning parts—Tires, Speedometer and Clock.	

CHAPTER XII— <i>Specifications and License Data</i>	113
---	-----

PART I OPERATION

CHAPTER I

Controls and Instruments

One of the first things the driver of a new car has to do is to familiarize himself with the various controls. This applies to the experienced motorist as well as to the beginner. Although there are many points of similarity between all motor cars, there are many important differences, and it is not wise, regardless of previous driving experience, to drive a new car without fully understanding what each control is for and how to use it. In the following chapter are described the levers, pedals, instruments, and other devices used in the operation of the La Salle.

Locks

The locks on the ignition switch, the tire or wheel carrier, and, on closed cars, the doors and package compartments, are operated by the same key.

The lock number is stamped on each key, but not upon the face of the lock. The owner should make a record of the key number as soon as he takes delivery of his car, so that in the event both keys are lost, a duplicate key can easily be obtained from a Cadillac distributor or dealer.

Ignition Switch Lock

The ignition is controlled by an ignition switch lock which is located at the lower right-hand side of the instrument panel. To switch on the ignition, insert the key in the lock and turn it to the right. The barrel of the lock will then slide out about $\frac{1}{4}$ inch. To shut off the ignition and lock the switch, simply push the lock all the way in.

The ignition switch lock has been given the highest rating granted by the Insurance Underwriters and has several theft-proof features that are of interest to the car owner.

When the switch is locked it not only disconnects the ignition coil from the battery but it also "grounds" the distributor. This means that any attempt to wire around the switch or to supply ignition current from an outside source would be futile, as the current would be automatically short circuited as soon as applied.

Tampering with the cable between the lock and the timer distributor is prevented by the hardened steel conduit in which the cable is carried. The cable is also connected to the distributor by a fastening which cannot be disconnected without removing and partly disassembling the distributor.




Figure 1. The new driver should familiarize himself with the instruments and controls before attempting to drive.

Gasoline Gauge

The gasoline gauge, marked "Fuel," is the small dial at the right on the instrument panel. This gauge indicates in gallons the quantity of fuel in the tank at the rear of the car, and is operated electrically. To read from the gauge the quantity of fuel in the tank, *the ignition must be switched on*. When the ignition is switched off, the gauge does not indicate the amount of fuel in the tank.



Figure 2. The gasoline gauge is operated electrically by current from the ignition circuit.

If the fuel supply should give out on the road, so that the vacuum tank on the dash becomes empty, it will be necessary after refilling the gasoline tank to *prime* the vacuum tank. To do this, close the throttle and hold the starter pedal down for 20 to 30 seconds. The throttle must be closed while this is done.

If the fuel supply should give out on the road, so that the vacuum tank on the dash becomes empty, it will be necessary after refilling the gasoline tank to *prime* the vacuum tank. To do this, close the throttle and hold the starter pedal down for 20 to 30 seconds. The throttle must be closed while this is done.

Temperature Indicator

The gauge at the top of the instrument panel (Fig. 3) is a thermometer for indicating the temperature of the engine and takes the place of a temperature indicator on the radiator. The bulb end of the thermometer is inserted in the water-jacket at the rear end of the left-hand cylinder head, and is connected by a small tube to the dial on the instrument board.




Figure 3. The temperature indicator shows the temperature of the water circulating around the cylinders.

The hand control is the upper lever above the steering wheel. Both

The normal engine temperature after the engine becomes warm is 150° to 180°.

Throttle Control

The power and speed of the engine are controlled by opening and closing a throttle valve in the carburetor. This throttle is operated both by a hand lever and a foot pedal.

The foot pedal, or accelerator, is at the right of the brake pedal (Fig. 1).

controls operate the same throttle; the hand lever, however, remains in the position to which it is moved, whereas the accelerator must be held down to keep the throttle open.

The normal position of the hand lever for driving the car is all the way up (at "Close"). In this position the throttle of the carburetor is open just enough to permit the engine to run at idling speed after it is warm. For starting, however, the lever should be moved approximately one-fourth the way down, and should be left in this position until the engine is warm enough to permit the lever to be returned to the idling position without stalling the engine.

In cold weather, the accelerator should not be pushed down suddenly before the engine is warm. Sudden opening of the throttle before the engine is warm causes "popping-back" in the carburetor. This should be avoided as much as possible by judicious opening of the throttle during the warming-up period. (See page 42 under "Use of Accelerator Before Engine Is Warm.")

Spark Control Lever

Correct timing of the spark in relation to the positions of the pistons is accomplished automatically by the timer-distributor, which provides for all ordinary advancing and retarding of the spark. (See page 88 under "Timer-Distributor.") A hand control is also provided for retarding the spark on certain occasions as hereafter described.

The hand control is a lever on the instrument board directly in front of the steering column. For average driving, the correct position of this lever is all the way toward "Advance." The lever should be left in this position except on the following occasions:

1. If the engine is being cranked by hand, the spark should be fully retarded by moving the lever all the way to "Retard."
2. In pulling at low speeds with the throttle well open, the spark should be retarded.
3. If, because of the accumulation of carbon in the combustion chambers, the engine knocks or "pings" on acceleration the spark may be retarded slightly. As soon as possible, the carbon should be removed so that the spark can be fully advanced.

Carburetor Enriching Control

The button at the left of the instrument panel (Fig. 4) controls a device on the carburetor for temporarily enriching the fuel mixture supplied to the engine. When starting the engine, it is necessary to

have the proportion of liquid gasoline in the fuel mixture greater than at other times, because in a cold mixture only a part of the gasoline is vaporized. Pulling out the enriching button increases the proportion of liquid gasoline to air, the normal proportions being restored when the button is released and permitted to return to its original position.

Correct use of the enriching control not only is essential to quick starting of the engine, but also has an important effect on the life of the engine. The enriching button must be pulled out far enough in starting to provide an explosive mixture quickly so that the battery is not unnecessarily discharged by useless cranking. The button must also be held out far enough during the warming-up period so that the engine will run without missing and "popping back." On the other hand, it should not be pulled out any further or held out any longer than is necessary to accomplish these results, because some of the excess liquid gasoline in the enriched mixture does not burn and washes off the oil on the cylinder walls, interfering with proper lubrication of the pistons.



Figure 4. The carburetor enriching control does not prime the carburetor. To have any effect, it must be held out while the starter is cranking the engine.

button must be pulled out and held partly out during the cranking operation.

Carburetor Heat Control

The lever marked "Carb. Heat" on the instrument board, directly in front of the steering column, controls the flow of exhaust gases through the jacket of the intake header which conducts the fuel mixture from the carburetor to the cylinders. This lever operates a valve at the front end of the left-hand exhaust manifold.

The normal position of the lever is as far towards "Heat On" as it will go. When the lever is in this position, the valve in the exhaust

If the engine still retains heat from previous running, the enriching control should not be used without first attempting to start the engine on the normal mixture. If the enriching button is pulled out for starting a hot engine the mixture may be made so rich that starting will be impossible.

The enriching button is not a priming device. It has no effect whatever on the fuel or the fuel mixture unless the engine is being cranked or is running under its own power. To have any effect, the

manifold is closed and the principal outlet for the exhaust gases from the left-hand cylinders is through the intake header jacket to the right-hand exhaust manifold. There is thus a constant flow of hot gases through the jacket of the intake header, insuring that the fuel mixture is quickly heated to the temperature at which complete vaporizing takes place.

Overheating of the mixture when driving continuously at high speeds is avoided by turning the lever to "Heat Off." When the lever is in this position, the valve in the left-hand exhaust manifold is open and the exhaust gases from the left-hand cylinders pass directly to the muffler. There is then no continuous flow of exhaust gases through the header jacket and the fuel mixture receives only just enough heat to vaporize the liquid fuel.

The lever should be turned to the "Heat On" position when starting the engine and should be carried in this position for average driving. For continuous driving at high speeds, the lever should be turned to "Heat Off." This is important, for the maximum power of the engine cannot be obtained with the valve in the exhaust manifold closed.

Starter Pedal

The starter pedal is at the right of the accelerator (Fig. 1). Pushing this pedal forward brings into action the electric motor that cranks the engine for starting. *Do not push the starter pedal when the engine is running.*

The starter pedal is only one of the controls that must be manipulated to start the engine. Unless there is an explosive mixture in the cylinders and a spark to ignite it, it is useless to crank the engine. The starter pedal should not be operated, therefore, until the necessary preliminary steps have been taken. The following, in their proper order, are the various steps that must be performed to start the engine. As each control is mentioned, reference is made to the page on which that control is explained in detail.

1. Make sure that the transmission control lever is in neutral. (Page 17.)
2. Place the spark control lever on the instrument board all the way toward "Advance."* (Page 11.)
3. Place the throttle lever about one-fourth the way down from the idling position. (Page 11.)

*If the engine is being cranked by hand, move the lever all the way to "Retard."

4. Place the carburetor heat control lever all the way toward "Heat On."

5. Switch on the ignition. (Page 9.)

6. Unless the engine is still warm, pull back the carburetor enriching button and hold it back. If the engine is still warm, do not pull back the enriching button unless the engine fails to start on the normal mixture. (Page 11.)

7. Push the starter pedal forward and hold it until the engine starts. Release it immediately as soon as the engine starts. (See below for probable causes for the engine failing to start.)

8. Let the carburetor enriching button partly in as soon as the engine starts, and all the way in as soon as the engine is warm enough to permit it. (Page 11.)

9. Note whether pressure is indicated on the oil pressure gauge and stop the engine at once if no pressure is indicated. (Page 15.)

10. Move the throttle lever up to the idling position as soon as the engine is warm enough to permit it.

In cold weather, disengage the clutch before pressing down the starter pedal, and hold it down during the cranking operation. This relieves the starter of the necessity of turning the transmission gears, which are immersed in lubricant. The additional load is small in warm weather when the lubricant is thin, but in cold weather the power required to turn the gears through the thickened lubricant adds unnecessarily to the demand upon the battery.

What to Do if the Engine Fails to Start.

If the engine fails to start after being cranked for a few seconds, release the starter pedal and investigate the following possible causes:

The ignition may be switched off.

There may be no gasoline in the tank at the rear of the car.

There may be no gasoline in the vacuum tank on the dash. If the vacuum tank should be empty, prime it by closing the throttle, and, with the ignition switched off, holding the starter pedal down for 20 to 30 seconds. The throttle *must be closed* while this is done. Then open the throttle, switch on the ignition, and try again to start the engine in the usual manner.




Figure 5. What to do when the engine refuses to start because the carburetor is flooded.

The carburetor may be flooded by unnecessary use of the enriching device when the engine is warm. To get rid of this surplus gasoline in the carburetor, *open the throttle wide*, and, with the ignition switched off, hold the starter pedal down for 10 to 15 seconds. Then return the throttle lever to the usual position for starting, switch on the ignition and try again to start the engine.

Oil Pressure Gauge

The small dial at the left on the instrument panel (Fig. 6) is the oil pressure gauge. This gauge does not indicate the quantity of oil in the engine. It indicates only the pressure under which the oil is forced to the engine bearings.




Figure 6. The oil pressure gauge does not show how much oil is in the engine—it shows pressure only. The pressure when the engine is idling should be 7 to 10 pounds.

When the engine is not running, the pointer on the oil pressure gauge should remain at zero, but as soon as the engine is started and as long as it runs, the gauge should show pressure. If the gauge does not show pressure when the engine is running, stop the engine at once and determine the cause. Serious damage may be done if the engine is run without oil pressure. (See page 49 under "Oil Pressure.")

The amount of pressure indicated by the gauge depends upon the speed of the engine and the viscosity of the oil. At idling speed with fresh oil of the correct viscosity, the oil pressure after the engine is warm

should be 7 to 10 lbs. Before the engine is warm the pressure will be higher. After the oil has become thin from use, the pressure will be lower. These are normal variations from the standard and do not indicate need for attention.

Clutch Pedal

The clutch pedal is the left-hand pedal. When this pedal is in its normal or released position, the clutch is engaged. The flywheel of the engine is then coupled to the transmission by a disc clutch under the pressure of twelve springs. When the clutch pedal is pushed down, these springs are compressed and the clutch discs separate. The clutch is then disengaged and the flywheel, if the engine is running, revolves independently of the transmission.

The clutch has two uses: First, to enable the car to be started gradually and without jerk or jar; second, to permit shifting of the transmission gears. The operation of the clutch pedal is discussed in connection with the transmission control on page 17. Further comment is unnecessary at this point except the following suggestions to the driver:

Do not drive with the foot resting on the clutch pedal. The La Salle clutch operates so easily that even the weight of the driver's foot may unintentionally cause the clutch to slip.

Do not form the practice of disengaging the clutch whenever the brakes are applied. Most occasions for use of the brakes require only slowing down without stopping or even shifting gears. A skilled driver will not touch the clutch pedal until the car is just about to stop or until he is about to shift to a lower gear. It is a mistaken idea that applying the brakes with the clutch engaged is more severe on the brake lining. The




Figure 7. A good driver uses the clutch pedal only when shifting gears or about to stop.

opposite is actually the case, proof of which is in the fact that in coasting down grades the resistance of the engine is used to assist the brakes in controlling the car speed.

It will be observed in operating the clutch pedal that the pedal offers almost no resistance until it has been moved about one inch. It is at this point that it actually begins to disengage the clutch. It is important that the pedal have this "lost motion." If the full pressure of the clutch springs is felt just as soon as the pedal is moved, the rod should be readjusted as directed on page 97. Failure to make this adjustment will result in the clutch slipping.

Transmission Control

The La Salle transmission has three forward speeds and reverse. It is controlled by a lever, the handle of which describes the letter "H" as it is moved from one position to another. It should be observed by those who have driven other makes of cars, that, although most cars have the conventional H-type of transmission control, all these cars do not have the same positions of the lever. The driver should study Fig. 8 carefully, and if the various positions of the lever are different from those to which he has been accustomed, he should master this arrangement before attempting to drive.




Figure 8. The positions of the control lever form the letter "H."

No attempt can be made here to teach the beginner the technique of gear shifting. The beginner should secure individual instruction from the distributor or dealer from whom the car was purchased and who will be glad to give this instruction. The following suggestions, however, may be of assistance.

Before shifting from neutral to low to start the car, wait a few seconds after disengaging the clutch in order to give the gears a chance to stop "spinning." The faster the idling speed of the engine the longer it will take for the gears to come to rest. For this reason it is best to have the throttle lever set as near the closed position as possible without stalling the engine.

When shifting *up*, from low to intermediate or from intermediate to high, there should be a short period of hesitation in neutral before completing the shift. This period will be shorter or longer according to the speed of the car when the shift is made. It is necessary to learn from practice just how long to wait.

When shifting back from high to intermediate there should be no hesitation whatever in neutral. The lever should then be moved as quickly as possible and the car should not be traveling faster than 15 miles per hour.

There are times when it is desirable to be able to shift from high to intermediate at higher car speeds. It is possible to do this by the following method which is called "double de-clutching":

Disengage the clutch and shift the transmission control lever at once to neutral. Re-engage the clutch, at the same time accelerating the engine; then disengage the clutch again and instantly shift to intermediate, after which re-engage the clutch. The speed to which the engine should be accelerated while the transmission control is in neutral depends upon the speed at which the car is traveling when the shift is made.

It is not recommended that the driver attempt the double de-clutching method until he has become expert in shifting from high to intermediate in the usual manner at lower speeds.

Make a practice of shifting the transmission control to intermediate or even to low before commencing the descent of steep grades. The reason for this is explained on page 21, where will also be found further suggestions for coasting.

Do not make any of the following shifts when the car is moving:

From reverse to any forward gear.

From any forward gear to reverse.

From high gear to low gear.

From intermediate to low gear (except when the car is moving very slowly.)

Brakes

The foot brakes, which consist of external brake bands on the rear wheels and internal bands on the front wheels, are operated by the right-hand pedal.

As the brake lining wears, the pedal must be pushed farther down to apply the brakes. Do not wait until the pedal goes all the way to the floor board before having the brakes re-adjusted. Re-adjustment is recommended as soon as the pedal must be pushed down to within one inch of the floorboard.

The hand brakes, which are internal brakes on the rear wheels, are operated by the hand lever at the right of the transmission control lever.

Speedometer

The lower dial of the speedometer, which is for recording "trip" mileage, can be reset to zero by pushing up and turning the knurled stem back of the instrument board.

Across the speedometer cover glass and below the total mileage dial is a strip of black celluloid on which are two white spaces. These spaces are for the lubrication notice described on page 46 in connection with the lubrication schedule. Use this notice in accordance with the schedule.

An automobile repairman should never be permitted to attempt to adjust or repair the speedometer head or to replace the glass. This work can be done only by men experienced in speedometer work and only with special machinery and tools. If the speedometer head is removed, handle it as carefully as a fine watch. The speedometer head may easily be damaged by rough handling.

Ammeter




Figure 9. The ammeter indicates the amount of electrical current flowing to or from the battery.

The lower dial on the instrument panel (Fig. 9) is the ammeter, which measures the electric current flowing to or from the battery at all times except when the starter is cranking the engine. When current is flowing from the battery, the ammeter shows a reading on the side marked "Discharge;" when current is flowing to the battery, the ammeter reading is on the "Charge" side.

The ammeter should indicate on the "Charge" side most of the time. Otherwise, more current will be taken out of the battery than is put into it and the battery will eventually become fully discharged. The exact amount of current that should be indicated by the ammeter at any time depends upon various conditions, which are explained on page 83.

Ordinarily, when no lights are in use, the ammeter should show "Charge" as soon as the car is running ten or twelve miles per hour in high gear. If the ammeter should show "Discharge" with all lights off, either when the engine is not running or when the car is running more than twelve miles per hour, the cause should be investigated.

Lighting Switch

The lighting switch control is at the upper end of the steering column in the center of the steering wheel. The lever has three positions besides "Off." These positions are marked respectively: "Parking," "Down," and "Up." The corresponding combinations of lights are as follows:

Parking—Parking lights (dim), and rear lamp.

Down—Headlamp lower beams (bright), and rear lamp.

Up—Headlamp upper beams (bright), and rear lamp.

The headlamp bulbs have two filaments, one above the other, instead of the customary single filament. Both filaments are of the same candlepower (21), but because they are located in different positions with respect to the reflector, the beam of light from one filament is projected at a different angle from the other. When the switch lever is at "Up," one set of filaments is lighted and the beams are projected straight ahead, illuminating the road at a distance. When the lever is at "Down," the other filaments are lighted and the beams are projected down at an angle, illuminating more brightly the road directly in front of the car.

The practice to be followed by the driver in using this double-beam feature of the headlamps will depend upon local regulations. In general, it is expected that the upper beams will be used except on the following occasions: When passing a vehicle approaching from the opposite direction, when rounding a sharp curve and when topping the crest of a hill. On these occasions and at other times when illumination is desired directly in front of the car, the lower beams should be used. For a further description of the headlamps, see page 93.

The instrument lamps are controlled by a separate switch at the left-hand end of the instrument board.

CHAPTER II

Driving

THE preceding chapter of the Manual has aimed to familiarize the driver with the controls and instruments used in operating the car. Actual skill in driving is, of course, more than knowledge of and familiarity with these individual devices. It is not the purpose of this Manual to discuss all phases of driving, but there are a few matters of sufficient importance to La Salle owners to warrant devoting a chapter to them.

Driving Speed When Car Is New

The parts of the La Salle car are machined and ground to secure the most accurate fit and the finest finish. Proper functioning of the assembled mechanism is further assured by testing the engine and chassis both on shop dynamometers and on the road. Nevertheless, it is not possible by manufacturing processes and tests to give to bearing surfaces the fine polish that results from continued operation at moderate speeds and loads.

Until a new car has been driven far enough to produce this effect on the bearing surfaces, the car should not be driven at high speeds. Moderate driving during the first five hundred miles will increase the life of the car more than enough to repay any inconvenience. Manufacturers of locomotives and stationary steam engines have always recognized the necessity for an initial "running in" period.

Danger of Running Engine in Closed Garage

Every person having to do with the operation or care of a motor car should be warned of the danger that attends running the engine while the car is in a small closed garage.

Carbon monoxide, a deadly poisonous gas, is present in the exhaust of all internal combustion engines. Most people are already familiar with carbon monoxide in the form of illuminating gas, or in the gas produced by furnaces and stoves when insufficient air is supplied to give complete combustion. But illuminating gas and coal gas have an unpleasant odor, which serves as a warning, whereas carbon monoxide, as produced in the internal combustion engine, is colorless, tasteless, and almost odorless, so that the victim may be overcome before he is aware of the danger.

When the engine exhausts into the open air, the carbon monoxide is so diluted that it has no effect. It is when the engine is run for a time in a closed room that the proportion of carbon monoxide in the air may increase to the point at which continued breathing of it would be fatal. The United States Public Health Service advises that the average automobile engine warming up in a single-car garage will give off enough carbon monoxide in three minutes to endanger life.

Proper precaution must be taken in cold weather when the natural tendency is to keep the garage doors and windows closed. The practice of letting the engine warm up in a closed garage before opening the doors is unsafe. The risk is made greater by the fact that the enriching of the mixture by manipulation of the carburetor enriching device increases the amount of carbon monoxide formed.

Coasting

To coast *on the level*, simply release the accelerator pedal and disengage the clutch. If coasting to a stop, the transmission control may also be shifted to neutral and the clutch re-engaged.

In coasting *down grades*, however, it is recommended that the transmission be left in gear and the clutch engaged. With the throttle in the idling position, the car is thus made to drive the engine, the resistance of which assists the brakes and saves wear on the brake lining. It must be remembered that the brakes are subjected to much more severe use on grades than on the level because gravity acts continuously, whereas on the level the brakes need absorb only the momentum of the car. Even on slight grades, coasting with the transmission in neutral or the clutch disengaged is not advisable. On any grade steep enough to warrant coasting, it is worth while to save the brakes as much as possible by utilizing the braking effect of the engine.

Ordinarily, the resistance offered by the engine when the transmission is in high is sufficient to control the speed of the car, supplemented by moderate use of the brakes. On steep grades, however, the transmission control should be shifted to intermediate or even to low if the grade is very steep. Shifting should always be done before commencing the descent of the grade, because, after the car has once gained speed, considerable braking may be necessary to slow down to the speed at which the shift can be made easily.

Do not switch off the ignition when coasting with the car driving the engine. Contrary to a common impression, this does not appreciably increase the resistance and is likely to cause damage to the engine.

Even with the throttle closed, some fuel is admitted to the cylinders, and if this is not burned it condenses on the cylinder walls and washes off the oil by which the pistons are lubricated.

High Compression Cylinder Heads

Some La Salle cars are equipped on special order with what are known as "high compression" cylinder heads. These are cylinder heads in which the space into which the fuel mixture is compressed just before it is ignited is so proportioned that a higher pressure is obtained than with standard cylinder heads. High compression cylinder heads can be identified by the letters "HC" in a circle cast on the outer surface of the heads.

High compression cylinder heads enable the engine to develop slightly more power, but they can be used only with anti-knock fuel (except at high altitudes.) The owner of a car equipped with these heads must therefore understand this limitation and arrange his fuel supply accordingly.

If, in an emergency, anti-knock fuel is not available and it is necessary to use regular fuel, this can be done but it is necessary to retard the spark to prevent spark-knock. The use of regular fuel with high-compression heads should be resorted to only in an emergency or at high altitudes.

An engine with high compression cylinder heads also requires special ignition timing. This is understood at Cadillac service stations; if it should ever be necessary to have the ignition timing checked elsewhere, instructions should be given to time the spark to take place $\frac{1}{2}$ inch (on the flywheel) ahead of center when the manual control is fully advanced.

General Driving Suggestions

Road and traffic laws vary greatly in different localities. It is unfortunately impossible to set down a complete list of rules that may be followed in all parts of the country. The following are some of the rules that are universal in practically all parts of the United States.

In meeting a vehicle going in the opposite direction pass to the right.

In overtaking a vehicle going in the same direction pass to the left.

Always stop with the right-hand side of the car next to the curb. If it is necessary to turn the car around to do this, it should be done.

Never turn around or turn off on another road without making absolutely certain that there is no other vehicle directly behind.

Do not cross street car or steam railroad tracks without making certain that it is absolutely safe to do so. At any railroad crossing that is on an upgrade or which for any reason must be approached very slowly, it is a wise precaution to shift to intermediate gear before crossing because the car can thereby be accelerated more quickly, if necessary.

In crowded traffic do not apply the brakes suddenly unless it is absolutely necessary. A vehicle following may not have brakes as efficient as La Salle four-wheel brakes.

On wet asphalt streets or slippery roads do not disengage the clutch when applying the brakes. Also, do not apply the brakes suddenly unless it is absolutely necessary. La Salle four-wheel brakes minimize the possibility of skidding under these conditions, but their effectiveness should not induce anyone to drive less carefully.

Slow down in passing vehicles going in the opposite direction.

Never take a chance.

Don'ts for General Operation

Don't fail to change the engine oil as frequently as recommended.

Don't fail to release the carburetor enriching button as soon after starting as possible.

Don't fill the lubricating system of the engine alone and neglect to lubricate all other parts of the car.

Don't neglect the lubrication of any part of the car.

Don't run the car at sustained high speed when it is new.

Don't allow the clutch to engage suddenly.

Don't prime the carburetor too much.

Don't allow the vent hole in the gasoline tank filler cap to become stopped up.

Don't attempt to shift from neutral to any gear, or from one gear to another gear, without first disengaging the clutch.

Don't attempt to shift from the reverse gear to any other gear when the car is moving.

Don't attempt to shift from any forward gear to the reverse gear when the car is moving.

Don't attempt to shift from the high gear to the low gear when the car is moving.

Don't attempt to shift from the intermediate gear to the low gear when the car is moving, unless it is moving very slowly. Ordinarily it is best to stop the car altogether.

Don't switch off the ignition when coasting with the car driving the engine.

Don't push the starter pedal when the engine is running.

Don't turn the steering gear when the car is standing. This is not only unnecessary but is also bad practice. The front wheels pivot more easily if they are rotating.

Don't fail to investigate any unusual sound which may develop in the car. The car should be regularly inspected at a Cadillac service station.

Don't neglect to inspect the level of the acid solution in the storage battery every 1000 miles and in summer every 500 miles, or at least every two weeks, and add distilled or other approved water if necessary. *Never add anti-freeze to the battery.*

Don't turn corners at high speed.

Don't neglect to keep the cooling system filled to the recommended level (page 39).

Don't drive fast or attempt to stop suddenly on wet pavements.

Don't attempt to start the engine with the switch turned off, or without gasoline in the tank.

Don't neglect to keep the tires inflated properly.

Don't race the engine when it is not driving the car. There is no worse abuse.

CHAPTER III

Equipment

The controls and instruments used in driving have already been described. In addition to these the car is equipped with various devices which are for the convenience and comfort of the occupants, and are used only as occasion demands. It is suggested that the driver anticipate his use of such equipment by becoming familiar at once with the directions contained in this chapter.

Windshield and Ventilation

CLOSED CARS—La Salle closed cars are equipped with a one-piece windshield, which can be moved up and down. Movement of the glass is controlled by a handle above the windshield. To raise the glass, the handle should be turned clockwise, and to lower the glass the handle should be turned counter-clockwise.

For ventilation under the cowl, the windshield should be raised not more than one inch so that the lower edge of the glass is still below the ledge over the instrument board. With the windshield in this position, air is deflected into the driving compartment through an opening in the cowl just forward of the instrument board. If desired, the wind-




Figure 10. The closed car windshield has three positions: the position shown in the center is best for warm weather.

shield can be raised above the level of the ledge over the instrument board, and air will then enter directly into the car. In this position, however, less air will be forced down under the cowl. (Fig. 10.)

Cowl ventilators are also provided on the closed cars to supplement the ventilation provided by the windshield. These ventilators are at

the sides of the cowl compartment and open toward the rear, serving as outlets for the air entering under the windshield.

OPEN CARS—La Salle open cars are equipped with two cowl ventilators which are operated by levers just in front of the instrument board.

The open car windshield is in one section, which is pivoted at the lower corners. To fold the windshield outward, loosen the wing nuts and tighten them again after the windshield is in the desired position.

Windshield Cleaner

The windshield cleaner is operated by the suction or vacuum in the passages between the carburetor and the engine.

The cleaner is controlled by a knurled button on the left-hand end of the instrument board. When the button is turned clockwise as far as it will go, the cleaner is shut off. To start the cleaner, turn the button counter-clockwise. On open cars, the control button is located at the cleaner itself.

Rear Vision Mirror

The rear vision mirror may be adjusted by the driver to suit his preference after loosening the clamp screws that hold the mirror to its supporting bracket.

Cigar Lighter

The car is equipped with a cigar lighter with flexible cord attached to the back of the instrument board.

To use the cigar lighter, pull it out from the instrument board and press the switch button on the side of the shield, holding it down until the cigar or cigarette is lighted. To light a pipe, remove the nickel plated shield by turning it slightly counter-clockwise and pulling it straight off.

Clock

The clock has an eight-day movement and is wound in the same manner as a watch. The stem is to the right of the clock back of the instrument board.

Top and Side Curtains

Top

Illustrated directions for folding the top on open cars are given in Fig. 11.




Fig. 11a

Remove the nickel-plated caps on the sockets for the top supports and install the supports by pushing them into the sockets and tightening the cap screws.




Fig. 11b

Detach the side quarter curtains from the bow sockets and fold the curtains back against the rear curtains. Unscrew the thumb screws over the windshield supports and push the top up so that the clamps are free from the supports.




Fig. 11c

Fold the front part of the top back toward the rear. Do not gather the top deck between the bows but let it fall back clear of the top. Then fold the deck neatly and tuck it under the bows.




Fig. 11d

Draw the dust boot over the folded top. It is secured by four straps at the open corners. These straps should be fastened around the bows and pulled tight to keep the boot smooth. The boot should look like this when properly strapped in place.

Figure 11. Folding the top

Side Curtains on Open Cars

The side curtains, with which the open cars are equipped, are carried in an envelope provided with cloth partitions to prevent rubbing and chafing. The side curtains are stowed in a special compartment back of the front seat.

The Phaeton curtains are in six sections, each of which is marked to indicate its position, as "Left Front," "Right Center." The front and center sections on both sides are each provided with a rod, the lower end of which fits in a socket in the top of the door. When a curtain is folded for stowing, this rod is parallel with the bottom of the curtain as shown in Fig. 12. Before the curtain can be attached to the door, the rod must be moved to the position shown by the dotted lines. The upper end of the rod is slotted to engage with the stiffener that runs along the upper edge of the curtain.




Figure 12. Side Curtain

The folding flap on the door curtains has the upper rear corner cut off diagonally. This is to permit its being tucked through on the outside when the flap is closed. By tucking the flap this way, the wind is prevented from blowing in at the rear of the flap.

The rear sections should be applied first, followed by the center and front sections. The rear sections should be fastened to the rear bows under the side flaps of the permanent rear curtains.

Before stowing the curtains, they should be dry and clean.

Curtain Fasteners

The curtain fasteners used on the top and side curtains are of three different types. The type used on the side curtains at the points where they fasten to the body is illustrated in Fig. 13b. To release this type of fastener




Figure 13. Three types of fasteners are used on the top and side curtains. The way to unfasten each is shown above.

press in on the small plunger or button in the center of the fastener.

At other points the fastener as illustrated in Fig. 13a is used. When this type of fastener is snapped on its stud, it becomes locked on three sides. To release this type of fastener, it must be lifted on the side that is not locked. This side is indicated by the small projection to which the arrow points in Fig. 13a. This type of fastener cannot be released by lifting it at any other side.

The remainder of the fasteners used on the top and side curtains are of the usual glove type. (Fig. 13c).

Tools

The compartment for the tools is under the front seat. The tools comprising the standard equipment are listed below and are illustrated in Fig. 14. Items listed opposite Nos. 24, 25, 26, 27 and 28 are not illustrated.

- | | |
|--|---|
| 1. Open end wrench $1\frac{1}{8}$ - $\frac{7}{8}$ | 15. Monkey wrench |
| 2. Open end wrench $\frac{3}{4}$ - $\frac{11}{16}$ | 16. Hand starting crank |
| 3. Open end wrench $\frac{5}{8}$ - $\frac{9}{16}$ | 17. Hub cap wrench (Fig. 14 shows wrench for wire wheels) |
| 4. Open end wrench $\frac{1}{2}$ - $\frac{7}{16}$ | 18. Brake adjusting wrench |
| 5. Distributor wrench (with gauge for adjusting timer contact points and spark plugs). | 19. Spoke wrench (Wire wheels only) |
| 6. Distributor wrench (plain) | 20. Grease gun |
| 7. Center punch | 21. Wheel bearing wrench (Wire wheels only) |
| 8. Cold chisel | 22. Jack handle |
| 9. Small screw driver | 23. Jack |
| 10. Large screw driver | 24. Rim wrench (Wood wheels only) |
| 11. Hammer | 25. Brace wrench (Disc wheels only). |
| 12. File | 26. Tool bag |
| 13. Pliers | 27. Lubrication chart |
| 14. Oil can | 28. Operator's Manual |

Tires

Tire Valve Caps

The valve caps used with some makes of tires are a combination dust and valve cap. This type of cap can be removed and installed without screwing the cap the entire length of the threads on the valve stem.

To remove one of these valve caps, turn it two or three turns counter-clockwise. This loosens the sliding nut inside the cap. (Fig. 15.) Next, pull the cap up as far as it will go. Then remove the cap by unscrewing it the rest of the way.




Figure 14. The tools are carried in the compartment under the front seat. See page 30 for the name and use of each tool.

To install a valve cap, place the cap over the valve stem and turn it a few turns clockwise to engage the threads in the sliding nut. If the sliding nut is too far inside the cap to be reached by the valve stem, shake the nut down by tapping the bottom of the cap on some solid object. When the valve stem has been started in the sliding nut, push the cap down over the stem as far as it will go. Then turn the cap until it locks tightly.



Figure 15.
Tire valve cap

from turning with the thumb of the left hand.

Remove the lock, using the key as a handle.

Unscrew the clamping screw with the wrench furnished in the tool equipment.

Let the clamp drop down, taking care not to lose the clamping screw.

Remove the tire with rim by pulling it out at the bottom and then lifting it off the carrier.

To place a tire and rim on the carrier reverse the above order. After tightening the clamping screw, snap the lock into place.





Figure 16. The spare tire can be removed after the clamp is unlocked in this manner.

Inflation Pressure

For normal driving, the tires should be inflated to a pressure of 40 lbs. per square inch. The inflation pressure should be checked at least weekly and should not be permitted to drop more than 5 lbs.

On cars driven at high speeds, the front tires should be inflated to 50 lbs. or higher if necessary. *This is important.*

Tire Carrier (Wood Wheel Equipment)

To remove the spare tire from the carrier, proceed as follows: Insert the key in the lock and turn it to the right, holding the lock itself




Figure 17. After unlocking the lock, the large nut holding the wire wheel can be unscrewed with the hub cap wrench.



Figure 18. The clamp over the disc wheel can be unscrewed by hand after it is unlocked.

Wire Wheel Carrier

To remove the spare wire wheel from the carrier, first unscrew the dust cap which protects the lock. Insert the key in the lock and turn it to the right. Then unscrew the large nut, using the hub cap wrench. The wheel can then be taken off the carrier.

When installing the wheel on the carrier, tighten the nut as far as it will go. Then insert the key and turn it to the left.

Disc Wheel Carrier

To remove the spare disc wheel, unscrew the small dust cap and unlock the carrier in the same way as for the wire wheel. Then unscrew the large clamp, removing the large dust shield. The wheel can then be taken off the carrier, after unscrewing the cap nuts by which it is fastened.

When installing a wheel on the carrier, tighten the clamp and lock it in place by turning the key to the left.

Lock for Spare Tires on Fenders

When the spare tires or wheels are carried on the fenders, a lock is provided for each wheel or tire. This lock is fastened to the fender and must be removed before the tire or wheel can be removed. To remove the lock insert the key and turn it to the right. The lock can then be lifted out.

When mounting spare tires in fenders, they should be partly deflated before being put in the fender well, and should be fully inflated after they are in position. By following this method a snug fit is secured, and the tires or tire covers are prevented from chafing.



Figure 19. When spare tires are carried on the fenders, the lock must be removed from the fender before the spare tire can be removed.

Truing Up Rim

If a rim on a wood wheel does not run true, it may be trued up in the following manner: Rotate the wheel slowly and mark the part that runs farthest out from the face of the wheel. Loosen slightly the nuts diametrically opposite the mark and then tighten the nuts on the marked side. Test the wheel again, and if it still does not run true, repeat the operation.





Figure 20. To jack up the car it is necessary to have the jack in the proper position under the axle.

In case of tire trouble, it is then merely necessary to remove the rim or wheel with the flat tire and install the spare in its place. Illustrated directions for performing this work on wood, wire and disc wheels are given on pages 35, 36 and 37.

Use of Jack in Changing Tires

When a tire is "flat," the axle is not far enough above the ground to permit placing the jack directly under the axle. It is then necessary to make use of the adjustable shoulder which engages with teeth on the side of the jack.

If a front wheel is to be raised, the jack should be so placed that the adjustable shoulder is under the axle. If a rear wheel is to be raised, the jack should be placed so that the adjustable shoulder is under the bracket shown in Fig. 20.

Changing Tires

If an inflated spare tire is always carried on the spare rim or wheel, the driver will seldom or never have to dis-




Figure 21a. Jack up the wheel until the tire clears the ground. Remove the dust cap and clamping nut from the valve stem. Remove the six rim clamps, unscrewing them with the brace wrench supplied in the tool kit.




Figure 21b. Rotate the wheel until the valve stem is at the top, and pull the bottom of the rim away from the wheel.




Figure 21c. Then rotate the wheel until the valve stem approaches the bottom, when the rim and tire will roll free from the wheel and can be removed without lifting.

To mount a rim, rotate the wheel until the hole for the valve stem is in the position shown in the last illustration. Insert the valve stem and rotate the wheel, which will carry the rim with it, until the valve stem is at the top. Then push the lower part of the rim into place. Install the rim clamps over the rim and turn the nuts partly down. Go over the nuts again and tighten them firmly. Install the valve stem clamping nut and the dust cap. Be sure the clamping nut is tight.

Figure 21. Changing Rims (Wood wheels)



Figure 22a. Jack up the wheel until the weight of the car is off it, but with the tire still dragging. Place the hub cap wrench on the cap with the cam lever lowered, engage the sliding barrel puller in the slots and turn the puller one-quarter turn either way.



Figure 22b. Raise the lever up and over, thus drawing out the sliding barrel of the hub cap. If the barrel does not withdraw easily, tap the end of the wrench back and forth. This will release the pressure on the teeth of the sliding barrel and allow it to disengage.




Figure 22c. Loosen the hub cap by striking the wrench a few times with a hammer. (The hub caps are marked with arrows showing the direction in which they screw on and off.) Then jack up the wheel, unscrew the hub cap and pull the wheel off the inner hub. Never attempt to remove the hub cap with the weight of the car on the wheel.

In installing the wheel, see that it is set up snugly on the corrugations on the inner hub. Hub caps are marked either "Right Side" or "Left Side" and must always be installed on the proper side. Start the cap by hand, taking care not to cross the threads. Then apply the hub cap wrench and disengage the sliding barrel as directed above. Securely tighten the cap, striking the end of the wrench with a hammer a few times. Lift up the cam lever. If the sliding barrel does not automatically engage, tighten the cap farther.

Figure 22. Changing Wire Wheels

Note: The nuts on the right-hand wheels are marked R; those on the left are marked L. All nuts screw off in the direction the wheels rotate when the car is going backward, and on in the forward direction.




Figure 23a. To remove a front wheel, jack it up until the weight of the car is off it, but with the tire still touching. Then loosen the cap nuts around the wheel hub with the brace wrench in the tool kit. Jack the wheel up further, unscrew the nuts and remove the wheel. In removing a rear wheel, set the hand brake and jack the wheel all the way up.




Figure 23b. In mounting disc wheels, use the rear end of the brace wrench as a pilot bar.

To mount a front wheel, bring it up close to the hub and pass the pilot bar through a lower hole and over a lower stud. Lift with the bar, and guide the wheel with the other hand. The weight of the wheel will keep the hub from turning, and the wheel will slip easily into place.



Figure 23c. To mount a rear wheel, set the hand brake and put the pilot bar through an upper hole and over an upper stud.

In either case, several nuts should be started by hand before the pilot bar is removed. The nuts should not be tightened in rotation. After tightening one nut, tighten the nut directly opposite. In this way the first two nuts center the wheel and insure a good fit. The nuts need not be as tight as they can be forced. They should be only moderately tight.

Figure 23. Changing Disc Wheels

CHAPTER IV

Cold Weather Operation

The La Salle car is an all-season car and no owner need hesitate to make full use of his car in severe winter weather as well as at other times. Satisfactory operation in freezing weather, however, depends upon having the car prepared for cold weather and in giving it the special attention which is required at that time. In this chapter has been grouped all the information relating to care and operation of the car during cold weather. It should be reviewed just prior to the beginning of the winter season.

Preparing for Cold Weather

Anti-Freezing Solutions

In freezing weather, the water in the cooling system must be replaced with some solution that has a lower freezing temperature than that of water. A solution of denatured alcohol and water is recommended.

Before putting anti-freeze in the radiator, the cooling system should be thoroughly cleaned by flushing (see page 81). It is also important to inspect the hose connections and see that they are all in good condition, so that loss of anti-freeze by leakage will be avoided.

The strength of an alcohol solution must be periodically tested with a hydrometer. Alcohol vaporizes more rapidly than water and the loss by evaporation must be replaced at frequent intervals or the weakened solution will afford little protection against freezing. Care must also be taken not to let an alcohol solution get on the finish of the hood or radiator.

The following table gives the freezing temperature and specific gravity of solutions of denatured alcohol and water:

Lowest Temperature Expected	Per cent by Volume	Specific Gravity (at 60° F.)	Qts. Alcohol required to make 5½ gls. solution
+10° F.	30	.9668	6¼
0° F.	38	.9567	8
-10° F.	45	.9485	9½
-20° F.	51	.9350	10¾
-30° F.	57	.9260	12

Patented substitutes should not be used unless tested and approved. Cadillac distributors and dealers should be consulted as to the suitability of an anti-freeze or inquiry may be made to the factory Service Department. Solutions containing calcium chloride or other ingredients injurious to the metal parts of the cooling system must never be used.

Capacity of Cooling System

The capacity of the cooling system is five and one-quarter gallons when filled to the proper level. It is not necessary to add liquid to the radiator whenever the level falls below the filler. There is sufficient liquid in the cooling system if the upper tank is half full, and any liquid in excess of this is usually forced out through the overflow pipe as soon as the engine becomes warm. When water is used, any loss from this cause is of little consequence, but in winter to conserve anti-freeze it is important to avoid adding more liquid than is necessary.

Effect of Alcohol on Finish

Strong solutions of alcohol have a harmful effect on the finish. In adding pure alcohol or solutions containing 50 per cent or more alcohol, extreme care must be used not to let the liquid spatter or spill. A funnel and a pouring vessel with a suitable spout are necessary. Especially avoid pouring cold alcohol into very hot water. The effect of this is to make the mixture foam up and possibly bubble over on the finish.

Winter Lubrication

Lubrication of the car requires special attention in winter, not only to insure proper lubrication of the moving parts, but to secure the same ease of operation in starting, steering and shifting gears as during warmer weather.

Contrary to popular impression, this does not mean the use of special winter lubricants. The lubricants approved by Cadillac engineers and sold by Cadillac distributors are year-round lubricants. It is not necessary therefore, to change the engine oil or the lubricant in the transmission or rear axle when cold weather approaches. It is merely necessary to thin these lubricants with kerosene. Authorized Cadillac service stations are prepared with full information as to the amount to be added and the conditions under which it is to be added.

The temperature at which thinning of the engine oil is necessary depends upon the oil used, but with most of the approved oils, some

kerosene should be added as soon as the temperature drops to freezing. From one to three quarts of kerosene are necessary, one quart being plenty for temperatures around freezing while three quarts will be required at 10° below zero.

After the oil is once thinned, additional kerosene does not ordinarily need to be added until the engine oil is changed at the usual 2000-mile interval. The fresh oil must then be thinned. However, on a long hard drive some of the kerosene will be driven out by evaporation. After such a drive, kerosene should be added to replace that which has evaporated.

When thinning the oil in the engine a small amount of kerosene should also be added to the oil in the fan reservoir.

The lubricant in the transmission, rear axle and steering gear should also be thinned as soon as the weather is so cold that the transmission gears are hard to shift. If a sufficient amount of kerosene is added to provide for the lowest winter temperature expected, it will not be necessary to add kerosene again thereafter during the winter. If ten per-cent kerosene is added, this will take care of temperatures down to ten below zero.

Storage Battery

The electrical system of an automobile has much more to do in winter than in summer. The engine is harder to crank and must usually be cranked longer before it starts. The lights are also used to a much greater extent than during the long days of summer. All this means that the battery must be ready for increased demands.

It is therefore a good plan in preparing for the winter season to see that the battery is well charged to begin with, that the battery connections are clean and tight and that the charging rate of the generator is sufficient.

Gasoline System

The carburetor on the LaSalle engine has automatic compensation for temperature. Nevertheless it is a good plan to check the carburetor adjustment when cold weather arrives. This inspection should give special attention to the carburetor choke control to make sure that the enriching device at the carburetor is fully effective when the choke button is operated.

In warm weather a small amount of water in the gasoline has little or no effect on the running of the engine. In freezing weather, however, even a small amount of water may freeze and stop the entire flow of fuel to the carburetor.

One of the things to be done in preparing for winter weather, therefore, is to clean the gasoline filter and the sediment chambers in the gasoline system. (See page 75.)

Starting the Engine

Carburetor Enriching Button

The first difference between starting the engine in cold weather and starting the engine in warm weather is in the greater use of the carburetor enriching device necessary in cold weather. Gasoline does not vaporize as readily at low temperatures, and in order to supply the cylinders with a gaseous mixture rich enough to be ignited, the proportion of liquid gasoline to air must be increased.

At the same time it is important not to apply the enriching device more than is necessary. The unvaporized gasoline collects on the cylinder walls and works down past the pistons, washing off the lubricant as it goes. Although dilution of the oil supply with this unburned gasoline is minimized in the La Salle engine by an exclusive system for ventilating the crankcase (see page 50), it is best to avoid an excess of liquid gasoline in the combustion chambers by careful and judicious use of the enriching device.

The following rule should govern the use of the enriching button in winter weather: Pull the enriching button back just as far as it is necessary to start the engine, but as soon as the engine starts, let the button return as far as possible without causing the engine to stop or slow down. Then release the button entirely as soon as the engine is warm enough to permit doing so.

In cold weather it is also a good plan to pull out the enriching button just before switching off the ignition to stop the engine. This will make it easier to start the engine.

Priming the Carburetor

In extremely cold weather, if the engine does not start after cranking for a few seconds with the enriching device fully applied, release the starter pedal. Then prime the carburetor by opening and closing the throttle once or twice rather rapidly with the accelerator. Opening

and closing the throttle operates a throttle pump on the carburetor and raises the level of gasoline in the carburetor bowl. The carburetor should never be primed in warm weather and should not be primed unnecessarily in cold weather. *Excessive* priming is likely to make starting difficult rather than easy.

Position of Throttle Hand Lever

The correct position of the throttle hand lever for starting in cold weather is the same as for starting under other conditions, that is, about one-fourth the way down from the idling position. In warm weather, however, the lever may be returned to the idling position almost as soon as the engine is started. In cold weather, the throttle must be left slightly open until the engine becomes warm.

Position of Spark Control Lever

It is the practice of some drivers to move the spark control lever all the way to "Retard", whenever starting the engine. This is the correct position if the engine is to be cranked by hand, but if the engine is to be cranked with the starter, there is no reason for retarding the spark, and in extremely cold weather "popping back" in the carburetor is less likely to occur if the spark is fully advanced.

Use of Starter

In extremely cold weather, when the car has been standing long enough to become thoroughly chilled, it is a good plan to disengage the clutch during the cranking operation. If this is not done, the starter is called upon to turn the jackshaft gears in the transmission in addition to cranking the engine. At ordinary temperatures, the additional energy required is negligible, but in extremely cold weather, the lubricant in the transmission offers sufficient resistance to rotation of the transmission gears to increase considerably the demand upon the battery and to retard the cranking speed.

Use of Accelerator Before Engine is Warm

In cold weather, after the engine has been started and before it has run long enough to become warm, the engine cannot deliver its normal power and it should not be called upon to do so. In accelerating the engine to start the car and in accelerating the car after the transmission is in gear, do not open the throttle suddenly or too far. To do so is not only to invite "popping back" in the carburetor, but to increase the amount of excess unvaporized gasoline in the combustion chambers, both of which results are undesirable. For this reason, also, starting in intermediate should never be attempted in cold weather.

PART II

LUBRICATION AND CARE



LA SALLE LUBRICATION SCHEDULE

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____

DATE DELIVERED _____

Do not wait for schedule lubrications before adding engine oil. The oil level should be checked every 100 to 150 miles and oil added if the indicator ball is below "Full." This is especially important on cars driven at high speed.

LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE															
	1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4
	1000	2000	3000	4000	1000	2000	3000	4000	1000	2000	3000	4000	1000	2000	3000	4000
CHECK RADIATOR LEVEL	WATER OR ANTI-FREEZE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
ADD ENGINE OIL AS NECESSARY	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
GENERATOR AND DISTRIBUTOR OIL CUPS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
FAN—ADD ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
BRAKE PINS AND CONNECTIONS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SPRING LEAVES	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DOOR HARDWARE	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
GREASE GUN CONNECTIONS (EXCEPT WATER PUMP)	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
WATER PUMP	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
*ADD WATER TO STORAGE BATTERY	DISTILLED WATER	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CHECK TIRE INFLATION		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
**TEST OIL FILTER		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DRAIN AND REPLACE ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
CLUTCH THRUST BEARING	FIBER GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
TRANSMISSION—ADD LUBRICANT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
REAR AXLE—ADD LUBRICANT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
STEERING GEAR—ADD LUBRICANT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
REAR WHEEL BEARINGS	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
FRONT WHEEL BEARINGS	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SPEEDOMETER DRIVE SHAFT	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
***FLUSH COOLING SYSTEM		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
****REFILL SHOCK ABSORBERS	SPECIAL OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:
 REMOVE OIL PAN AND CLEAN PAN AND SCREEN—ONCE A YEAR OR WHENEVER OIL FILTER IS CHANGED.
 THIN REAR AXLE AND TRANSMISSION LUBRICANT AS REQUIRED FOR LOW TEMPERATURES.
 DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING.
 *IN SUMMER, INSPECT BATTERY EVERY 500 MILES OR AT LEAST EVERY 2 WEEKS. **AFTER FIRST 10,000 MILES.
 NOT INCLUDED IN LUBRICATION NO. 4. *EVERY 12,000 MILES

RECORD ON OTHER SIDE

CHAPTER I

Systematic Lubrication

Necessity for Lubrication

The quiet, dependable operation of a new car is primarily the result of the accurate finishing of surfaces separated from each other by a few thousandths of an inch. In the La Salle, there are hundreds of such surfaces. If the clearances between these surfaces are to be maintained, so that the car will continue to operate quietly and dependably, wear must be prevented and the only way this can be done is by correct lubrication.

Cadillac engineers have provided for the lubrication of all surfaces where friction is a factor. The most that a manufacturer can do, however, is to provide a place for the lubricant and means for it to reach the surfaces to be lubricated. The car cannot be equipped with an inexhaustible supply of lubricant. Upon the car owner devolves the responsibility of replenishing the supply at the proper time with lubricant of the prescribed specifications.

Because of the importance to the car owner of proper lubrication of his car, every effort has been made in this Manual to give explicit information. Lubricant is prescribed for each point requiring lubrication, directions are given for applying it, and recommendations are made as to the frequency with which it should be applied.

Lubrication Schedule

Systematic lubrication, at regular mileage intervals, is the only kind that is effective. On page 44 is a complete lubrication schedule which, if faithfully followed, will insure correct lubrication for each wearing surface.

The unit of the La Salle lubrication schedule is 4000 miles, which is divided into four 1000-mile intervals. Corresponding to these is a series of four consecutive groups of lubricating operations. When the car has traveled 1000 miles the points enumerated under Lubrication No. 1 should receive attention. At 2000 miles, Lubrication No. 2 is due, and so on until at 4000 miles Lubrication No. 4 should be performed. At 5000 miles the schedule begins again with Lubrication No. 1.

In order that the driver may be continually reminded of the mileage at which the next lubrication is due, the speedometer is provided with

Figure 24. This is a fac-simile of the La Salle Lubrication Schedule and Record. Provision is made on the back of the card for recording when and where the car is lubricated. A copy of this card can be obtained on request from Cadillac distributors and dealers.

a lubrication notice. This consists of a strip of black celluloid (Fig. 25) which is placed across the speedometer cover glass below the total mileage dial and which has two white spaces, one for the lubrication number and one for the mileage at which it is due. Whenever the car is lubricated on the schedule, the figures then on the celluloid should be erased and the next lubrication number and the mileage at which it is due should be written or stamped in their places. If this notice is used, the driver need only glance occasionally at the speedometer and compare the mileage on the dial with the figures on the notice in order to plan for the necessary attention.




Figure 25. Lubrication notice.

Note: Do not wait for the mileage indicated on the notice before adding engine oil. The oil level should be checked every 100 to 150 miles and oil added, if the indicator ball is below "Full."

Cadillac distributors and dealers are prepared to sell lubrication based on this schedule. A car that is being lubricated on the schedule can be taken to any authorized Cadillac service station, and without further ordering than to specify "Schedule Lubrication," the car will receive the necessary attention.

Lubricants

The selection of proper lubricants for the La Salle car should be one of the first concerns of the owner in his attention to the lubrication of the car. The lubricants must not only be of high quality, but their viscosity and other characteristics must be suited to the car.

The owner is urged to consult the distributor or dealer from whom he purchased his car in regard to the names of lubricants which have been tested and approved for use in the La Salle car.

Engine Oil

It is particularly important that only approved engine oils be used for high-speed, continuous driving. Other oils cannot be depended upon to give satisfactory lubrication and economical mileage under such conditions. If, in an emergency, an unapproved oil must be used, special care must be taken to watch the oil level and add oil as soon as the level drops to "Fill."

During winter it may be necessary to thin the engine oil with kerosene in order to make the engine crank easily. See page 39 for instructions on lubrication in cold weather.

Chassis Lubricant

Lubricant conforming to the specifications for Chassis Lubricant is recommended for the transmission, rear axle, steering gear and all chassis points fitted with grease gun connections, except the water pump.

Lubricants conforming to these specifications may be used without thinning during all weather except winter weather below temperatures of 20° above zero. Below this temperature, thinning with kerosene is necessary in order to secure easier gear shifting, easier steering and proper lubrication of gears and bearings.

Wheel Bearing and Cup Grease

Greases approved under the specifications for Wheel Bearing and Cup Grease are suitable for lubricating the front wheel bearings and the water pump. This grease is not recommended for chassis lubrication, as Chassis Lubricant is much more effective.

Fiber Grease

Fiber grease approved under the specifications for this type of lubricant is recommended for the clutch thrust bearing.

CHAPTER II

Engine Lubrication

Oil Circulating System

The supply of oil is carried in the pressed steel reservoir that covers the bottom of the crankcase. The oil is circulated by a gear pump attached to the front main bearing cap inside of the crankcase. The pump is driven by a vertical shaft which is in turn driven by a spiral gear on the camshaft.

The pump draws oil from the bottom of the reservoir and delivers it under pressure to the bearings. Oil reaches the front main bearing through a passage in the bearing cap. A supply pipe from the pump runs the length of the engine parallel to the crankshaft and leads branch off from it to feed the center and rear main bearings. From the rear bearing the oil is conducted to the hollow camshaft through which it flows forward and lubricates the camshaft bearings.




Figure 26. Showing the location of the oil filler, oil level indicator, oil pan drain plug and other lubrication features.

(48)

The oil is carried from the front end of the camshaft to the oil pressure regulator, which is attached to the crankcase just ahead of the right-hand cylinder block. The regulator contains a by-pass with metering screw for adjustment of the oil pressure at idling speeds and a spring-controlled valve that opens to prevent excessive pressure at high speeds. The oil that passes the regulator, either through the by-pass or around the valve, lubricates the front end chains.

The valve stems are automatically lubricated by oil sprayed from two small holes drilled in the wall of each cylinder at such a distance from the bottom of the cylinder that, when the piston is at the bottom of its stroke, these holes register with a groove in the piston between the second and third piston rings. As the piston descends on the power stroke, the oil collects in this groove and as soon as the groove registers with the holes, the pressure of the gases above the piston forces oil out upon the valve stems. Surplus oil collecting in the valve compartments is returned to the crankcase through drain passages.

All oil returns to the pan through a fine mesh screen in the oil pan.

Oil Level

The normal capacity of the oil pan is two gallons, which fills it to the level of the screen in the pan. When the oil pan contains this amount, the oil level indicator on the right-hand side of the engine (Fig. 26) indicates "Full." As the oil level descends, the indicator indicates "Fill" and then "MT" (Empty). Oil should be added as soon as the indicator ball has dropped to "Fill." If the indicator indicates "MT," under no circumstances should the engine be run until oil has been added.

The mileage interval at which oil must be added depends upon individual circumstances. *It is recommended that the oil level indicator be checked every one hundred to one hundred and fifty miles, although it is improbable that oil will be required as frequently as this.*

Oil Pressure

The pressure of the oil in the supply pipe is indicated by the oil pressure gauge on the instrument panel (Fig. 6).

It is absolutely necessary that there be oil pressure just as soon as the engine starts and as long as the engine is running. If the oil pressure gauge does not indicate pressure as soon as the engine starts, stop the engine at once and investigate the cause. First, check the level of oil in the oil pan. If the level is above "Fill," consult the nearest Cadillac service station.

The *amount* of pressure indicated by the gauge depends upon several things: the kind of oil, the temperature of the oil and the speed of the engine. With fresh oil of the correct viscosity, the oil pressure at idling speed should be from 7 to 10 lbs. after the engine has become thoroughly warm.

The pressure indicated at speeds above idling speed may be assumed to be correct if the pressure at idling speed is correct.

Crankcase Ventilating System

In every internal combustion engine, seepage of vapors by the pistons takes place to some extent, permitting water vapor and other products resulting from combustion, as well as unburned gasoline, to enter the crankcase. Contamination of the lubricating oil from this source makes it necessary in most engines to replace the oil supply at frequent intervals.

La Salle engines are equipped with a system to prevent the seepage vapors from entering the crankcase. To bring about this result, advantage is taken of the fact that the La Salle crankshaft with its compensating weights acts naturally to draw air through an inlet in the left-hand side of the engine, building up within the crankcase a pressure slightly above the atmospheric pressure. No outlet is provided in the crankcase itself, but in the wall of each cylinder is a port connecting the space below the piston with the valve compartment. The port is open except when the piston is at the extreme bottom of its stroke.

The effect of this arrangement is as follows: The seepage vapors that pass the two upper piston rings are forced through slots milled in the circumference of the lower piston ring and through corresponding holes in the piston into the space inside the piston, where they are carried down as the piston descends. The vapors cannot enter the crankcase, however, because they are prevented from doing so by the pressure built up in the crankcase by the revolving crankshaft. Instead, the vapors are expelled through the port into the valve compartment. From the valve compartments, the expelled vapors are conducted through pipes underneath the car where they are discharged.

Oil Filter; 16*

Another source of contamination of the oil supply is dirt. In the La Salle engine all solid matter in the oil is removed by means of a

*The numbers following the headings in this chapter and Chapter III refer to Fig. 28.

filter, which is attached to the right-hand side of the engine and which is connected to the oil circulating system.

The filter is connected to the oil line by a pipe that leads from a tee on the crankcase at the rear of the right-hand cylinder block. The oil pressure gauge on the instrument board is also connected to this tee. Oil is thus forced to the filter whenever the engine is running and there is pressure in the oil line.

When the filter cartridge is new, the capacity of the filter is such that at a car speed of 25 to 30 miles per hour, the quantity of oil in the crankcase will pass through the filter approximately every five minutes. This rate of flow will gradually decrease until the filter ceases to function due to clogging, and when this occurs it will be necessary to replace the filter cartridge. The filter is provided with a safety valve which prevents excessive pressure on the filter tank.

To determine whether oil is passing through the filter, open the T-shaped valve on the filter fitting. If oil flows from the opening, the filter is operating. When performing this test the engine must be running and should be sufficiently warm to allow free oil flow. Make sure that the valve is tightly closed after the test is completed.

It is important that the filter cartridge be replaced just as soon as the filter ceases to function. Otherwise the whole purpose of the filter is defeated and wear of the engine parts will result from the dirty oil.

Under average conditions, replacement of the filter cartridge is recommended every 10,000 miles. In any event the flow of oil through the filter should be tested at the end of 10,000 miles and every 1000 miles thereafter until the filter cartridge is replaced. Filter cartridges for replacement can be obtained from Cadillac distributors and dealers or from United Motors Service stations.

Replacing Engine Oil; 14

Although the crankcase ventilating system and the oil filter described in the preceding sections greatly prolong the useful life of the oil, it is recommended that the oil be drained and replaced with fresh oil every 2000 miles.

To drain the oil, simply remove the drain plug (Fig. 26). Be sure to reinstall the drain plug before adding the fresh oil. Two gallons of fresh oil should be added, or enough to bring the oil level indicator ball to "Full."

At the end of the first 1000 miles, it is recommended that the car be taken to a Cadillac service station to have the oil pan and screen

removed and cleaned with gasoline or kerosene. This should be repeated once a year or whenever the filter unit is replaced.

Generator Oil Cups; 15

Two oil cups on the generator conduct lubricant to the forward and rear bearings on the armature shaft. A few drops of engine oil should be applied to each cup every 1000 miles.

Timer-Distributor Oil Cup; 10

The oil cup at "10" is for lubricating the ball bearing at the upper end of the timer-distributor shaft. A few drops of engine oil should be applied every 1000 miles.

Fan; 9

The fan is lubricated by oil contained in a reservoir in the fan hub. The screw plug in the outside of the reservoir should be removed every 1000 miles and engine oil should be added to bring the oil to the proper level. In adding oil, it is necessary to add somewhat more than enough and then drain off the surplus by turning the fan so that the hole points down. A short stand-pipe inside the reservoir insures that the proper amount of oil is retained. If no oil runs from the hole when it is first turned down, do not assume that the oil level is correct. Sometimes the reservoir is "air-bound," and the hole should be left pointing down for at least half a minute to give the air a chance to work in. A cloth or piece of waste may be held under the hole to catch the oil.




Figure 27. Oil for lubricating the fan is carried in the fan hub. The supply should be replenished every 1000 miles. Grease or heavy oil must never be used in the fan.

Do not put heavy oil or grease in the fan.

Water Pump; 13

A grease cup is provided for lubricating the water pump. This cup should be turned down and refilled with cup grease every 1000 miles.

Front Engine Support; 7

A grease gun connection is provided for lubricating the front engine support. Chassis lubricant should be applied with the grease gun every 1000 miles.




Figure 28. Each "G" represents a grease gun connection. Each number indicates a lubricating point for which instructions are given in Chapters II and III.

CHAPTER III

General Lubrication

Grease Gun Connections; G

Spring bolts, steering connections, brake rocker shafts and other points are provided with connections to fit the grease gun supplied with the tool equipment. These points are indicated by "G" in Fig. 28. Chassis lubricant as specified on page 47 should be applied to these points with the grease gun every 1000 miles.

Clutch Thrust Bearing; 3

The lubricating point on the clutch thrust bearing is fitted with a grease cup on an extension that passes through the right-hand side of the transmission case. It can be reached after lifting the right side of the hood.

The grease cup should be filled with fiber grease and turned down two or three times every 2000 miles.

Transmission; 17

The transmission case should contain sufficient lubricant to bring the level up to the filling hole at the right-hand side. The level should be inspected every 2000 miles and chassis lubricant added if necessary.

If, in cold weather, the transmission gears are difficult to shift, the lubricant should be thinned by the addition of kerosene. On the return of warm weather in the spring, the drain plug should be removed from the bottom of the transmission case and the lubricant should be drained and replaced with fresh lubricant. One and one-half quarts of lubricant are required to fill the transmission case to the proper level.

Rear Axle; 20

The rear axle housing should contain enough lubricant to bring the level up to the filling hole in the rear cover plate. The level should be inspected every 2000 miles and chassis lubricant added if necessary.

In weather cold enough to warrant thinning the transmission lubricant, the lubricant in the rear axle should also be thinned. On the return of warm weather in the spring the drain plug should be removed from the bottom of the axle housing and the lubricant should be

drained and replaced with fresh lubricant. Three quarts of lubricant are necessary to fill the rear axle housing to the proper level.

Front Wheels; 5, 12

The wheel bearings are packed in grease when the car is assembled. Every 4000 miles the front wheels should be removed and the bearings should be thoroughly cleaned in gasoline or kerosene. They should then be repacked with wheel bearing and cup grease and the bearings adjusted in accordance with the directions on page 107.

Rear Wheels; 2, 19

Every 4000 miles the screw plugs in the rear wheel hubs should be removed and chassis lubricant should be injected with the grease gun. On cars with wire wheels, the wheels must be removed to reach the plugs in the hubs. On cars with disc wheels it is necessary to remove the hub caps and the dust caps underneath them in order to reach the plugs in the hubs.

Steering Gear; 4

The grease gun connection for adding lubricant to the steering gear is on top of the housing just at the base of the steering column. Chassis lubricant should be added every 2000 miles. If, in cold weather, the car steers hard, the lubricant should be thinned by the addition of kerosene.

Speedometer Flexible Drive Shaft

The flexible shaft by which the speedometer is driven is housed in a flexible casing. To lubricate the speedometer drive shaft, the shaft should be removed from its casing and lubricant applied to it for its entire length. Cup grease is recommended for this lubrication, which should be performed every 4000 miles.

Do not under any circumstances attempt to lubricate the speedometer itself. Any parts in the speedometer requiring lubrication are amply supplied when it is assembled.

Springs; 1, 6, 11, 21

To lubricate the spring leaves, it is recommended that the edges and ends of the leaves be painted with engine oil every 1000 miles. A small stiff brush should be used. After applying the oil, the car should not be washed until it has been driven far enough to allow the lubricant to work in between the leaves. Do not separate the leaves and insert

lubricant. A certain amount of friction between the spring leaves is necessary in order to give the springs the desired characteristics.

If spring covers are used, it is not necessary to lubricate the spring leaves as directed in the preceding paragraph. It is sufficient to repack the springs once a season with petroleum jelly.

Door Hardware

Whenever the chassis is being lubricated, the door locks and other door hardware should also be lubricated as follows:

Place a few drops of oil on each door lock plunger or striker, turning the handle back and forth so that the oil will work into the lock. Also place a drop of oil on each of the striker plates against which the strikers engage when the doors are closed. The hinge pins should also be oiled sparingly so as not to get oil on the finish.

Each door has a wedge-shaped tongue that dovetails into a receptacle on the body when the door is closed. These tongues should receive a small amount of grease or oil.

Each closed car door is also fitted with a check at the top which limits the outward movement of the door. A small amount of grease should be applied to the pin that slides in the slot at the top of the door.

Cooling System; 8

The level of the liquid in the cooling system should be checked every 1000 miles. Every 4000 miles the system should be drained and flushed as directed on page 81.

Storage Battery; 18

Distilled water should be added to the cells of the storage battery at least every 1000 miles. (See page 85)

Shock Absorbers.

The Delco-Remy-Lovejoy shock absorbers with which La Salle cars are equipped should have oil added every 12,000 miles. If the oil in the shock absorbers is not up to the proper level, the normal spring action will not be obtained. The shock absorbers require a special oil which can be obtained from Cadillac distributors or dealers or United Motors Service Branches and authorized distributors.

CHAPTER IV

Care of Body

Care of Finish When New

ON CARS finished with varnish, more careful and more frequent attention is necessary when the car is new than after the varnish has hardened. Particular care should be taken to keep mud from the body and hood for the first few weeks. Even after the varnish has hardened, mud must not be permitted to remain on the finish over night or long enough to dry. If it is not possible to wash the car thoroughly before putting it away for the night, flush it off and then thoroughly wash the car the next morning. Mud permitted to remain on the car until it has dried is not only difficult to remove, but stains and dulls the finish.

The same degree of caution, although commendable, is not as necessary on cars finished with Duco, because Duco hardens much more quickly than paint or varnish.

Washing Varnished Cars

Use clean water and plenty of it. Do not use water containing alkali. In parts of the country where the regular water supply contains alkali, use rain water.

Do not use hot water as it destroys the luster. The temperature of the water should be between 40 and 60 degrees Fahrenheit. Do not wash the hood while it is hot, because the effect on the finish is the same as washing it with hot water. Unless the hood is allowed to cool before washing, the luster will soon disappear.

If a hose is used in washing, do not have pressure greater than will carry the water six inches beyond the end of the hose. Water under higher pressure drives the grit and dirt into the varnish. It is best not to use a nozzle.

Wash the chassis first, going over the under sides of the fenders, the wheels, and the running gear with water flowing gently from the hose. This will flush off most of the mud and dirt.

If it is necessary to use soap to remove road oil from the under side of the fenders, or machine oil or grease from the chassis, use a good automobile soap dissolved in a pail of water and apply the soapy solution with a sponge. Do not let this soapy solution remain on the finish

more than two or three minutes, but immediately wash it off thoroughly with a soft carriage sponge.

After washing the chassis, begin at the front of the car and flow water from the hose upon the body, hood and upper surfaces of the fenders. This will soften the accumulation of road dirt, removing most of it. Then go over the car again and remove all dirt by rubbing with a soft wool sponge, at the same time applying an abundance of water from the hose. The sponge, which should be kept exclusively for the body, hood, and upper surfaces of the fenders, should be rinsed frequently in clean water to remove any grit.

After the washing is completed, squeeze the sponge as dry as possible and pick up all water from crevices. Then thoroughly wet a clean, soft chamois, wring it as dry as possible, and dry the finish. Be sure and use a chamois that has not been used on the chassis. Rinse the chamois and wring it out frequently. Do not rub the finish or apply more pressure than is necessary to dry off the surplus water. The remaining water will evaporate quickly, leaving the finish in good condition.

If it is desired to chamois the wheels and chassis, and they have become dry, wet these parts with clean water and then wipe them. Be sure to use a separate chamois for the chassis. The chamois that has been used on the body should be saved for the body exclusively.

Do not use soap, gasoline, kerosene, or anything of similar nature on the finish. Such materials attack the finish.

Washing Duco

Although it is not necessary in washing cars finished in Duco to use the same degree of care as in washing varnished cars, nevertheless the same general directions should be followed.

Cleaning Windows

Do not clean the window glass with preparations that may contain harmful ingredients. Use only cleaning compounds that are known to have no destructive effects on highly polished glass.

Cleaning Upholstery

To keep the upholstery in closed cars in the best condition, it should be cleaned thoroughly at least once a month with a whisk broom and

vacuum cleaner. Dirt and grit accumulating in the fabric wear it out faster than use.

Spots on the upholstery may be cleaned with any good dry cleaner. When the cleaner has thoroughly evaporated, apply a hot flatiron wrapped in a wet cloth. Steaming the fabric and rubbing lightly against the nap will raise the nap to its normal position.

CHAPTER V

Care of Tires

EACH tire maker publishes a booklet with instructions for care and repair of tires. Every motorist should provide himself with one of these and thoroughly familiarize himself with the contents. The suggestions here apply to pneumatic tires in general.

Three-fourths of so-called "tire trouble" is the result of misuse. We give here some suggestions regarding the more important points of the care of tires.

Result of Under-Inflation

Under-inflation causes a tire to flatten out under load. This causes the side walls to bend sharply as the tire revolves. The result is the breaking of the side walls. An under-inflated tire is susceptible to bruise, broken cords and blow-out.

Result of Improperly Aligned Front Wheels

Running a car with the front wheels out of alignment causes rapid tread wear. This usually affects both tires similarly, although sometimes only one tire is affected. An incorrect adjustment of the front axle parallel rod or a bent steering arm is responsible for the condition. Unless the wheels are in proper alignment the treads of the front tires will wear away in a remarkably short time.

Neglect of Small Cuts

If cuts extending to the cords are neglected, deterioration and blistering of the tire tread is the result. It is unnecessary to remove a tire to treat small cuts of this nature. Tire companies furnish a plastic compound for filling cuts. This prevents moisture and dirt from getting in. If a cut is large, it should be vulcanized at once.

Result of Improperly Adjusted Tire Chains

Tires are sometimes badly damaged through the use of tire chains which are incorrectly adjusted or which are fastened to the spokes of the wheel holding the chains tightly in place.

The least injury results when chains are applied loosely, leaving play enough to permit them to work around. The wear on the tire is thus

distributed evenly. Probably the greatest amount of injury comes from using chains unnecessarily on paved streets.

Result of Sudden Application of the Brakes

The sudden application of the brakes resulting in sliding the wheels causes the tread to wear away in spots. A tire will give away very rapidly under this severe treatment.

Additional Suggestions

The tires are constructed for the purpose of carrying up to certain maximum loads and no more. It should be realized that overloading a car beyond the intended carrying capacity is sure to materially shorten the life of the tires. Do not turn corners or run over sharp obstructions, like car tracks, at a high rate of speed. Such practice is sure to strain or possibly break the cords, with the result that the further life of the tires will be limited. Remember that most tire troubles are the result of abuse.

Avoid scraping the tires against the curb and running in ruts. This kind of wear scrapes off the rubber wall and exposes the layers of cords to dirt and moisture, which soon starts to rot the cords.

In turning in a narrow street, avoid striking the curb.

If a tire goes flat without any indication of injury to the tire, see that the valve is not leaking. A little moisture on the tip will show bubbles if the air is escaping.

In case of puncture, the car should be stopped at once and the tube repaired or replaced, or the tire replaced by the extra one. The tire should also be examined carefully and the cause of the puncture ascertained and the nail, glass or whatever it may be, should be extracted. Before replacing the tire on the rim, examine the inside of the casing, to see that the cause of the puncture is not still protruding. It is also advisable to look over the outside of the tires frequently and take out any pieces of glass or other particles which may have become imbedded in the casing.

Don't run in ruts or car tracks; the sides of a tire will soon wear out under such treatment. Avoid large stones or other obstructions in the road. To hit one of these may break the carcass even though no external injury be visible.

The garage floor should be kept free from oil or gasoline. The tires on a car left standing on a grease-covered floor deteriorate quickly, the

natural enemies of rubber being oil and gasoline. These destroy the nature of the rubber, rendering it soft, so that it cuts and wears away quickly.

If the car is not used during the winter, it is better to remove the tires from the rims, keeping casings and tubes in a fairly warm atmosphere away from the light. It will be better to slightly inflate the tubes as that keeps them very nearly in the position in which they will be used later on. If the tires are not removed and the car is stored in a light place, it will be well to cover the tires to protect them from the strong light, which has a deteriorating effect on rubber.

CHAPTER VI

Storing Car

IF THE car is not to be used for a period of several months, it should be protected from deterioration during the period when it is not in use by carefully preparing it for storage.

Engine

To prepare the engine for storage, proceed as follows: Run the engine until opening of the radiator shutters indicates that the engine is warm. This may be done by driving on the road or by running the engine idle. In the latter case care should be taken that there is sufficient ventilation to avoid injury from carbon monoxide poisoning. (See page 21.)

After the engine is warm, place the car where it is to be stored and shut off the flow of gasoline to the carburetor by turning the valve above the filter. As soon as the engine starts to slow down raise the polished aluminum cap on top of the carburetor and inject three or four tablespoons of clean fresh engine oil into the carburetor. Injection of the oil will stop the engine.

Remove the spark plugs. Inject two or three tablespoonsfuls of engine oil into each spark plug hole and before replacing the plugs crank the engine three or four revolutions with the ignition switched off. This will tend to distribute the oil over the cylinder walls. The engine should not be started again after injecting the oil. If it is started, it will be necessary to repeat the treatment.

Storage Battery

If the car is to be stored during the winter, the storage battery should have special treatment in order to protect it against freezing.

Shortly before the car is used for the last time, distilled water should be added to bring the level of the solution up to the bottom of the filling tubes. (See page 86.) After the water added has had an opportunity to mix thoroughly with the acid solution by running the car or engine, the specific gravity should be taken with a hydrometer. If the specific gravity of the solution is above 1.270 there will be no danger of the acid solution freezing. If, however, the specific gravity is below 1.270, the battery should be removed and charged. *Unless the battery is fully charged or nearly so it is probable that the acid solution in the battery will freeze and cause extensive damage.*

(64)

The battery ground connection should in all cases be disconnected during storage as a slight leak in the wiring will discharge the battery and lower the specific gravity to the point where the solution may freeze.

If possible, the storage battery should be removed and charged from an outside source every two months during the storage period.

Tires

During storage of the car, it is best to remove the tires *from the rims* and to keep the casings and tubes in a fairly warm atmosphere away from the light. The tubes should be inflated slightly after the tires have been removed.

If it is not convenient to remove the tires from the car and the car is stored in a light place, cover the tires to protect them from strong light, which has a deteriorating effect on rubber.

The weight of the car should not be allowed to rest on the tires during the storage period. If tires are not removed, the car should be blocked up so that no weight is borne by the tires. The tires should also be partly deflated.

Body and Top

A cover should be placed over the entire car to protect it from dust. In storing an open car, the top should be up.

Taking Car Out of Storage

In putting into use again a car that has been stored, it is advisable, unless the storage battery has been removed and charged at periodic intervals, to remove the battery from the car and give it a fifty-hour charge at a four-ampere rate. If the battery has received periodic charges, or if the specific gravity is above 1.200, simply add distilled water to the proper level and connect the leads. If there is a greenish deposit on the terminals of the battery, remove this with a solution of bicarbonate of soda (common cooking soda) and water. Do not allow any of this solution to get into the battery.

Before starting the engine, drain the oil from the oil pan and remove and clean the oil pan and screen. After reinstalling the oil pan, add eight quarts of fresh engine oil. Fill the cooling system, being sure to use anti-freezing solution in freezing weather. Remove the spark plugs

and inject two or three tablespoonfuls of engine oil into each cylinder. Reinstall the spark plugs and, with the ignition switched off, crank the engine a few seconds with the starter to distribute the oil over the cylinder walls.

Start the engine in the usual manner. As soon as the engine starts, immediately let the carburetor enriching button go as far forward as possible without causing the engine to stop or slow down materially and then open the throttle until the ammeter reads approximately 10 with all lights switched off. While the engine is running lift the aluminum cap on top of the carburetor and inject from two to three tablespoonfuls of engine oil into the carburetor. It is a good plan to run the car outdoors as soon as this has been done. Release the carburetor enriching button entirely as soon as the engine is warm enough to permit it.

PART III

GENERAL INFORMATION

It is not the object of this section of the Manual to give complete directions for the repair and adjustment of La Salle cars. Most La Salle owners prefer to depend for the majority of such work on Cadillac Service Stations, where proper equipment and skilled workmen are available.

The details given here include general information regarding the construction of the car and some of the simpler adjustments and operations which do not require special equipment, and which, in emergency, can be performed satisfactorily by the average automobile mechanic.

CHAPTER I

Engine

Important Features of Construction

The La Salle engine is of the water-cooled, four cycle type with two L-head cylinder blocks of four cylinders each, placed at an angle of 90° between the blocks. The cylinders of one block are directly opposite those of the other block, the lower ends of opposite connecting rods working side-by-side on the same throw of the crankshaft.

The crankshaft has four throws or cranks, and three main bearings. The camshaft has four bearings and is driven by the crankshaft through a silent chain. The camshaft has sixteen cams, each operating one valve through a camslide which carries a roller.

The engine base is the aluminum crankcase that supports the cylinder blocks and carries the crankshaft and camshaft bearings. The crankcase is supported at the rear end by two arms which are cast integrally with the crankcase, and which are bolted to brackets on the frame. The front end of the engine is supported on a cross-member of the frame below the radiator.

Firing Order

In valve and ignition adjustments, the cylinders are referred to by numbers, the numbers indicating the order in which the cylinders fire. These numbers, the arrangement of which is shown in Fig. 29, are stamped on the cylinder heads near the spark plugs.




Figure 29. The cylinders fire in the order of the numbers shown here.

Main and Connecting Rod Bearings

The large diameter of the main and connecting rod bearings and the freedom of the crankshaft from vibration renders it ordinarily unnecessary to adjust these bearings for many thousands of miles. When bearing work is necessary, it should be performed only by one who is familiar with the work and who has the proper equipment.

(68)

The connecting rod bearings are cast in the connecting rods by a special process. When new connecting rod bearings are necessary, the entire rod should be replaced. Rods with new bearings can be procured from Cadillac distributors and dealers on an exchange basis.

Cylinder Heads and Removal of Carbon

La Salle cylinder heads are detachable, to facilitate access to the cylinders and combustion chambers for the removal of carbon.

To remove the cylinder head, first drain the water from the cooling system. Then disconnect the hose connections from the head by removing the two nuts that hold each outlet elbow to the head.

Remove the spark plugs. Remove the remaining nineteen nuts by which the cylinder head is held to the cylinder block. This will permit removal of the brackets holding the high tension ignition conduits.




Figure 30. When installing the cylinder heads, tighten the nuts in the order shown above.

After removing the distributor head, the distributor head with ignition conduits can be removed out of the way. The cylinder head can be removed by lifting it off.

Carbon should be removed only with a soft iron scraper or wire brush. When re-installing the cylinder head, tighten the cylinder head nuts in the order shown in Fig. 30. After all nuts are tightened lightly, go over them again, tightening them firmly.

Adjustment of Valve Stem Clearance

It is important that the clearance between the lower end of each valve stem and the head of the adjusting screw in the camslide be

properly adjusted. If this clearance is too small, the valve will not close properly and over-heating and pitting of the valve and its seat are likely to result.

In order to adjust this clearance, it is necessary for the cam to be in the correct position, which is when the piston in the corresponding cylinder is on firing center.




Figure 31. The valve stem clearance must be accurately adjusted.

With the piston thus on firing center, the valve stem clearance for the inlet valve should be .004 inch and for an exhaust valve .006 inch, *when the engine is cold*.

To adjust a camslide, loosen the locking screw with a suitable screw-driver and turn the adjusting screw with a wrench (Fig. 31). After the correct clearance has

been obtained, tighten the locking screw.

When installing the valve compartment cover plates be sure the ribbed surface is toward the outside.

Grinding Valves

Valve grinding will seldom be necessary if the valve stem clearance has been correctly adjusted. Valves should not be ground unless they require it. Misfiring is often due to incorrectly adjusted timer contact points or other causes besides leaking valves. A competent tester can determine quickly whether the misfiring is due to ignition or valves.

No attempt can be made here to describe in detail the procedure for grinding valves. The following are in the nature of suggestions and cautions to one who is already familiar with the general method of valve grinding.

If the seats on the valves are grooved or pitted, they should be refaced in a suitable grinder. If the seats in the cylinder blocks are very rough, they should be cleaned up with a reseating tool.

The angle of the inlet valve seats is 30°, and the angle of the exhaust valve seats is 45°. When refacing valves, be sure to set the machine to these angles, and when reaming valve seats use reamers with the proper angles.

Be very careful to leave none of the grinding compound in any part of the cylinder, as it will cause serious damage if it works into the cylinder bore or other parts of the engine.




Figure 32. Sectional view through sprocket for water pump and generator drive.

After grinding the valves, be sure to readjust the valve stem clearance, as described in the preceding section.




Figure 33. The water pump and generator driving chain should not be adjusted too tight.

Chains

The chain which drives the water pump and generator is adjustable to take up any slack that may develop. Adjustment should be made after the first 2000 miles of travel, after that adjustment will not be required oftener than every 10,000 miles.

To make the adjustment, it is necessary to remove the right-hand mud pan, but it is not necessary to remove the generator or water pump.

After removing the mud pan and the oil filler, loosen the nuts on the two bolts which pass through the upper part of the housing to which the water pump and generator are fastened. Loosen also the two screws, one on each side of this housing at the bottom (Fig. 32). Loosen the two screws by which the water pump is fastened to the sprocket support. This permits the hose between the pump and the radiator to align itself as the sprocket support is moved.

With a bar or lever pry against the support to which the water pump is attached, forcing it out from the engine as far as it will go. Holding the lever in this position, mark the support and the housing. Then release the lever, allowing the support to move back toward the engine $\frac{1}{8}$ inch. Hold the support at this point and tighten the two bottom screws and the nuts on the two upper bolts. Also tighten the water pump screws.

The camshaft driving chain requires no adjustment.

CHAPTER II

Gasoline System

General Description

The general arrangement of the gasoline system is illustrated in Fig. 34. The supply of fuel is carried in a 20-gallon tank at the rear, from which it is fed by vacuum to a tank on the dash. The fuel flows from this tank to the carburetor by gravity.

The vacuum for feeding the fuel from the supply tank to the tank on the dash is supplied from two sources: (1) The intake header and (2) a special vacuum pump driven by an eccentric on the rear end of the camshaft. The vacuum of the intake header alone is insufficient at wide open throttle to insure adequate flow of fuel and the pump is provided to supplement the intake header and furnish an adequate vacuum at all times.

The vacuum tank (Fig. 35) consists of an outer chamber and an inner chamber, the bottom of which communicates with the outer chamber through a flapper valve. The feed pipe from the supply tank enters the inner chamber of the vacuum tank which contains a float. This float




Figure 34. The gasoline is fed by vacuum from the supply tank to the vacuum tank on the dash and from there to the carburetor by gravity.

operates two valves, one in the passage to which the intake header and suction pump are connected, and the other in a passage communicating with a vent tube open to the atmosphere. When the float is

down, the vent valve is closed and the vacuum valve is open. When the float is up, the vacuum valve closes and the vent valve opens.

Operation of Vacuum Tank




Figure 35. Sectional view of vacuum tank. There is a check valve in the connection to the intake header which prevents back-flow when the vacuum of the header is less than that of the pump.

weight of gasoline, emptying the contents of the inner chamber into the outer chamber. The float drops simultaneously, and, as it reaches the bottom, again operates the valves, this time opening the vacuum valve and closing the vent valve. The cycle thereupon starts again.

This alternate filling and emptying of the inner tank is repeated rapidly until the level of gasoline is the same in the inner and outer chambers, and therefore only as the carburetor demands fuel.

Ordinarily, there is enough fuel in the carburetor and in the vacuum tank to start the engine. If not, the automatic feeding action can usually be started by closing the throttle and operating the starter for about ten seconds. Wait a few seconds to allow the fuel to flow to the carburetor, and then start the engine as usual.

The action of the system in operation is as follows:

Starting with the inner chamber empty and the float at the bottom, the vacuum valve is open and the vent valve is closed. The suction of the intake header and the vacuum pump immediately causes gasoline to be drawn through the feed pipe from the supply tank to the inner chamber. The flapper valve is held closed by the vacuum within the inner chamber and the level of gasoline in the inner chamber rises until the float reaches the top of its travel, closing the vacuum valve and opening the vent valve. This breaks the vacuum in the inner chamber and the flapper valve at the bottom opens under the

The flow of fuel from the supply tank depends upon the difference in pressure between the vacuum tank and the supply tank. It is, therefore, essential that the supply tank be open to atmospheric pressure. For this reason, the vent hole in the gasoline filler cap *must* be kept open.

Gasoline Filter

A gasoline filter (Fig. 36) is provided in the gasoline line between the vacuum tank and the carburetor. This filter has a glass bowl through which the accumulation of water and sediment can be easily seen. The bowl should be removed and the gauze screen should be cleaned, as soon as any accumulation appears in the bowl. This can be done as follows:




Figure 36. To remove the filter bowl for cleaning the screen, close the shut-off valve, loosen the wing nut at the bottom and disengage the supporting yoke.

First shut off the gasoline by turning clockwise the small T-handle valve at the side of the filter. Then unscrew the thumb screw under the bowl, after which the yoke supporting the bowl can be swung to one side and the bowl can be removed. If the screen does not come off with the bowl, it can be removed by pulling it straight down.

In putting back the bowl, make sure that it seats properly against the cork gasket in the top of the filter before tightening the thumb screw. Do not forget to turn the gasoline on by turning the valve counter-clockwise as far as it will go.

There is also a strainer in the vacuum tank at the point where the gasoline enters the inner chamber. The strainer should be removed and cleaned occasionally. The strainer is accessible after disconnecting the feed pipe and unscrewing the inlet elbow. To unscrew the elbow it is also necessary to remove the check valve (Fig. 35).

Adjustment of Carburetor

The carburetor should not be tampered with unless it needs adjustment. Good carburetor action cannot be expected before the engine is thoroughly warmed up. This is particularly true during cold weather. Imperfect carburetor action while the engine is cold does not indicate




Figure 37. Before adjusting the carburetor, make sure that the enriching control rod is properly adjusted.

that the carburetor requires adjustment, and carburetor adjustment should not be made under such conditions.

If possible, the carburetor should be adjusted by an authorized Cadillac service station. The following instructions, however, are given for reference when a Cadillac service station is not convenient.

In adjusting the carburetor, select a quiet place, for correct adjustment depends largely upon being able to detect slight changes in engine speed.

Before making any other adjustments, make sure that the tongue on the auxiliary air valve shaft stands in the center of the slot in the enriching control lever, when the button on the instrument board is forward as far as it goes (Fig. 37). If the tongue does not stand in the center of the slot, readjustment should

be made by altering the length of the control rod.

The next adjustment to be checked is that of the throttle stop screw for controlling the idling speed of the engine (Fig. 38). Under normal conditions, this speed should be about 300 R.P.M. To adjust the idling speed, loosen the set screw in the collar on the control rod running from the steering gear

to the lever on the accelerator pedal shaft on the front face of the dash. Then adjust the stop screw on the carburetor until the correct idling speed is obtained. When the throttle stop screw at the carburetor has been correctly adjusted, then move the throttle control lever to the closed position and set the collar on the control rod $\frac{1}{32}$ inch from the trunion on the lever.




Figure 38. The idling speed, which should be about 300 r.p. m., is controlled by the throttle stop screw.

If the mixture is so far from correct that the engine will not idle as slowly as 300 R.P.M., close the throttle as far as possible without stalling the engine, and proceed with the adjustment of the auxiliary air valve.

The auxiliary air valve spring, which constitutes the main adjustment of the carburetor, is adjusted by the knurled adjusting screw shown in Fig. 39. Before turning this screw to make any adjustment, determine whether the mixture is lean or rich. Start the engine and run it until the engine is thoroughly warm. Place the spark lever in the fully retarded position and move the throttle lever to the closed position.

Then press down gently on the ball-shaped counterweight of the auxiliary air valve, and note whether the immediate result is an increase or a decrease in engine speed. Release the counterweight and




Figure 39. The principal carburetor adjustment is the auxiliary air valve. This should be done with the spark retarded and the hand throttle in the idling position.

allow the engine to run a few seconds to regain its normal speed. Then press gently up on the counterweight and note the effect on the engine speed.

If the mixture is correct, the immediate result of gentle pressure, either up or down, on the counterweight of the auxiliary air valve will be a slight decrease in engine speed. If the immediate result of gentle upward pressure is a slight decrease in engine speed, while the result of downward pressure is an increase in engine speed, a rich mixture is indicated. If the immediate result of upward pressure is an increase in engine speed, a lean mixture is indicated.

If this test indicates an incorrect mixture, adjust the auxiliary air valve screw by turning it clockwise to correct a lean mixture and

counter-clockwise to correct a rich mixture. Continue to change the adjustment of this screw and to test as above until a correct mixture is indicated. Do not turn the screw more than a few notches at a time, and not more than two notches at a time when nearing the correct adjustment.

If, after adjusting the auxiliary air valve, the engine idles too fast, readjust the throttle stop screw.

Gasoline Tank Gauge

As explained on page 9, the gasoline gauge is an electrical device and is connected in the ignition circuit. It is therefore in operation only when the ignition is switched on. The purpose of this arrangement is so that the gauge will not draw current while the car is not in use.

When the ignition is switched off, the gauge hand may come to rest anywhere on the gauge. It does not return to zero, nor does it ordinarily stay in the position it had before the ignition was switched off. At such times, therefore, the reading of the gauge is not a true reading. A true reading is given only when the ignition is switched on.

It is of vital importance that the electrical connections in the gauge circuit be correctly made. If the connections are reversed, the gauge will not only fail to register correctly, but is likely to be injured.

CHAPTER III

Cooling System

Water Circulation

THE La Salle engine is cooled with water circulated through the jackets of the cylinder blocks by a centrifugal pump. This pump is mounted on the right-hand side of the engine near the front, and is driven by a chain from the crankshaft. The pump draws cold water from the bottom of the radiator and delivers it to a connection on the right-hand side of the engine, where the stream divides, half going to the right-hand cylinder block and half through a passage in the crankcase to the left-hand cylinder block. From the front end of each cylinder head, an outlet pipe with hose connections carries the heated water to the top of the radiator.

Adjustment of Fan Belt

The tension of the fan belt must be maintained correctly. If the belt is too loose the fan will slip, and if it is too tight, an unnecessary load will be imposed on the bearings.

To test the tension of the fan belt, slip the fan by pulling on one of the blades. If it is difficult or impossible to slip the fan in this way, the belt is too tight. If the fan slips easily, the belt is too loose.

To change the tension of the belt, loosen the nut on the rear end of the fan shaft. Then raise the fan with a small lever to increase the tension or lower it to decrease the tension. Be sure to tighten the nut after the correct tension has been secured.

Radiator and Shutters

The radiator consists of an upper tank and a lower tank connected by water passages, around the outside of which air is circulated by the fan. The water passages are so constructed that they expose a large amount of surface to the air, which cools the water as it passes from the upper to the lower tank. Until the water in the cylinder blocks and radiator is warm, the cooling effect of the radiator is not only unnecessary but undesirable. The radiator is accordingly provided with shutters that prevent air from circulating around the water passages until the engine becomes warm. The shutters are pivoted vertically and are controlled automatically by a powerful thermostat contained in the upper tank of the radiator.

When the engine is cold, the shutters are held tightly closed and circulation of air is prevented. The water from the cylinders consequently undergoes little change in temperature as it flows through the radiator, and the engine quickly becomes warm. As soon as the water entering the upper tank of the radiator reaches the temperature at which the engine operates best, the shutters are forced open by the thermostat and air begins to circulate. The resulting cooling effect checks the rising temperature of the water, which is thereafter maintained uniformly at the temperature of most efficient operation as long as the engine is running. (See "Temperature Indicator," page 10.)

Radiator Thermostat

There is no adjustment in connection with the radiator thermostat. The thermostat is filled and sealed at the factory, the liquid determining the temperature at which the thermostat operates.

Water Pump

The water pump shaft is packed against leakage by a gland which can be tightened by turning the gland nut. This nut is held from turning of its own accord by a locking plunger. To tighten the gland nut, first remove the oil filler, then lift this plunger, and with a screw-driver or punch, turn the top of the nut toward the engine. Do not tighten the nut more than just enough to prevent leakage. Further tightening causes unnecessary friction on the pump shaft.




Figure 40. View looking down on water pump. The water pump packing nut should be tightened only enough to prevent leakage.

Filling and Draining the Cooling System

Except during freezing weather, water should be used in the cooling system. In freezing weather, a suitable anti-freezing solution, such as those described on page 40, must be used.

To add liquid to the cooling system or to refill the cooling system after it has

been drained, remove the radiator filler cap and pour the liquid in through the filler.

It is not necessary to add liquid to the radiator whenever the level falls below the filler. There is sufficient liquid in the cooling system if the upper tank of the radiator is half full, and any liquid in excess of this is usually forced out through the overflow pipe as soon as the engine becomes warm. When water is used, any loss from this cause is of little consequence, but in winter, to conserve anti-freeze, it is important to avoid adding more liquid than is necessary.


To drain the cooling system, open the drain valve in the water pump outlet elbow by turning the hexagonal end of the valve counter-clockwise.

Cleaning the Cooling System

The cooling system should be drained and flushed every 4000 miles. If possible, this should be done at a Cadillac service station or where there are facilities for reversing the flow of water through the radiator. If this is not possible, use the following method:

Run the engine until the opening of the radiator shutters indicates that the engine is warm. Stop the engine and immediately open the water pump drain valve.

After the liquid has drained off, refill the cooling system with hot water and repeat the operation described above. If in draining the second time, the water is very dirty it may be advisable to repeat the flushing operation a third time, placing one or two handfuls of sal-soda in through the radiator filler. The sal-soda must not be permitted to get on the finish of the hood or radiator. If sal-soda is used, the cooling system must be drained and flushed again before refilling for use.



CHAPTER IV

Electrical System

THE electrical system comprises the following units: The generator, or source of electrical energy; the storage battery, which stores the current generated; the starting motor, which cranks the engine for starting; the ignition system; the lamps and other devices using electrical current; the ammeter; the ignition and lighting switch; and the circuit breakers, which protect the system. The wiring system connecting these units is the single-wire or grounded type, the engine and frame forming one side of the electrical circuit.

Generation of Current

Generator

The generator is below the right-hand cylinder block at the front of the engine, and is driven by a silent chain from the crankshaft.

At very low engine speeds, the voltage of the current generated is not sufficient to provide current for lighting or ignition, and the battery is then the source of current. To prevent the battery, at such times, from discharging through the generator, a cut-out relay on the generator automatically opens the circuit whenever the generated voltage drops below the battery voltage. At approximately eight miles per hour, the generated voltage is sufficient to operate the cut-out, which then closes the circuit between the generator and the battery and lighting circuits. If no lights are switched on, the entire output of the generator, less the current required for ignition, flows to the battery for recharging it. If all the lights are on, the generator will not generate sufficient current to start charging the battery until a speed of twelve to fifteen miles per hour is reached.

Ammeter

The ammeter on the instrument board indicates the amount of current flowing to or from the battery, except when the starter pedal is down and the starting motor is cranking the engine. When the engine is not running, the ammeter will indicate a current on the discharge side, depending in amount upon the number of lights in use. The rate of charge or discharge when the engine is running depends upon the speed of the engine, whether the thermostat is opened or closed and how many lights are in use, and is equal in amount to the difference between the current generated and the current used by the

lights, horn, ignition, and other electrical devices. The ammeter does not indicate the current used in cranking the engine.

Thermostatic Control of Charging Rate

The generator is provided with a thermostatic control. This is so arranged that the amount of current generated is automatically reduced as soon as the temperature of the generator rises above a predetermined point. When the engine is cold the charging rate is normal. When, due to the combined heat of the engine and the generator, the temperature of the generator reaches the predetermined point, the thermostat operates and the charging rate is correspondingly reduced.

The purpose of this is to give the battery, as quickly as possible, the energy used for starting or for the lights while parking. This also compensates in a measure for seasonal variations, because in cold weather, when the demand on the battery is greater, a longer period elapses after starting the engine before the thermostat operates to reduce the charging rate. It is thus unnecessary to have a different adjustment of the charging rate for winter from that for summer.




Figure 42. The charging current is adjusted by moving the third brush. This must be done when the engine is cold.

Adjustment of Charging Rate

The charging rate must be checked and adjusted before the engine is warm enough for the thermostat to open. All the lights must be off. Start the engine and open the throttle until the ammeter reading ceases to increase and starts to decrease. The maximum reading should not be more than 18 amperes, and ordinarily not less than

16. In no case should the maximum reading exceed 20 amperes. These figures are for a cold engine. If the charging rate is adjusted to these figures when the thermostat is open, damage is likely to result to the generator.

The amount of the charging rate is adjusted by changing the position of the third brush on the generator commutator. This brush is accessible after removing the cover band around the rear end of the generator (Fig. 42). The brush holder is held by friction and can be moved by prying it. Do not pry against the brush itself, and be very careful not to spring the brush holder.

Do not under any circumstances put oil on the commutator of the generator.

Storage Battery

The storage battery is a three-cell, six-volt Exide battery made especially for the La Salle electrical system by the Electric Storage Battery Company of Philadelphia, Pennsylvania. The battery com-




Figure 43. The storage battery is under the right-hand end of the front seat.

partment is attached to the right-hand side bar of the frame under the front seat. To have access to the battery, remove the seat cushion,

unscrew the four wing nuts which hold the cover plate, and lift up the cover plate.

Adding Water to Storage Battery

The battery is filled with a solution from which the water slowly evaporates, and fresh distilled or other approved water must be added at intervals to maintain the correct level. The level should be inspected at least every 1000 miles, and in warm weather every 500 miles or at least every two weeks. Distilled or other approved water should be added to bring the level up to the bottom of the filling tubes.

Each cell is provided with a filling tube and vent plug. To remove a vent plug, turn it as far as possible counter-clockwise and then lift it straight up. To install it, set the plug in place and turn it clockwise until tight. If a plug is lost or broken, obtain a new one and install it as soon as possible.

Nothing but pure distilled or other approved water should be added to the battery solution. Melted artificial ice or rain water caught in an earthenware receptacle may be used. Hydrant water or water that has been in contact with metallic surfaces will cause trouble if used. Acid must never be added to the battery.

After adding water to the storage battery in freezing weather, the car should immediately be run far enough to mix the water and acid solution thoroughly. If the car is parked immediately after adding water, the water is likely to stay on top of the acid solution and may freeze, causing extensive damage.

If one cell regularly requires more water than the others, a leaky jar is indicated. A leaky jar should be replaced immediately by a new one, as even a very slow leak will in time result in the loss of all the solution in the cell.

Specific Gravity of Battery Solution

As the storage battery is charged and discharged, the solution reacts chemically with the plates of the battery, the specific gravity of the solution changing as the reaction proceeds. The state of charge of the battery is thus indicated by the specific gravity of the solution. As the battery is charged, the specific gravity of the solution increases, reaching 1.270 to 1.285 when the battery is fully charged. The specific gravity of the solution decreases as the battery is discharged. A fully discharged battery has a specific gravity of 1.150 to 1.165.

A hydrometer is the instrument used to measure the specific gravity of a solution. A hydrometer syringe is a hydrometer especially de-

signed for convenience in testing the specific gravity of the acid solution in the storage battery. A hydrometer syringe can be obtained at any battery service station. Be sure and get a reliable instrument, for cheap ones may be in error as much as 25 or 30 points.

The specific gravity of the acid solution should never be tested immediately after adding distilled water. If the solution is below the plates so that it cannot be reached with the syringe, add the necessary amount of water and then drive the car for a few hours before taking the hydrometer reading.

Disconnecting Battery

Do not remove the generator or attempt any adjustment of the circuit breakers or remove any of the wires to the circuit breakers without first disconnecting the storage battery.

Never run the engine with the storage battery disconnected. Serious damage to the generator may result.

Exide Depots and Sales Offices

The Electric Storage Battery Company, whose general offices and works are at Allegheny Avenue and Nineteenth Street, Philadelphia, Pennsylvania, has representative stations in towns of any considerable size, as well as sales offices and Exide battery depots in a number of the larger cities. If a storage battery is in need of attention other than recharging, it is advisable to communicate either with a Cadillac service station or with the nearest Exide station or depot. Do not ship a storage battery without receiving instructions.

Starting Motor

Operation of Starter

The starting motor is a series-wound motor, mounted horizontally at the right-hand side of the transmission case. When cranking the engine, the starting motor drives the flywheel through a pinion which meshes with teeth machined on a ring bolted to the flywheel. The pinion is normally held out of engagement with the teeth on this ring. It is moved into mesh with the teeth on the ring by pushing forward on the starter pedal. Further movement of the pedal operates a switch that closes the battery circuit and starts the armature revolving.

If, in pushing down the starter pedal, the ends of the teeth on the pinion strike against the ends of the teeth on the flywheel ring, preventing further movement of the pinion, continued movement of the pedal

compresses a spring. As soon as the pedal has been pushed down far enough to close the starting switch, the armature starts to revolve. The pressure of the spring then forces the pinion the rest of the way, completing the meshing operation.

An over-running clutch on the armature shaft prevents the fly-wheel from driving the starting motor after the engine is running under its own power and before the starter pedal is released.

Ignition

General Description

The function of the ignition system is, first, to multiply the low voltage (six to eight volts) of the storage battery and generator into voltage of sufficient intensity to cause a spark to jump between the electrodes of the spark plugs; and second, to time this spark so that ignition will take place in the proper cylinder at the proper instant.

The Delco single-spark system is used, consisting of a combination timer-distributor unit in connection with a transformer or induction coil. The primary circuit, through which flows the current from the storage battery or generator, includes the primary winding of the ignition coil; the timer contact arms and points; and the condenser, which is enclosed in the timer. The secondary or high-voltage circuit includes the secondary winding on the ignition coil, the distributor and the spark plugs.

Current flows through the primary circuit whenever and as long as either of the two sets of timer contact points is closed. Current flows through the secondary circuit for an instant only when either set of contact points is opened; but the voltage of this current is several thousand times that of the primary circuit and is sufficient to cause a spark at the spark plug.

Timer-Distributor

The timer-distributor is mounted on the top of the crankcase at the front end and is driven by a spiral gear on the camshaft. The shaft of the timer-distributor, which revolves at one-half crankshaft speed, carries a four-lobed cam. As this cam revolves, it actuates the two contact arms alternately, closing and opening first one set of contact points and then the other. The circuit is thus made and broken eight times during each revolution of the cam and eight corresponding sparks are produced at the spark plugs.

In order to procure the maximum power from each explosion, ignition must occur at the right instant in relation to the position of the

piston. But the ignition process, although apparently a matter of an instant, consumes a measureable amount of time. It is therefore necessary to break the circuit at the contact points far enough in advance so that actual ignition will take place in the cylinder at the correct time. The lapse of time is always the same, regardless of the speed of the engine, but because the pistons move faster when the engine is running at higher speeds than when it is running at lower speeds, the degree of advance in relation to the positions of the pistons must be increased as the engine speed increases.

This advancing of the relative timing of the spark for higher engine speeds is automatically accomplished by a centrifugal ring governor on the timer shaft below the cam. As the speed of the engine increases, the governor ring assumes a position more nearly horizontal, forcing the cam ahead of the shaft by which it is driven. This causes the contact points to open earlier, starting the ignition process earlier in relation to the positions of the pistons in the cylinders.

In addition to the automatic advance, the timer has a manual control by which the opening of the contact points may be still further advanced or still further delayed. This is operated by a lever on the instrument board (Fig. 1).

The distributor is the mechanism that insures that the high voltage current in the secondary circuit is switched to the proper spark plug at the proper time. It consists of a rotor, which is carried on the upper end of the timer shaft and which has a metal terminal electrically connected at all times with the secondary current from the coil. As the rotor revolves, this terminal faces successively eight metal inserts in the distributor head, which is only a few thousandths of an inch from the rotor. The eight inserts are connected each to a different spark plug. When either set of timer contacts opens, the terminal in the rotor is directly opposite one of the inserts and the high voltage in the secondary circuit jumps from the rotor to the insert, and thence it is conducted to the corresponding spark plug. The relation between the rotor and the timer shaft is such that the spark plugs fire in correct relation to the pistons.

Adjustment of Contact Points

The gaps between the timer contact arms and the contact screws are accurately adjusted at the factory to the correct amount. As the rubbing blocks on the contact arms wear, however, the gaps decrease and eventually readjustment must be made, although ordinarily this is not necessary for many thousands of miles.

The correct gap is .027 inch. To adjust the contact points, turn the distributor shaft until the rubbing block of one of the contact arms is on one of the lobes of the cam. Then adjust the corresponding contact screw so that there is .027 inch gap between the points (Fig. 44).

After adjusting the gap for one set of contact points, turn the shaft until the rubbing block of the other contact arm is on one of the lobes of the cam, and adjust the other set of points.

It is not absolutely necessary to re-time the ignition after adjusting the contact points, but it is recommended.

Timing Ignition

All timing of the ignition should be done with the spark control lever fully advanced.

Timing the ignition should not be attempted without making sure that both sets of contact points are correctly adjusted for gap as previously directed.




Figure 44 The timer contact points must be correctly adjusted to produce proper ignition.




Figure 45. Marks for timing the ignition are stamped on the flywheel.

Ignition for the odd-numbered cylinders is provided by one of the contact arms, this arm being mounted on a fixed plate. Ignition for the even-numbered cylinders is provided by the other contact arm, which is mounted on an adjustable plate (Fig. 47). The timing for the odd-numbered cylinders depends only on the position of the cam. The timing for the even-numbered cylinders depends both on the position of the cam and on the adjustment of the plate which carries the second arm. This plate is correctly adjusted at the factory and ordinarily will not need to be readjusted.

To check the timing for the odd-numbered cylinders, disconnect the wire from the spark plug for the No. 1 cylinder, and place the terminal of the wire so that it is about

$\frac{1}{8}$ inch from the cylinder block. Open the cover on the flywheel inspection hole at the rear of the right-hand cylinder block. Switch on the ignition and crank the engine slowly by hand until a spark jumps from the disconnected wire to the cylinder. Stop cranking at once and observe the position of the flywheel. The mark $\frac{1}{2}$ on the flywheel should then be opposite the pointer attached to the crankcase.

If the mark on the flywheel has passed the pointer, the ignition is late. If the mark has not reached the pointer, the ignition is early.

To correct the timing, loosen the screw in the center of the timer shaft. Then carefully turn the cam either with a wrench or with the rotor. Turn the cam clockwise to advance the ignition, or counter-clockwise to retard it. After moving the cam, tighten the screw and check by again cranking the engine and noting the position of the flywheel when the spark occurs.

To check the timing for the even-numbered cylinders, disconnect the




Figure 46. The ignition is timed by adjusting the cam on the timer shaft.

wire from the No. 2 spark plug. Then crank the engine by hand, the same as before, stopping the instant the spark takes place. The mark $\frac{1}{2}$ on the flywheel should then be opposite the pointer.

If the ignition for the odd-numbered cylinders has been carefully timed, the ignition for the even-numbered cylinders will ordinarily be correct. If it is not, it is best to have the distributor serviced at a Cadillac service station, where




Figure 47. The contact arm for the even-numbered cylinders must be synchronized with relation to the contact arm for the odd-numbered cylinders.

*If the car is equipped with high-compression cylinder heads (page 23,) disregard the ignition timing marks on the flywheel and set the spark to take place $\frac{1}{2}$ inch ahead of center.

a gauge is available for setting the plate which carries the adjustable arm. In an emergency, however, the timing of the even-numbered cylinders can be corrected as follows:

Loosen the two screws shown in Fig. 47. Then carefully turn the eccentric adjusting collar with a screw-driver, turning the collar clockwise to retard the ignition and counter-clockwise to advance it. Be sure to tighten the screws after the correct adjustment has been secured.

Spark Plugs

For best results, the electrodes of the spark plugs should be .032 to .035 inch apart. If the spark plugs should be removed, it is recommended that the electrodes be inspected and adjusted to this clearance.

Lighting System

Lamp Bulbs

It is recommended that bulbs for the lamps, particularly the two-filament bulbs for the headlamps, be purchased from a Cadillac distributor or dealer. In any event, bulbs should have the correct voltage and candle-power ratings. Only three different types of lamp bulbs are used in the entire lighting system. The bulbs and the lamps in which they are used are as follows:

LAMP	VOLTAGE	CANDLE-POWER
Headlamps	6-8	21 (Two-Filament) Mazda No. 1110
Stop Light	6-8	21 (Single Filament)
Side Lamps	6-8	3
*Instrument Lamps (2)	6-8	
*Rear Lamp	6-8	
Closed Car Dome Lamps	6-8	
**Running Board Step Light	6-8	

Cleaning Headlamp Reflectors

The headlamp reflectors are plated with pure silver. Although the reflectors ordinarily require no attention, if they should require polishing, extreme care must be exercised to select materials that will not scratch the silver. In polishing reflectors, always rub from the bulb outward, do not rub in circles.

Powdered dry rouge and a chamois skin are recommended. If the reflectors are tarnished, the rouge may be moistened with alcohol. Afterwards, polish with a dry chamois and rouge.

The chamois used for the headlamp reflectors must not be used for any other purpose. It must be soft and free from dust.

Do not touch the reflectors with the bare hands.

Adjustment of Headlamps

Approval of the headlamps by the state authorities is conditional upon the headlamps being adjusted to a definite standard. The directions which follow are for this standard adjustment.

*Bulbs rated at 3-4 volts, such as are used in the rear lamps of some cars, must not be used in these lamps. If installed, they will burn out almost immediately.

**Used only on cars with 134-inch wheelbase.




Figure 48. Double-filament headlamp bulb.




Figure 49. Marks for adjustment of headlamps

Select a level spot where the car can be placed facing toward, and twenty-five feet distant from, a wall upon which the lines shown in Fig. 49 can be drawn. The adjustment should be made when it is dark enough so that the outlines of the projected beams are plainly visible.

Locate a point on the wall directly opposite the front of the car by sighting through the center of the rear curtain toward the radiator cap. Draw a vertical line on the wall through this point. Measure the distance between the centers of the headlamps, and draw two vertical lines "B" parallel to the center line and distant from it by an amount equal to one-half of the distance between the headlamps. Measure the distance from the headlamp centers above the ground or floor and draw the horizontal line "A" at the same elevation.

The adjustment should be made with the upper beam on, that is, with the lighting switch lever at "Up." Cover the headlamp that is not being adjusted.

Turn the adjusting screw, which is in the back of the headlamp shell, until the small beam of high intensity at the top is most clearly defined. (Fig. 50a.) This focuses the lamp.




Figure 50a. Upper beam of right headlamp




Figure 50b. Lower beam of same lamp




Figure 50c. Upper beam with lens removed

With the car fully loaded, loosen the nut on the headlamp support and aim the high intensity beam so that it is centered on the corresponding vertical line "B," with the upper part cut off on the horizontal line "A." (Fig. 50a.) Tighten the nut securely, taking care not to move the lamp out of adjustment.

No adjustment for the lower beam is necessary. If the lamp has been correctly focused and aimed with the upper beam on, the lower beam will appear as in Fig. 50b.

If it is desired to focus the lamp with the door removed, this can be done. Fig. 50c shows the upper beam as it should appear with the lens removed.




Figure 51. Headlamp adjusting screw

CHAPTER V

Clutch and Transmission

Clutch

The La Salle clutch is a disc clutch of exclusive design. There are three driving plates, the center plate being bolted to the flywheel. The front and rear driving plates float or slide on pins carried by the center plate.

There are two driven discs, one between the center and rear driving plates and the other between the center and front driving plates. Both discs are bolted to a central hub which slides on the splined end of the clutch shaft. The discs are fan shaped and are lined on both sides with a ring of friction material.

When the clutch is engaged, the plates and discs are pressed firmly together under the pressure of twelve 70-lb. springs. The driven discs then revolve with the flywheel, and the engine, if running, drives the transmission.

When the clutch pedal is pushed down to disengage the clutch, a series of levers releases the pressure of the springs and the driven discs separate from the driving plates, permitting the flywheel to revolve independently of the clutch and transmission.

The clutch itself requires no adjustment or attention other than lubrication of the clutch thrust bearing, as directed on page 55. Adjustment of the clutch release rod, however, may be necessary after the car has been driven some distance.

Adjustment of Clutch Release Rod

As described on page 16, the clutch pedal is purposely given about one inch of "lost motion." That is, the clutch does not begin to disengage until the pedal has been moved down about an inch from its released position. This lost motion is necessary in order to allow the clutch discs and plates to come closer together as the facings are reduced in thickness. The lost




Figure 52. The clutch control must be adjusted so as to give the clutch pedal proper play.

motion gradually decreases as the clutch is used, and eventually will be taken up. Before this happens, the clutch release rod must be readjusted to restore the lost motion; otherwise the clutch discs will slip and the engine will not drive the car.

To make the adjustment, unscrew the nut (Fig. 52) on the end of the rod until the clutch pedal has a movement of one inch without starting to disengage the clutch.

The nut must be turned a half-turn at a time.

Transmission

The purpose of the transmission is to provide a means for varying the ratio and direction of the rear axle speed in relation to the engine speed. Three things are accomplished by doing this: First, the engine is enabled to drive the car backwards. Second, the engine is permitted to revolve fast enough to develop the power necessary for starting and for driving the car at extremely low speeds. Third, the turning effort of the engine is multiplied, so that it may be sufficient for climbing steep hills and pulling through deep sand and mud.

The La Salle transmission is known as the selective, sliding gear type. It has three speeds forward, of which one is direct drive, and one speed in reverse. Selection of the various speeds is accomplished by movement of two shipper gears (Fig. 53) which are controlled by the transmission control lever.

The positions of the gears corresponding to the five positions of the control lever, as illustrated in Fig. 8, are as follows:

Neutral—When the control lever is in neutral position, the shifter gears are in the positions shown in Fig. 53, that is, they are not in mesh with any of the other gears.

Low—When the control lever is moved from neutral to low, the low and reverse shipper gear is moved forward into mesh with the low gear on the jackshaft. The ratio of engine speed to propeller shaft speed in low is approximately 3 to 1.

Intermediate—When the control lever is moved from low to intermediate, the low and reverse shipper gear is first returned to its neutral position and the high and intermediate shipper gear is then moved back into mesh with the intermediate gear on the jackshaft. The ratio of engine speed to propeller shaft speed in intermediate is approximately 1.7 to 1.

High—When the control lever is moved from intermediate to high, the high and intermediate gear is first moved forward out of mesh with the intermediate gear on the jackshaft, and then farther forward until teeth, cut internally in a recess in the high and intermediate shipper gear, engage teeth on the extreme end of the gear on the clutch shaft. The drive is then direct from the clutch shaft to the transmission main shaft without reduction.

Reverse—When the control lever is moved from neutral to reverse, the low and reverse shipper gear is moved back into mesh with an idler gear, which is at all times in mesh with the reverse gear on the jackshaft. The interposition of the idler gear reverses the direction of rotation. The ratio of engine speed to propeller shaft speed in reverse is approximately 3.7 to 1.




Figure 53. Sectional view of clutch, transmission and universal joint

CHAPTER VI

Steering Gear

Description

THE La Salle steering gear is of the worm and sector type. In this construction, the tube or shaft, to which the steering wheel is fastened, has on its lower end a worm which engages a sector gear. The steering arm is fastened to the shaft of this sector gear.

The steering gear has three adjustments: one to adjust the position of the sector in its relation to the worm; a second to take up end-play in the worm thrust bearings; and a third to take up end-play in the sector shaft.

Adjustment of Worm and Sector

This adjustment consists in moving the sector away from or toward the worm, so as to give the proper amount of backlash. Provision is made for doing this by means of the sleeve or bushing in which the sector shaft turns. The outside of this bushing is eccentric, and by turning the hexagonal end of the bushing, which projects through the side bar of the frame, the sector can be moved away from or toward the worm. To make the adjustment, proceed as follows:




Figure 54. This adjustment is to take up backlash between the worm and sector.

Turn the steering wheel so that the front wheels point straight ahead. Loosen the locking screw shown in Fig. 54. Then move the locking arm down to tighten the adjustment, or up to increase the backlash. The steering wheel should have from one-half to three-quarter inch play. If the amount of backlash to be taken up is very great, it may be necessary to remove and replace the locking arm in a different position on the hexagonal end of the eccentric bushing, in order to bring the locking arm in such a position that it can be locked by the screw.

(100)

Adjustment of Worm Thrust Bearings

To take up end-play in the worm thrust bearings, first back off the worm and sector adjustment (described in the preceding section) and loosen the cap on the support bracket on the instrument board. Loosen the clamping screw shown in Fig. 55. Then with a large wrench turn the adjusting nut until all play in the bearings is taken up. Tighten the clamping screw and the cap on the instrument board bracket after the proper adjustment has been made. Finally, take up the worm and sector adjustment again.



Figure 55. This adjustment is to take up end-play in the worm thrust bearings.

Adjustment of Sector Shaft

The third adjustment is to take up end-play in the sector shaft. This adjustment is on the rear cover of the steering gear housing and is rarely necessary.

To make the adjustment, loosen the lock nut shown in Fig. 56, and turn the adjusting screw until the end play is taken up.




Figure 56. This adjustment is on the cover plate of the steering gear housing, and is to take up end play in the sector shaft.




Figure 57. To adjust the joints at the ends of the steering connecting rod, draw each adjusting plug tight and then back it off one cotter pin hole.

Steering Connecting Rod

The steering connecting rod, which connects the steering arm at the steering gear with the steering arm on the front axle, has a ball and socket joint at each end. Wear at these joints can be taken up by adjusting the screw plugs in the ends of the rod. The plugs should be screwed in tight and then backed off one cotter pin hole.

CHAPTER VII

Front Axle

Description

THE La Salle front axle is of the reverse-Elliot type, in which the spindles are yoked or forked to receive the ends of the center member of the axle. The bolts on which the spindles pivot are keyed in the axle and turn in bronze bushings in the spindle. The thrust is taken by a ball bearing in the lower fork of the spindle.

Stop Screws

It is desirable to have the smallest turning radius possible without the front wheels scraping at any point on the chassis.

To prevent such interference, stop screws (Fig. 58) are provided on the ends of the axle. The stop screw at the right-hand end of the axle limits the angle to which the wheels can be turned to the right. The stop screw at the left-hand end of the axle limits the angle at which the wheels can be turned to the left.




Figure 58. The stop screws at the ends of the front axle should be adjusted so as to prevent the tires from scraping on the chassis.

Alignment of Front Wheels

The correct amount of toe-in for the front wheels is not less than $\frac{1}{8}$ inch nor more than $\frac{1}{4}$ inch. Every reliable garage has a gauge for measuring this distance. In the absence of such a gauge, it may be measured in the following manner:

Pull the car forward one or two feet. Then spread the wheels as far apart as possible by pushing on both tires at the same time. This will duplicate in the steering connections the conditions that exist on the road.

Locate on the side of each tire a point approximately 9 inches above the floor, and at the widest part of the tire, marking this point with chalk (Fig. 59). Measure the distance between these two points, using a tape measure or two yard-sticks placed so they overlap.

Pull the car forward until the two chalk marks pass under the axle and are again 9 inches above the ground, but to the rear instead of in front of the axle. Then measure the distance between the two chalk marks again. The difference between the two measurements should be not less than $\frac{1}{8}$ inch nor more than $\frac{1}{4}$ inch.




Figure 59. Alignment of the front wheels is important to give proper steering and prevent excessive tire wear.

Adjustment of the front wheel alignment is made by loosening the clamp screws at the ends of the parallel rod and turning the rod, which has right-hand threads at one end and left-hand threads at the other.




Figure 60. Sectional view of rear axle with wood wheel, wire wheel and disc wheel.

CHAPTER VIII

Rear Axle and Torsion Tube

The rear axle is of the three-quarter floating type. The flanges on the outer ends of the axle shafts are bolted to the wheel hubs and the inner ends of the shaft are splined to fit the holes in the differential gears. The ring gear mount, which contains the differential, is mounted on tapered roller bearings supported by the differential carrier. The pinion shaft is mounted on ball bearings in the differential carrier.

Except for lubrication as described in Part II, the rear axle requires no attention. The rear axle gears are correctly adjusted at the factory and no attempt should be made to readjust them. If attention appears to be required, a Cadillac service station should be consulted.

The tractive effort of the rear wheels is transmitted to the car through a torsion tube which encloses the propeller shaft and which is bolted at the rear end to the differential carrier and at the front end to a ball and socket joint on the transmission. The torsion tube is trussed by strut rods running diagonally to the ends of the rear axle housing.

CHAPTER IX

Wheels

Tire Balancing Marks

The tires are balanced to offset the weight of the valve stem. If a tire is removed, it must be re-installed in its original position with respect to the rim; otherwise the tire and wheel will be unbalanced.

A small red square is accordingly branded in the rubber on the side of each tire. This mark must always be in line with the valve stem.

Removing Front Wheel

To remove a front wheel (wood type) first jack up the axle until the wheel is free from the ground and then proceed as follows:

Remove the hub cap by unscrewing it. Remove the cotter pin in the spindle and unscrew the nut. The nut on the right-hand spindle has right-hand threads and the nut on the left-hand spindle has left-hand threads. Remove the washer. The wheel may then be removed by pulling it straight off.

To remove the inner hub of a front *wire* wheel, first remove the wheel from the hub. Then unscrew the dust cap which is just inside the hub. This will give access to the nut on the spindle.

To remove a *disc* wheel, with hub, from the spindle, proceed the same as for a wood wheel.

Installing Wheel

Before installing the wheel, make sure that the bearings are cleaned and that they are packed in light grease that is free from dirt and grit.

Set the wheel in place on the spindle, install the washer and draw up the adjusting nut just tight enough to make sure that the bearing races are seated.

Back off the nut slowly until it is possible to feel a slight shake in the wheel.

Draw the nut up again until the next cotter pin


Figure 61. Front wheel bearings should be adjusted too loosely rather than too tightly.

slot in the nut lines up with the cotter-pin hole in the spindle. Spin the wheel, making sure that all parts are in correct position, then insert the cotter pin and clinch it securely.

In order to avoid mistaking play in the spindle bolt for play in the wheel bearings, it is a good plan to insert a wedge between the spindle and the end of the axle.

Rear Wheels

Rear wheel bearings are not adjustable and there should be no occasion for the removal of the rear wheels.



CHAPTER X

Brakes

General Description

There are three pairs of brakes: The rear wheel external brakes, the rear wheel internal brakes, and the front wheel brakes, which are also internal. The rear wheel external brakes and the front wheel brakes are operated by the brake pedal and comprise the foot brakes. The rear wheel internal brakes are operated by a hand lever and are used principally for locking the rear wheels when the car is standing.

The purpose of the front wheel brakes is to add to the braking ability as much as is consistent with safety. It is not desirable to attempt to secure the maximum possible braking effect on the front wheels for the reason that, when a front wheel slides without rotating, it has no power to change the direction of the car.

La Salle front wheel brakes are accordingly designed so that when the foot brakes are applied while the steering wheel is turned to the right or left, only the brake on the inside wheel is effective and the brake on the outer wheel is released, leaving the outer wheel free to rotate. It is thus impossible to lock both front wheels even on slippery pavement unless the car is moving straight ahead. If, while the car is moving straight ahead on slippery pavement, the brakes should be applied with sufficient pressure to lock both front wheels and it then becomes necessary to make a turn, the car will instantly respond because the brake on the outer wheel is automatically released as soon as the steering wheel is turned.

Brake Adjustment

When the brake pedal must be pushed down to within one inch of the floorboard in order to fully apply the brakes, it is time for the brakes to be readjusted. The brakes should then be completely readjusted, that is, both front and rear brakes should be taken up to compensate for the wear that has taken place.

In an emergency, however, the rear brakes can be taken up in the manner described in the following paragraph so as to serve until the complete adjustment can be made, which should be as soon as possible thereafter.

(108)

Temporary Adjustment

When time or facilities are lacking for a complete adjustment of the brakes, a temporary adjustment can be made by taking up one or two turns on the upper and lower nuts shown at (4) and (5) in Fig. 62. A wrench is provided in the tool equipment for this adjustment.




Figure 62. The left-hand rear foot brake as viewed from under the car. The five adjustments should be made in the order shown. The object is to have a uniform clearance of .035 between the lining and drum.

This temporary adjustment must be followed by a thorough adjustment of both front and rear brakes as soon as possible.

Adjustment of Rear Wheel Brakes

The most important thing in adjusting brakes is to secure the proper uniform clearance between the brake lining and the drum. A feeler .025 inch thick should be used to test the clearance.

The first adjustment is that of the anchor adjusting screw (1, Fig. 62). Adjust this screw until the clearance between the brake drum and those parts of the lining nearest the anchor is .025.

Second: Adjust the stop screws (2 and 3) which are above the upper part of the brake band so that there is .035 inch clearance between this part of the band and the brake drum.

Third: Adjust the nut (4) on the lower end of the adjusting rod so that there is .025 inch clearance between the lower part of the brake band and the drum.

Fourth: Adjust the nut (5) on the upper end of the rod so that the end of the upper part of the brake band has .035 inch clearance.

Fifth: After a uniform clearance of .025 inch has been secured, the results should be checked by applying the brakes and measuring the travel of the lower end of the lever at the band. This travel should be $\frac{3}{4}$ to $\frac{15}{16}$ inch. If the end of the lever travels more than $\frac{15}{16}$ or less than $\frac{3}{4}$ inch, the adjustments should be repeated, increasing or decreasing the clearance as required.

This procedure should be followed first on one brake, then on the other.

Do not change the adjustment of the rods which operate the rear wheel brakes. The rear brakes should be adjusted only by the screws and nuts described. The brake rods are correctly adjusted at the factory and should not be tampered with.

Adjustment of the front wheel brakes is usually not necessary until the rear wheel foot brakes have been adjusted several times. When this adjustment becomes necessary, it is recommended that the car be taken to an authorized Cadillac service station.

CHAPTER XI

Repair Parts

Genuine La Salle Parts

La Salle owners are cautioned against permitting the use of other than genuine La Salle parts in the repair of their cars. The quality of the La Salle car is identical with the quality of its component parts, the production of which is based upon the more than twenty-five years experience of the Cadillac Motor Car Company in designing, manufacturing, and inspecting. No other individual or organization has access to the data resulting from this experience nor could they possibly have the same interest in protecting the owners of La Salle cars.

Uniform Parts Prices

La Salle parts are sold at uniform prices throughout the United States, and are not subject to the addition of handling, excise or other supplementary charges. Printed price lists published by the Cadillac Motor Car Company are open to inspection by owners at any authorized Cadillac distributor's or dealer's establishment.

Ordering New Parts

It is obviously impractical for the factory to deal directly with each one of the many La Salle owners. We cannot open accounts with any except regular distributors with whom annual contracts are made.

To avoid unnecessary delay and correspondence, new parts should, where possible, be ordered from the distributor or dealer from whom the car was purchased or from the nearest Cadillac distributor or dealer, who carries a large stock and is generally in a position to supply a part immediately. If he cannot do so, he can order it. Where, however, conditions are such as in our judgment to warrant it, we will fill orders for parts at current list prices, f. o. b. factory, provided the order is accompanied by cash.

In ordering parts, either from a Cadillac distributor or from the factory, send the engine number and the unit assembly number (see page 113) with an accurate description of the part desired, preferably accompanied by a sketch with dimensions. If this cannot be done, send the part itself properly tagged and with transportation charges prepaid. (See below under "Returning Parts.") Otherwise prompt and intelligent filling of the order will be impossible.

Our responsibility ceases in all cases with delivery to the transportation company.

Returning Parts

In the event parts are returned, transportation charges must be prepaid or the parts cannot be accepted. They should be tagged properly with the name of the owner and the engine number of the car. A letter should be sent, giving complete instructions regarding the disposition of the parts.

Tires, Speedometer and Clock

In case of repairs to tires, speedometers or clocks, correspondence should be opened with the manufacturers or their representatives. If necessary, the parts should be sent to them. Transportation charges should be prepaid.

CHAPTER XII

Specifications and License Data

Type of engine.....	8 cyl. V-type
Diameter of cylinder bore.....	3 $\frac{1}{8}$ in.
Length of stroke.....	4 $\frac{1}{8}$ in.
Piston displacement.....	303 cu. in.
Horsepower (N. A. C. C. rating).....	31.25
Engine number.....	See below
Diameter of crankshaft main bearings.....	2 $\frac{3}{8}$ in.
Exhaust valves.....	1 $\frac{1}{2}$ in.
Inlet valves.....	1 $\frac{1}{2}$ in.
Capacity of gasoline tank.....	20 gals.
Capacity of engine lubricating system.....	2 gals.
Capacity of cooling system.....	5 $\frac{1}{4}$ gals.
Capacity of transmission.....	1 $\frac{1}{2}$ qts.
Capacity of rear axle.....	3 qts.
Wheelbase.....	125 in. and 134 in.
Tires (125 in. wheelbase).....	32x6.00 (low pressure)
(134 in. wheelbase).....	32x6.20
Tread.....	56 in.

Engine and Unit Assembly Numbers

EACH La Salle car when shipped carries an *engine number* which is also a serial number. This is the number to be used in filling out license and insurance applications and in general reference to the car. The engine number is stamped on the car in two places: On the name plate on the front face of the left side of the dash and on the crankcase just below the water inlet on the right-hand side.

The various units such as the transmission, steering gear, etc., also carry unit assembly numbers. These are located as described below. It is important in ordering parts to give, not only the engine number of the car, but also the unit assembly number of the unit to which the part belongs.

Transmission number—on the front surface of the support for the clutch pedal spring, or on either the top or the left-hand edge of the flange by which the transmission is bolted to the crankcase.

Steering gear number—on the steering gear housing, just below the grease gun connection.

Carburetor number—on right front face of the flange by which the carburetor is attached to the intake header.

Generator number—on the side of the generator just in front of the cut-out relay.

Starting motor number—on the right-hand side of the starter, just below the switch.

Front axle number—on the upper surface of the axle I-beam at the right-hand end just above the steering stop screw.

Rear axle number—on the rear surface of the axle housing just to the right of the cover plate.

Chassis (frame) number—on the upper surface of the left-hand side bar opposite the steering gear, or on the upper surface of the right-hand side bar opposite the crankcase support arm.

The Cadillac Motor Car Company reserves the right without notice to make changes in design, construction and specifications.

Index

A		
Accelerator (see throttle control).....	10	
Accelerator, use of before engine is warm.....	42	
Adding water to storage battery.....	86	
Adjustment of brakes.....	108	
Adjustment of carburetor.....	75	
Adjustment of clutch release rod.....	97	
Adjustment of generator charging rate.....	84	
Adjustment of headlamps.....	93	
Adjustment of steering gear.....	100	
Adjustment of timer contact points.....	89	
Alcohol as anti-freeze.....	38	
Alcohol, effect of, on finish.....	39	
Alignment of front wheels.....	103	
Ammeter.....	19	
Ammeter, its use.....	83	
Anti-freezing solutions.....	38	
Axle, front.....	103	
Axle, rear.....	106	
Axle, rear, add lubricant to.....	55	
B		
Balancing marks on tires.....	106	
Battery, storage.....	85	
Bearing, clutch thrust, to grease.....	55	
Bearings, main and connecting rod.....	68	
Bearings for wheels, adjustment of.....	106	
Body, care of.....	58	
Brake adjustment.....	108	
BRAKES	18, 108	
Brakes, general description of.....	108	
Bulbs for lamps, voltage.....	93	
Button, carburetor enriching.....	11	
C		
Carbon, removal of.....	69	
Carburetor, adjustment of.....	76	
Carburetor enriching button.....	11	
Carburetor enriching button, use of in cold weather.....	41	
Carburetor, to prime.....	41	
Capacity of cooling system.....	39	
Caps, tire valve.....	30	
CARE OF BODY	58	
Care of finish on body when new.....	58	
CARE OF TIRES	61	
Chains.....	71	
Chains for tires, when improperly adjusted.....	61	
Changing tires.....	34	
Changing tires, use of jack in.....	34	
Chassis lubricant.....	47	
Chassis lubrication diagram.....	54	
Choke rod.....	11	
Choke rod button (carburetor enriching button) use of in cold weather.....	41	
Cigar lighter.....	27	
Circulating system for oil.....	48	
Circulation of water.....	79	
Cleaner for windshield.....	27	
Cleaning headlamp reflectors.....	93	
Cleaning the cooling system.....	81	
Cleaning upholstery.....	59	
Cleaning windows, closed cars.....	59	
Clock.....	27	
Clock, repairs to.....	112	
CLUTCH AND TRANSMISSION	97	
Clutch, construction of.....	97	
Clutch pedal.....	16	
Clutch release rod, adjustment of.....	97	
Clutch thrust bearing, to grease.....	55	
Coasting.....	22	
COLD WEATHER OPERATION	38	
Contents.....	5	
Contact points, adjustment of.....	89	
CONTROLS AND INSTRUMENTS	9	
Control, spark lever.....	11	
Control, throttle lever.....	10	
Control, transmission.....	17	
COOLING SYSTEM	79	
Cooling system, capacity.....	39	
Cooling system, drain and refill.....	80	
Cooling system, to clean.....	81	
Cowl ventilators, open cars.....	27	
Crankcase ventilating system.....	50	
Curtain fasteners, open cars.....	29	
Curtains, side, open cars.....	27	
Cylinder heads.....	69	
D		
Danger of running engine in closed garage.....	21	
Data for license purposes.....	113	
Diagram, chassis lubrication.....	54	
Disc wheels, to change.....	37	
Distributor oil cup, fill with oil.....	52	
Dont's for general operation.....	23	
Door hardware, to oil.....	57	
Draining cooling system.....	80	
DRIVING	21	
Driving on steep grades.....	22	
Driving speed when car is new.....	21	
Driving suggestions.....	23	
Duco finished cars, to wash.....	59	
E		
Effect of alcohol on finish of body.....	39	
ELECTRICAL SYSTEM	83	
ENGINE	68	
Engine fails to start.....	14	
Engine, important features of.....	68	
ENGINE LUBRICATION	48	
Engine number, location of.....	113	
Engine oil.....	46	
Engine oil, to replace.....	51	
Engine, prepare for storage.....	64	

Engine, starting of	13	Lever, spark control	11
Engine, starting in cold weather	41	Lever, throttle control	10
EQUIPMENT	26	Lever, transmission control	17
Equipment, tools	30	License data	113
Exide depots for battery maintenance	87	Lighter, cigar	27
F		Lighting switch	20
Fan belt adjustment	79	Lighting system	93
Fasteners, curtain, open cars	29	Locks	9
Fiber grease	47	Lubricant for chassis	47
Filling and draining cooling system	80	Lubricants	46
Filter for gasoline	75	LUBRICATION AND CARE	43
Filter for oil	50	Lubrication chart	54
Finish of body, care of, when new	58	LUBRICATION, ENGINE	48
Foot brakes	19	Lubrication schedule	44
Foreword	3	Lubrication, systematic	45
FRONT AXLE	103	M	
Front wheels, alignment of	103	Mirror, rear vision	27
G		N	
Gas in closed garage, when engine is running	21	New car, driving speed	21
Gasoline filter	75	New car, washing	58
Gasoline gauge	10	O	
Gasoline strainer, cleaning in cold weather	40	Official approval of headlamps	93
GASOLINE SYSTEM	73	Oil circulating system	48
Gauge, gasoline quantity	10	Oil cups on generator, to fill	52
Gauge, oil pressure	15	Oil cup on timer-distributor	52
General driving suggestions	24	Oil filter	50
GENERAL INFORMATION	67	Oil for engine	46
GENERAL LUBRICATION	55	Oil for engine in cold weather	40
General operation don'ts	24	Oil level	49
Generator	83	Oil pressure	49
Generator oil cups, fill with oil	52	Oil pressure gauge	15
Genuine La Salle parts	111	Oil pressure regulator	50
Grease gun connections, to grease	55	Oil, replacing of, in engine	51
Grinding valves	70	Operation, in cold weather	38
H		Operation don'ts	23
Hand brakes	19	Operation of starter	87
Hardware on doors, to oil	57	Ordering new parts	111
Headlamp reflectors, to clean	93	P	
Headlamps, adjustment of	93	Parts, genuine La Salle	111
Headlamps, operation use of beams	20	Parts, ordering new	111
I		Parts, returning of	112
Ignition, general description of	88	Pedal, clutch	16
Ignition spark control lever	11	Pedal, foot brake	19
Ignition switch	9	Pedal, starter	13
Ignition timing	90	Position of spark control lever	11, 42
Inflation pressure, tires	32	Position of throttle hand lever	10, 42
Inflation of tires, under-inflation	61	Pressure for tires	32
INSTRUMENTS AND CONTROLS	9	Pressure of oil	49
L		Pressure, oil gauge	15
Lamp bulbs	93	Prices of parts, uniform	111
Level for oil, engine	49	Priming the carburetor in cold weather	41
		R	
		Radiator and shutters	79
		Rear axle, to add lubricant	56
		REAR AXLE AND TORSION TUBE	106

Rear vision mirror.....	27	Timer-distributor.....	88
REPAIR PARTS.....	111	Timer-distributor oil cup, fill with oil.....	52
Repairs to speedometer head.....	19	Timing ignition.....	89
Replacing engine oil.....	51	Tire balancing marks.....	106
Result of under-inflation of tires.....	61	Tire carrier, (tire holder).....	32
Returning parts.....	112	Tire chains, improperly adjusted.....	61
Rim, true up.....	34	Tire holder.....	32
		Tire pressure.....	32
S		Tires.....	30
Schedule of lubrication.....	44	Tires, care of.....	61
Shifting transmission gears.....	17	Tires, to change.....	34
Shutters on radiator.....	79	Tire valve caps.....	32
Side curtains, open cars.....	29	Tools.....	30
Small cuts in tires, neglect of.....	61	Tools (illustration).....	31
Solutions for anti-freeze.....	38	Top, care of when car is stored.....	65
Spark control lever.....	11	Torsion tube.....	106
Spark plugs.....	91	Transmission control.....	17
Specific gravity of battery solution.....	86	Transmission, to add lubricant.....	55
SPECIFICATIONS AND LICENSE		Truing up rim.....	34
DATA.....	113		
Speed of new car.....	21	U	
Speedometer.....	19	Uniform parts prices.....	111
Speedometer flexible drive shaft, to lubricate.....	56	Upholstery, to clean.....	59
Speedometer lubrication notice.....	46	Use of accelerator before engine is warm.....	42
Speedometer, repairs to.....	112	Use of jack in changing tires.....	34
Springs, to lubricate leaves.....	56	Use of starter in cold weather.....	42
Starter pedal.....	13	V	
Starter, use of in cold weather.....	42	Vacuum tank.....	74
Starting engine.....	13	Valve caps, tire.....	32
Starting engine in cold weather.....	41	Valve grinding.....	70
Starting motor.....	87	Valve stem clearance.....	69
Steering connecting rod.....	102	Valve stems, how lubricated.....	49
STEERING GEAR.....	100	Varnished cars, washing, when new.....	58
Steering gear, add lubricant.....	56	Ventilating system for crankcase.....	50
Strainer in gasoline system.....	40, 75	Ventilators in cowl, open cars.....	27
Storage battery.....	85		
Storage battery, location on car.....	85	W	
Storage battery, when car is stored.....	64	Washing Duco finished cars.....	59
Storage of car, placing car in service.....	65	Washing varnished cars.....	58
Storage of tires.....	65	Water circulation.....	79
STORING CAR.....	64	Water pump.....	80
Suggestions for driving.....	23	Water pump, lubrication of.....	52
Switch, ignition.....	9	Wheel alignment.....	103
Switch, lighting.....	20	WHEELS.....	106
SYSTEMATIC LUBRICATION.....	45	Wheels, pack bearings with grease.....	56
		Wheels, removal of.....	106
T		Wheels, to adjust bearings of.....	107
Taking car out of storage.....	65	Windows, to clean.....	59
Throttle control.....	10	Windshield and ventilation.....	26
Throttle hand lever position, cold weather.....	42	Windshield cleaner.....	27
		Wire wheels, to change.....	36

CADILLAC SHOP MANUAL

LaSalle Supplement



The following section should be used as a supplement to the 314 Shop Manual rather than as a complete LaSalle Manual. The information contained in these pages includes only those features in which the LaSalle differs from the 314 Cadillac. Wherever similar construction is used in both cars, reference should be made to the Cadillac section of the Manual.

Front Axle

1201. Spindle Arm Stop Screws

The stop screws on the LaSalle are adjusted in the same manner as on the 314. They are in back of the axle instead of in front of it. See §201.

1202. Alignment of Front Wheels

The front wheels should toe-in not less than $\frac{1}{8}$ inch nor more than $\frac{1}{4}$ inch as measured with tool 102789. To use this tool see directions in §202.

Adjustment of the front wheel alignment is made by shifting the position of one or more of the spacers (Fig. 102). To do this, first remove the cotter pin and plug (2) in the end of the parallel rod. The rod can then be taken off the end of the spindle arm.




Fig. 102. Sectional View of Ball and Socket Joints at Ends of Parallel Rod

To make the wheels toe out more, remove spacers from between the inner seat and the inner plug, and place them between the outer seat and the outer or adjustable plug. To make the wheels toe in more, remove spacers from between the outer seat and the adjustable plug, and place them between the inner seat and the inner plug.

A $\frac{1}{16}$ -inch spacer will change the toe-in $\frac{1}{8}$ inch as measured by the gauge. A $\frac{1}{32}$ -inch spacer will change the toe-in $\frac{1}{16}$ inch. Extra spacers, if necessary, can be secured from the Parts Division. When replacing the plug in the end,

tighten it as far as it will go, then back it up one cotter pin hole.

It is recommended that the rims on the front wheels be trued up whenever the front wheels are aligned.

1203. Adjustment of Parallel Rod Joints

To adjust the ball and socket joints, jack up the front axle. Remove the cotter pins (Fig. 102) and screw the adjusting plugs in as far as they will go. By working the front wheels back and forth against each other, make sure that all play in the parallel rod has been taken up. Then back the screw plugs out to the next cotter pin hole.

1204. Removal and Disassembly of Parallel Rod

Disconnect the ends of the rod from the pivots on the steering arms by removing the screw plugs (2, Fig. 102). The spacers and inner plugs will fall out of their own accord.

1205. Inspection

Clean the rod and the pivots on the arms.

Examine the rod carefully. The rod should be straight and free from dents. The threads in the ends of the rod should be in good condition.

Replace the leather dust cap (1) if the old one is not in good condition. In order to do this it is necessary to remove the pivot (3), from the spindle arm.

1206. Assembly and Installation

To assemble and install the parallel rod, reverse the operations under "Removal and Disassembly," placing the seats and spacers as shown in Fig. 102.

Before completing the installation of the parallel rod, make sure the front wheels are in alignment in accordance with the directions in §1202.

Spindle Arms

1207. Removal

Disconnect the arm from the parallel rod by removing the screw plug in the end of the rod.

If the arm is the left-hand spindle arm, disconnect it also from the steering connecting rod.




Fig. 103. Right-Hand Spindle Arm

Remove the cotter pin and large nut by which the arm is attached to the spindle and remove the arm by driving it out, being careful not to damage the threads. A good plan is to loosen the nut until it is flush with the end of the arm and then tap it until the arm is loosened in the spindle.

1208. Inspection

Examine the forging carefully.

Determine if the arm is bent or sprung (Fig. 103 or 104).

Make sure the key and threads on the arm are in good condition.




Fig. 104. Left-Hand Spindle Arm

INSPECTION OF OTHER PARTS—Examine the pivot on the arm. The ball end should be round within .010 inch and the threads should be in good condition.

1209. Installation

To install, reverse the operations under "Removal."

Adjust the steering connecting rod in the

same manner as on 314 cars after chassis unit assembly 1-32060.

Front Axle Spindles

1210. Adjustment of Spindle Bearings

Adjustment of up-and-down play in the spindle bearings is made by placing shims (13, Fig. 105) of the proper thickness between the upper fork of the spindle and the axle. These shims can be obtained from the Parts Division. To install the shims it is necessary to remove the spindles (§1211).

These shims are not intended as an adjustment to compensate for wear. When the bearings are worn so much as to permit excessive play, they should be replaced.

1211. Removal

Jack up the front axle and remove the wheel.

Disconnect the brake cable by removing the two nuts on the front end. Disconnect the brake operating shaft from the frame by removing the two cap screws that hold the bracket to the side bar.

Remove the six machine screws that hold the brake dust shield to the spindle and remove the dust shield with brake and brake operating shaft.

With a screw driver, force off the dust cap at the upper end of the spindle bolt.

Remove the locking key or pin (17, Fig. 105) by taking off the nut and driving out the key. Be careful not to injure the threads on the key.

The spindle bolt can then be driven down and out and the spindle removed.

1212. Inspection

Clean all parts removed.

INSPECTION OF SPINDLE—With the spindle placed on lathe centers, that part of the spindle which receives the wheel bearings should run true within .002 inch.

There should be no more than .003 inch clearance between the cones of the wheel bearings and the spindle.

The threads on the spindle should be in good condition.

Note that the right-hand spindle has right-hand threads and the left-hand spindle, left-hand threads.

INSPECTION OF OTHER PARTS—Inspect the

ball bearing. The balls and the races should be round and free from pits.

If there is more than .006 inch clearance between the spindle bolt and the bushings within the spindle, the bushings should be replaced. Ream new bushings to a free fit on the bolt.

1213. Installation

To install a spindle, reverse the operations under "Removal."

Before driving the spindle bolt into place, note the amount of up-and-down play in the spindle. If there is more than .004 play, install one or more shims at (13). Shims can be secured from the Parts Division in the following thicknesses: .003 and .005.

In replacing the spindle bolt, line up the flat surface on the bolt with the hole in the axle for the locking key (17).

New dust caps must be installed above and below the spindle bolt.

Front Axle I-Beam

1214. Removal

Jack up the front end of the car until the front wheels are clear of the ground.

Disconnect the Stabilator straps from the axle. Remove the wheels.

Disconnect the front end of the steering connecting rod.

Disconnect the brake cables.

Disconnect the brake operating shafts from the frame.

Remove the nuts from the spring clips.

The complete axle can then be removed.

1215. Disassembly

Remove all grease gun connections.




Fig. 105. Sectional View of Left-Hand Front Spindle and Wheel




Fig. 106. Front Axle Inverted for Testing Angles

Remove the parallel rod (§1204).

Remove the spindles with steering arms from the axle (§1211).

1216. Inspection

The lines through the centers of the holes in the ends of the axle should be in the same plane and at an angle of $7\frac{1}{2}^\circ$ with the vertical.

This may be tested by inserting the spindle bolts in their holes and placing the axle upside down upon parallel bars under the spring seats, (See Fig. 106). Then with a square, take dimensions (A) and (B) at the ends of the bolt. The difference between (A) and (B) should be $\frac{5}{8}$ inch.

The center lines of the holes in the ends of the axle should be exactly at right angles to the spring seats. This may be tested by taking dimensions (C and D, Fig. 107) at the ends of




Fig. 107. End View of Axle Inverted for Testing Angles. (When Testing First Type Axle, Place Scale in Front of Axle)

the bolt. The dimensions (C) and (D) should be equal.

Note: On some of the first LaSalle cars built the spring seats on the axle are machined at an angle of 89° with the spindle bolts. When testing these axles the dimension (C) should be $\frac{7}{8}$ inch greater than dimension (D), the scale being placed in front of the axle.

INSPECTION OF OTHER PARTS—Inspect the bushings in the spindles. There should be no more than .006 inch clearance between the bushings and the bolt.

The ball races and ball bearings should be free from pits and chips.

1217. Assembly and Installation

To assemble and install the front axle, reverse the operations under "Disassembly" and "Removal."

It is very important that the front axle be installed with the proper side toward the front. The stop screws should be on the rear side of the axle.

In installing the spindle bolt, line up the flat surface on the bolt with the hole in the axle for the draw key.

For the adjustment of the front brake cables see "Brakes."

Adjust the front wheel bearings in accordance with the directions in §2-1024.

Adjust the steering connecting rod in the same manner as on 314 cars after chassis unit assembly 1-32060.

Adjust the spindle arm stop screws in accordance with the directions in §201.




Fig. 108. Sectional View of LaSalle Rear Axle

Rear Axle and Torsion Tube

Note: For the universal joint and ball and socket members see "Transmission"

Axle Drive Shafts

1230. Removal

WOOD WHEELS—Remove the six nuts (Fig. 109) which hold the flange to the wheel.

Withdraw the flange and axle shaft together. Should the flange stick, loosen it by jarring one side of the wheel. Then, if necessary, drive wedges back of the flange taking care not to mar the finish.

If the flange is to be removed from the shaft, which is seldom necessary, remove the hub cap and unscrew the nut on the end of the shaft. The flange can then be pressed off the shaft.

WIRE WHEELS—Jack up the rear wheel which is to be removed.

Remove the wire wheel. (When removing a wire wheel, turn the nut in the same direction the wheels turn when the car goes ahead. The right wheel nuts have left-hand threads. The left wheel nuts have right-hand threads.)

This will give access to the six nuts on the bolts which hold the wire wheel hub and the brake drum together.




Fig. 109. View of Rear Wheel Showing Nuts Which Hold Axle Shaft to Wheel




Fig. 110. Rear Wheel with Axle Shaft Removed

After the nuts are removed, insert a wedge between the flange and the drum.

To remove the wire wheel hub from the axle shaft, remove the nut from the end of the shaft and press the axle shaft out.

DISC WHEELS—It is not essential to remove the wheel in order to remove the axle shaft on a car with disc wheels but it makes the removal of the shaft much easier.

Remove the wheel. (The disc wheel retaining nuts have left-hand threads for the left side and right-hand threads for the right side.)

Remove the hub cap and shield.

Remove the eight nuts which hold the shaft and flange to the drum.

1231. Inspection

Placed on lathe centers, the axle shaft should run out of true no more than .004 inch.

The clearance between the splines on the axle shaft and the sides of the grooves in the hub of the equalizer gear should not exceed .006 inch.

1232. Installation

Install each shaft on its proper side. The axle

shafts are not interchangeable, the right-hand shaft being $34\frac{5}{16}$ inches and the left-hand, $31\frac{11}{16}$ long.

Rear Axle Assembly

1233. Removal

Disconnect the Stabilator straps.

Raise the rear end of the frame of the car so that the wheels are just clear of the floor. Block the front wheels, both in front of and behind the wheels.

Disconnect the wire from the stop lamp switch to the brake rod.

Disconnect the brake rods at the connections under the cross member just back of the transmission.

Remove the rear spring clips.

Remove the wire (4, Fig. 111) holding the universal joint boot (3) to the torsion tube.

Disconnect the torsion tube from the ball member by removing the four cap screws.

Raise the car high enough so the wheels will clear the fenders and the whole rear axle can then be rolled out from under the car.

1234. Installation

To install, reverse the operations under "Removal."

Make sure that the ball member is turned so that the side marked "TOP" is up.

Torsion Tube

1235. Removal

Remove the rear axle and torsion tube from the car (§2-233).




Fig. 111. Front End of Torsion Tube as Seen From Below

Remove the nuts (3, Fig. 112) on the front ends of the two strut rods.

Remove the eight nuts and two cap screws (1) that hold the torsion tube to the differential carrier.

Pull the torsion tube off over the drive shaft.

1236. Inspection

The tube should be straight. Make sure all rivets are tight.

1237. Installation

Reverse the operations under "Removal."

Propeller Shaft

1238. Removal

Remove the torsion tube (§1235).

Drive the pin (4, Fig. 113) out of the rear end




Fig. 112. Rear Axle and Torsion Tube Assembly




Fig. 113. Rear Axle with Torsion Tube Removed

of the propeller shaft. This pin is peened over at the factory and may have to be drilled out.

Pull the propeller shaft off the end of the pinion shaft with puller 109404.

1239. Inspection

The shaft should run true within .003 inch when placed in lathe centers.

There should be no more than .003 inch clearance between the sides of the splines on the front end of the propeller shaft and the sides of the splines in the universal joint.

Inspect the bronze bushing in the ball member at the rear of the transmission (See Fig. 146). This is the bearing for the front end of the propeller shaft and if it is badly worn the shaft will whip and cause noise.

For replacement see §1988.

1240. Installation

Reverse the operations under "Removal."

Differential Carrier Assembly

1241. Removal

Remove the rear axle from car (§1233).

Drain the lubricant.

Remove the torsion tube and propeller shaft (§§1235, 1238).

Remove the supports at the inner ends of the brake rocker shafts.

Remove the remaining ten cap screws (2, Fig. 112) by which the differential carrier is fastened to the rear axle housing.

It is a good plan to leave the axle shafts in place until the carrier is ready to be removed. This helps to hold the carrier in place and reduces the danger of its falling out.

Remove the differential carrier assembly.

1242. Installation

To install, reverse operations under "Removal."

It is a good plan to place the carrier in position in the axle and then force the axle shafts in place. This helps to hold the carrier in position until the cap screws are started.

Make sure there is the proper amount of lubricant in the rear axle. When connecting the torsion tube at the front end, make sure that the ball member is turned so that the side marked "TOP" is up.

Rear Axle Gears

1243. Adjustment and Replacement

The rear axle gears are correctly adjusted when the axle is assembled, and their positions must not be changed. If the gear and pinion require replacement, the entire differential carrier assembly should be replaced. Differential carrier assemblies for replacement can be obtained from the factory Parts Division on an exchange basis.

Rear Axle Housing

1244. Removal

Remove the differential carrier assembly (§2-241).

Remove the rear cover plate.

Place the housing on a stand and then remove the wheels.

Disconnect the brake rods.

Disconnect the rear ends of the strut rods from the axle by removing the nuts on the ends.

Remove the brakes and brake rocker shafts.

Remove the truss rod.

1245. Inspection

Place the axle on V-blocks (Fig. 114) over a




Fig. 114. Rear Axle Housing Being Tested for Alignment—1st Position

perfectly flat, true surface. Turn the housing so that the flat sides are horizontal as shown. With a square, measure the distance at (A) and again at (B). Revolve the axle 180° and take these measurements again. All four measurements should be within $\frac{1}{16}$ inch of each other.

Turn the housing so that the flat sides are vertical as shown in Fig. 115. With a square, measure to the center of the hole (C) then again at (D). Revolve the axle 180° and take the same measurements. All four measurements should be within $\frac{1}{16}$ inch of each other.

All rivets should be tight.

The threads on the ends of the housing should be in good condition.

INSPECTION OF OTHER PARTS—Inspect all parts removed in accordance with directions in this book. Inspect the bronze bushing in the ball member at the rear of the transmission (4, Fig. 146). There should be no more than .010 clearance between the universal joint yoke and the bushing in the ball member.

1246. Assembly and Installation

Reverse the operations under "Disassembly and Removal."




Fig. 115. Testing Rear Axle Housing—2nd Position

Brakes

1310. General Description

The LaSalle four-wheel brakes embody the same general features as 314 brakes but they are different in adjustments and other details of construction. The general information in §§310 and 311 applies also to the LaSalle. New features are described below.

1311. Adjustment of Foot Brakes

The method of adjusting LaSalle foot brakes is shown in Figs. 116, 117 and 118. The clearances used for setting the LaSalle brakes are .035 inch for the rear brakes and .010 inch for the front brakes.

Fig. 116 shows the adjustment of the brake connections, Fig. 117 the adjustment of the rear foot brakes, and Fig. 118 the adjustment of the front foot brakes.

Ordinarily it should be unnecessary to touch the adjustments shown in Fig. 116 as the brake connections are correctly adjusted at the factory. For the ordinary adjustment to take up wear, start with 8 in Fig. 117 and follow the numbers through to 20 in Fig. 118.

If there is any reason to believe the connections are not in correct adjustment or if the link shown at 5 in Fig. 116 is to be replaced with the second type link, the connections should be readjusted as directed in Fig. 116, starting with 1. This should be followed by adjustment of the front and rear brakes, 8 to 20 inclusive, Figs. 117 and 118.

1312. Adjustment of Hand Brakes

The hand brakes on the LaSalle are similar to the 314. There is no adjustment of these brakes. There is sufficient movement of the hand brake lever to permit the wearing down of the lining without any take-up being necessary.

1313. Removal of Rear Foot Brake Bands

Attached to each rear brake dust shield is a circular angle plate to prevent dust and water getting into the brake lining. It is possible to remove the brake band without removing this plate, but it is easier if the plate is removed.

1314. Removal of Front Brake Bands

To remove the front brake bands, first remove the wheel, then the two cap screws which hold the cam to the trunnion. Remove the anchor by taking out the four cap screws which fasten it to the shield. Disconnect the springs and remove the brake band.

When installing the band, install a new piece of anti-friction material between the anchor plate and the outside of the dust shield. This prevents any slipping of the brake anchor.

1315. Front Brake Trunnion and Yoke

To remove the trunnion and universal joint, proceed as follows:

Remove the wheel.

Disconnect the boot from the trunnion bearing (10, Fig. 105).

Remove the two cap screws which hold the guide socket to the bracket (20) on the frame.

Remove the two cap screws (2) which hold the cam to the trunnion.

The trunnion yoke and guide can then be removed.

The universal joint can be disassembled as soon as the trunnion is taken out of its bearing.

Should the trunnion bearing require replacement it can be removed by cutting off the rivets which hold it to the dust shield.




Fig. 116. Adjustment of Brake Connections. (Follow with adjustment of brake bands, Figs. 117 and 118)




Fig. 118. Adjustment of Front Foot Brakes. Clearance between Lining and Drum, .010 inch




Fig. 117. Adjustment of Rear Foot Brakes. Clearance between Lining and Drum, .035 inch

Clutch

1350. Description

The clutch is a multiple disc clutch similar to the 314 clutch but with six driven discs and five driving discs. The driver for the driving discs is a separate part bolted to the flywheel.

The thrust or release bearing is mounted on a support bolted to the transmission rather than on the clutch itself.

The pressure of the clutch spring is 420 lbs. when compressed to a length of $2\frac{1}{2}$ inches.

1351. Adjustment of Clutch Release Rod

The clutch pedal should have at least one inch play or lost motion the same as described in §351. The adjustment itself is slightly different from the 314. To make the adjustment on the LaSalle, unscrew the nut (2, Fig. 119), the nut is notched so that it will lock at every half turn.

It is very essential that the play in the clutch pedal be checked at regular intervals and not allowed to fall below $\frac{3}{4}$ inch.

1352. Adjustment of Pedal Stop Screw

The clutch pedal stop screw (3) should be adjusted so as to let the clutch pedal come as far back as possible without touching the toe board.

1353. Removal

Remove the rear axle and transmission (§1960).




Fig. 119. Adjustment of Clutch Pedal




Fig. 120. Sectional View of Clutch

Remove the nut (5, Fig. 120) which holds the clutch on the shaft, using wrench 101421.

Pull the clutch off with puller 109409.

1354. Disassembly

The easiest way to remove the discs is to place the clutch in an arbor press, with the spider directly under the plunger of the press, and force the spider down until the six nuts can be removed from the studs. Release the arbor carefully so the spring will not fly out.

If no arbor press is available, pass a long bolt with large washers on each end and through the center of the clutch hub. Then screw the nut down on the bolt far enough to release the spring and take the nuts off the studs.

With the removal of the nuts the clutch can be taken apart.

1355. Inspection

With the exception of the specifications for the clutch spring, the directions in §356 for inspecting the 314 clutch applies to the LaSalle.

The clutch spring should support a load of not less than 420 pounds when compressed to $2\frac{1}{2}$ inches.

All of the discs except the front plate with its studs are interchangeable with 314 discs.

1356. Relining Clutch Discs

The clutch lining on the LaSalle is different from the lining which has been used on Cadillac cars. This lining is lighter in color than the lining on the Cadillacs. The previous Cadillac clutch lining should not be used in lining LaSalle discs.

1357. Assembly and Installation

Reverse operations under "Removal and Disassembly."

The rear disc in the clutch is thicker than the other discs. This plate is fitted in the clutch driver at the factory and is marked to indicate its position in relation to the driver. When re-installing the clutch, make sure the marked tooth on the driver goes between the two marked teeth on the rear disc.

Clutch Thrust Bearing**1358. Removal**

Remove the clutch (§1353).

The thrust bearing can be removed from the support as soon as the spring is disconnected.

Cooling System

1370. Differences

The LaSalle cooling system is essentially the same as the 314 after engine unit 1-41001. Those features which are different are described below.

1371. Water Pump

The water pump is interchangeable with the 314 water pump.

1372. Radiator

The radiator is of the same type as the 314 but is not interchangeable with it. The radiator is removed in the same manner as the 314 radiator after engine unit 1-41001.

1373. Removal of Radiator Shutter Assembly

The shutter assembly has the same general construction as on the 314 but is removed in a different manner as follows:

Remove the hood.

Remove the radiator filler cap.

Remove the radiator casing.

Remove the clevis pin from the thermostat connection.

Loosen the two cap screws which hold the bottom of the shutter assembly to the radiator. These are behind the lower apron of the shutter assembly and are reached from underneath.

Remove the two cap screws which hold the assembly at the top.

The assembly can then be removed.

1374. Removal of Thermostat

To remove the thermostat it is first necessary to remove the radiator shutter assembly; after this has been done the thermostat is removed in the same manner as the 314.




Fig. 121. LaSalle Circuit Diagram

L A S A L L E

Electrical System

1410. Difference

With the exception of the units described below the electrical system is identical with that of the 314 after engine unit number 1-41001.

1411. Storage Battery

The battery is located under the front seat in a box attached to the right-hand side bar of the frame and is accessible after removing the front cushion and the cover plate over the battery. To remove the battery, loosen the clamp screws at the corners of the steel battery box, disconnect the cables and lift the battery out.

1412. Generator

The generator is the same as the 314 generator after engine unit 1-41001. The procedure for adjusting the third brush is the same as described in §421-a. To remove the generator the carburetor drain pipe must be removed. Otherwise the removal is the same as on the 314.

1413. Starting Motor

The starting motor is mounted on the right-hand side of the transmission case, and the pinion engage teeth on the outside surface of the fly-wheel.

The starting motor is essentially the same as the starting motor of the 314 but is not interchangeable with it.

1414. Removal of Starting Motor

Disconnect the cable (1, Fig. 122) at the starting motor switch. Tape the end of the cable or else disconnect it at the battery.

Remove the starter pedal rod (3).

Remove the cap screws (2) which bolt the starting motor to the transmission case.

The starting motor can then be removed from underneath the car.

1415. Ignition System

The same ignition system is used on the LaSalle as on the 314 after engine unit 1-41001.




Fig. 122. Starter Attached to Transmission Case

The distributor is essentially the same but is not interchangeable.

1416. Distributor

The LaSalle distributor is different from the 314 in that the automatic advance is different. The points have the same setting, also the spring tension of the breaker points should be the same as on the Cadillac.

1417. Ignition Timing

The ignition on the LaSalle should be timed in the same manner as on the Cadillac.

The same "IG|A" marks are used on the fly-wheel but they are stamped $\frac{7}{8}$ inch in advance of dead center. On a few of the first cars the marks are stamped the same as on the Cadillac, that is $1\frac{3}{8}$ inches. On these cars the timing should be set $\frac{7}{8}$ inch from the dead center mark.

1418. Ignition Coil

The same type coil and method of mounting is used on the LaSalle the same as on the 314 after engine unit 1-41001.

1419. Circuit Breakers

The circuit breaker unit on the LaSalle is the same as used on the Cadillac V-63 cars. The description and instructions in §§470-474, apply to this unit as well as to the 314.

1420. Horn

The horn is similar to the horn used on later 314 cars and is adjusted in the same manner.

To indicate the front main bearing, remove the oil pump and attach adapter B of holder 65530 to one of the oil pump studs, letting the plunger rest on the edge of the throw of the crankshaft (See Fig. 123).

The holder with adapter A (as supplied for 314 engines) can be used as it is for the center main bearing.

For the rear main bearing adapter C is necessary. This adapter is attached to the bearing cap by a thumb screw which screws into the holes for the oil pipe flange (See Fig. 124).

No shims or liners are used under the main bearing caps. When the indicated clearance in a bearing exceeds .006 it is recommended that the bearing be replaced.

Taking up bearings by dressing down the bearings and caps is not recommended. It is possible to do this but the caps cannot then be used again when new bearings are installed. When a cap which has been dressed down is used with a new bearing the cap forces the bearing out of shape and the proper clearance cannot be secured.

1523. Removal

Replacement bearings are furnished to exact size and do not require reaming or scraping.

To remove the bearings, proceed as follows:

Remove the mud pans and oil pan.
Remove the cover under the flywheel.
Remove the oil suction and header pipes.



Fig. 125. Removing Rear Main Bearing Cap with Puller 109406




Fig. 126. Bottom View of Engine, Oil Pan and Flywheel Cover Removed

L A S A L L E

Engine

1520. Removal of Engine

In removing the LaSalle engine from the car the essential difference between it and the 314 is that the rear axle must be removed first. The procedure is as follows:

Remove the hood.

Remove the headlamps.

Remove the radiator.

Remove the two bolts and cap from the front motor support.

Remove the bottom mud pans.

Disconnect the generator wire from the generator.

Disconnect the distributor wire and conduit from the front of the engine.

Disconnect the muffler pipe from the exhaust manifolds.

Disconnect the carburetor feed pipe from the filter at the bottom of the vacuum tank.

Remove the check valve and vacuum pipe assembly from the vacuum tank.

Disconnect at the engine the oil pipe leading to the gauge. It is also well to remove the oil filter at this time to avoid injury to it.

Remove the rear axle and the transmission (§2-960).

Remove the starter pedal.

Remove the two side engine support bolts using wrench number 109200.

1521. Disassembly

To disassemble the engine, proceed in the same manner as for the 314 after engine unit 1-41001 (§522-a).

Main Bearings and Crankshaft

1522. Inspection of Bearings for Clearance

To inspect the main bearings, proceed in the same manner as for the 314. The clearances are the same.




Fig. 123. Indicating Front Main Bearing. Indicator 196-B and Holder 65530 with Adapters A and B




Fig. 124. Indicating Rear Main Bearing. Indicator 196-B and Holder 65530 with Adapters A and C

Remove the bearing caps. Use puller 109406 to remove the rear bearing cap. This is shown in Fig. 125. To remove the front main bearing cap, the oil pump must first be removed.

1524. Installation

When installing main bearings, make sure that the small dowel pins in the bearings are inserted in their holes before clamping down the caps.

The rear main bearing cap requires special attention to install. Between the sides of the bearing cap and the crankcase are two wood plugs (4, Fig. 126) which act as an oil seal. These plugs must be removed after the bearing cap is removed and new plugs must be driven in after the cap is reinstalled. Only plugs furnished by the Factory Parts Division should be used.

those described in §§531-3 for the 314. They do not, however, need to be removed for the removal of the connecting rods.

Crankshaft

1526. Description of New Features

The principal new feature of the LaSalle crankshaft is the provision for distributing oil from the main bearings to the connecting rod bearings. Because of the side-by-side rod construction, each crankpin has two oil holes—one for each rod bearing. To connect these oil holes to the passages from the main bearing journal there is an aluminum oil passage plug (Fig. 127) which fits snugly inside each crankpin and is fastened by a machine screw. The plugs do not




Fig. 127. Section of Crankshaft Showing Oil Passages to Connecting Rod Bearings

Care should be used to see that these plugs are driven all the way in so as to form a proper oil seal.

The three main bearings are all the same diameter—2.375 inch.

Compensators

1525. Removal Unnecessary

The compensators of the LaSalle are similar to

have to be removed except for cleaning after a bearing burns out.

1527. Removal of Crankshaft

- Remove the transmission (§1960).
- Remove the front end chains (§§619-g, 619-m).
- Remove the connecting rods (§1533).
- Remove the cover under the flywheel.

Remove the flywheel. The crankshaft can be removed without removing the flywheel but the added weight makes it hard to handle.

Remove the main bearing caps, supporting the shaft so that it does not drop.

The crankshaft can then be removed.

1528. Inspection

Remove the oil passage plugs in the four throws of the crankshaft. They should be cleaned out before being reinstalled.

Wash the shaft with gasoline or kerosene and inspect all bearing surfaces. If any of the bearing surfaces are cut, or out-of-round more than .003 inch they should be dressed down.

If the clearance between the connecting rod bearing and the crank pin exceeds .0035 inch the connecting rod should be replaced.

End play in the connecting rod bearings should be not over .011 inch.

The crankshaft should have no more than .015 inch end play in the rear bearing, which is the bearing that takes the end thrust.

The shaft should run out of true no more than .004 inch at the center bearing.

1529. Installation

Before installing the shaft, wipe it off with a

cloth and lubricate the bearing surfaces with engine oil of a suitable quality.

To install, reverse the operations under "Removal."

The main bearings are numbered on one end. The bearing nearest to the radiator is stamped "1," the center bearing "2" and the rear bearing "3." Always install these with the number toward the front.

Always replace the wooden plugs in the rear main bearing cap with new ones.

In assembling and installing the pistons and connecting rods, follow carefully the directions in §1536.

Flywheel

1530. Removal and Installation

The marks stamped on the LaSalle flywheel are the same as those on the 314, except that the "I G | A" marks are $\frac{7}{8}$ inch instead of $1\frac{3}{16}$ inches ahead of center. The first cars shipped had the "I G | A" mark $1\frac{3}{16}$ inches ahead of dead center. Should one of these flywheels be removed, the marks should be changed to $\frac{7}{8}$ inch ahead of dead center.

The flywheel is removed and installed the same as the 314 (§§537-541).

Connecting Rods and Pistons



Fig. 128. Determining Clearance Between Connecting Rod Bearing and Crankpin. Indicator 196-B, Holder 109414 and Prying Bar 109415

1531. Difference between 314 and LaSalle Rods

In the LaSalle the two connecting rods from opposite cylinders are placed side by side on the crankpin. All eight rods are therefore the same.

On the first few LaSalle engines the oil hole for throwing oil on the cylinder walls is drilled only in the right-hand rods. On later engines both right and left-hand rods are drilled. When replacing a rod, be sure the new rod has an oil hole, whether it is a right or left-hand rod.

There are no separate connecting rod bearings, the babbitt being cast in place in the rod by a special process. Re-babbiting of rods should not be attempted outside of the factory. Rods should be returned to the factory for re-babbiting and replacement rods should be carried in stock.

1532. Inspection of Bearing Clearance Without Removal

There should be .0005 to .0015 inch clearance

between the connecting rod bearing and the crankpin. The clearance can be measured with indicator 196-B held in holder 109414, Fig. 128. Prying bar 109415 is necessary to force the rod back and forth.

1533. Removal

Remove the mud pans and oil pan.

Remove the cotter pins and nuts from the connecting rods.

Remove the bearing caps.

Turn the crankshaft to such a position that the rod and piston can be pulled out of the cylinder. Then turn the crankshaft to another position in which the piston can be moved past the compensator and out of the crankcase. Care should be taken in turning the shaft not to let it jam the piston.

All pistons and rods can be removed in this manner without removing the compensators.

1534. Adjustment of Connecting Rod Bearings

The connecting rod bearings are not adjustable.

If the connecting rod caps should be dressed down the rod could not be re-babbitted. No attempt should therefore be made to take up

connecting rod bearings by dressing down the caps.

1535. Inspection

INSPECTION OF BEARINGS—Clean the babbitt bearing and wipe it off with a cloth.

To insure against excessive oil consumption, smoking at the exhaust, the rapid formation of carbon in the cylinders, and noisy operation, the clearance between a connecting rod bearing and the crankpin should not exceed .0035 inch, as measured by the indicator (§1532).

The bearing should show no cracks. If the babbitt is broken or chipped out the connecting rod should be replaced. The babbitt alone is not interchangeable. It is cast in place in the connecting rod by special process. Re-babbiting of the rod should not be attempted outside of the factory.

INSPECTION OF RODS—The wrist pin bushing should be free from scores. If it is necessary to replace the bushing, proceed as follows:

With a press force out the used bushing and force in the new one, being sure that the oil holes line up. Ream the new bushing to a fit in accordance with §1537.




Fig. 129. Identification Numbers Stamped on Connecting Rods

Each rod should be tested for alignment before being installed in the engine.

OIL HOLE—Make sure that there is an oil hole in the large end of all rods. On some of the early engines this hole was drilled only in the right-hand rods. This hole should be drilled in both right-hand and left-hand rods.

ALIGNMENT OF RODS—The rods can be aligned in the same manner and with the same gauge as 314 rods (§561).

It is important that connecting rods always be tested for alignment before they are installed.

If a bearing has burned out, the oil passage plugs in the four throws of the crankshaft should be removed and cleaned out.

1536. Installation

To install, reverse the operations under "Removal."

LaSalle rods are numbered from 1 to 8 beginning with the rod nearest the front of the engine (Fig. 129). These numbers do not correspond to the firing order numbers. The numbers are stamped both on the rod and on the cap. Rods should always be assembled with the numbers facing toward the bottom of the engine.

Each rod is chamfered on one face of the bearing. The chamfered face should always be placed toward the end of the crankpin. The plain faces should be toward each other.

Check the following after the rods are installed:

1. Numbers on rods toward the bottom of the engine, (See Fig. 129).
2. Numbers on bearing caps corresponding to numbers on rods.
3. Oil holes in both connecting rods and facing the top.
4. All nuts tightened and cotter pinned.
5. The screws in the oil passage plugs should be tightened.

Fill the oil pan with eight quarts of engine oil.

Pistons, Pins and Rings

1537. Fitting of Pistons

LaSalle pistons should be fitted to a clearance of .0025, as measured with a feeler or thickness gauge. Feeler ribbon, not less than one-half inch wide, should be used in two thicknesses, .002 and .003.

When the .002 feeler is placed along side the

piston, the piston should go into the cylinder without forcing. When the .003 feeler is used, the piston should not go in.

To assist in fitting pistons, cylinders and pistons are both marked for size indicating differences of .0005 inch. Cylinder bores are in four sizes as follows:

- 1—3.1250—3.1255
- 2—3.1255—3.1260
- 3—3.1260—3.1265
- 4—3.1265—3.1270.

The figures 1 to 4, indicating the cylinder sizes, are stamped on the surface to which the exhaust manifold is attached, the mark for each cylinder being placed just in front of the corresponding exhaust connection.

Pistons are grouped in sizes, also varying by .0005 inch. These sizes and the limits for each size are as follows:

- 1—3.1222—3.1227
- 2—3.1227—3.1232
- 3—3.1232—3.1237
- 4—3.1237—3.1242
- 5—3.1242—3.1247
- 6—3.1247—3.1252
- 7—3.1252—3.1257.

When the cylinders are new, ordinarily the correct piston to be used will have the same size number as the cylinder or the next higher number. Thus, a No. 1 cylinder will ordinarily have a No. 1 or No. 2 piston. In fitting pistons when the cylinder bores are slightly worn, however, a larger piston will in most cases be necessary.

It will save time in selecting the correct piston to note first the size number stamped on the cylinder and then try a piston with the same mark. If this piston is too small, or if a piston of this size is not available, try the next size larger.

Markings for Weight

LaSalle pistons are the same approximate size as 314 pistons, but the weight specifications are not the same. It is therefore important that only pistons shipped by the Parts Division for LaSalle engines be used in LaSalle engines. If 314 pistons are used, the balance of the engine is likely to be destroyed.

In production, LaSalle pistons are stamped to indicate the weight classification, Roman numerals from I to X being used. Replacement pistons are selected to a "mean" or average weight, so

that in fitting replacement pistons, no attention need to be paid to weight markings.

Piston Pins

The proper fitting of piston pins in the LaSalle engine is important.

The piston pin should be a tight hand press fit in the piston. In other words, it should be just possible to push the pin into the piston by pressing with both thumbs on the end of the pin.

The piston pin should be a slightly easier fit in the bushing in the connecting rod than in the piston. To test this fit, assemble the rod and piston and hold the piston horizontal. The large end of the rod should then just drop slowly on its own weight.

To make it possible to fit piston pins to these specifications in service, the Parts Division furnishes four oversizes in addition to standard size pins. These oversizes are .001, .002, .003 and .005.

When fitting an oversize pin, the piston and the bushing in the connecting rod should be carefully reamed with an expansion reamer.

Piston Rings

The same piston rings are used in the LaSalle pistons as in 314 pistons, and directions for fitting and inspecting 314 piston rings, apply also to the LaSalle.

Cylinders

1538. Removal, Inspection and Installation

The cylinder heads and blocks on the LaSalle can be removed in the same manner as described in §§ 570-575 for the 314. The exhaust manifolds can be left on the blocks by disconnecting them at the front end. Before removing the left-hand head the temperature indicator should be disconnected.

The right and left-hand cylinder blocks are interchangeable. The heads are not.

Valve System

1539. Valves and Springs

The valve system is essentially the same as the 314.

The valve springs should support a load of 136 pounds when compressed to $2\frac{3}{4}$ inches.

The valves are $1\frac{1}{2}$ inch nominal diameter.

The angle of the inlet valve seat is 30° and that of the exhaust valve seat 45° .

The method of adjusting the valve stem clearance and the amount of the clearance is the same as for the 314 (§582).

Valve spring lifter 109206 is necessary for removing valves and springs.

When installing the valve cover plates on the LaSalle, care should be taken to install them with the mark "Top" up and on the outside.

If these cover plates are not properly installed oil will leak from them.

1540. Refacing and Reseating Valves

The angle of the inlet valve seat is 30° , of exhaust valves 45° . In refacing and reseating valves, the seats must have the correct angles.

Reseating tool 109403 is for the inlet valves and tool 109207 is for the exhaust valves.

1541. Camslides and Guides

The camslide guides are in groups of four. To remove a guide, first remove the four valves and springs above it. Remove the four nuts that hold the guide block to the crankcase and lift up the guide block.

1542. Camshaft

The camshaft is removed in the same manner as on the 314 after engine unit 1-41001. The directions and specifications in §§590-592 should be followed.

Fan, Front Cover and Chains

1543. Description

FAN—The fan is similar in construction to the fan on the 314 engines after engine unit 1-41001 but is not interchangeable with it. The difference is in the fan blades. The remainder of the fan assembly—hub, gear pump, and shaft—is the same on both cars. The fan belt is also the same for both cars.

CHAINS—The camshaft driving chain is shorter than on 314 engines, and is not interchangeable with the 314 chain.

The water pump and generator chain is the same length and width as the 314 chain but has bushed joints (marked B-45) instead of rocker type joints. Should replacement of this chain be necessary be sure to use the bushed joint type of chain.

Engine Lubrication System

1544. Description

The oil circulating system is essentially the same as for the 314. The oil pumps are interchangeable but the pressure regulators are not.

To remove the oil pan, the mud pans must first be removed.

The construction of the oil pan and screen is different. The screen rests on the inside of the oil pan and there is only one cork gasket between the oil pan and crankcase. To clean the oil pan and screen, the screen should be removed from the oil pan after taking out the six screws that hold it.

Exhaust System

Mufflers

1700. Differences

The exhaust manifolds of the LaSalle engine are joined at their front ends and a single exhaust pipe carries the gases down in front of the engine and back between the crankcase and the left-hand side of the frame. A single muffler of special construction is used and is fastened to the two center cross members.

1701. Removal

Remove the bolts which bolt the muffler sup-

ports to the frame, cross members at the front and rear of the muffler.

Disconnect the tail pipe from the two rear cross members.

The muffler with tail pipe attached can now be pulled off the end of the exhaust pipe.

To separate the muffler from the tail pipe, place the pipe in a vise, loosen the clamp screw and pull the muffler off the pipe.

1702. Disassembly

The muffler is crimped and welded together and cannot be disassembled.

Fenders, Running Boards and Shields

Fenders and Running Boards

2-710. Removal and Installation

The fenders and running boards on the LaSalle are removed and installed in a manner similar to those on the 314.

The front stabilators are fastened to the front fender bracket and these must be removed before removing the fender.

Dust Shields

2-719. Removal and Installation

The dust shields are similar to the 314 shields

except that there are no tool and battery boxes. With this exception the method for the removal of the dust shield is the same as the 314.

Radiator Splash Shields

2-723. Removal

There is very little occasion to remove the splash shields. They can be removed without first removing the fenders but in order to insure against injury it is best to remove the fenders first.

L A S A L L E

Frame

1740. Removal

Remove the body.
Remove the running boards.
Remove the front fenders and dust shields as a unit.
Remove the radiator.
Remove the engine (§1520).
Remove the steering gear as a unit.
Remove the front axle.
Remove the muffler and exhaust pipes.
Remove the front springs.
Remove the rear springs

Remove the gasoline tank, pipes and wiring.
Remove the stop light switch.
Remove the brake cross shafts, cables and rods.

1741. Inspection

To determine whether the frame has become bent or sprung, follow general procedure as given in §741 for the 314. The differences in dimensions are as follows:

The dimension C to D in Fig. 71 should be $20\frac{3}{4}$ to $20\frac{1}{2}$ inches on the LaSalle.

The distance A in Fig. 70 should be $6\frac{5}{8}$ inches on the LaSalle.

L A S A L L E

Gasoline System

1750. General Description

The general arrangement of the LaSalle gasoline system is illustrated in Fig. 130. The supply of fuel is carried in a 20-gallon tank at the rear, from which it is fed by vacuum to a tank on the dash. The fuel flows from this tank to the carburetor by gravity.

The vacuum for feeding the fuel from the supply tank to the tank on the dash is supplied from two sources: (1) The intake header and (2) a special vacuum pump driven by an eccentric on the rear end of the camshaft. The vacuum of the intake header alone is insufficient at wide open throttle to insure adequate flow of fuel and the pump is provided to supplement the intake header and furnish an adequate vacuum at all times.

The vacuum pump and the intake header are both connected to the vacuum tank and, except at wide open throttle, they together supply the vacuum to operate the vacuum tank. At wide

when the vacuum of the intake header drops below that of the pump.

The windshield cleaner is connected on the same side of the check valve as the intake header and is operated entirely by the vacuum of the intake header. The cleaner is not affected by the closing of the check valve.

1751. Operation of Vacuum Tank

The action of the system in operation is as follows:

Starting with the inner chamber empty and the float at the bottom, as in Fig. 131, the vacuum valve is open and the vent valve is closed. The suction of the intake header and the vacuum pump immediately causes gasoline to be drawn through the feed pipe from the supply tank to the inner chamber. The flapper valve is held closed by the vacuum within the inner chamber and the level of gasoline in the inner chamber rises until the float reaches the top of its travel, closing the vacuum valve and opening the vent valve. This




Fig. 130. Gasoline System

open throttle, when the vacuum of the intake header is less than that of the vacuum pump, the pump alone supplies the vacuum for operating the tank. At such times, backflow from the intake header is prevented by a check valve (Fig. 131) in the fitting to which the pipe from the intake header is connected at the vacuum tank. This check valve automatically closes

breaks the vacuum in the inner chamber and the flapper valve at the bottom opens under the weight of gasoline, emptying the contents of the inner chamber into the outer chamber. The float drops simultaneously and, as it reaches the bottom, again operates the valves, this time opening the vacuum valve and closing the vent valve. The cycle thereupon starts again.

This alternate filling and emptying of the inner tank is repeated rapidly until the level of gasoline is the same in the inner and outer chambers, and thereafter, only as the carburetor demands fuel.

Ordinarily, there is enough fuel in the carburetor and in the vacuum tank to start the engine. If not, the automatic feeding action can usually be started by closing the throttle and operating the starter for about ten seconds. Wait a few seconds to allow the fuel to flow to the carburetor, and then start the engine as usual.




Fig. 131. Sectional View of Vacuum Tank and Check Valve

The flow of fuel from the supply tank depends upon the difference in pressure between the

vacuum tank and the supply tank. It is, therefore, essential that the supply tank be open to atmospheric pressure. For this reason, the vent hole in the gasoline filler cap must be kept open.

1752. Gasoline Filter

A gasoline filter (Fig. 132) is provided in the gasoline line between the vacuum tank and the carburetor. This filter has a glass bowl through which the accumulation of water and sediment




Fig. 132. Gasoline Filter

can be easily seen. The bowl should be removed and the gauze screen should be cleaned, as soon as any accumulation appears in the bowl. This can be done as follows:

First shut off the gasoline by turning clockwise the small T-handle valve at the side of the filter. Then unscrew the thumb screw under the bowl, after which the yoke supporting the bowl can be swung to one side and the bowl can be removed. If the screen does not come off with the bowl, it can be removed by pulling it straight down.

In putting back the bowl, make sure that it seats properly against the cork gasket in the top of the filter before tightening the thumb screw. Do not forget to turn the gasoline on by turning the valve counter-clockwise as far as it will go.

There is also a strainer in the vacuum tank at the point where the gasoline enters the inner chamber. This strainer is accessible after disconnecting the feed pipe and unscrewing the inlet elbow. The strainer should be removed and cleaned occasionally.

Vacuum Tank

1753. Disassembly

If the hood is on the car it will be necessary to loosen the vacuum tank from the dash in order to disassemble it. If the hood is off, this is not

necessary. To disassemble the tank, proceed as follows:

Disconnect the feed pipe from the top of the tank.

Disconnect the intake header pipe from the fitting on the vacuum tank. Disconnect the vacuum pump pipe from the pump. Disconnect the windshield cleaner tube from the pipe under the cowl. Remove the screw which fastens the vacuum fitting to the tank and remove the fitting with the two pipes.

Remove the eight screws which hold the cover on the top of the vacuum tank.

Loosen the cork gasket by running a knife under it. Lift off the cover with the mechanism and float attached.

The inner tank with flapper valve can also be lifted out if necessary.

1754. Inspection

The float must be perfectly air-tight. A leaking float will not properly operate the vacuum and vent valves and will cause gasoline to be drawn through the vacuum valve, into the intake header.

The vent passage and tube must be free from dirt or any obstruction.

The vent valve should seat tightly. To examine this valve, remove the sleeve around the vent tube.

1755. Assembly

To assemble the vacuum tank, reverse the operations under "Disassembly."

Be sure to install a new gasket between the cover and the tank. The large hole in the edge of the gasket should be placed over the short vent tube in the outer tank.

When installing the cover, place it so that the short vent tube in the outer tank is directly under the vent opening in the cover. Also be sure that, as the float is lowered into the tank, the float stem enters the guide at the bottom of the tank. The tank will not operate unless the float stem is properly entered in this guide.

1756. Vacuum System Tests

There are only two ways in which failure of the vacuum system may affect operation of the engine: (1) by not supplying gasoline to the carburetor in sufficient quantity and (2) by

gasoline being drawn into the intake header, causing an over-rich mixture or "flooding."

The possible causes for an insufficient flow of fuel are as follows:

(1) Clogged strainer at top of vacuum tank. Remove and clean.

(2) Clogged vent hole in gasoline tank filler cap. Clean out with wire.

A clogged vent in the gasoline tank filler cap may also cause gasoline to overflow through the vent tube on the vacuum tank.

(3) Air leaks in vacuum connections. Points to be especially examined are the union nuts on the pipes to the intake header and vacuum pump, the windshield cleaner pipe and hose and the joint between the check valve fitting and the top of the vacuum tank.

(4) Air leaks in the supply line from the gasoline tank to the vacuum tank. The principal point to check is the union where the feed pipe enters the vacuum tank. The threads on this union are not pipe threads and the union must be screwed down to a seat on the cover in order to make a tight connection.

Ordinarily air leaks in the vacuum or supply line connections will not cause total failure of the fuel supply unless the leak is unusually large.

(5) Clogged vent tube or passage. If the inner tank is not properly vented to the atmosphere, the gasoline in the inner chamber will not empty through the flapper valve. To remedy this, remove the cover (§1753) and clean the vent passage and tube.

(6) Vent valve not seating properly. This prevents the vacuum from building up in the inner chamber. It is usually due to dirt or corrosion. If cleaning the valve and seat does not correct this condition, a new valve or seat may be necessary.

(7) Sticking flapper valve. Corrosion of the flapper valve seat may cause the flapper to stick and prevent fuel from flowing to the outer chamber.

(8) Leaking flapper valve. On a car that has been idle for some time with gasoline left in the vacuum tank, the flapper valve may leak air enough to prevent the vacuum from building up in the inner chamber. This is usually due to dirt under the valve or corrosion on the valve seat. Dirt can be washed out by disconnecting the feed pipe and pouring a small amount of gasoline

into the inner chamber. If this does not correct the condition, remove the inner tank and clean or replace the valve.

The cause of gasoline being drawn into the intake header is in nearly every case a leaking float. A leak in the float will cause it to fill partly and it will then fail to open the vent valve. To investigate this, remove the float (§1753) and test it.




Fig. 133. Section of Vacuum Pump

Vacuum Pump

1757. Description

The vacuum pump on the LaSalle is located in the same position and is driven in the same manner as the automatic pressure pump on the 314 after engine 1-41001, (See Fig. 133).

The pump is similar to the pressure pump but the parts are so arranged that instead of pumping air into the system it draws the air out of the system. The outlet discharges into the crankcase so as to return any oil that may pass the piston. No check valve is necessary at the pump.

The pump is removed and installed in the same manner as the 314 pressure pump.

1758. Inspection

The vacuum pump should be tested for efficiency in the same manner as described in §755 for the 314 pressure pump. In other words, with the cylinder and piston inverted in a vertical position, the piston and cylinder being free of oil, the piston should drop of its own weight from the inlet position to the discharge position in not less than 20 seconds and not more than 40 seconds.

Carburetor

1759. Description

The carburetor is essentially the same as the 314 carburetor but is turned around so that the inlet connection is toward the rear. The purpose of this is to make the pipe between the carburetor and the vacuum tank as short as possible. The float valve is also larger in diameter to take care of gravity feed. The choke and throttle controls are, of course, somewhat different.




Fig. 134. Thermostat Block

The LaSalle carburetor adjustments are identical with the 314 carburetor adjustments.

Two of the vent holes in the thermostat block are different from those on the 314. The LaSalle block is marked "LaS" to distinguish it from the 314 block, (See Fig. 134). (A few of the first LaSalle thermostat blocks are marked "2" instead of "LaS.")

The temperatures at which the thermostats open and close are the same as on the 314 carburetor.

Lighting System




Fig. 135. Headlamp Fog Cap

1820. Bulbs

The bulbs listed in §820 for 314 cars, with the exception of the back-up light and running board step lights, are used on the LaSalle.




Fig. 136. Headlamp Adjusting Screws

1821. Headlamp Adjustment

The headlamps have the same two-beam feature

as 314 headlamps, but the adjusting screws are different. The tilt adjusting screw is inside the focus adjusting screw, both screws being at the extreme rear of the lamp (Fig. 136). The method of adjustment is the same as for 314.

1822. Headlamp Conduits

The nickel-plated tubes below the headlamps are conduits for the headlamp wires. The con-



Fig. 137. Disconnecting Wires on Headlamps

nectors are at the lower ends of these conduits. To disconnect the wires, first remove the screws in the flanges support at the bottom of the conduit, then pull down on the conduit to disengage the upper end and tilt it to one side (Fig. 137). The flanged support can then be raised high enough to separate the two halves of the connector.



LA SALLE LUBRICATION SCHEDULE

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____ DATE DELIVERED _____

DO NOT WAIT FOR SCHEDULE LUBRICATIONS BEFORE ADDING ENGINE OIL. THE OIL LEVEL SHOULD BE CHECKED EVERY 100 TO 150 MILES AND OIL ADDED IF THE INDICATOR BALL IS BELOW "FULL". THIS IS ESPECIALLY IMPORTANT ON CARS DRIVEN AT HIGH SPEEDS.		LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE															
			1				2				3				4			
			1000	2000	3000	4000	1000	2000	3000	4000	1000	2000	3000	4000	1000	2000	3000	4000
LUBRICATION NO. 4	LUBRICATION NO. 2	ADD ENGINE OIL AS NECESSARY	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		GENERATOR AND DISTRIBUTOR OIL CUPS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		FAN—ADD ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		ENGINE REAR SUPPORTS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		BRAKE PINS AND CONNECTIONS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		SPRING LEAVES	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		DOOR HARDWARE	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		GREASE GUN CONNECTIONS (EXCEPT WATER PUMP)	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		WATER PUMP	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		*ADD WATER TO STORAGE BATTERY	DISTILLED WATER	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	CHECK TIRE INFLATION		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	LUBRICATION NO. 1 & 3	DRAIN AND REPLACE ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		CLUTCH THRUST BEARING	FIBRE GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		TRANSMISSION—ADD LUBRICANT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		REAR AXLE—ADD LUBRICANT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		STEERING GEAR—ADD LUBRICANT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		REAR WHEEL BEARINGS	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		FRONT WHEEL BEARINGS	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		SPEEDOMETER DRIVE SHAFT	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:
REMOVE OIL PAN AND CLEAN PAN AND SCREEN—ONCE A YEAR OR WHENEVER OIL FILTER IS CHANGED.
THIN REAR AXLE AND TRANSMISSION LUBRICANT AS REQUIRED FOR LOW TEMPERATURES.
DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING.

*IN SUMMER INSPECT BATTERY EVERY 500 MILES OR AT LEAST EVERY TWO WEEKS.

RECORD ON OTHER SIDE

FORM NO. 102-A
ISM 4-27 SPC.

Fig. 138. Facsimile of Lubrication Record Card

Lubrication

Engine Lubrication

1846. Oil Circulation

The oil circulation in the LaSalle engine is the same as that in 314 engines after engine unit 1-41001 except in one particular. Instead of a separate lead from the rear end of the header pipe to a fitting on the crankcase, there is a tube-cast in the crankcase between the rear main bearing and the camshaft rear bearing. The oil filter and the pressure gauge are connected to a nipple which communicates directly with the rear camshaft bearing.

1847. Oil Level

The LaSalle oil pan contains eight quarts of oil when filled to the level of the screen. On the first few cars the oil level indicator is stamped "Full" and "Fill". On later cars, the oil level indicator is stamped "Full," "Fill" and "MT" (Empty).

1848. Oil Filter

The LaSalle oil filter is attached to the right-

hand crankcase support arm. It is similar in principle to the 314 filter but is not interchangeable with it. Both filters are tested in the same manner.

General Lubrication

1849. Grease Gun Connections: G (Fig. 140)

Spring bolts, steering connections, brake rocker shafts and other points are provided with connections to fit the grease gun supplied with the tool equipment. These points are indicated by "G" in Fig. 140. Chassis lubricant as described in §841 should be applied to these points with the grease gun every 1000 miles.

1850. Clutch Thrust Bearing: 3

On the first cars, the lubricating point on the clutch thrust bearing is fitted with a grease gun connection on an extension that points straight down. This is accessible after removing the small plate on the bottom of the transmission case.




Fig. 139. Showing the Location of the Oil Filler, Oil Level Indicator, Oil Pan Drain Plug and other Lubrication Features




Fig. 140. Chassis Lubrication Diagram

(Each "G" indicates a grease gun connection. Each number indicates a lubricating point for which instructions are given under "Engine Lubrication" or "General Lubrication." Lubricating points that are visible in the diagram are surrounded by circles. Others are indicated by arrows)

On later cars the extension pipe extends through the right-hand side of the transmission case and a grease cup is used instead of a grease gun connection. This grease cup can be reached from under the hood.

The clutch thrust bearing should be lubricated every 2000 miles with fiber grease.

Caution: Do not inject too much grease into the clutch thrust bearing. One or two turns of the grease gun handle or grease cup cap are sufficient.

1851. Transmission: 17

The transmission case should contain sufficient lubricant to bring the level up to the filling hole at the right-hand side. The level should be inspected every 2000 miles and chassis lubricant added if necessary.

If, in cold weather, the transmission gears are difficult to shift, the lubricant should be thinned by the addition of kerosene. On the return of warm weather in the spring, the drain plug should be removed from the bottom of the transmission case and the lubricant should be drained and replaced with fresh lubricant. One and one-half quarts of lubricant are required to fill the transmission case to the proper level.

1852. Rear Axle: 19

The rear axle housing should contain enough lubricant to bring the level up to the filling hole in the rear cover plate. The level should be inspected every 2000 miles and chassis lubricant added if necessary.

In weather cold enough to warrant thinning the transmission lubricant the lubricant in the rear axle should also be thinned. On the return of warm weather in the spring the drain plug should be removed from the bottom of the axle housing and the lubricant should be drained and replaced with fresh lubricant. Three quarts of lubricant are necessary to fill the rear axle housing to the proper level.

1853. Front Wheels: 6, 12

The wheel bearings are packed in grease when the car is assembled. Every 4000 miles the front wheels should be removed and the bearings should be thoroughly cleaned in gasoline or kerosene, and then repacked with wheel bearing and cup grease.

1854. Rear Wheels: 2, 18

Every 4000 miles the screw plugs in the rear wheel hubs, should be removed and chassis lubricant should be injected with the grease gun. On cars with wire wheels, the wheels must be removed to reach the plugs in the hubs. On cars with disc wheels the hub caps and hub shields must be removed.

1855. Steering Gear: 5

The grease gun connection for adding lubricant to the steering gear is on top of the housing just at the base of the steering column. Chassis lubricant should be added every 2000 miles. If, in cold weather, the car steers hard, the lubricant should be thinned by the addition of kerosene (§842-a).

1856. Speedometer Flexible Drive Shaft

The flexible shaft by which the speedometer is driven is housed in a flexible casing. To lubricate the speedometer drive shaft, the shaft should be removed from its casing and lubricant applied to it for its entire length. Cup grease is recommended for this lubrication, which should be performed every 4000 miles.

Do not under any circumstances attempt to lubricate the speedometer itself. Any parts in the speedometer requiring lubrication are amply supplied when it is assembled.

1857. Springs: 1, 7, 11, 20

To lubricate the spring leaves, it is recommended that the edges and ends of the leaves be painted with engine oil every 1000 miles. A small stiff brush should be used. After applying the oil, the car should not be washed until it has been driven far enough to allow the lubricant to work in between the leaves. Do not separate the leaves and insert lubricant. A certain amount of friction between the spring leaves is necessary in order to give the springs the desired characteristics.

If spring covers are used, it is not necessary to lubricate the spring leaves as directed in the preceding paragraph. It is sufficient to repack the springs once a season with petroleum jelly.

1858. Stabilators

The stabilators, with which the car is equipped and which are for the purpose of controlling the recoil of the springs, not only need no lubrication

—they *must not* be lubricated. To lubricate the stabilators would defeat their purpose just as oil or grease on the brakes would prevent them from holding.

1859. Door Hardware

Whenever the chassis is being lubricated, the door locks and other door hardware should also be lubricated as follows:

Place a few drops of oil on each door lock plunger or striker, turning the handle back and forth so that the oil will work into the lock. Also place a drop of oil on each of the striker plates

against which the strikers engage when the doors are closed. The hinge pins should also be oiled sparingly so as not to get oil on the finish.

Each door has a wedge-shaped tongue that dovetails into a receptacle on the body when the door is closed. These tongues should receive a small amount of grease or oil.

Each closed car door is also fitted with a check at the top which limits the outward movement of the door. A small amount of grease should be applied to the pin that slides in the slot at the top of the door.




Fig. 143. Sectional View of LaSalle Steering Gear

Spring Suspension

1880. Rear Spring Shackles

The shackles at the rear ends of the rear springs are the same type as is used on the 314 at this point. The adjustment is covered in §880.

On the LaSalle, shackles are also used at the front ends of the rear springs because the drive




Fig. 141. Rear Spring Front Shackle

is through the torsion arm rather than through the rear springs. This shackle is shown in Fig. 141.

To facilitate removal of the shackle a hole is drilled in the side bar of the frame opposite the lower bolt. The bolt can be driven through this hole by using a drift inserted through the hole in the dust shield. Wrench 109200 is designed for the nut on this bolt.

When removing the rear spring, drive out the lower bolt, removing the shackle with the spring. The upper bolt and shackle can then be removed.

1881. Front Spring

The shackles at the rear ends of the front springs are the same as on the 314. The construction at the front ends of the front springs is shown in Fig. 142. The inner ends of the

spring bolts are carried in floating sleeves which are free to move in the outrigger. End play in the spring can therefore be taken up simply by tightening the nut on the bolt. Care should be taken not to get the nut tight enough to bind the spring.

1882. Stabilizers

The rear stabilizers on the LaSalle should be adjusted to 28 lbs. tension, the front stabilizers to 32 lbs.




Fig. 142. Sectional View of Front Spring Shackle

LA SALLE

Steering Gear

1900. Description

The LaSalle steering gear is the same as used on 314 cars after steering gear unit 1-44025, except that the column has no spark control tube. The adjustments are made in identically the same manner.

1901. Removal of Steering Gear

Before the LaSalle steering gear can be removed the brake rod and idler lever on the left-hand side must be removed. This idler lever is attached to the left-hand side bar just ahead of

the steering gear. The steering gear can then be removed in the same manner as on the 314 cars after steering gear unit 1-44025.

1902 Steering Connecting Rod

Fig. 144 shows a sectional view of the LaSalle steering connecting rod. The spacers (2 and 6) perform the same function as the spacer (4, Fig. 91-a) in the 314 rod. In adjusting the screw plugs, tighten the plug as far as it will go, then back it off one cotter pin hole. This will allow the pivot seats the proper amount of movement.




Fig. 144. Section of Steering Connecting Rod

Transmission

1960. Removal of Transmission Assembly

To remove the transmission, the rear axle and torsion tube must first be removed. The procedure thereafter is as follows:

Remove the floor boards.

Remove the control lever and brake lever assembly by removing the four nuts which hold the top cover to the transmission case.

Disconnect the speedometer cable.

Remove the clutch pedal. (The brake pedal cannot be removed until the transmission has been removed.)

Remove the starting motor.

Remove the hand hole cover over the clutch.

Remove the bolts that fasten the transmission case to the crankcase.

Pull the transmission back and out, taking care to support it so it does not drop.

1961. Removal of Clutch Connection

After removing the transmission from the car, the clutch connection can be removed as follows:

Remove the clutch. Puller 109409 is necessary for this.

Disconnect the pull-back spring from the clutch thrust bearing and remove the bearing from the support on which it slides.

Remove the four nuts that hold the thrust bearing support to the transmission and remove




Fig 145. Sectional View of Transmission

the support. The clutch connection with the ball bearing on it can then be removed.

The retaining nut which holds the bearing on the clutch connection can be removed with wrench 83224 provided it has the adapter for 314 cars.

1962. Removal of Main Shaft

After removing the rear axle and torsion tube, proceed as follows to remove the transmission main shaft:

Remove the four screws which hold the rear half of the socket member of the transmission case. The main shaft with the universal joint and its housing, the speedometer drive and the main shaft bearing can then be removed as a unit. Care should be taken not to let the shipper gears drop when pulling the shaft out.

To disassemble the shaft and universal joint, proceed as directed in §1967.

1963. Removal of Shipper Gears

The shipper gears can be removed after removing the main shaft and the jackshaft gears.

1964. Jackshaft and Jackshaft Gears

The jackshaft gears are removed in the same manner as on 314 cars except that there is no locking screw for the jackshaft. The cover plate for the jackshaft acts as a lock to keep the jackshaft from turning.

Puller 100228 can be used for removing the jackshaft but in order to use this puller the main shaft and universal joint assembly must first be removed to avoid interference between the puller and the socket members.

Universal Joint

1965. Description

Only one universal joint is used on the LaSalle. This is housed in a ball and socket joint at the rear of the transmission and is lubricated by the lubricant in the transmission.

The front yoke of the universal joint is a tight fit on the splined end of the transmission main shaft. The rear yoke is splined to receive the splined end of the drive shaft.

The socket member is bolted to the transmission case, and acts also as a retainer for the rear transmission bearing. The ball member is fastened to the front end of the torsion tube.




Fig. 146. Sectional View of Universal Joint

1966. Adjustment of Ball and Socket Joint

The ball member should have no end play in its socket but it should not be so tight as to bind. To take up excessive end play, remove the screws which hold the two halves of the socket member together and take out one or more of the paper gaskets (12, Fig. 146). Cars are assembled at the factory with 3 gaskets at this point.

1967. Removal and Disassembly of Universal Joint

Remove the rear axle and torsion tube and remove the transmission main shaft and universal joint assembly as directed in §1962.

Remove the four screws which hold the two halves of the socket member together and remove the rear half and the ball member.

Remove the screws which hold together the two flanges of the universal joint. Remove the nut (6) with wrench 109417. The universal joint can then be removed from the main shaft by pulling with puller 109209.

1968. Inspection

There should be no more than .003 inch clearance between the splines on the drive shaft and the splines in the universal joint yoke.

The front yoke should be a snug fit on the end of the transmission main shaft.

There should be no more than .002 inch clearance between the yoke pins and the joint rings.

There should be no more than .010 inch clearance between the rear yoke in the universal and the bronze bushing in the ball member.

Examine both the oil and drain hole.

1969. Installation

When assembling and installing the universal joint, place the proper number of gaskets between the two halves of the socket member so that there

will be no play in the ball joint and yet so it will not bind.

If a new bushing is installed in the ball member, be sure to place it in the proper position with relation to the ball member. The front end of the bushing is marked "Top-Front." The rear end of the ball member is marked "Top." Install the bushing with "Top-Front" in line with "Top" on the ball member but at the opposite end so that "Top-Front" will appear from the inside of the ball member after installation.

Before connecting the torsion tube to the ball member, be sure the word "Top" on the ball member is uppermost.

Wheels, Rims and Tires

2020 Tire Inflation Pressure

The recommended inflation pressure for LaSalle cars is 40 lbs, front and rear.

Front Wheels

2021 Removal and Bearing Adjustment

The LaSalle front wheel bearings are ball bearings and must not be adjusted as tightly as tapered roller bearings. The nut should be drawn up just tight enough to take up all play in the bearings and then backed off one cotter pin hole.

To remove a front wheel, proceed as follows:

Remove the hub cap and adjusting nuts. (The left-hand spindle has a left hand-thread.) The right-hand spindle has a right-hand thread.

Remove the wheel with ball races and outer cone.

To reach the spindle nut on a car with wire wheels, the dust cap in the wire wheel hub must be removed. Wrench 109405 fits this nut.

When installing, be sure the bearings are clean and that they are packed in grease free from dirt and grit. Do not adjust bearings too tightly.

Rear Wheels

2022 Removal

The rear wheel bearings are single-row ball bearings and require no adjustment. Should it be necessary for any reason to remove a rear wheel, first remove the axle shaft (§1230). Then unscrew the nut on the end of the axle housing and pull the wheel off. The right-hand nut has right-hand threads and the left-hand nut left-hand threads. If the bearing is to be removed, it should be driven out.

2023 Installation

When installing the rear wheels, tighten the large nut on the axle housing as tight as possible and lock it with the washer. This nut does not adjust the play in the bearing and it does not require backing off as in the case of the front wheels.

L A S A L L E

Inspection and Adjustment Limits

Axle, Front

Front wheel toe-in..... $\frac{1}{8}$ – $\frac{3}{8}$ inch

Axle, Rear Clutch

Clutch pedal free movement 1 inch
Clutch spring compression at $2\frac{1}{8}$ inches Not under 420 lbs.

Electrical

Generator

Charging rate..... 18–20 amps., thermostat closed

Starting Motor

Tension of brush arm springs..... $2\frac{1}{4}$ – $2\frac{1}{2}$ lbs.

Ignition

Gap between timer contact points027 inch
Tension of contact arm springs 16–20 ozs.

Circuit Breakers

Vibrating circuit breaker starts..... 25–30 amps.
Lockout circuit breaker opens 25–30 amps.

Engine

Main and Connecting Rod Bearings

Cylinders and Pistons

Limits for standard cylinder bore (see §1537)..... 3.1250–3.1270 inch
Cylinder bore, out-of-round..... Not over .002 inch
Piston out-of-round..... Not over .001 inch
Clearance between piston and cylinder (measure with feelers)..... .002–.003 inch
Clearance between ends of piston rings..... .005–.015 inch
Clearance between wrist pin and piston See § 1537
Clearance between wrist pin and bushing in connecting rod See § 1537
Clearance between crankshaft and main bearings..... .0015–.002 inch
End play in crankshaft..... .005–.010 inch
Clearance between crankpin and connecting rod bearing..... .0005–.0015 inch
End play in connecting rods..... .005–.011 inch

Valve System

Camslide or valve stem clearance, inlet valve..... .004 inch when cold
Camslide or valve stem clearance, exhaust valve..... .006 inch when cold
Compression of valve spring at $2\frac{3}{4}$ inch..... Not under 133 lbs.
Clearance between camslide and guide..... Not over .004 inch
Clearance between camslide roller and pin..... Not over .003 inch
Clearance between water pump and gen. drive sprocket and support..... .003–.005 inch
Clearance between camshaft and bearings..... .0024–.0032 inch
End play in camshaft004 inch
Clearance between splines of drive shaft and splineways in the yoke of universal joint Not over .005 inch
Clearance between universal joint yokes and rings001–.0025 inch

Oil Pump

Clearance between outside diameter of oil pump gears and oil pump body..... .003–.005 inch
End play in oil pump gears..... .005–.0125 inch
Thickness of oil pump gasket..... .009–.011 inch

Water Pump

Clearance between water pump shaft and bushings001-.003 inch

Oil Pressure Regulator

Oil pressure at idling speed7-10 lbs.

Gasoline System**Carburetor**

Adjustment of enriching device:

Opening of air valve at 65°-85° F.	$\frac{1}{8}$ - $\frac{1}{16}$ inch
Throttle pump control thermostat closes	74° F.
Throttle pump control thermostat opens	78° F.
Vent control thermostat closes	125° F.
Vent control thermostat opens	130° F.
Float setting	$\frac{1}{16}$ - $\frac{1}{8}$ inch
Throttle pump adjusting screw fully open	7 turns
Clearance between throttle disc and mixing chamber	Not over .005 inch
End play in throttle shaft	Not over .004 inch
Clearance between throttle shaft and bushings	Not over .005 inch

LIBRARY REFERENCE COPY

NOT TO CIRCULATE

1927 - 1928 LaSalle Production

Total Production: 26,804 automobiles and chassis (three serial numbers not used.)

Serial Numbers: 1927 - 200001 thru 216850.

1928 - 216851 thru 226807.

The Vehicle (engine) serial number is stamped "On the name plate on the front face of the left side of the dash and on the crankcase just below the water inlet on the right-hand side."

Chassis Numbers: Start with prefix "2 -" and increase from the first unit, which has chassis number "2-27." The numbers are not sequential. Location of chassis unit number is "on the upper surface of the right-hand side bar just in front of the oil filter."

Body Plates: Fisher job/style number (e.g., 1168) or Fleetwood job number (e.g., 3751) and body serial number are on the body plate attached "to the front face of the left side of the dash" (in the engine compartment.)

<u>Body Type and Style Numbers:</u>	<u>1927</u>	<u>List Price</u>	<u>1928</u>	<u>List Price</u>	<u>W.B.</u>	<u>Production</u>
<u>Series 303 (LaSalle) Fisher Bodies</u>		(various dates)		(Jan. 4, 1928)		
4-Pass. Phaeton	1168	\$2495.00	1168	\$2485.00	125"	1575
4-Pass. Sport Phaeton (dual cowl)	1168-B	\$2995.00	1168-B	\$2975.00	125"	270
2-Pass. Roadster	1169	\$2525.00	1169	\$2485.00	125"	1184
5-Pass. Sedan (metal back)			8110	\$2495.00	125"	763
5-Pass. Family Sedan (metal back)			8110-A	\$2350.00	125"	2720
5-Pass. Sedan (leather back)	7380	\$2685.00			125"	5001
5-Pass. Sedan (leather back)	8120		8120	\$2495.00	125"	1823
4-Pass. Victoria (Coupe, leather back)	7390	\$2635.00			125"	1250
4-Pass. Victoria (Coupe, leather back)	8130		8130	\$2550.00	125"	405
2-Pass. Convertible Coupe	7400	\$2635.00	7400	\$2550.00	125"	3001
2-Pass. Coupe (leather or fabric back)	7410	\$2585.00			125"	1100
2-Pass. Coupe (leather back)	8140		8140	\$2450.00	125"	527
2-Pass. Business Coupe (leather back)			8140-A	\$2350.00	125"	446
5-Pass. Town Sedan (metal back)	7420	\$2650.00	7420	\$2495.00	125"	1600
5-Pass. Coupe (metal back)			8050	\$2625.00	134"	1001
7-Pass. Sedan (metal back)	8060	\$2795.00	8060	\$2775.00	134"	1666
7-Pass. Family Sedan (metal back)			8060-A	\$2575.00	134"	1064
7-Pass. Imperial Sedan						
(div., metal back)	8070	\$2895.00	8070	\$2875.00	134"	485
5-Pass. Cabriolet Sedan			8080	\$2675.00	134"	500
(leather back, blind qtrs.)						
5-Pass. Imperial Sedan	8090	\$2795.00	8090	\$2775.00	134"	210
(division, leather back, blind qtrs.)						
Touring (non-production body)				Not listed	134"	1
Chassis				Not listed	125"	55
Chassis				Not listed	134"	34
Unidentified units						65
<u>Series 303 (LaSalle) Fleetwood Bodies</u>						
5-Pass. Transformable Town Cabriolet	3051	\$4700.00	3051	\$4700.00	125"	9
(front door crank-up windows)						
2-Pass. Coupe	3110	\$3600.00	3110	\$4275.00	125"	12
5-Pass. Sedan	3120	\$3800.00			125"	13
5-Pass. Town Cabriolet	3130	\$5000.00	3130	\$4500.00	125"	22
(front compartment wing windows)						
5-Pass. Transformable Town Cabriolet			3751	\$4800.00	134"	2
(front door crank-up windows)						
Total						26,804

Canadian (Oshawa, Ontario) built units. (Identified units are included in the production totals above):

5-Pass. Sedan (leather back)	7380			125"	41
2-Pass. Convertible Coupe	7400		7400	125"	16
7-Pass. Sedan (metal back)	8060		8060	134"	18
5-Pass. Sedan (metal back)	8110		8110	125"	24
5-Pass. Sedan (leather back)			8120	125"	4
Unidentified					57
Subtotal					160

Cars were assembled at Oshawa on complete chassis shipped from Detroit. Shipments of as few as three and as many as twenty-five chassis in a group are listed in the serial ledgers. Some cars were subsequently recorded in the Detroit records by body style, body number and other details. It is likely that many of the unidentified units were style 8110 5-passenger Sedans or style 8060 7-passenger Sedans, and account for most of the unidentified 65 cars in the overall production total.

<u>Upper Panels</u>	<u>Paint #</u>
Ardsley Green	2443038
Black	
Black	
Black	
Ching Blue	2441282
La Force Gray	2441765
Senator Green	2441306

<u>Lower Panels</u>	<u>Paint #</u>
Canoe Brook Green	2441638
Black	
Derby Red, Medium	2443336
Vineyard Lake	2443089
Norse Blue	2441467
La Force Gray	2441765
Desert Sand	2441313

Fender set in black enamel is standard with all body colors, special color fenders at additional list charge of \$85.00
 Chassis is finished in black, but special color may be had at additional list charge of \$15.00

Trim Options

LaSalle Fisher Bodies

Open/Convertible bodies - job/style: 1168, 1168-B, 1169, 7400

18 T 1327 Green Leather
 19 T 1327 Blue Leather
 20 T 1327 Tan Leather (finish not indicated)
 21 T 1327 Gray Leather
 22 T 1327 Black Leather
 23 T 1327 Red Leather
 26 T 1327 Tan Leather (finish not indicated)

Top: 16 T 1527 Drab-duck (khaki)
 6 T 1527 Black (optional)
Rumble Seat: 35 T 1227 Black Imitation Leather

Closed bodies - job/style: 7380, 7390, 7410, 7420, 8050, 8060, 8070, 8080, 8090, 8110, 8120, 8130, 8140

68 T 127 Cloth (color and type not listed)	84 T 127 Brown & Tan Mohair
70 T 127 Green-Gray Mohair	85 T 127 Tan Mohair
71 T 127 Plush (Mohair, color not listed)	32 T 128 Blue Mohair
80 T 127 Blue-Gray Mohair	36 T 128 Bedford Cord Cloth (color not listed)
81 T 127 Taupe Mohair	

1928 Family Sedan and Business Coupe closed bodies - job/style: 8060-A, 8110-A, 8140-A

112 T 128 Broadcloth (color and type not listed)

Note: The above trim numbers are from Trim Charts #1 and #2 of the Fifth Edition, *Cadillac Master Body Parts List*, March 1936, which does not contain material type and color descriptions. Descriptions are included where positive correlations from other records can be established. Factory documents describe available 1927-1928 Fisher body trims in general terms as Mohair, Wool Velour, Broadcloth or Worsted; two-tone Bedford Cords for owner driven cars; hair-line broadcloths, figured cloths, doeskin broadcloths in light drab shades for Cabriolets; Mohair Worsted Velvet and Cotton Velvet.

LaSalle Fleetwood Bodies

"Trim options include four broadcloth materials of special weave offered exclusively on Cadillac/LaSalle Fleetwood bodies:

2423-24 Mouse-gray broadcloth	2427-28 Fawn-gray broadcloth
2425-26 Tan broadcloth	2429-30 Gunmetal-gray broadcloth

In addition, two new mohair materials have been especially developed, one in fawn and the other in green." Source: *Distributors Convention*, August 30 - September 1, 1927

Standard and Optional Equipment

Standard Equipment: Five wood wheels (except Sport Phaeton), size 32 X 600/32 X 620; rear spare tire carrier.

Optional Equipment:

Wood wheels - natural (instead of painted)	\$ 10.00
Five disc wheels, 32 X 600/32 X 620	No charge
Five wire wheels, 32 X 620	\$ 95.00
Six disc wheels, fenderwells and 2 spare tires	\$150.00
Six wire wheels, fenderwells and 2 spare tires (standard equipment on Sport Phaeton only)	\$250.00
Fenderwells for wood wheels, 2 spare tires	\$140.00
Folding Trunk Rack (standard equipment on Sport Phaeton only)	\$ 35.00
Running Board Searchlight (standard equipment on Sport Phaeton only)	\$125.00
Special Trunk	\$ 75.00

"Cadillac Motor Car Co. announces it is offering high compression heads and a low gear ratio for LaSalle roadsters and phaetons. The new high compression heads will have a ratio of 5.1 to 1. The new gear ratios are 4.0 to 1. Extra cost for this equipment is \$125.00. When such equipment is used, the factory recommends the purchase of wire wheels, due to the higher speeds and acceleration. These wheels are offered at \$95.00 additional, bringing the total cost of this high speed equipment to \$220.00." *Automobile Trade Journal*, September 1927.

Research Methodology: Microfilm copies of the ledger records of the as-built configuration of each serial number were individually viewed. All record sheets were accounted for. Three serial numbers were not used in production. All Fleetwood body styles were recorded by serial and body number to determine the quantity of each body style built. All chassis were recorded by serial number. Because of shared body number sequences and unusual body numbers, Fisher body styles 1168-B, 8060, 8060-A, 8110, 8110-A, 8120, 8130, 8140 and 8140-A were individually recorded to determine actual production totals. No attempt was made to construct cross reference lists of the other Fisher body numbers with corresponding engine numbers to account for the 65 unidentified vehicles. The Canadian assembled cars that are not identified by body style undoubtedly result in somewhat understated production totals by body style.

1. 1927-1928 model distinctions. There is a long running discussion among enthusiasts and automotive historians as to which cars are 1927 LaSalle and which are 1928's. Automotive historians have published differing views. All known factory records have been carefully studied in an attempt to resolve the discussion. We are all accustomed to thinking of cars as specific **model years**, irrespective of when they were built or shipped to the dealers. Cadillac Motor Car Company does not appear to have distinguished between 1927 and 1928 LaSalle by model year. Therein lies the problem. A cursory review of Cadillac serial numbers from 1902 through 1927 will demonstrate that model year designation was not the norm; automobile production was recorded by **calendar year**. Introduction of the LaSalle on March 5, 1927, with subsequent introduction of the new Cadillac series 341 on September 1, 1927, resulted in the model year confusion that was not clarified until the introduction of the 1929 models of both marques.

Production was continuous from the first 1927 LaSalle built through the last 1928, with no break in the engine serial numbers and many body style changes. In all subsequent years of LaSalle production, there is a distinct break between model years, with a change in the prefix of the engine serial number group (e.g., 4----- in 1929; 6----- in 1930; 220---- in 1935; 221---- in 1936.)

Undated factory distribution summaries, labeled *10 Day Pre-War*, list 1927 production of 10,767 LaSalle and 1928 production of 16,038 LaSalle, for a total of 26,805, which is within one car of matching the actual record count. Using the 10,767 number for the end of the 1927 LaSalle, (some historians have) would put the start of 1928 production in late July 1927, less than five months after the March 5, 1927, introduction. There is no apparent basis for selecting serial #210767 as a break between 1927 and 1928 cars. Serial numbers for all of the early body styles continue well beyond the 10,767 point; none of the additional or new-for-1928 body styles were ready for shipment and dealers had not seen or been able to order the new styles.

The Distributors Convention was held in Detroit from August 30-September 1, 1927. The new Cadillac series 341 models were on display, along with thirty-two LaSalle display models. The convention handouts indicate in part: "The number assigned to each specification corresponds with the number on the tag of each car and may be used for convenience in ordering duplicates on any job shown." "Three welcome additions to the LaSalle line are announced. The 5-passenger Imperial Sedan (style 8090), 7-passenger Sedan (style 8060) and 7-passenger Imperial Sedan (style 8070) are all mounted on the 134" wheelbase." Although no delivery dates are indicated, the implication is that LaSalle Distributors could immediately order the new body styles. The convention handouts show side views of body styles with features common to 1928 but do not say that the new LaSalle styles offered are 1928 models. Initial shipment of six added or changed body styles (8120, 8130, 8140, 8060, 8070 and 8090) commenced in late August/early September 1927. Early serial number cars in those styles can be considered to be 1927 models that continue into the new calendar year as 1928 LaSalle. A 1927 model year from March through December 1927 (out of 19 months of shipments) seems reasonable.

Record analysis reveals a series of running changes to various components (not unlike current manufacturing), with an overlap in the building of new body styles that are distinctly 1928 models and the phaseout of distinctly 1927 body styles. The running changes are reflected in the multiple editions of the LaSalle Operators Manual for the Series 303, which indicate applicability by engine serial number. Sales of the LaSalle were far greater than expected and all existing stocks of bodies and components were apparently utilized in a seamless transition to the 1928 LaSalle. "Due, the company says, to unexpected sales volume which the LaSalle has enjoyed since its introduction last March - 15,000 having been sold in nine months instead of a year as anticipated - it has been possible to materially lower the prices of the other LaSalle models." Source: *Automobile Topics*, January 7, 1928. Factory list prices for 1928 were reduced from the 1927 introductory level.

Although there is no perfect fit in terms of the introduction of additional body styles, discontinuation of early body styles, mechanical component changes, etc., accepting a break point recorded by Cadillac Motor Car Company is the only reasonable differentiation between 1927 and 1928 LaSalle. The records do not show the date that vehicles were built, only the date they were shipped. Cars were shipped as late as December 31, 1927, with serial #216954 being the highest number shipped in 1927. Shipments resumed on January 3, 1928. *Cadillac-LaSalle Facts*, a vest pocket booklet produced by Cadillac Motor Car Company in early 1928, lists both the Cadillac 341 and LaSalle 303 cars shipped through the end of the year as 1927 cars and lists 1927 LaSalle engine numbers as serial #200001 to #216955 (which was shipped on 2/14/28). The *Cadillac Master Parts List* shows engine serial #216851 as the first 1928 LaSalle. Serial #216851 is the **third** serial number shipped on January 3, 1928, which makes that change point appear to be totally arbitrary. Eighty-five cars with serial numbers higher than #216851 were shipped in December 1927 and thus obviously built sometime in 1927.

Initial shipments of six new body styles (8110, 8110-A, 8140-A, 8050, 8060-A and 8080) began between December 22, 1927, and January 17, 1928. Switching from a **calendar year** to a **model year** designation, beginning with the resumption of production in calendar 1928 and the sale of six new body styles, aligns the LaSalle with Cadillac designations for all future models. It is a logical choice. Lacking further documentation, the Cadillac-LaSalle Club, Inc., has chosen to accept the January 3, 1928, change point as the beginning of the 1928 LaSalle model year. Any date accepted necessarily results in some number of cars being improperly categorized when considered only on the basis of serial number, shipping date or body style.

2. Body Styles. The array of Fisher body styles is confusing at the very least, due to mid and late calendar year body style changes and additions, the appearance that Cadillac selected an arbitrary serial number to designate 1928 cars and the addition of distinctly 1928 body styles. A simplified breakdown follows:

<u>1927 early Fisher body styles</u>	<u>Style #</u>	<u>W.B.</u>	
4-Pass. Phaeton	1168	125"	Retained through 1928
4-Pass. Sport Phaeton (dual cowl)	1168-B	125"	Introduced in July 1927, retained through 1928
2-Pass. Roadster	1169	125"	Retained through 1928
5-Pass. Sedan (leather back)	7380	125"	Replaced by style 8120, Sept. 1927
4-Pass. Victoria (Coupe, leather back)	7390	125"	Replaced by style 8130, Sept. 1927
2-Pass. Convertible Coupe	7400	125"	Retained through 1928
2-Pass. Coupe (leather or fabric back)	7410	125"	Replaced by style 8140, Sept. 1927
5-Pass. Town Sedan (metal back)	7420	125"	Introduced in July 1927, retained through 1928

5-Pass. Sedan (leather back)	8120	125"	Slight changes from style 7380, see note below
4-Pass. Victoria (Coupe, leather back)	8130	125"	Slight changes from style 7390, see note below
2-Pass. Coupe (leather back)	8140	125"	Slight changes from style 7410, see note below
7-Pass. Sedan (metal back)	8060	134"	Announced at Distributors Convention, Aug. 1927
7-Pass. Imperial Sedan (metal back)	8070	134"	Announced at Distributors Convention, Aug. 1927
5-Pass. Imperial Sedan (leather back, blind qtrs.)	8090	134"	Announced at Distributors Convention, Aug. 1927

1928 new Fisher body styles

5-Pass. Sedan (metal back)	8110	125"	First car shipped December 31, 1927
5-Pass. Family Sedan (metal back)	8110-A	125"	Announced January 1928
2-Pass. Business Coupe (leather back)	8140-A	125"	Announced January 1928
5-Pass. Coupe (metal back)	8050	134"	Announced January 1928
7-Pass. Family Sedan (metal back)	8060-A	134"	Announced January 1928
5-Pass. Cabriolet Sedan (leather back, blind qtrs.)	8080	134"	Announced January 1928

Note: "Slight changes have been made in the 2-passenger Coupe, 4-passenger Victoria and 5-passenger Sedan. The radius of the curve at the rear of the roof has been slightly lessened, giving a lower appearance to the body; dark glass sun visors have been substituted; and cowl ventilators opening to the rear have been located on each side. These changes in design are made to correspond with the design of the three new models. Wide auxiliary seats are supplied in the 7-passenger Sedan and 7-passenger Imperial." Source: *Distributors Convention*, August 30 - September 1, 1927.

"Five new LaSalle models have been perfected and put on the 1928 market by Cadillac Motor Car Co." Source: *Automobile Topics*, January 7, 1928. (No mention of the style 8110 5-Pass. Sedan as a new model.)

Visually, the most recognizable distinction between early 1927 and late 1927/1928 models is the change from an engine hood with 12 louvers on each side for 1927, to a hood with 28 louvers on each side and the addition of cowl ventilators opening to the rear on closed body styles. There are surviving cars with serial numbers in the 1927 block that have the later hood, Electrolock ignition, carburetor heat control, new type chassis and brakes, etc. On the mechanical level, the 1928 units principally have the twin disc clutch instead of the eleven disc clutch, Lovejoy hydraulic shock absorbers instead of Watson stabilators and 16-inch front brake drums instead of 14-inch.

3. Vehicle Records. The 1927 and 1928 LaSalle's are recorded as hand-written, single-line, two-page entries in large leather bound ledgers. The data elements listed are: Engine Number / Date Shipped / Shipped to Distributor at / Delivered to / City and State / Date Delivered / Type (style #) / Number (body #) / Upholstery / Top / Center & Lower Panels (color name) / Stripe / Moulding / Lock No. / Wheels - Type & Size, Color, Stripe, Hubs / Radiator & Lamps (nickel plated) / Gear Ratio / Frame Number / Engine Unit Number / Front Axle Number / Rear Axle Number / Transmission Number / Carburetor Number / Steering Number / Generator Number / Extra Equipment / Car Cover / Decking Charge.

In practice, the last three blocks of the ledger were used for notes including hood and cowl color, fenderwells and trunk rack, high compression cylinder heads if so equipped, etc.

Very few of the records were filled in to indicate the Delivered to / City and State / Date Delivered information. After serial #212000, those three data elements were eliminated in a new ledger. Less than one hundred vehicles are annotated with the name of the original purchaser; most of whom were factory or other General Motors employees. Harley Earl received a style 8090 5-Passenger Imperial Sedan. Nine vehicles were charged to the factory accounts of the Fisher brothers.

Some highly unusual record changes were entered in the vehicle ledgers, changing the body style notations as a result of modifications made by dealers. Two particularly odd entries are changes from a 7-Pass. Sedan (8060) and 7-Pass. Family Sedan (8060-A) to five-passenger styles 8110 and 8110-A with the notation "Auxiliary seats removed by Don Lee" (the Los Angeles based distributor). The seven-passenger body is physically longer than the five-passenger body and thus the style number change is inappropriate. Three 5-Pass. Imperial Sedans, style 8090, were annotated "Body style changed by dealer from Imp 5 Sedan to Cabrio." and the body style changed to 8080. Removal of the Imperial Partition would make that physical change and be an appropriate style number distinction. It is unlikely that any of the body tags were changed.

4. Color. No listing of standard color combinations for the complete 1927 and 1928 LaSalle model years could be located. To determine the probable standard colors and entire range of color combinations, body color listings (upper panel/lower panel) were recorded. Black is standard for all years. Six combinations are rubber stamped in the ledgers and are obviously standard. All other entries are hand written. Thirteen other combinations were found on more than 500 cars each, one on 463 cars, and one on 372 cars. All of those colors are probable standard colors and so listed below. New apparently standard colors were introduced throughout the production run. A total of 482 color combinations were found to have been applied to the 1927-1928 cars. Many of the combinations were special orders found on a single car. Other colors were found on as many as 174 cars, which is less than one percent of total production and thought to not represent a standard color.

Cadillac Motor Car Company maintained a policy of discouraging the use of what they considered to be non-durable paint colors, to the point of declining orders to paint cars in such finishes. Fifty-three cars (eleven body styles) were shipped to dealers with the body in primer "Rubbed out of rough stuff" for local finishing as arranged by the dealer or purchaser.

(probable) Standard Color Combinations

<u>Upper Panels</u>	<u>Paint #</u>	<u>Lower Panels</u>	<u>Paint #</u>
Algerian Blue	1254	Algerian Blue	1254
Black		Bolling Green	1331
Black		Calumet Blue	20235

Black		Phantom Gray	2443356
Black		Powder Blue	3116
Black		Wissahickon Green	20366
Bruce Green	2441723	Cape Smoke	2441482
Czarina Beige	2443009	Cossack Brown	2441322
Czarina Beige	2443009	Czarina Beige	2443009
Dustproof Gray	2441274	Dustproof Gray	2441274
English Gray	2441774	English Gray	2441774
Gettysburg Blue	2441205	Gettysburg Blue	2441205
Larchmont Blue	2441273	Pelham Blue	2441297 (Phaetons & Roadsters)
Lush Green	2441478	Canoe Brook Green	2441638 (Phaetons & Roadsters)
Royal Purple Lake	20528	Royal Purple Lake	20528

5. Special Features: Customer requests for non-standard upholstery material, deviations from the standard trimming methods (e.g., Cadillac style pleated and tufted), application of non-standard colors, etc., were handled by the assignment of a Fisher Order number with detailed written instructions to the body plant. None of those individual order records are known to exist for 1927-1928 LaSalle. Only a small fraction of the F.O. numbers are indicated in the ledgers, although there were many such orders as evidenced by the large volume of non-standard paint cars, which required a sixty-day delivery time. None of the individual orders for the Fleetwood bodied cars are known to exist.

Numerous cars were annotated "Natural cane work in belt panel." Four cars were fitted with a single fenderwell; three on the left side, one on the right side. A Phaeton charged to F. J. Fisher had all of the nickel parts (body and chassis) chromium plated, a precursor of the 1929 models. A style 7380 5-Pass. Sedan charged to the factory was equipped with nickel plated disc wheels and "Special walnut panels." It was probably a show car. An unorthodox combination was an 8060-A 7-Pass. Family Sedan (austere interior trim), painted Black with "Chromium plating on fenders."

Few truly custom Fisher Orders were done. A "Partition 5-Pass. Sedan 1153 LX," using a style 7380 body shell, was charged to the factory account of A. J. Fisher. The car featured: Weise cloth, Special Maroon top and body, special steering column, walnut door panels, fenderwells and trunk cover. A "Special 5-Pass. Sedan 1157LX," also using a style 7380 body shell, was built for an unknown buyer. No indication of the body modifications was listed, but the car was trimmed in "special cloth" and the body painted Willeys Pale Auto Yellow. Two special body cars were done with modified style 1168 Phaeton bodies and listed as "Double Cowl Phaeton." These likely were prototypes for the Sport Phaeton that went into production some 4600 cars later. One was charged to the factory account of John J. Raskob (GM Executive Committee). Cadillac cars were available in a 7-Pass. Touring body style that was not offered on LaSalle. A single "134" Chassis Touring, Non-Production LX1290" car, presumably a 7-passenger, was built and charged to the factory. A "134" Chassis 5 Coupe, Sample Body 1295 LX" is shown charged to the factory. An "8120 Special 5 Sedan" is listed with "Special body built for Eng. Dept." An "8080 Special 5 Cabrio. Sedan" was charged to the factory account of L. P. Fisher, but no details are listed.

6. Factory installed accessories: Very few cars had factory installed accessories other than the wire wheels, sidemounts and folding trunk rack option. Installed items were:

Heavy duty rear springs	Lovejoy Shock Absorbers (pre 1928)
High Compression cylinder heads	Special Camshaft
High Speed Equipment	Spotlight
Houdaille Shock Absorbers	Standard Trunk
Kelch Heater	Trunk Cover to match top (Drab Duck)

7. Chassis: Complete drivable chassis, in both the 125" and 134" wheelbases, were produced and sold to both domestic and foreign coach-builders. Typically the units included the bumpers, radiator, hood and cowl, lights, dashboard, running boards, fenders (with or without fenderwells and trunk rack), etc. The finished vehicle would thus have a distinctly recognizable LaSalle origin. Chassis distribution was:

Alexandria, Egypt	3	London, England	11 (Right hand drive)
Antwerp, Belgium	8	Newark, New Jersey	1
Berlin, Germany	15	New York City, New York	1
Boston, Massachusetts	1	Oshawa, Canada	1
Buenos Aires, Argentina	3 (Right hand drive)	Paris, France	20
Buffalo, New York	2	Stockholm, Sweden	1
Chicago, Illinois	1	Utica, New York	2
Copenhagen, Denmark	3	Washington, D.C.	4
Factory, Detroit	12		

The first eleven LaSalle serial numbers are chassis indicated as "Factory - Experimental." At least one of those was eventually fitted with an unspecified body with center and lower panels in Cadillac Blue, Lt. Two "Cut Open Chassis" for show displays were done, one sent to Newark and one charged to the factory. The records give only a brief hint of the custom coachwork done on the LaSalle chassis. Serial #216545, a 134" wheelbase chassis, was shipped to Paris on 12/9/27. It was returned to the factory for credit and shipped to New York City on 6/11/28 with the record annotated "Hibbard & Darrin 5 Sedan." Serial #216741, a 134" wheelbase chassis, was shipped to Utica, New York, on 12/21/27. It was returned to the factory for credit on 6/11/28 with the record annotated "Willoughby body on chassis - 4 Sport Sedan." It is reasonable to guess that Willoughby, based in Utica, also built a body for the other chassis shipped to Utica.

8. Export Cars: Export sales rapidly became an important element of LaSalle production - the first export being a 5-passenger Sedan, serial #202641, to Copenhagen on April 6, 1927. Car and chassis exports totalled 1975 units; 1334 in 1927 and 641 in 1928. All LaSalle body styles were available in either left or right hand drive, a feature that was essential to international sales. Sales to Canada (in addition to the cars assembled in Oshawa) were not treated as exports, whereas, sales to Mexico were through the General Motors Export Division. Vehicles destined for the U.S. Territory of Hawaii were treated as exports. Right hand drive was a common feature for export cars destined for island nations plus Argentina, India and South Africa. Export totals by body style were:

4-Pass. Phaeton	1168	460	5-Pass. Cabriolet Sedan	8080	6
4-Pass. Sport Phaeton	1168-B	13	5-Pass. Imperial Sedan	8090	34
2-Pass. Roadster	1169	121	5-Pass. Sedan	8110	19
5-Pass. Sedan	7380	206	5-Pass. Family Sedan	8110-A	10
4-Pass. Victoria	7390	39	5-Pass. Sedan	8120	242
2-Pass. Convertible	7400	253	4-Pass. Victoria	8130	11
2-Pass. Coupe	4110	7	2-Pass. Coupe	8140	8
5-Pass. Town Sedan	7420	67	2-Pass. Business Coupe	8140-A	2
5-Pass. Coupe	8050	5	Chassis, 125" wheelbase		34
7-Pass. Sedan	8060	111	Chassis, 134" wheelbase		31
7-Pass Family Sedan	8060-A	8	5-Pass. Town Cabriolet, Fleetwood	3130	1
7-Pass. Imperial Sedan	8070	287			

Where did the exports go? Destinations are listed below (destination not indicated in the records for 10 units):

City	Qty.	City	Qty.	City	Qty.
Berlin, Germany	252	Osaka, Japan	41	Kingston, Jamaica	5
Antwerp, Belgium	205	Barranquilla, Columbia	39	Nairobi, Kenya	4
Paris, France	128	Havana, Cuba	39	Guatemala	3
Buenos Aires, Argentina	122	Melbourne, Australia	38	Lima, Peru	3
Alexandria, Egypt	118	Caracas, Venezuela	25	Perth, Australia	3
Madrid, Spain	109	Adelaide, Australia	22	Delhi, India	2
Copenhagen, Denmark	96	Brisbane, Australia	15	Leon, Mexico	2
London, England	91	Santo Domingo, Dom. Rep.	12	Madras, India	2
Stockholm, Sweden	69	Wellington, New Zealand	12	Rangoon, Burma	2
Honolulu, Territory of Hawaii	67	Montevideo, Uruguay	11	Recife, Brazil	2
Port Elizabeth, South Africa	67	Bombay, India	8	San Jose, Costa Rica	2
São Paulo, Brazil	58	Panama City, Panama	7	Torreón, Mexico	2
Sydney, Australia	55	Calcutta, India	6	Valparaíso, Chile	2
San Juan, Puerto Rico	51	Cali, Columbia	6	Barcelona, Spain	1
Mexico City, Mexico	49	Oruro, Bolivia	6	Port Au Prince, Haiti	1
Batavia, Java	48	San Salvador, El Salvador	6	Santiago, Chile	1
Manila, Philippine Islands	44	Colombo, Ceylon	5	Tampico, Mexico	1

9. Indianapolis: "Before a crowd estimated at 135,000, the LaSalle Roadster driven by "Big Boy" Rader paced the Indianapolis Memorial Day race and made a very splendid showing. The Roadster which Rader drove had a beautiful black finish and with its nickel work made a most impressive sight as it tore around the curve and flashed into the straight-away with the pack of 33 racing cars roaring at its heels." Source: *Clearing House*, June 2, 1927. Selection of the new LaSalle as the pace car provided a significant stamp of approval and publicity boost. LaSalle was destined to pace the Indianapolis race three times, an impressive record for a car that was built for only fourteen years. The identity of the 1927 pace car is not clear from factory records. Roadster serial #204256, body #340, is listed in the ledger as "For Indpls Speedway, Steve Hannagan" and was shipped on 4/23/27. That car, however, had Black upper panels and Derby Red Medium lower panels. There are no other indications of cars for the Speedway. Is the race account incorrect? Was serial #204256 repainted for the race, or was there a second Roadster that was the actual pace car?

10. Serial numbers. None of the body styles were assembled in body number sequence. For body styles that shared the same body number sequence, blocks of serial numbers were apparently assigned to a particular style and, when all were used, another block was assigned.

Fisher body styles.

First car built in each body series	Last car built	Highest body number
1168 serial 200018, body 273	serial 226806, body 1489	1999
1168-B serial 208955, body 28	serial 226778, body 267	371
1169 serial 200019, body 5	serial 226695, body 1173	1184
7380 serial 200016, body 1074	serial 216160, body 2455	5001
7390 serial 200028, body 77	serial 223991, body 1244	1250
7400 serial 200015, body 239	serial 226741, body 2993	3001
7410 serial 299924, body 11	serial 216772, body 1063	1100
7420 serial 209192, body 30	serial 226807, body 1224	1600
8050 serial 216947, body 3	serial 226732, body 992	1839
8060 serial 212036, body 1264LX	serial 226805, body 2542	2826 Note 1
8060-A serial 216911, body 1115	serial 226794, body 2463	3469 Note 1
8070 serial 212046, body 1266	serial 226529, body 480	1468
8080 serial 217095, body 2	serial 226804, body 500	500
8090 serial 212061, body 70	serial 226637, body 119	210
8110 serial 208251, body 310	serial 226791, body 3067	3169 Note 2
8110-A serial 217045, body 18	serial 226802, body 3513	7429 Note 2
8120 serial 205614, body 1452	serial 224558, body 1578	2110
8130 serial 207102, body 154	serial 226749, body 275	1215
8140 serial 211834, body 254	serial 226625, body 934	962 Note 3
8140-A serial 216812, body 146	serial 226793, body 967	975 Note 3
Chassis 125" serial 200001	serial 226636	
Chassis 134" serial 214892	serial 222897	

Note 1: Body styles 8060 and 8060-A share the same body number sequence.

Note 2: Body styles 8110 and 8110-A share the same body number sequence.

Note 3: Body styles 8140 and 8140-A share the same body number sequence.

Fleetwood body styles. All of the Fleetwood bodies had body numbers assigned by the body works in Pennsylvania. The chassis were shipped to Fleetwood and returned to Cadillac Motor Car Company in Detroit with the body installed.

First car built

3051 serial 204384, body 10322
3110 serial 200012, body 10050
3120 serial 200022, body 10189
3130 serial 200013, body 10177
3751 serial 219256, body 10941

Last car built

serial 217223, body 10608
serial 217098, body 10061
serial 207761, body 10199
serial 217312, body 10611
serial 226002, body 10943

CONDENSED SPECIFICATIONS

POWER PLANT

Engine—Compensated eight-cylinder, V-type; 90-degree angle between cylinder blocks. Engine and transmission in unit; 3-point suspension. Piston displacement 303 cubic inches. Bore $3\frac{1}{8}$ "; stroke $4\frac{1}{8}$ ". Horsepower S.A.E. rating 31.25; actually more than 75.

Cylinders—Cast in blocks of 4, with detachable heads.

Pistons—Nickel-iron, close grained and long wearing; 3 rings; lower ring special oil regulating type.

Connecting Rods—Drop-forged alloy steel, I-beam section; side by side, two on each pin. Bearings $2\frac{3}{8}$ "x $1\frac{3}{8}$ ". Babbitt in rods.

Valves—Inlet $1\frac{1}{2}$ ", tungsten steel; exhaust $1\frac{1}{2}$ ", silico-chrome steel. Single spring. Automatically lubricated.

Crankcase—Special copper alloy aluminum; non-resonant.

Crankshaft—Diameter $2\frac{3}{8}$ ", length to outer ends of front and rear bearings $23\frac{3}{32}$ ". Supported on 3 main bearings, bronze-backed—Chadwick interchangeable. Crank throws 90 degrees apart, provided with compensators.

Camshaft—Single hollow shaft, with 16 cams; shaft supported on 4 bearings. Driven from crankshaft by silent chain.

Clutch—New dry-plate type with two discs, $9\frac{1}{2}$ " in diameter. Positive release.

Transmission—Selective type with 3 speeds forward and 1 reverse. Alloy steel, oil-hardened gears and shafts. Faces of gear teeth accurately ground and ends of teeth chamfered to obtain easy and quiet gear shifting.

GASOLINE SYSTEM

Supply—20-gallon fuel tank located at rear of chassis. Feed is by vacuum to smaller tank on dash.

Vacuum Pump—Special design, located at rear of crankcase and driven by eccentric on the camshaft, provides vacuum necessary to lift gasoline to vacuum tank under all conditions.

Fuel Strainer—Straining device located between tank and the carburetor, cleans engine fuel before it enters the mixing chamber of the carburetor.

Carburetor—LaSalle design and manufacture; maximum efficiency and economy. Air valve, single jet type. Automatic Thermostatic mixture control. Intake header exhaust-heated. Valve in left exhaust manifold operated from instrument board, when closed deflects back exhaust gases from left cylinders through intake header jacket thus giving maximum heat for carburetor almost immediately. Manifold high turbulence type.

COOLING SYSTEM

Radiator—Copper with cellular core; nickeled casing.

Water Cooling—Capacity $5\frac{1}{4}$ gallons. Centrifugal pump mounted on right side of engine and driven by silent chain from crankshaft. Cylinder blocks interconnected. One drain plug for entire system; necessary to disconnect only 3 hose couplings to remove radiator.

Temperature Control—Thermostatically controlled by vertical balanced radiator shutter blades.

Fan—6 blades; driven at engine speed by a V-belt from camshaft. Hub carries gear oil pump and oil reservoir for its own lubrication.

LUBRICATING SYSTEM

Engine lubrication—Pressure circulation system employing gear pump carried in oil pan and driven by extension of the distributor shaft. Supply in 8-quart capacity steel reservoir with screen for cleaning oil. Oil manifold runs length of crankcase, with leads connecting main bearings, the rear camshaft bearing, the pressure gauge and filter. Hollow camshaft carries oil from rear to other camshaft bearings. Passages in crankshaft conduct oil from main bearings to connecting rod bearings. Pressure is regulated by adjustable piston valve, overflow from which lubricates chain mechanism. Valves automatically lubricated by ports in cylinder walls. Oil level gauge on top of crankcase at rear of cylinder blocks.

Crankcase Ventilation—An effective and unique system which prevents contamination of crankcase oil with water and unburned fuel.

Oil Filter—An effective filtering device for removing impurities in solid form.

ELECTRICAL SYSTEM

Ignition—Delco-Remy high tension system; ignition timer with two sets of contact points, induction coil and condenser. Jump-gap type distributor.

Generator—Two-pole Delco-Remy, mounted on right side of crankcase. Driven by same silent chain as water pump. Current regulated by automatic, thermostatic switch.

Starting Motor—Four-pole Delco-Remy, mounted horizontally at the right side of transmission case. Has exceptionally high stalling torque.

Battery—LaSalle-Exide, 100 ampere hour, 6-volt, 3 cells. Carried on right-hand side of frame under front seat.

Horn—Delco-Remy high frequency type, mounted on left side of radiator.

Lighting Equipment—Two headlamps, two side lamps; new design, bullet type; tail lamp, controlled from single lever at center of steering wheel. Stop signal lamp in unit with tail lamp, controlled by foot brake. Instrument board lighting controlled by light switch at center of steering wheel. Dome light in Two-passenger Coupe, Four-passenger Victoria and Five-passenger Sedan.

OPERATING CONTROLS

Gear Shift—Center.

Service Brakes—Two independent braking systems. Mechanically operated, internal expanding on front wheels and external contracting on rear wheels. Division of pedal pull automatically proportioned between front and rear systems. Both front brakes operate when straight ahead, outer brake released on turn.

Hand Brake—Internal expanding on rear wheels and will not require adjustment during life of brake lining.

Steering Gear—LaSalle design, worm and sector, completely adjustable; reduction $17\frac{1}{2}$ to 1. Steering wheel 18" in diameter, rubber composition with steel reinforcement; metal cast hub and spokes.

Engine Controls—Accelerator at right of brake pedal. Hand throttle lever built into central portion of steering wheel.

Automatic Spark Control—With manual lever located on instrument board directly in front of steering column.

Instrument Board—Special die cast panel; ignition switch with coincidental lock; ignition advance control; fuel gauge; ammeter; speedometer; oil pressure gauge; carburetor enriching button; intake header heat control; clock; motor heat meter and cigar lighter. Instrument lamps with separate switch.

MISCELLANEOUS

Axles—Rear axle, LaSalle design, three-quarter floating type with helical bevel gear and pinion. Shafts and pinion are alloy steel forgings. Front axle, reversed Elliott type; drop-forged special alloy steel with inclined king bolts. Drop-forged steering spindles with ball thrust bearing at lower end.

Drive—Solid steel propeller shaft $1\frac{1}{8}$ " in diameter, turns in torque tube which completely seals assembly. Rear end rigidly connected to rear axle by splined sleeve; front end, to transmission shaft through universal joint. Torque tube is bolted to differential carrier at rear, and front end pivoted in ball-and-socket joint at rear of the transmission. Transmits drive of rear wheels to chassis and absorbs torque reactions due to acceleration and brakes.

Fenders—One-piece metal; oval contour.

Fender Wells—Optional, at extra charge.

Frame—Side bar channel section with wide top flange, carbon steel, maximum depth of side members $6\frac{1}{2}$ "; 4 channel cross members and 2 tubular cross members.

Springs—Semi-elliptic suspension. Rear shackle tension type provided with ball-and-socket joint. Delco-Remy-Lovejoy shock absorbers are standard equipment. Front springs 39" x 2"; rear 58" x 2".

Tires—32" x 6.00" cord balloon.


Tire Carrier—Rim type mounted at rear of chassis.

Tools—Complete set of tools in compartment under front seat.

Wheelbase—125" and 134".

Wheels—Artillery type, 20" diameter, 12 hickory spokes with steel felloe; demountable split type rim. Wire wheels, and disc wheels having rim integral, optional at extra charge.

The Cadillac Motor Car Company reserves the right to make changes in specifications at any time without incurring any obligation to install same on cars previously sold



Harley Earl and a 1928 LaSalle Roadster in California.