

1934



CADILLAC OPERATOR'S MANUAL

FILE COPY
DO NOT REMOVE



V-8

EDITION NO. 355-2

*In ordering a duplicate of this Manual specify the
above number or the engine number of the car.*

Table of Contents

	Page
CHAPTER I— <i>Cadillac Service</i>	3
Cadillac-La Salle Service Stations—Identification Card—Care of the car—Authorized Service—Preventive Service—Repair Parts—Service Charges—Flat Rate Service—Standard Service Contract—Lubrication Agreement.	
CHAPTER II— <i>Lubrication</i>	11
Lubrication Schedule—Lubrication Notice—LUBRICANTS—Engine oil—Axle and Transmission Lubricant—Steering Gear Lubricant—Chassis Lubricant—Clutch and Wheel Bearing Lubricant—Water Pump Lubricant—ENGINE LUBRICATION—Oil Level—Crankcase Ventilating System and Oil Filter—Changing Engine Oil	
CHAPTER III— <i>Operation</i>	18
Gasoline Gauge—Oil Pressure Gauge—Ammeter—Temperature Indicator—Throttle Control—Carburetor Choke Control—Starting the Car—Starting Hints—Controlled Free-Wheeling—Ride Regulation—Lighting Switch—DRIVING HINTS—Speed—Gravel Roads—Hills—Slippery Roads—Danger of Running Car in Closed Garage.	
CHAPTER IV— <i>Cold Weather Operation</i>	29
PREPARING FOR COLD WEATHER—Anti-Freezing Solutions—Winter Lubrication—Storage Battery—Gasoline System—STARTING THE ENGINE—Choke Button—Position of Throttle Hand Lever—Priming the Carburetor—Use of Starter—Use of Accelerator Before Engine is Warm.	
CHAPTER V— <i>Equipment</i>	35
Locks and Keys—Ignition Switch Lock—Door Locks—Package Compartment—Interior Lights and Switches—Windshield and Ventilation—Windshield Cleaner—Sun Visor—Adjustable Seat—Cigar Lighter—Tools—Tires—Spare Wheel Carrier—Changing Wheels.	
CHAPTER VI— <i>General Care</i>	44
Storage Battery—Generator Charging Rate—Spark Plugs—Cooling System—Gasoline System—Carburetor Air Cleaner—Brakes—Tires—Removing Tires from Wheels—Tire Balancing Marks—Lights—Replacing Map Lamp Bulb—Aiming the Headlamps—Storing the Car—BODY—Care of the Finish—Care of the Top—Cleaning Upholstery—Door hardware—Body Adjustments.	
CHAPTER VII— <i>Specifications and License Data</i>	60

CHAPTER I

CADILLAC SERVICE

THE OWNER of a Cadillac motor car has purchased a fine piece of machinery to serve him as a pleasant and dependable means of transportation. The Cadillac provides this means; pleasant because of its fine performance, comfort and ease of control; dependable because of the care with which it was built and because of Cadillac Service, which operates on a standard policy, guaranteeing the owner efficient service everywhere at standard prices under factory regulation.

Cadillac-La Salle Service Stations

Cadillac Service is available wherever Cadillac and La Salle cars are sold. Service stations conducted by Cadillac distributors and dealers are designated as "Authorized Cadillac-La Salle Service Stations," and are identified by the exclusive sign shown on this page. Wherever this sign is displayed, the owner will find an organization prepared to service Cadillac cars. This means proper equipment, factory-trained personnel, a stock of genuine replacement parts and standardized policies and methods.



Fig. 1. Authorized Cadillac-La Salle Service Stations display this sign at the service entrance.

The car owner's first and most frequent contact with Cadillac Service naturally will be in the service station of the distributor or dealer who sold him the car and who therefore has the greatest interest at stake in assuring him satisfaction. Cadillac Service is so organized, however, that the owner may feel perfectly free to use his car for extended travel, secure in the knowledge that other Authorized Cadillac-La Salle Service Stations are able and willing to offer the same service benefits to which he is entitled at his local service station.

Identification Card

As a means of introduction at other Authorized Cadillac-La Salle Service Stations, every purchaser of a Cadillac car is given credentials in the form of an Identification Card. This card, mailed to the owner by the Cadillac Motor Car Company as soon as delivery of the car is reported by the distributor or




Fig. 2. The Identification Card, when properly signed, introduces the owner at any Authorized Cadillac-La Salle Service Station.

dealer, is supplied in a celluloid case and is intended to be carried in a holder on the car. This holder is located under the cowl in the driving compartment on the right-hand side of the car as shown in figure 3.

Upon presentation of this Identification Card at any Authorized Cadillac-La Salle Service Station, the car owner is assured of standard

Cadillac Service under factory regulation.

Care of the Car

A fine piece of machinery, such as the Cadillac, naturally requires a certain amount of care to assure smooth running, dependability and long life, and the owner will derive the utmost in

continuous satisfaction and utility from operation of the car by following the instructions given below:

1. Drive the car at moderate speeds for the first 500 miles.
2. Operate the car in accordance with the instructions contained in this manual.
3. Check the engine oil level every 100 to 150 miles and add oil as often as necessary to keep the indicator at "Full."
4. Check the air pressure of the tires at least once a week and keep it up to the recommended pressure—40 pounds front and rear; on cars driven at high speeds, 45 pounds in front.
5. Add distilled water to the storage battery every 1000 miles, and in warm weather every 500 miles, or at least every two weeks.
6. Have the car lubricated every 1000 miles, or once a month in accordance with the lubrication schedule given on page 10.



Fig. 3. The Identification Card should be kept in its holder under the cowl at all times.

7. Have the car inspected by an Authorized Cadillac-La Salle Service Station every 1000 miles, or at least once a month.

Authorized Service

The first five items above do not necessarily warrant a visit to the service station. The last two, however, require the attention of those whose knowledge and experience qualifies them to perform the required work efficiently and in accordance with factory recommendations.

A car such as the Cadillac V-8, built with skill, precision and

fine workmanship, is deserving of the finest care of qualified experts in any service work that may be required. Authorized Cadillac-La Salle Service Stations are qualified to do this work in a manner not to be duplicated elsewhere because they have greater reason to be interested in the operation of the Cadillac owner's car. Their personnel are specialists; they have had more experience on Cadillac and La Salle cars than anyone could have who works on all makes of cars. They have up-to-date, expert information on Cadillac adjustments and service methods supplied by the factory in regular publications and special bulletins.

Preventive Service

Preventive service is the fundamental principle of Cadillac Service. It is based on the knowledge that regular expert attention keeps emergency service at a minimum, assuring continuous satisfactory operation of the car with a minimum of interruption and expense.

The first thought, of course, is the proper protection of all working parts through correct lubrication according to schedule. The second, of great importance, is systematic inspection every 1000 miles, or once a month, so that any necessary adjustments may be made before the need becomes an emergency.

Authorized Cadillac-La Salle Service Stations will make such inspections without charge. Lubrication and any necessary adjustments are performed at standard prices under factory regulation after the owner has approved the work and the prices.

Repair Parts

Genuine Cadillac parts, manufactured to the same rigid specifications as the parts originally used in the car, are carried in stock by Authorized Cadillac-La Salle Service Stations. They are sold at uniform prices throughout the United States and are not subject to the addition of handling, excise or other supplementary charges. Printed price lists, published by the Cadillac Motor

Car Company, are open to inspection by owners at any Cadillac distributor's or dealer's service station.

Service Charges

Authorized Cadillac-La Salle Service Stations, in line with the Cadillac policy of serving the owner to his best advantage, are prepared to offer service in three ways:

1. Individual operations on a flat-rate basis, authorized by the owner as occasion requires.
2. A Standard Service Contract covering complete mechanical maintenance—lubrication, inspection, all adjustments and repairs—over a period of one year or 12,000 miles at a fixed price.
3. A Lubrication Agreement covering inspections and all necessary lubrication over a period of one year or 12,000 miles at a fixed price. Under this plan any adjustments or repairs the owner authorizes are paid for as individual operations.

The owner may obtain service in any of these three ways he chooses. Certain advantages are to be derived from the Standard Service Contract or the Lubrication Agreement, but the owner may purchase service in any of these forms with perfect assurance that the work will be done in accordance with Cadillac standards.

Flat Rate Service

When a car enters the service station, it is promptly inspected by an expert tester who quotes the owner an exact price for the work he finds necessary. The owner then authorizes the work at this price and when he receives the bill, this is the price he pays.

Charges prevailing at Authorized Service Stations are based on standard schedules furnished by the Cadillac Motor Car Company. These schedules call for methods and tools approved by the same engineers who designed and built the car, thus assuring the highest quality of work at the lowest possible price. Standard price schedules are open to owners for inspection at any Authorized Cadillac-La Salle Service Station.

Standard Service Contract

The Standard Cadillac Service Contract is available to owners who wish to be assured of continuous satisfactory operation and maintenance of their cars at a predetermined, economical cost. It is based on Cadillac's principle of preventive service insuring the greatest satisfaction with the fewest possible interruptions. Complete lubrication on schedule and thorough inspection to anticipate the need of adjustment and repair largely eliminates the need of service between regular inspections.

The Service Contract is recognized by all Authorized Cadillac-La Salle Service Stations in the United States and Canada regardless of where it may have been purchased. The owner is thus assured of all Contract service due him without additional charge wherever he may travel. He needs only to present the identification card issued to him at the time the Contract is purchased to receive this service the same as if the work was performed by the service station from which the Contract was purchased.

These contracts are available at all authorized service stations. Three contracts are available to cover each of three periods; the first year or first 12,000 miles, the second year or second 12,000 miles and the third year or third 12,000 miles, respectively. Owners are urged to take advantage of the conveniences offered by Contract ownership to obtain efficient and expert service under factory regulations for their cars at the predetermined economical cost.

Lubrication Agreement

Owners who do not purchase a Service Contract are urged to purchase a Lubrication Agreement. Lubrication according to schedule is the most important attention required by the car and the Lubrication Agreement assures this service regularly for 12 months or 12,000 miles at a price lower than the total cost of the twelve operations if paid for individually.

The Lubrication Agreement is recognized by all Authorized

Cadillac-La Salle Service Stations in the United States and Canada, the same as the Service Contract, and the identification card need only be presented to have the work scheduled performed at any Authorized Service Station regardless of where the Agreement was purchased.

The holder of a Lubrication Agreement is relieved of the thought of lubrication cost during the entire 12 months or 12,000 mile period by budgeting his expense beforehand. He needs only take his car to the service station at monthly or 1000 mile intervals and request "schedule lubrication" to obtain all of the lubrication due performed according to factory specifications.

Regardless of how the owner prefers to have the necessary service performed on his car, the surest guarantee of long life and complete motoring satisfaction at the least possible expense is correct lubrication and preventive service rendered every 1,000 miles or once a month by an Authorized Cadillac-La Salle Service Station.



LUBRICATION SCHEDULE

CADILLAC V-8 355-B

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____ DATE DELIVERED _____

DO NOT WAIT FOR SCHEDULE LUBRICATIONS BEFORE ADDING ENGINE OIL. THE OIL LEVEL SHOULD BE CHECKED EVERY 10 TO 15 MILES AND OIL ADDED IF THE INDICATOR BALL IS BELOW "FULL." THIS IS ESPECIALLY IMPORTANT ON CARS DRIVEN AT HIGH SPEEDS.	LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE											
		1000	2000	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000
LUBRICATION NOS. 1, 2, 7 AND 11 LUBRICATION NOS. 3 AND 9 LUBRICATION NOS. 4, 8 AND 10 LUBRICATION NOS. 5 AND 12	ADD LIQUID TO RADIATOR	○	○	○	○	○	○	○	○	○	○	○	○
	ADD ENGINE OIL AS NECESSARY	○	○	○	○	○	○	○	○	○	○	○	○
	STARTER, GENERATOR AND DISTRIBUTOR OIL CUPS	○	○	○	○	○	○	○	○	○	○	○	○
	BRAKE AND RIDE REGULATOR PINS AND CONNECTIONS	○	○	○	○	○	○	○	○	○	○	○	○
	ACCELERATOR, ROCKER SHAFT	○	○	○	○	○	○	○	○	○	○	○	○
	DOOR HARDWARE	○	○	○	○	○	○	○	○	○	○	○	○
	GREASE GUN CONNECTIONS	○	○	○	○	○	○	○	○	○	○	○	○
	WATER PUMP GREASE CUP	○	○	○	○	○	○	○	○	○	○	○	○
	CLUTCH RELEASE FORK	○	○	○	○	○	○	○	○	○	○	○	○
	ADD WATER TO STORAGE BATTERY	○	○	○	○	○	○	○	○	○	○	○	○
	CHECK TIRE INFLATION	○	○	○	○	○	○	○	○	○	○	○	○
	DRAIN AND REPLACE ENGINE OIL	○	○	○	○	○	○	○	○	○	○	○	○
	CLUTCH RELEASE BEARING	○	○	○	○	○	○	○	○	○	○	○	○
	TRANSMISSION—ADD LUBRICANT	○	○	○	○	○	○	○	○	○	○	○	○
	REAR AXLE—ADD LUBRICANT	○	○	○	○	○	○	○	○	○	○	○	○
	STEERING GEAR—ADD LUBRICANT	○	○	○	○	○	○	○	○	○	○	○	○
	FRONT BRAKE LEVERS	○	○	○	○	○	○	○	○	○	○	○	○
	SPRING COVERS	○	○	○	○	○	○	○	○	○	○	○	○
	WHEEL BEARINGS	○	○	○	○	○	○	○	○	○	○	○	○
	SPEEDOMETER DRIVE SHAFT	○	○	○	○	○	○	○	○	○	○	○	○
**REFILL SHOCK ABSORBERS	SPECIAL OIL												
**FLUSH COOLING SYSTEM													
**REPLACE OIL FILTER CARTRIDGE, CLEAN OIL PAN AND SCREEN													

*IN SUMMER INSPECT BATTERY EVERY 50 MILES OR AT LEAST EVERY 2 WEEKS.

**RECOMMENDED BUT NOT INCLUDED IN LUBRICATIONS 4 AND 12.

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:
THIN REAR AXLE AND TRANSMISSION LUBRICANT—AS REQUIRED FOR LOW TEMPERATURES.
DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING

RECORD ON OTHER SIDE

Fig. 4. This is a fac-simile of the Cadillac Lubrication Schedule and Record Card. Provision is made on the back of the card for recording when and where the card is lubricated. A copy of this card can be obtained on request from Cadillac distributors and dealers.

[10]

CHAPTER II

LUBRICATION

Lubrication Schedule

THE moving parts of the Cadillac V-8, built with infinite care and fitted to precision limits, deserve *effective* lubrication to preserve their smooth operating efficiency. Lubrication, to be most effective, must be done systematically at regular mileage intervals. To assist the owner in obtaining proper lubrication, a complete lubrication schedule is reproduced on page 10. This schedule, if faithfully followed, will insure correct lubrication of each wearing surface. As a further aid to the owner, an illustrated lubrication chart, based on the lubrication schedule, is furnished with this Manual to assist the operator in visualizing the location of the various lubricating points.

The unit of the chart as well as the schedule is 12,000 miles which is divided into twelve 1000-mile intervals. Corresponding to these is a series of lubricating operations, grouped and numbered consecutively from 1 to 12, intended to be performed successively at each 1000 mile interval until the 12,000 mile cycle has been completed. At 13,000 miles, the schedule begins again with Lubrication No. 1 and continues through the series of twelve operations.




Fig. 5. The lubrication notice plate can be seen by opening the front left hand door a few inches.

[11]

Lubrication Notice

A metal plate in the shape of the Cadillac Crest is provided to serve as a lubrication notice and record. This plate is mounted on the left front door pillar about six inches below the top of the door as shown in figure 5.

Authorized Cadillac-La Salle Service Stations, after performing each schedule operation, post on this plate the number of the next operation and the mileage at which it will be due. Thus, when the mileage recorded on the speedometer is the same as the mileage marked on the notice, the car may be taken to any Authorized Cadillac-La Salle Service Station, and, without further ordering other than specifying "schedule lubrication," the car will receive the exact lubrication necessary.

Although the schedule is expressed in terms of miles the car should be lubricated once each month even though the mileage indicated on the speedometer is less than 1000 since the last lubrication operation was performed. The lubrication work can be done while the car is in the service station for its regular monthly or 1000 mile inspection.

Lubricants

The selection of proper lubricants should be one of the first concerns of the owner in his attention to the lubrication of the car. The lubricants must not only be of high quality but their viscosity and other characteristics must be suited to the purpose for which they are to be used.

Cadillac engineers have worked out in detail the specifications for the lubricant required for each point to meet the particular conditions of speed, load, temperature and kind of metals in contact.

Authorized Cadillac-La Salle Service Stations are prepared to furnish lubricants under these specifications to give the best results in their respective localities. When the car is lubricated by

someone not familiar with Cadillac specifications, lubricants should be called for by the S. A. E. viscosities recommended in the following paragraphs.

Engine Oil

Engine oil recommendations are given in the chart below. It should be noted that different grades of oil are to be used for average driving and for prolonged high speed driving in both summer and winter.

TYPE OF SERVICE	SUMMER	WINTER	
	All Temperatures Above 32° F.	Between 32° and 15° Above	Below 15° Above Zero
AVERAGE DRIVING (No prolonged high speed driving)	S. A. E. visc. 40 or 50	S. A. E. visc. 20	S. A. E. visc. 10
		<i>These oils are not suitable for prolonged high speed driving and if used under such conditions the oil level must be closely watched, as the rate of consumption will be higher than with heavier oils.</i>	
PROLONGED HIGH SPEED DRIVING	CADILLAC APPROVED "HEAVY DUTY" OILS— SUMMER AND WINTER		
	<p>These oils have an S. A. E. viscosity of 40-50-60, and are required to meet certain specifications as to volatility in order to demonstrate their fitness for prolonged high speed driving. To make certain of using an oil approved for this service, consult your Cadillac distributor or dealer.</p> <p>NOTE: Approved heavy duty oils vary in their suitability for winter use. If an approved heavy duty oil with sufficiently low cold viscosity is not available and if the car is not kept in a heated garage, the lighter oils specified above for average driving must be used to avoid hard starting. In this case, be sure to watch the oil level closely as cautioned above.</p>		

*The system used in this table to designate body or viscosity is the one developed by the Society of Automotive Engineers and adopted by all oil companies. It takes the place of the old indefinite method of describing oils as "Light," "Medium," "Heavy," etc. Oil should be called for by these numbers. If a filling station attendant does not know the S. A. E. numbers of his oils, the following grades can be substituted in emergency: S. A. E. 10, Extra Light; S. A. E. 20, Light; S. A. E. 40, Heavy; S. A. E. 50-60, Extra Heavy.

Rear Axle and Transmission Lubricant

Gear lubricant of S. A. E. Viscosity 160 should be used in the rear axle and transmission at temperatures above 20° F. For temperatures below 20° F a light lubricant of S. A. E. viscosity 90 should be used or the lubricant used during summer weather should be thinned with kerosene.

Important: Gear lubricants known as "sulphurized" or "chlorinated" oil and designated by "EP" following their S. A. E. classification are injurious to bronze parts and should not be used in Cadillac cars under any circumstances. Likewise soap greases will not satisfactorily lubricate these gears and should not be used.

Steering Gear Lubricant

The selection of the proper lubricant for the steering gear is of special importance, particularly to avoid hard steering in cold weather. A special steering gear lubricant suitable for extreme heat and cold is available and should be used in the steering gear the year round.

Chassis Lubricant

A good grade of chassis lubricant should be used for all chassis points indicated in the lubrication chart as requiring this type of lubricant. Ordinary cup grease is not satisfactory and if, in an emergency, it is used in place of chassis lubricant, the car should again be lubricated within 300 or 400 miles.

Clutch and Wheel Bearing Lubricant

The front wheel bearings and the clutch release bearings should be lubricated with a good grade of Clutch and Wheel Bearing Lubricant having a high melting point. Ordinary grease at these points is likely to melt and run on to the brakes or the clutch.

Water Pump Lubricant

A water-resistant calcium soap lubricant is recommended for use in the water pump grease cup. Only lubricants of this type should be used; other lubricant will be dissolved into the cooling system liquid. Cup greases and wheel bearing lubricants are entirely unsuited for this purpose.

Engine Lubrication

The supply of engine oil is carried in an oil pan at the bottom of the crankcase and is circulated through the engine by means




Fig. 6. The external features of the engine lubricating system.

of a gear pump inside of the crankcase. The oil circulated by this pump lubricates the main and connecting rod bearings, the camshaft bearings, the cylinder walls, the pistons and the piston pins, the front end chains, the valve mechanism and the fan.

There are a few points on the engine that cannot be taken care

of by the pressure system and these points should be lubricated according to the instructions given in the lubrication chart. This includes the starting motor, the generator, the distributor and the water pump.

Oil Level

The normal capacity of the oil pan is eight quarts which fills it to the level of the screen in the pan. When the oil pan contains this amount the oil level indicator between the two blocks at the rear of the engine (figure 6) shows "Full." The oil level should be checked every 100 to 150 miles and, whenever necessary, enough oil should be added to bring the indicator up to "Full." It should never be permitted to drop below "Fill."

Particular attention should be paid to the oil level in case of prolonged driving at high speed. At high speeds the oil is consumed many times as rapidly as at city driving speeds and oil must be added more frequently to maintain the proper level.

Crankcase Ventilating System and Oil Filter

Cadillac V-8 engines are equipped with a crankcase ventilating system and an oil filter to keep the oil in the best condition possible. The ventilating system, which functions automatically, prevents dilution and contamination of the oil by removing the vapors which seep past the pistons.

The oil filter removes dirt and solid matter from the oil until it gradually becomes so clogged that it ceases to function. The filter cartridge must then be replaced. Normally, replacement should be at 12,000 miles. The oil pan and screen should be removed and thoroughly washed with gasoline every 12,000 miles to remove any carbon or foreign particles that may have collected.

Changing Engine Oil

The useful life of the engine oil is greatly prolonged by the use

of the crankcase ventilating system and the oil filter, but the oil pan should be drained and the engine oil replaced every 2000 miles. To drain the oil, simply remove the drain plug (figure 6) and allow the oil to flow into a receptacle placed under the car. The drain plug should then be reinstalled and tightened securely before pouring in fresh oil. Eight quarts are required to bring the oil level indicator to "Full."

CHAPTER III

OPERATION

ONE of the first things the driver of the Cadillac V-8 should do is to familiarize himself with the location and use of the instruments and controls described in this chapter.

Gasoline Gauge

The gauge marked "Gasoline" indicates in gallons the quantity of fuel in the tank at the rear of the car. This gauge operates




Fig. 7. General arrangement of the driving controls.

Oil Pressure Gauge

The oil pressure gauge indicates only the pressure under which the oil is being forced to the engine bearings. It *does not* indicate the *quantity* of oil in the engine. The gauge should indicate zero as long as the engine is not running, but as soon as it is started and as long as it runs, it should show pressure. If no pressure is indicated when the engine is running, the engine should be stopped at once. Serious damage may result if the engine is run for any length of time whatever with no oil pressure.

electrically and indicates the quantity of fuel *only when the ignition is turned on*. When the tank is being filled and the driver wishes to check the amount of fuel in the tank, he should first shut off the engine to comply with filling station regulations and then switch on the ignition so that the gauge will operate.

Ammeter

The gauge marked "Amperes" indicates the rate of charge or discharge of the battery. It does not indicate the total output of the generator at any time nor does it indicate the current drawn by the starting motor when starting the car.

The ammeter should indicate on the charge side most of the time; otherwise more current will be drawn from the battery than is put into it and the battery will eventually become fully discharged. Normally, when no lights are in use, the ammeter




Fig. 8. Arrangement of the instrument panel.

should show "charge" as soon as the car is running ten or twelve miles an hour in high gear. If it fails to show a charge under these conditions, or if it shows a discharge when the engine is not running and no electrical equipment is in use, the cause should be investigated.

Temperature Indicator

The temperature of the cooling liquid in the radiator is indicated by the gauge marked "Temperature." For ordinary driving, after the engine has warmed up, the indicator should

stay within the "Normal" range, but under conditions of long hard driving, especially in summer weather, it may indicate "Hot." This is to be expected and will not interfere with efficient operation of the engine. If it indicates "Hot" after short runs and under average operating conditions, however, the cause should be investigated. The temperature indicator will always show a temporary rise in temperature immediately after stopping the engine. This likewise is a natural condition and is due to the residual heat in the engine.




Fig. 9. The hood ports may be opened by pulling out on the windsplits.

of cold weather in the fall. They may be opened by simply pulling out on the windsplits on the hood ports.

Throttle Control

The throttle of the carburetor is controlled by a hand lever and a foot pedal or accelerator. The normal position of the hand lever for driving the car is all the way up to "CLOSE." In this position the throttle of the carburetor is open just enough to permit the engine to run at idling speed after it is warm. For starting, however, the lever should be moved approximately




Fig. 10. The throttle hand control is the top lever on the hub of the steering wheel.

one-fourth the way down, and should be left in this position until the engine is warm enough to permit the lever to be returned to the idling position without stalling the engine. (Also see Chapter on "Cold Weather Operation.")

Carburetor Choke Control

Correct use of the choke control is essential not only to quick starting of the engine, but also has an important effect on the life of the engine. The button must be pulled out far enough in starting to provide an explosive mixture quickly so that the battery is not unnecessarily discharged by useless cranking. The button must also be left out far enough during the warming-up period so that the engine will run without missing and "popping-back."

On the other hand, it should not be pulled out any further or left out any longer than is necessary to accomplish these results, because some of the excess liquid gasoline in the enriched mixture does not burn and may wash off the oil on the cylinder walls, interfering with proper lubrication of the pistons. The button should be pushed all the way in as soon as this can be done without causing "popping-back."

If the engine still retains heat from previous running, the choke control should not be used without first attempting to start the engine on the normal mixture. If the choke button is pulled out for starting a hot engine the mixture may be made so rich that starting will be impossible.

The choke button is not a priming device. It has no effect whatever on the fuel or the fuel mixture unless the engine is being cranked or is running under its own power. To have any effect, it must be pulled out and kept partly out during the cranking operation.

Starting the Car

To start the car, first make sure the transmission is in neutral

and the hand throttle is in the normal starting position. Then pull out the choke (unless the car is warm from previous running), switch on the ignition by turning the key to the left until the lock cylinder springs out, and step on the starter.

As soon as the engine starts, release the starter pedal and push the choke button in as far as possible without stalling the engine. When the engine warms up, *push the choke button all the way in*. The proper use of the choke control will permit the engine to run smoothly until it warms up. The engine should never be raced

to warm it up. Racing the engine is not only unnecessary, but ineffective.




Fig. 11. The position of the hand throttle and the proper use of the choke control is of particular importance in starting the car.

Starting Hints

In cold weather, disengage the clutch to get a quicker start and to relieve the battery of the strain of turning the transmission gears.

If the engine does not start readily, release the starter pedal and look for the cause.

Do not run down the battery by too much use of the starter motor when the engine does not start readily. First find the cause; otherwise, the battery may be run down sufficiently to make starting impossible.

Check the contents of the gasoline tank.

See that the throttle hand lever is in the normal starting position and that the choke control has been used properly.

If the carburetor is choked from unnecessary use of the choke control or unnecessary priming with the accelerator pedal (see

page 34), turn off the ignition, move the hand throttle to the fully open position and hold the starter pedal down for 10 to 15 seconds to get rid of the surplus gasoline. Next, return the hand throttle to the normal starting position, turn on the ignition and step on the starter.

Controlled Free-Wheeling

The Cadillac V-8 is equipped with controlled free-wheeling, a means by which the engine can be disconnected from the transmission at the will of the driver, permitting the car to coast while the engine idles. This is accomplished by the main clutch, automatically operated by vacuum from the intake manifold of the engine in a manner similar to that of the windshield cleaner.

To free-wheel, it is simply necessary to depress a small foot pedal below the main clutch pedal. While this button is depressed, the clutch is automatically engaged when the car is accelerated, and disengaged when the accelerator pedal is released. By releasing the free-wheeling button, the car operates in the conventional manner.




Fig. 12. While the free-wheeling control button is depressed the clutch will engage when the accelerator pedal is depressed and disengaged when it is released.

The free-wheeling mechanism does not interfere in any way with the conventional operation of the clutch pedal. The free-wheeling control button, however, may be used, if desired, in place of the clutch pedal when shifting gears, thus saving the additional effort required.

When using the free-wheeling control in place of the clutch pedal in shifting "up," it is not necessary to let it up for each

shift. Simply depress the pedal before the first shift and let it up after the final shift into high.

The use of the conventional clutch pedal is necessary only when parking the car in close quarters and when starting the engine after the car has been left in gear.

Ride Regulation

The driver may control the action of the shock absorbers at any time to suit the conditions of road and speed. The control handle is located beneath the instrument panel on the left-hand side of the car next to the steering column.



Fig. 13. The degree of ride regulation can be controlled by the handle on the left hand side of the steering column.

The degree of control is indicated by a dial on the instrument panel labeled "Ride Regulation," and marked with five degrees, ranging from "free" to "firm." In general, "free" is for slow speeds over city pavements, while "firm" is for fast speeds over rough roads, but the driver can best deter-

mine by trial the degree of firmness or softness best suited to his requirements under conditions of car load, speed and the road.

Lighting Switch

The lighting switch is located at the center of the steering wheel opposite the throttle hand control. It has six positions; two country and two city positions, as shown in figure 14, as well as "Parking" and "Off."

In the "Driving" position for both Country and City, light is projected evenly down the road. In the "Passing" positions, however, the light is concentrated down the right-hand side of the road where it is most effective in cutting through any glare from the lights of the oncoming car, and, at the same time, direct beams down the right-hand side of the road that might affect the oncoming driver are eliminated. The driver of the Cadillac V-8 thus benefits from increased illumination where it is most needed without inconveniencing the oncoming driver. To switch to "Passing" when a car approaches from the opposite direction is

not only courteous but safe. (See figs. 15a to 15d)

The "Country" positions should be used only on the open road. The "City" positions provide plenty of illumination for all conditions within the environs of a city. The City "Driving" position should be used only on poorly lighted streets where there is little or no traffic. For general driving on lighted streets or wherever there is much traffic, the City "Passing" position will give




Fig. 14. The headlight switch is the lower lever on the hub of the steering wheel.

more effective illumination with no glare for oncoming drivers whatever, and this position should always be used under such circumstances.

The use of the Country "Driving" position is premissible in practically all states. In states which do not permit its use the driver should respect local regulations by using the Country "Passing" position for all driving on country roads.

Driving Hints

The driver owes it to other users of the streets and highways as well as himself to drive in such a way that the car is always



Fig. 15a. The "City Driving" position amply illuminates the street for driving where there is little or no traffic.



Fig. 15b. The "City Passing" position concentrates the light on the right-hand side of the road where it is most needed.

under his complete control. The driving equipment on the Cadillac V-8—the brakes, the ride control, the lighting equipment and the synchro-mesh transmission—is designed to afford maximum safety at all times, but there are certain conditions requiring special care to make its use fully effective.

Speed

The Cadillac V-8 can be driven at speeds faster than the driver will ever require. The car operates so smoothly that the driver sometimes fails to appreciate the speed at which he is driving. He must, therefore, use judgment in driving to keep the car always in control. Blind curves, hills, rough roads, side roads and wind-




Fig. 15c. The "Country Driving" position illuminates the entire road for a considerable distance ahead of the car.




Fig. 15d. In the "Country Passing" position intense light is projected down the right-hand side of the road, cutting through any glare from the oncoming car.

ing roads require a slower speed than smooth concrete straight-aways where the driver may see clearly for considerable distance ahead. Where the vision ahead is limited, speed should be kept low enough so that the car can be stopped within a safe distance for any emergency.

Gravel Roads

Adjust the Ride Regulator control to whatever degree of firmness required to prevent excessive bouncing and side sway. Do not swerve quickly or hold to the outside edge of the road on a curve.

Hills

When approaching the top of a hill, be prepared for any cars coming up the other side.

If the speed of the car becomes excessive while coasting down hill, put the transmission in gear and use the engine to assist the brakes. It must be remembered that the brakes are subjected to much more severe use on grades, where they must absorb the force of gravity as well as the momentum of the car, than on the level where they must absorb only the momentum of the car.

Ordinarily, the resistance offered by the engine with the transmission in high, supplemented by moderate use of the brakes, is sufficient to control the speed of the car. If excessive use of the brakes is still required, however, the transmission should be shifted to intermediate.

Slippery Roads

When stopping on slippery pavements, keep the car in gear and the clutch engaged until the car is nearly stopped. Apply the brakes gently. This will minimize the possibility of skidding. Do not attempt sudden stops.

Danger of Running the Car in Closed Garage

Always open the doors of the garage before starting the car.

Carbon monoxide, a deadly poison gas, is present in the exhaust of all internal combustion engines and for safety, this gas must be allowed to escape outside the garage. Under normal starting and warming up of the engine in a two car garage enough gas will accumulate in three or four minutes to overcome any occupants. When the choke is used excessively, such as for cold weather starting, the accumulation is more rapid.

Carbon monoxide is colorless, tasteless and almost odorless. *It gives no warning.*

Open the garage doors before starting the engine.

CHAPTER IV

COLD WEATHER OPERATION

SATISFACTORY operation of the car in freezing temperatures depends upon having the car prepared for cold weather and in giving it the special attentions which are required under such conditions. All the information relating to the care and operation of the car during cold weather has been grouped in this chapter to assist the operator in maintaining the fine performance of the car throughout the winter as well as the summer. This chapter should be reviewed just before the beginning of the winter season so that full benefit may be had of all the suggestions it contains.

Preparing for Cold Weather

Anti-Freezing Solutions

In selecting anti-freezing solutions for winter operation the local conditions and the type of service must be considered. The following information is given to enable the individual owner to more intelligently select the anti-freezing solution best suited to meet his own conditions.

The available commercial materials for preparing anti-freezing solutions for automobile radiators are denatured alcohol, methanol (synthetic wood alcohol), distilled glycerine, and ethylene glycol.

Denatured alcohol and methanol solutions are at present, the most generally used anti-freezing solutions. Denatured alcohol and methanol are widely distributed, afford protection against freezing, and are not injurious to the materials used in the cooling system.

There are two principal objections to denatured alcohol and

methanol. These materials are lost by evaporation, especially on heavy runs, and unless the solution in the radiator is tested periodically and sufficient anti-freeze added to replace the loss by evaporation, the motor or radiator, or both, are likely to be damaged by freezing. The car finish is damaged by contact with denatured alcohol or methanol solutions or vapors, and any material accidentally spilled on the finish should be flushed off immediately with a large quantity of water.

Methanol for anti-freeze purposes is sold in the United States in the correct concentration to give the same protection against freezing as denatured alcohol. The table below may be used for both denatured alcohol and methanol.

Lowest Temperature Expected	Per cent by Volume	Specify Gravity (at 60° F.)		Qts. Alcohol or Methanol required to make 6½ gal. solution
		Denatured Alcohol	Methanol	
10 F.	30	.9668	.972	7¾
0 F.	38	.9567	.964	10
-10 F.	45	.9475	.957	11¾
-20 F.	51	.9350	.950	13¾
-30 F.	57	.9260	.944	14¾

Important: The soluble oil used in the cooling system (see page 46) affects the hydrometer readings of the solution and allowances must be made for the difference. With soluble oil in the cooling system, the actual freezing temperature of an alcohol or methanol solution is five degrees higher than indicated by the hydrometer. In other words, if the hydrometer reading indicates protection down to zero, the actual protection would be only down to five degrees above zero and similarly throughout the scale.

Distilled glycerine and ethylene glycol solutions are, in first cost, more expensive than alcohol but, as they are not lost by evaporation, only water need be added to replace evaporation losses. Any solution lost mechanically, however, either by leakage or foaming, must be replaced by additional new anti-freezing solution. These solutions, under ordinary conditions, are not harmful to the car finish.

The principal objections to glycerine and ethylene glycol are the tendency of these solutions to loosen rust and scale, which form in the water passages of the cylinder blocks and heads, and the difficulty of securing and maintaining tight, leakproof connections. It is absolutely necessary that the entire cooling system be thoroughly cleaned and flushed before glycerine or ethylene glycol is used.

It is also necessary to tighten or replace the cylinder head gaskets, hose connections and pump packing. The cylinder head gaskets must be kept tight to prevent the solution from leaking into the crankcase where it might cause gumming and sticking of the moving parts. The pump packing must be kept tight to prevent air from being drawn into the cooling system, in order to avoid foaming and other difficulties which may result when air is present.

Ethylene glycol, as sold in the United States for anti-freezing purposes, is chemically treated to overcome the principal difficulties mentioned above and under normal operating conditions with tight cylinder head gaskets and tight hose connections should be satisfactory for use in the cooling system.

Glycerine and ethylene glycol should be used in accordance with the instructions and in the proportions recommended by the anti-freeze manufacturer. With soluble oil in the cooling system, however, the actual freezing temperature will be five degrees lower than indicated by the hydrometer reading. In other words, if the hydrometer reading indicates zero, the solution will actually give protection down to five degrees below zero, and similarly throughout the scale.

In using a hydrometer to determine the temperature at which a solution will freeze, the test must be made at the temperature at which the hydrometer is calibrated. If the solution is warmer or colder, it must be brought to this temperature or large errors may result. In some cases these errors may be as large as 30 degrees Fahrenheit. Freezing point hydrometers are not inter-

changeable, a different float is required for denatured alcohol, methanol, glycerine and ethylene glycol.

Salt solutions, such as calcium chloride, magnesium chloride or sodium silicate, kerosene, honey, glucose and sugar solutions are not satisfactory for use in automobile radiators. The capacity of the cooling system is $6\frac{1}{2}$ gallons when filled to the level of the overflow pipe.

Winter Lubrication

Lubrication of the car requires special attention in winter, not only to insure proper protection for the moving parts, but to secure the same ease of operation in starting, steering and shifting gears as during warm weather.

The chart of engine oil recommendations on page 13 gives the proper grade of engine oil to be used for cold weather driving. It will be noticed that lighter oils can be used during cold weather providing the car is not driven at high speeds. "Heavy duty" oils, however, must be used for prolonged high speed driving in winter as well as summer to prevent excessive oil consumption.

The lubricant in the transmission and rear axle should be thinned or replaced with a lubricant of suitable cold viscosity as soon as the gears are hard to shift.

The lubricant used during winter weather in the steering gear should have a low cold viscosity and should preferably be an all year-round lubricant. Steering gear lubricants should not under any circumstances be thinned with kerosene as the pressure between the worm and sector will force out a thinned lubricant and permit excessive wear at this point.

Storage Battery

The electrical system of a car has much more to do in winter. The stiffness of the lubricant makes the engine harder to crank in cold weather and it generally is cranked longer before it starts. The lights are also used to a much greater extent than during the long days of summer. All this means that the battery must be ready for increased demands.

It is a good plan in preparing for the winter season, therefore, to see that the battery is fully charged, that the battery connections are clean and tight, and that the charging rate is sufficient to take care of the requirements of the system. At the same time, the spark plugs, the contact points and the ignition timing should be checked to assure easy starting and smooth performance.

Gasoline System

A small amount of water in the gasoline system during warm weather has little or no effect on the running of the engine. In freezing weather, however, even a small amount of water may freeze and stop the entire flow of fuel to the carburetor. It is important, therefore, to clean the filter and the strainers in the gasoline system before the start of cold weather. (See page 48.) It is also advisable to check the adjustment of the carburetor and the operation of the choke control.

Starting the Engine

Choke Button

Gasoline does not vaporize as readily in cold weather as in warm weather and in order to supply the cylinders with a gaseous mixture rich enough to be ignited, the proportion of liquid gasoline to air must be increased. This is accomplished by the greater use of the choke control.

For cold weather starting, pull the choke control button all the way out until the engine starts. After the engine starts push the control button part way in. Experience will show the correct place to set the control, which will depend to some extent on the temperature. As the engine warms up the control button should be pushed further in until it has been pushed all the way in. The choke should not be left out any longer than necessary.

Position of Throttle Hand Lever

The correct position of the throttle hand lever for starting in cold weather is the same as for starting under other conditions,

that is, about one-fourth the way down from "close." In warm weather, however, the lever may be returned to the idling position almost as soon as the engine is started. In cold weather the throttle must be left slightly open until the engine becomes warm.

Priming the Carburetor

In extremely cold weather the carburetor may be primed by quickly depressing and releasing the accelerator pedal a few times. This procedure sprays gasoline into the intake chamber and provides a richer mixture. The carburetors should never be primed in warm weather or in cold weather when the engine is warm. Excessive priming at any time is likely to make starting difficult rather than easy.

Use of Starter

It is a good plan to disengage the clutch during the cranking operation in winter weather to relieve the strain on the battery. With the clutch disengaged the starter is not called upon to turn the transmission gears which are immersed in lubricant. At ordinary temperatures the resistance created by the gears turning in the lubricant is negligible, but in cold weather, when the lubricant is stiffened considerably, the strain is sufficient to retard the cranking speed and increase the demand on the battery.

Use of the Accelerator Before Engine is Warm

In cold weather, after the engine is started and before it has run long enough to become warm, the engine cannot deliver its normal power and should not be called on to do so. In accelerating the engine to start the car and in accelerating the car after the transmission is in gear, the throttle should not be opened too suddenly or too far. This merely invites "popping back" in the carburetor and an increase in the amount of excess unvaporized gasoline in the combustion chamber. Unvaporized gasoline in the cylinders washes the oil off of the pistons and cylinder walls, leaving the surface unprotected and open to scoring.

CHAPTER V

EQUIPMENT

THE equipment provided on the Cadillac V-8 is designed for the comfort, convenience and protection of the occupants. The driver, therefore, should acquaint himself with the operation of the equipment described in this chapter so that he may derive full benefit from its use as occasion demands.

Locks and Keys

The locks on the car are for protection against theft, and full use should be made of this protection whenever the car is to be left unattended for any length of time whatever.

Two sets of two keys each, which may be distinguished by the shapes of their handles, are provided with the car. Two different keys are provided so that the owner may leave the car temporarily in the hands of another operator without foregoing the protection of the various compartments.

The handle of one key is hexagonal in shape while the other is rounded. The hexagonal shaped key operates the combination ignition switch and transmission lock, the right front door and the spare wheel carrier. The key with the rounded handle operates the instrument panel package compartment lock, the rear deck lock, the golf compartment lock on roadsters and




Fig. 16. A record should be kept of the key numbers so that new keys may be easily obtained in case of loss.

coupes, the trunk lock on town sedans and 5-passenger coupes, and the rear door lock on town cars and imperial sedans.

Each key has the lock number stamped on the handle, as shown in figure 16, but this number does not appear on the lock. The owner should make a record of the key numbers as soon as he takes delivery of the car so that in case both keys are lost, a duplicate key may be easily obtained from a Cadillac distributor or dealer.

Ignition Switch Lock

The ignition switch lock is located in the center of the instrument panel. When the key is placed in this lock and is turned, the cylinder of the lock slides out about one half an inch turning on the ignition. Turning the key to the locked position and pushing the cylinder all the way in shuts off and locks the ignition.

This lock is also connected to the transmission through a cable. The transmission is thus automatically locked when the ignition is turned off, but the construction of the cable connection at the transmission is such that the car can be locked only in neutral or reverse. No attempt should be made to turn off the ignition when the transmission is in any forward speed.

Be sure to remove the key before leaving the car.

Door Locks

All the doors of the car can be locked from the inside by tilting the inside door handles up above their normal closed position. The driver, however, cannot lock himself out because only the right front door can be locked from the outside.

If the driver leaves the car through any door other than the right front door, the lock will be automatically released as soon as he shuts the door. The right-hand front door lock operates similarly, but it can be locked from the outside with the key. To lock the car completely, the driver must go out through the right-hand front door after the handles of all the other doors have been

tilted up. The right-hand front door must then be locked from the outside with the key.

Package Compartment




Fig. 17. The compartment on the right-hand side of instrument panel may be used for carrying small articles.

this compartment to be available for handy reference. The door of the compartment swings down to a horizontal position for convenience in resting maps or making notes.

Interior Lights and Switches

A map lamp which may be turned on by pulling it straight out is located so that it may be used to illuminate the driving compartment for reading maps or making notes when driving at night. This lamp is located at the top of the center panel directly above the ignition lock and the choke button. It may be turned around in its socket toward either side to throw the light in any direction desired.




Fig. 18. The map lamp may be turned to either side.

Dome lights on sedans and town cars and quarter lights on coupes turn on automatically when the doors are opened. When the doors are closed the lights are turned off, but they may also be turned on and off when the doors are closed by a switch located on the right-hand door pillar. Quarter lights on cars having dome lights do not operate with the doors but can be controlled by a switch on the left hand rear door pillar.

Phaeton and All Weather Phaeton cars have a tonneau light operated by the door and by a switch integral with the lamp. Deck compartment lights in roadsters and convertible coupes are operated in a like manner.

A chart of bulbs for replacement on all of these lights will be found on page 54, chapter VI.

Windshield and Ventilation



Fig. 19. In closing the windshield, it is important that the regulator be turned the last notch to imbed the glass in the weather stripping.

which hold the adjustment. When closing the windshield, the driver should make sure the regulator is turned into the last notch so that the windshield will imbed itself securely in the rubber weather strip. *This is important to prevent leakage.* Slightly more effort is required to turn this last notch.

[38]

Ventilation in the driving compartment is provided for by the windshield, which may be raised or lowered, and by a cowl ventilator. The windshield may be raised from the bottom by means of the crank above the windshield on the driver's side shown in figure 19. The regulator mechanism has five separate notches

The cowl ventilator is controlled by the handle at the right-hand side of the steering column. It may be opened to any one of three positions by merely pushing down on the handle.

Windshield Cleaner

The windshield cleaner consists of two wiper blades operated simultaneously by suction from a vacuum pump on the engine. On closed cars the wipers are controlled by one push button located on the cleaner motor above the center of the windshield. On open and convertible cars, each wiper is controlled separately by two buttons located on the cowl at each side of the center section above the instrument panel.

Sun Visor

A sun visor is provided on the left-hand side of the driving compartment to protect the driver from the glare of the sun. The visor operates on a universal joint and can be turned down or up or tilted to either side to give the protection desired.




Fig. 20. The sun visor may be turned and tilted in any direction.

Adjustable Seat

The driver's seat on closed cars may be adjusted to suit individual requirements in giving the most comfortable reach to the controls. A crank located on the left-hand side of the driving compartment at the seat base just above the floor boards, operates the control mechanism.

Cigar Lighter

Cordless lighters are provided on the instrument panel and in

[39]

the smoking sets of the various body styles. These lighters have a green translucent button through which the glow of the heating element may be seen when the lighter is ready for use. To use a lighter, press it all the way into its socket and hold it there until the glow of the heating element is seen; then lift it out.

Tools

A compartment for the tools is located under the front seat except in 5-passenger coupes. In these cars it is located under the rear seat. A compartment for tire chains is provided in the left hand front fender corresponding to the battery box on the right-hand side. The oil can is placed in a holder on the cover of this compartment under the hood.

It is important that the tools be placed in the tool compartment in such a way that they do not interfere with the proper placing of the seat cushion or with the seat adjusting mechanism. The jack should be placed under the driver's seat with the base toward the rear and the remainder of the tools should be arranged as shown in figure 22.




Fig. 22. Arrangement of the tools in the tool compartment.

[40]




Fig. 21. To operate the cigar lighter press it in its socket, hold until the glow is seen; then remove it.

Tool equipment provided with the car is as follows:

Hammer
Large Screw Driver
Small Screw Driver
Pliers
Spark Plug Wrench
Crescent Adjustable Wrench
Starting Crank

Jack Handle
Jack
Oil Can
Hub Cap and Wheel Mounting Wrench
Tool Bag
Operator's Manual

Tires

For normal driving the front and rear tires should be inflated to a pressure of 40 lbs. *Important*—On cars driven at high speeds, the front tires should be inflated to 45 lbs.

The tires should be checked at least weekly and brought up to the recommended pressure if necessary. The pressure should never be permitted to drop more than five pounds. If this is done, tire wear will be kept at a minimum.

Spare Wheel Carrier

To remove a spare wheel from the carrier either on the rear of the car or in the fenders, first remove the hub cap; then unlock the lock and take it out, using the key as a handle. It may be necessary to hold the lock while turning the key. Unscrew the clamping nut underneath the lock. On cars with the wheel carrier in the rear, the wheel may then be lifted off. On cars with fenderwell carriers, however, the clamping knob on the brace rod must first be loosened by turning to the left until the wheel may be cleared from the brace rod and lifted off.




Fig. 23. The clamping nut may be reached after unlocking and removing the lock.

[41]




Fig. 24. The spare wheels on cars with fenderwell carriers may be removed after loosening the brace rod clamping screw.

To reinstall a spare wheel on the rear carrier, mount it on the carrier, reinstall the clamping nut, snap the lock back into place and place the dust shield in position. On fenderwell carriers, place the wheel in the well, screw the clamping knob on the brace rod down until the clamping screw can be pushed into position and install the clamping nut. Reinstall the lock and the hub cap, then screw the brace rod clamping knob down until the wheel is held solidly in place.

Changing Wheels

If a fully inflated spare tire is always carried, it is only necessary, in case of tire trouble, to remove the wheel with the flat tire and install the spare wheel in its place. Illustrated directions for performing this work are given in figure 25, page 43.

In case tire trouble develops when no spare is available, the tire can be easily removed from the drop-center rim for repair. Instructions for removing and installing tires on the wheels are given on page 51, Chapter VI.

Fig. 25a. Set the hand brake lever to prevent the car from rolling and jack up the axle. Remove the hub cap with the wrench in the tool kit. Arrows on the hub cap indicate the direction in which it turns off and on.



Fig. 25b. Loosen the nuts around the wheel hub by turning them in a counter clockwise direction with the wrench. Remove the nuts and pull the wheel off of the hub.




Fig. 25c. To remount the wheel, set it up on the hub and start the nuts by hand; then tighten the nuts with the wrench, but not in rotation. After tightening one nut, tighten the nut directly opposite until all have been securely drawn up. Install the hub cap, using the hub cap wrench, and lower the jack.




Fig. 25. Changing Wheels.

CHAPTER VI

GENERAL CARE

NO ATTEMPT has been made to include in this manual directions for making adjustments and repairs to the car. Most Cadillac owners prefer to depend on authorized Cadillac-La Salle service stations for such work as these stations can invariably perform the work more conveniently and economically.

Every owner should, however, know how to perform the few simple operations of general care described in this chapter. These

operations are not difficult enough to necessitate a visit to the service station, although this work also can be done in the service station if desired.




Fig. 26. The cover of the battery compartment is held by four screws.

The battery is filled with an acid solution from which the water slowly evaporates and fresh distilled water must be added to each of the three cells at regular intervals to bring the level up to the bottom of the filling tubes. Distilled water should be added at least every 1000 miles and, in warm weather, every 500 miles or at least every two weeks. Hydrant water or water that has been in contact with metallic surfaces is not satisfactory.

Storage Battery

The Delco Storage battery is carried in a compartment in the right-hand front fender. The battery may be reached after removing the four screws and taking off the cover shown in figure 26.

After adding water to the storage battery in freezing weather, the car should immediately be run far enough to thoroughly mix the water with the acid solution. If the car is parked immediately after water is added, the water is likely to stay on top of the acid solution and may freeze, thus causing extensive damage to the battery.

No attempt should be made to add acid or any so-called "rejuvenator solution" to the battery. Adding anything other than distilled water will materially shorten the life of the battery.

The specific gravity of the acid solution changes as the battery is charged and discharged. The state of charge of the battery can thus be determined by measuring the specific gravity of the solution with a hydrometer. As the battery is charged, the specific gravity of the solution increases, reaching 1.270 to 1.285 when the battery is fully charged. A fully discharged battery has a specific gravity of 1.150 to 1.165.

An accurate test cannot be made immediately after adding distilled water. The hydrometer reading should be taken before water is added, or, if the solution is so low that it cannot be reached, distilled water should be added to bring the solution up to the proper level and the car run for several hours until the solution is properly mixed before the test is made.

Generator Charging Rate

Current is supplied to the battery from a generator driven by the engine and the generator charging rate must be high enough to keep the battery charged. Under normal operating conditions, if a hydrometer test shows the battery is low the charging rate should be checked and adjusted at a service station. If the test shows the battery is extremely low, it should be recharged from an outside source before continuing to drive the car.

Winter driving places greater strains on the battery than summer driving and the generator charging rate should be adjusted to take care of the increased demands. If the maximum charging rate is not sufficient to take care of this extra load,

arrangements should be made to have the battery charged from an outside source periodically to insure dependable operation throughout the winter months.

Spark Plugs

The spark plugs provide the spark which ignites the gasoline mixture in the cylinders, and smooth and economical engine performance depend largely upon their efficiency. The accumulation of carbon and improper gap setting are generally the cause of inefficient spark plug operation. Their efficiency can be increased in such cases by cleaning out the carbon and by resetting the gap.

To clean carbon from the insulator, fill the lower part of the plug with alcohol, liquid metal polish or equal parts of ammonia and water and allow it to stand for a few seconds. Rub the carbon from the insulator with a wire covered with one thickness of cloth; then wipe it clean and dry before replacing the spark plug in the engine.

Whenever spark plugs are reinstalled in the engine, the firing points should be tested to make sure they are properly spaced. The gap should be .025 to .028 inches, measured with a feeler gauge. All adjustments of the gap should be made by moving the side wire only.

Cooling System

The capacity of the cooling system is $6\frac{1}{2}$ gallons. When the car is delivered to the owner the cooling system contains, in addition to the water and whatever anti-freeze is used, a small amount of soluble oil such as is used in machine shops as "cutting" oil. This oil has particular advantages in reducing foaming and retarding the formation of rust and scale, thus helping to keep the cooling system clean so that it will better perform its cooling action. It is not necessary to add the oil each time water or anti-freeze is added. Whenever the cooling system is drained and re-

filled, however, it is recommended that one pint of a good soluble oil be added. More than this should not be added as too much may result in foaming, defeating the purpose for which it is intended.

In freezing weather a suitable anti-freeze solution, such as those described on page 29, should be used. The soluble oil, although it has no anti-freezing qualities in itself, will blend satisfactorily with any approved anti-freeze. Allowances must, of course, be made when testing the cooling solution for the effect soluble oil has on its specific gravity.

Before the start of cold weather, the cooling system should be cleaned and thoroughly inspected to make sure all connections are tight. If soluble oil is used this cleaning will suffice for the entire year; otherwise it is advisable to clean it thoroughly every 6000 miles, using the reverse flow method which is standard at all Authorized Cadillac-La Salle Service Stations.

If this is not possible a satisfactory cleaning, although not as effective as the reverse flow-method, may be obtained by using the following procedure:

Run the engine until the opening of the radiator shutters indicates that the engine is warm; then stop the engine and open the drain valve on the right-hand side of the engine at the water inlet elbow and a little to the rear of the generator as shown in figure 27. After the liquid has drained off, refill the cooling system with warm water, run the engine for a few moments, and drain the system. Repeat this operation until the water is clean when it is drained.

In cases where the accumulation of rust and scale is so great that this method does not clean the system sufficiently, the flushing




Fig. 27. The cooling system may be drained by opening the one valve.

operation should again be repeated after one or two handfuls of sal soda have been added. Care must be taken, of course, that the cooling system is thoroughly flushed after this operation to clean out all traces of the sal soda, and that none of the solution is allowed to reach the car finish.

Gasoline System

A gasoline filter is provided at the bottom of the fuel pump on the front left-hand side of the engine. Any accumulation of water or sediment should be cleaned out when it can be seen in the glass bowl.




Fig. 28. The gasoline filter should be removed and cleaned whenever water or sediment appears in the bowl.

be wiped clean. The bowl should then be reinstalled with the screen on top. Make sure the bowl seats properly against the cork gasket at the top of the filter, swing the yoke into place and tighten the thumb nut.

The strainer on the carburetor where the gasoline enters should also be cleaned periodically. It may be removed by disconnecting the feed pipe, removing the two cap screws above the inlet connection shown

The bowl may be removed by unscrewing the thumb nut on the underside of the bowl and swinging the yoke to one side. The screen strainer at the top of the bowl usually comes off with the bowl but if it does not, it may be removed by pulling it straight down.

Any dirt on the strainer should be washed off with gasoline and the bowl should




Fig. 29. The strainer in the carburetor may be removed with the bowl by disconnecting the feed pipe and removing the two screws shown.

in figure 29. Both the strainer and the sediment chamber should be cleaned in the same manner as the gasoline filter.

Carburetor Air Cleaner

The carburetor intake silencer serves also as an air cleaner. This cleaner is designed to catch any dust or lint in the air before it is drawn into the carburetor. It is automatic in operation and requires no attention other than periodic cleaning.

The mileage at which the air cleaner requires attention depends entirely upon the conditions under which the car is operated. For normal driving in cities and on hard surfaced roads, cleaning once every 6000 miles is sufficient. Under extreme conditions, however, such as continuous driving on dusty roads or in localities where there is considerable dust in the air, cleaning may be required as frequently as every 2000 miles.

The air cleaner may be lifted out, as shown in figure 30, after the cover of the intake silencer has been removed. The cover of the silencer is held by two acorn nuts. After the air cleaner has been removed it should be thoroughly washed in gasoline, permitted to drain and then dipped in fresh engine oil. *Do not wash the cover.* It may then be reinstalled by placing it in the top of the silencer cylinder and replacing the cover.




Fig. 30. The cover to the air cleaner and silencer should not be washed under any circumstances.

Brakes

The importance of the proper operation of the brake system as an essential measure of safety is so great that all service on it

should be performed at a service station where proper adjustments and tests can be made with the greatest accuracy. Adjustment should never be neglected so long that the pedal reaches the floor board before the brakes take effect. In case of emergency, however, should this occur, the following temporary adjustment can be made by the driver.

Turn the adjusting nut on the cam lever, shown in figure 31, of each of the four brakes one half a turn in a clock-wise direction. These adjusting nuts lock each sixth of a turn to hold the adjustment.

A permanent adjustment should be made as soon as a service station can be reached.



Fig. 31. A temporary brake adjustment can be secured by turning the adjusting nut on each brake one-half a turn clockwise.

Tires

The most important factor in the life of a tire is its inflation pressure. Each tire should be tested at least once a week and the pressure should be kept at 40 pounds front and rear; if the car is to be used for high speed driving the pressure of the front tires should be increased to 45 pounds.

With the inflation pressure properly maintained injuries to the tire structure will be kept at a minimum. Severe cuts, however, caused by sharp obstructions in the street or on the road, will invariably appear. If these cuts are neglected, the action of the

weather and grit and gravel will in time weaken the tire around those points. If the cuts are sealed immediately by a good vulcanizer, however, these points will be protected and the life of the tire will be lengthened.

Removing Tires from Wheels

The wheels used on the Cadillac V-8 have rims of the drop center type, constructed as shown in figure 32. The tires supplied with this type of wheel have a soft rubber tip on the bead to protect the tube from chafing and a hoop of wire inside the bead to maintain the shape of the tire.

The removal and installation of tires on the drop center rim is simple and easy, because the bead can be pushed down into the well on one side while it is being pulled over the flange on the opposite side. Illustrated directions for removing and installing tires are given in figures 33 and 34. Care must be taken in removing and installing the tires not to damage the soft rubber tip or to break or unnecessarily strain the hoop of wire. If prying the bead over the flange seems to require too much force it is an indication that the bead is not down in the well on the opposite side of the wheel.

The changing of tires on drop center rims is made easier by coating the inside and outside of the bead as required with a vegetable oil or soft soap. *Do not use oil or grease.* If it is applied each time a tire is changed there should never be any difficulty in




Fig. 32. Principal features of the drop center rim and special tires.



Fig. 33a. Deflate the tube completely and remove the rim nut on the valve stem. Loosen both beads from the bead seats, using a tire tool if necessary. Stand on the tire, opposite the valve stem, with the feet about 15 in. apart, to force the bead into the rim well.



Fig. 33b. Insert two tire tools, about 8 in. apart, between the bead and the rim flange near the valve. Leaving one tool in position, pry short lengths of the bead over the flange with the other until the entire bead has been removed.



Fig. 33c. Remove the inner tube before attempting to remove the second bead. Raise the wheel to an upright position, insert a tire tool between the second bead and the rim flange at the top side of the wheel and pry the wheel out of the tire. This operation will be simplified if the soft tip of the bead is first coated with vegetable oil or soft soap.

Fig. 33. Removing Tires

[52]

Fig. 34a. Coat both beads of the tire with vegetable oil or soft soap before reinstalling the tire. Inflate the tube until barely rounded out and insert in the tire with the stem at the tire balancing mark. Place the tire on the rim, guiding the valve through the hole, and apply the rim nut loosely. Push the bottom bead down into the well at the valve and force the remaining portion of the bead over the rim flange, using a tire tool if necessary.



Fig. 34b. Force the top bead over the rim flange and into the well at the point opposite the valve. Kneeling on this side of the tire to hold it in the well, pry short lengths of the remaining portion of the bead, working around the rim until the entire bead is in place. Always keep as much of the top bead in the well as possible while prying the remainder of the bead.



Fig. 34c. Remove the rim nut and push the valve stem back into the casing as far as possible without letting go of the stem to make certain that the tube is not pinched under the bead; then reapply the rim nut. With the wheel flat on the floor, inflate the tire slowly, making sure that both sides of the tire are centered on the rim.



Fig. 34. Reinstalling Tires

[53]

removing or installing the tire. If, when removing the tire, however, some difficulty is experienced in removing the second bead, coating the bead with the vegetable oil or soft soap will make the removal easier.

Tire Balancing Marks

The tires used on the Cadillac V-8 are balanced to offset the weight of the valve stem and if a tire is removed it must be reinstalled in its original position with respect to the rim, otherwise the tire and wheel will be unbalanced.

A small red or black dot branded in the side wall of the tire indicates the point of balance. This mark must always be kept in line with the valve stem.

Lights

In replacing lamp bulbs in any of the lights on the car, the same candle power bulb should be used for replacement as was originally installed. This is particularly important in the case of the headlamps in which a special 3-filament bulb is used. It is a good plan to carry a spare set of these lamp bulbs at all times in the car.

The lamp bulbs used in the car are as follows:

Location	Voltage	Candle Power	Mazda No.
Headlamps	6-8	$\left\{ \begin{array}{l} 32 \\ 21 \text{ (three filament)} \\ 21 \end{array} \right.$	3001
Rear Lamp (signal position)	6-8	15	87
Rear Lamps (parking driving)	6-8	3	63
Instrument Lamp	6-8		
Map Lamp	6-8		
Fender Lamps	6-8		
Dome Lamp	6-8	6	81
Quarter Lamps	6-8		
Deck Compartment Lamps	6-8		
Tonneau Lamp	6-8		

[54]

Replacing Map Lamp Bulb

The bulb in the map lamp may be replaced after the lamp shield has been removed. To remove the shield, pull the lamp out until the threaded terminal at the rear (behind the instrument panel) is about flush with the edge of the lamp cylinder. Turn the lamp slowly until the hole in the plunger lines up with the hole in the lamp cylinder and insert a small nail as shown in figure 35, to keep the plunger from turning. The shield may then be unscrewed by turning to the left. The nail should be kept in place until after the bulb has been replaced and the shield reinstalled.




Fig. 35. The bulb shield may be unscrewed after the holes in the lamp cylinder and the plunger have been lined up and a nail inserted to hold the plunger.

Aiming the Headlamps

The headlamps used on the Cadillac V-8 are of the Super-Safe fixed focus type. For this lighting system the three filament bulb and the Super-Safe headlamp lenses must be used. The right and left lenses are not interchangeable and in case of replacement, the proper parts designed for the particular side must be used. The Super-Safe trademark is clearly marked on the lens, the reflector and the lamp housing.

The only adjustment ever necessary on these headlamps is the aiming of the beam. The aim should be tested periodically in accordance with the procedure given below, except where state

[55]

or local regulations apply. In such cases, the procedure should be modified to satisfy the legal requirements.

A light colored vertical surface, such as a blank wall or a garage door, marked as shown in figure 36 according to the dimensions indicated, is required for the test. The car should be placed so that the front of the headlamps are square with and twenty-five feet from the vertical surface. The center line of the markings on the wall can then be located by sighting through the center of the rear window over the radiator cap.

The test should be made with one lamp at a time, and with the light switch on the steering column in the "City Driving" position. One lamp should be covered while the other is being tested. If the lamps are properly aimed, the light beam of the left hand




Fig. 36. Light pattern of the left-hand headlamp with the car twenty-five feet from the vertical surface and the light switch in the "City Driving" position. The location of the beam should be determined in relation to the lines drawn in at the dimensions indicated.



Fig. 37. Light pattern of the right-hand headlamp projected under the same conditions as the left-hand headlamp.

[56]

lamp will be patterned and located as shown in figure 36, while those of the right hand lamp will be patterned and located as shown in figure 37.

If either lamp fails to project a beam patterned and located as shown, the acorn nut at the bottom of the lamp, shown in figure 38, should be loosened. The lamps should first be set so that the flutes on the lens are straight up and down. They may then be turned sidewise or up and down until the proper aiming is secured. Holding the lamp in position, the nut should be securely tightened and the lamp again tested.



Fig. 38. The headlamps may be turned in any direction necessary for aiming after loosening the clamping nut at the base of the lamp.

Storing the Car

If the car is to be stored for any length of time it is important that a few precautions be taken to protect it from deterioration. Blocking up the car to take the weight off of the tires and placing a cover over the entire body will protect the tires and finish. The engine and the storage battery, however, require special attention.

Oil should be injected into the cylinders while the engine is warm. This may be done by pouring two or three tablespoonsful of engine oil into the spark plug holes after the engine has been run long enough to warm it up. Cranking the engine a few times after this is done will distribute the oil evenly over the pistons and cylinder walls. The cooling system should then be drained.

The battery should be fully charged and the solution should be at the proper level. If possible, arrangements should be made to have the battery charged from an outside source every two months during the storage period.

[57]

Body

The body of a Cadillac car is deserving of care and attention the same as the most intricate working parts of the chassis. In



Fig. 39. Authorized Cadillac-La Salle Service Stations displaying this sign are equipped to render complete body service.

recognition of this fact, Authorized Cadillac-La Salle Service Stations displaying the *Complete Service* Sign, shown in figure 39, at the bottom of the authorized service sign have equipped themselves to service the body with as much expert skill and care as the chassis. The simple attentions described below, however, are frequently performed by the owner or under his immediate supervision.

Care of the Finish

Keeping the lacquer finish of the car new and lustrous requires only a thorough wiping with a soft dry cloth every few days and an occasional polishing with a recognized lacquer polish. With this care, the car will need to be washed only when considerable mud or dust has accumulated.

Washing of the car can be accomplished simply and easily with plenty of clean cold water, a soft wool sponge and a clean chamois. Soap and hot water are not only unnecessary but undesirable. The dust or mud should be flushed off with a *gentle* stream of water from a hose without a nozzle, using the sponge merely to loosen the dirt. After all the dirt has been removed in this way, the sponge should be squeezed dry and used to pick up the water from the crevices. Thoroughly wet the chamois and squeeze it dry, then rub the finish with it until all of the water has been removed.

Care of the Top

The top may be kept clean by an occasional wiping to remove

the dust. This is all the care required to keep the top clean unless grease spots, stains or dirt film occur. In these cases washing with a mild, neutral soap may be resorted to. Gasoline, naphtha, kerosene and fabric cleaners should never be used since such preparations can easily dull the finish and damage the fabric. Soap and water is not harmful and is fully as effective.

Cleaning Upholstery

Regular monthly cleaning of the car interior with a vacuum cleaner and a whisk broom will keep the upholstery in the best of condition and will prevent excessive wear. The whisk broom should be used to loosen the dirt and grit, which causes more rapid wear than use, while the vacuum cleaner should be used to lift out the loosened dirt.

Spots on the upholstery may be cleaned with any good dry cleaner used sparingly. When the cleaner has thoroughly evaporated, fold a piece of cheese cloth four or five times, dampen it, and place it over the spotted surface; then run a hot iron over surface just long enough to raise a good steam. Plush fabrics can be restored to their original appearance by rubbing lightly against the nap with a brush after the fabric has been steamed in this way.

Door Hardware

The lubrication of the body hardware on the car is fully as essential as the lubrication of chassis parts if it is to work smoothly and silently. Directions for the lubrication of door locks, hinges and striker plates every 1000 miles are included on the lubrication chart. These directions should be followed as faithfully as the rest of the chart.

Body Adjustments

Preventive service on the body at regular intervals will keep the appearance of the car at its best and will eliminate more

extensive repairs at a later date. This service should include body bolts, tie-down bolts, door adjustments and the operation of window regulators.

Authorized Cadillac-La Salle service stations include the body as well as chassis in the regular monthly or 1000 mile inspection and quote flat rate prices for necessary body service. The necessary work may be authorized by the owner at the time he has chassis adjustments made and the car lubricated.

CHAPTER VII

SPECIFICATIONS AND LICENSE DATA

Type of engine.....	8 cyl. V-type
Diameter of cylinder bore.....	3 $\frac{3}{8}$ in.
Length of stroke.....	4 $\frac{15}{16}$ in.
Piston displacement.....	353 cu. in.
Horsepower (N. A. C. C. rating).....	36.45
Engine number.....	See below
Capacity of gasoline tank.....	30 gals.
Capacity of engine lubricating system.....	8 qts.
Capacity of cooling system.....	6 $\frac{1}{2}$ gals.
Capacity of transmission.....	2 $\frac{1}{4}$ qts.
Capacity of rear axle.....	3 qts.
Wheelbase.....	134-140 in.
Tires.....	7.00 x 17
Spark plug setting.....	.025-.028 in.
Contact point setting.....	.018-.024 in.
Generator charging rate, maximum.....	<div style="display: inline-block; vertical-align: middle;"> <div style="display: inline-block; vertical-align: middle;"> { 22-24 amps. cold 13$\frac{1}{2}$-16$\frac{1}{2}$ amps. hot </div> </div>

Engine and Unit Assembly Numbers

Each Cadillac car, when shipped, carries an engine number, which is also a serial number. This is the number to be used in filling out license and insurance applications and in general reference of the car. The engine number is stamped on the right hand side of the crankcase just below the water inlet.

The various units, such as the transmission, steering gear, etc., also carry unit assembly numbers. These are located as described below. It is important in ordering parts to give, not only the engine number of the car, but also the unit assembly number of the unit to which the part belongs.

Transmission number—on the upper left-hand edge of the flange by which the transmission is bolted to the crankcase.

Steering gear number—on the steering gear housing next to the grease plug.

Generator number—on the right-hand side of the generator.

Starting motor number—on the right-hand side of the starter, just below the switch.

Front axle number—on the upper surface of the right-hand spring pad, just outside of the car spring.

Rear axle number—on right-hand side of the axle housing to the right of the cover plate.

Chassis (frame) number—on the flange of the first channel cross-member, next to the left front engine support.

Job and body numbers—on the right-hand side of car on the cowl under the hood.

INDEX

A

Accelerator	20
Accelerator, use in cold weather	34
Adding water to battery	44
Adjustable seats	39
Air cleaner	49
Alcohol for anti-freeze	29
Ammeter	19
Anti-freeze solutions	29
Authorized service stations	5

B

Balancing marks on tires	54
Battery	32, 44
Battery, preparing for storage	57
Body, Care of	58
Brake adjustment	49

C

Cadillac service	3
Carbon monoxide poisoning	28
Carburetor air cleaner	49
Carburetor flooded	22
Carburetor, to prime	34
Card, identification	4
Changing engine oil	16
Changing tires	51
Charging rate	45
Charges for service	7
Chart, lubrication	11
Chassis lubricant	14
Choke control	21
Cigar lighters	39
Clutch, use of	23
Coasting	23, 28
Controlled Free-Wheeling	23
Cold weather lubrication	32
Cold weather operation	29
Compartment for tools	40
Contract, Service	8
Cooling system	46
Crankcase ventilating system	16

D

Danger from carbon monoxide	28
Door Locks	36
Driving Hints	25
Driver's seat adjustment	39
Driving speed when new	5

E

Effect of alcohol on finish	29
Engine fails to start	22
Engine lubrication	15
Engine number	61
Engine oil	13
Engine oil, changing	16
Engine, preparing for storage	57
Engine, running in garage	28
Equipment	35

F

Filter for gasoline	48
Filter for oil	16
Flat-rate service charges	7
Flooded carburetor	22
Flushing cooling system	47
Free-Wheeling	23

G

Gasoline filter	48
Gasoline gauge	18
Gasoline system, cold weather	33
Gear lubricant	14
General care	44
Glycerine for anti-freeze	30

H

Headlamps	24, 55
Hood Parts	20

I

Identification card	4
Ignition control	36
Ignition switch lock	36
Inflation pressure	41, 50
Inspections	6
Instrument Panel Package Compartment	37

K

Keys	35
------	----

L

License data	60
Lighting switch	24
Locks	35
Locks for spare tires	35, 41
Lubricants	12
Lubrication	11
Lubrication Agreement	8
Lubrication, chart	11
Lubrication, cold weather	32
Lubrication, engine	15
Lubrication notice	12
Lubrication, schedule	10

M

Map lamp	37, 55
----------	--------

O

Obligations of owner	5
Oil filter	16
Oil level	16
Oil pressure	18
Operation	18

P

Parts, uniform prices	6
Preventive service	6
Priming carburetor	34

R

Repair parts	6
Replacing engine oil	16
Replacing filter cartridge	16
Ride Regulation	24

S

Schedule lubrication	10
Seat adjustments	39
Service contract	8
Service charges	7
Service stations	3
Shifting gears	23
Spare tire carriers	41

Copyright 1932 by
Cadillac Motor Car Company

Specifications	60
Specific gravity of battery	45
Standard Service Contract	8
Starting Hints	22
Starting the engine	21
Starting the engine in cold weather	33
Storage battery	32, 44
Storing car	57

T

Throttle control	20, 33
Tire balancing marks	54
Tire carrier	41
Tire pressure	41, 50
Tires, changing	51
Tires, preparing for storage	57
Tools	40
Tourists, service to	4
Transmission control	23
Transmission lock	36

U

Unit assembly numbers	61
Use of accelerator before engine is warm	34

V


Ventilator	38
Visor	39

W

Water pump lubricant	15
Wheel bearing lubricant	14
Windshield	38
Windshield cleaner	39
Winter lubrication	32
Winter operation	38
Wheel carrier	41

355-2
5900-12-31
Printed in U. S. A.

CADILLAC-LA SALLE
SHOP MANUAL



Changes to be made in "B" series Shop Manual

Make the following changes in your copy of the "B series Shop Manual, so that it will contain the latest information. This information does not appear on the revised pages.



- Page 11. Differential carrier assemblies (Note 1) are no longer serviced as a unit for V-8 and V-12 "B" and "C" series cars. See "Replacement and Adjustment of Rear Axle Ring Gear and Drive Pinion," page 13A.
- Page 19. The sentence "When ordering chassis parts affected by wheelbase, the Body Job Number must be given the same as when ordering body parts" should be crossed out. This information is no longer necessary.
- Page 32. The instruction "Lubricate control valve with light machine oil" should be changed to read, "Lubricate with S. A. E. No. 10 oil or light machine oil of weight similar to shock absorber oil."
- Page 46. In Fig. 2, the dimension $\frac{7}{8}$ in. indicating the distance the timing mark is ahead of the dead center mark on 345-B and 355-B flywheels, should be changed to $1\frac{1}{8}$ in.
The dimensions $1\frac{3}{4}$ in. and $1\frac{1}{4}$ in. for the 370-B and 452-B engines, respectively, applies only to these models. On 370-C and 452-C engines the ignition timing mark is $\frac{1}{2}$ in. ahead of the center mark as measured on the circumference of the flywheel.
- Page 47. Opposite the subject "Timing mark IG/A ahead of center" the dimension $1\frac{1}{8}$ " for the 370-B should be changed to $1\frac{3}{4}$ ".
- Page 53. The piston clearances as given in Note 10 are no longer recommended. New limits have been set up in production and are now recommended for fitting pistons in service for both standard and oversize blocks. For V-8 and V-12 cars (with Electro-plated pistons), use a .0025 in. feeler gauge, with a pull of 6 to 15 pounds pull on the spring scale. With V-16 cars (unplated pistons), use a .003 in. gauge with a pull of 6 to 9 pounds on the scale.
- Page 61. Opposite the subject "Width of rings—Lower compression (Two on 452-B)," the dimension $\frac{1}{8}$ " should be inserted in the 452-B column.
- Page 79. The fourth paragraph in the second or right column should be changed to read as follows:
"The beam modification for Pennsylvania consists in rendering the 32 candle-power beam in the right headlamp inoperative by the use of a special switch lever at the top of the steering wheel. In the remaining states the beam modification is obtained by disconnecting the right head-lamp wire leading to the 32 candle-power filament in the lamp bulb. Owners of cars thus modified should be cautioned against any attempt to restore to use the filament thus eliminated."

NOTE—A special bulb with a filament arrangement of 21-32-21 candlepower is available from the Factory Parts Division, under Part No. 883874, for use in the Super-Safe lighting system in Pennsylvania. When used in the Super-Safe lamps, these bulbs provide a City Driving Beam by lighting a 32 c.p. filament in each lamp in place of the 21 c.p. filament normally used. This provides a very satisfactory driving light for either city or country driving. The Country Passing Beam utilizes both a 32 c.p. and a 21 c.p. filament in the left lamp and a 21 c.p. filament in the right lamp. The City Passing Beam lights a 21 c.p. filament in each lamp. The Country Driving Beam is, of course, not used. These arrangements all comply with the Pennsylvania law.

- Pages 86 and 88. The caption above the top row of illustrations "Clutch Control Cylinder" should read "Clutch Control Valve."
- Page 99. The yoke throw from neutral to applied position should be $\frac{1}{8}$ — $\frac{5}{32}$ " instead of $\frac{3}{32}$ — $\frac{5}{32}$ ".
- Page 102. In Fig. 2, the yoke travel should be $\frac{1}{8}$ — $\frac{5}{32}$ in.
- Page 107. The instructions presented in Note 1 for adjusting the front wheel bearings are now obsolete. See latest recommendations given in Note 4 on page 106B.
- Page 109. Opposite the subject "Pressure in Pounds—Normal—Front and Rear" the Number 40 should be changed to 35 for all car models.
The following item should also be included under Tires-Pressure in pounds. "The front tires on all models should be inflated to 40 pounds for continuous high speed driving."
The rim diameter and tire size as given for the 452-B applies also to early 452-C cars. Later 452-C cars are provided with 17-in. rims and 7.50 x 17-in. tires the same as the 370-C.

CADILLAC - LA SALLE SHOP MANUAL

CADILLAC 355-B-C, 370-B-C, 452-B-C
LA SALLE 345-B-C



Service Department
CADILLAC MOTOR CAR COMPANY
DETROIT, MICHIGAN

FILE COPY
DO NOT REMOVE

FILE COPY
DO NOT REMOVE

Foreword

THIS Shop Manual is a book of reference on the adjustment and repair of Cadillac and La Salle motor cars. It is intended for the use of service men who are already familiar with automobile construction and repairing in general. It is not a text book for those who have had no previous Cadillac shop experience and does not present instructions in elementary form.

The style in which the information is presented is a distinct departure from the usual book of this sort. Straight reading matter has been eliminated as far as possible and the facts and figures needed by service men are presented briefly in two ways—by illustrations and by tabulated specifications.

At the beginning of each group is a brief description accompanied by service information in the form of notes. Following this is a specification table giving clearances, dimensions and other facts important to service men. The rest of the information is in picture form.

Our Service Department invites correspondence with Service Managers and Shop Foremen on all matters discussed in the Shop Manual.

CADILLAC MOTOR CAR COMPANY

Detroit, Michigan

FILE COPY
DO NOT REMOVE

Introduction

Arrangement of Tables

THE subjects covered in the specification tables are listed in alphabetical order in the first column. Under these items will be found important comments, cautions and references to illustrations and notes.

One class of information in the specification tables consists of limits for the clearance between parts subject to wear. The limits given are of two kinds. The "New limits" are those to be observed when installing new parts. The "Worn limits" are those beyond which it is inadvisable to continue to use the worn parts if quietness of operation and maximum performance are to be expected. Some service, although not the most satisfactory, can of course be obtained from parts worn beyond these limits.

Arrangement of Illustrations

The illustrated pages are laid out to show as far as possible in picture form the repair operations, together with the differences and similarities of the various car units.

Unless otherwise specified all illustrations apply to both the Cadillac and the LaSalle.

Identification Numbers

Each Cadillac and La Salle car when shipped carries an engine number which is also a car serial number. This is the number to be used in filling out license and insurance applications and in general reference to the car. On Cadillac 355-B and La Salle 345-B cars, this engine number is stamped on the crankcase near the water inlet on the right-hand side. The Cadillac 370-B and 452-B have the engine number stamped on the right-hand side of the crankcase on the generator drive chain housing.

The various units such as the engine, transmission, steering gear, etc., also carry unit assembly numbers. These are located as described in the specification tables. It is important when ordering parts to give, not only the engine number of the car, but also the unit assembly number of the unit to which the part belongs.

Contents

NOTE: The information contained in this book is grouped under the headings shown below.

Front Axle

	Page
General Description.....	7
Service Information.....	7, 9
Specifications.....	9
Plate 1. Front Axle Details.....	8
Plate 2. Front Axle Alignment, Camber and Caster.....	10

Rear Axle

General Description.....	11
Service Information.....	11, 13A, 13B, 13D
Replacement and Adjustment of Rear Axle Ring Gear and Drive Pinion.....	13A, 13B, 13D
Specifications.....	13
Plate 3. Rear Axle Details and Alignment.....	12
Plate 3A. Details of Rear Axle Gear Adjustment.....	13C

Body

General Description.....	15, 17, 21B
Service Information.....	17, 18, 21B, 21D, 21F
Body Type and Job Numbers for "B" Series Cars.....	19
Body Type and Job Numbers for "C" Series Cars.....	21A
Body Type and Job Numbers.....	19
Plate 4. Door Window Details and Windshield Adjustment.....	14
Plate 5. Body Mounting and Door Details.....	16
Plate 6. Location and Type of Moulding Fastenings—Fisher and Fleetwood Bodies.....	20
Plate 7. Location and Type of Moulding Fastenings—Fleetwood Bodies.....	21
Plate 7A. Front Door Details—"C" Series Cars.....	21C
Plate 7B. Rear Door and Rear Quarter Window Details—"C" Series Cars.....	21E

Brakes

General Description.....	23, 27B
Service Information.....	23, 25, 27B
Specifications.....	25
Plate 8. Brake Connections and Adjustments.....	22
Plate 9. Brake Assister Adjustments, Cadillac 370-B and 452-B.....	24
Plate 10. Diagrams Showing Operation of Vacuum Brake Assister, Cadillac 370-B and 452-B.....	26
Plate 11. Brake Details and Adjustments.....	27
Plate 11A. Diagrams Showing Operations of Vacuum Brake Assister—Cadillac 355-C—LaSalle 345-C.....	27A
Plate 11B. Brake Assister Adjustments—Cadillac 355-C—LaSalle 345-C.....	27B

Clutch

General Description.....	29, 31
Service Information.....	31, 35
Specifications.....	35
Plate 12. Clutch Details.....	28
Plate 13. Adjustment of Clutch Pedal Control and Driven Disc Details.....	30
Plate 14. Power Clutch Control Adjustments.....	32
Plate 15. Accelerator Pedal Adjustment and Power Cylinder and Control Valve Details.....	33
Plate 16. Diagram Showing Operation of Power Clutch Control.....	34

Contents

Cooling System

	Page
General Description.....	37
Service Information.....	37
Specifications.....	39
Plate 17. Cooling System Details.....	36
Plate 18. Water Pump Details and Drive Adjustments.....	38

Electrical System

General Description.....	41, 43, 50A
Service Information.....	43, 50A
Specifications.....	45, 47
Plate 19. Generator and Starting Motor Details.....	40
Plate 20. Circuit Control Box and Horn Adjustments.....	42
Plate 21. Ignition Distributor.....	44
Plate 22. Ignition Timing.....	46
Plate 23. LaSalle 345-B Wiring Diagram.....	48
Plate 24. Cadillac 355-B, 370-B and 452-B Wiring Diagram.....	49
Plate 25. Ignition Wiring Diagrams.....	50
Plate 25A. Ignition Timing—Cadillac 355-C and LaSalle 345-C Using Type 661-P Distributor.....	50B

Engine

General Description.....	51
Service Information.....	51, 53, 55, 67A, 67B, 68
Specifications.....	57, 59, 61, 63
Engine Speeds.....	55
Table of Cylinder Heads and Gaskets.....	57A
Plate 26. Sectional Views of Cadillac 355-B Engine, Typical of LaSalle 345-B.....	52
Plate 27. Bottom View of Engine and Valve Details, Cadillac 355-B, LaSalle 345-B.....	54
Plate 28. Generator and Water Pump Drive, Cadillac 355-B, LaSalle 345-B.....	56
Plate 29. Cross-sectional View of Cadillac 370-B, Typical of Cadillac 452-B except number of Cylinders.....	58
Plate 30. Bottom View of Engine and Cylinder Details, Cadillac 370-B and 452-B.....	60
Plate 31. Valve Details, Cadillac 370-B and 452-B.....	62
Plate 32. Front End Drive, Cadillac 370-B and 452-B.....	64
Plate 33. Piston and Connecting Rod, Vacuum Pump and Engine Mounting.....	65
Plate 34. Oiling System, Cadillac 355-B, LaSalle 345-B.....	66
Plate 35. Oiling System, Cadillac 452-B, Typical of 370-B.....	67

Exhaust System

General Description.....	69
Service Information.....	69
Plate 36. Exhaust System Details.....	69A

Fenders

Plate 36A. Front Fender Tie Rods—"C" Series Cars.....	69B
---	-----

Frame

General Description.....	71
Specifications.....	71
Plate 37. Frame Alignment.....	70

Gasoline System

General Description.....	73, 75
Service Information.....	75, 77
Specifications.....	77
Plate 38. Carburetor Details and Adjustment, and Intake Muffler, Cadillac 355-B, LaSalle 345-B.....	72
Plate 39. Carburetor Details and Adjustment, Cadillac 370-B and 452-B.....	74
Plate 40. Fuel Pump and Carburetor Air Cleaner.....	76

Lighting System

	Page
General Description.....	79, 81
Service Information.....	81
Specifications.....	81, 82
Plate 41. Lamp Details.....	78
Plate 42. SUPER-SAFE Lamp Bulb and Focusing Charts.....	80

Lubrication

Service Information.....	83
Specifications.....	83
Engine Oil Recommendations.....	85
Changes for "B" Series Lubrication Charts for "C" Series Cars.....	85
Plate 43. Lubrication Schedule and Record Card, Cadillac 355-B, Typical of LaSalle 345-B.....	84
Plate 44. Lubrication Chart, Cadillac 355-B, Typical of LaSalle 345-B.....	86
Plate 45. Lubrication Schedule and Record Card, Cadillac 370-B, Typical of 452-B.....	87
Plate 46. Lubrication Chart, Cadillac 370-B, Typical of 452-B.....	88

Springs and Shock Absorbers

General Description.....	89, 92A
Service Information.....	89, 92A
Specifications.....	91
Chart Showing Interchangeability of "B" and "C" Series Shock Absorbers.....	92B
Plate 47. Modulator and Spring Shackles.....	90
Plate 48. Shock Absorbers and Control.....	92
Plate 48A. Shock Absorbers—"C" Series Cars.....	92A

Steering Gear

General Description.....	93
Service Information.....	93
Specifications.....	93, 95
Plate 49. Steering Gear and Connections.....	94
Plate 50. Steering Gear Adjustments.....	96

Transmission

General Description.....	97
Service Information.....	97, 106A
Specifications.....	99, 101
Speedometer Pinion Chart.....	101, 103
Plate 51. Sectional View of Transmission, Typical of all Models.....	98
Plate 52. Transmission Synchronizing Mechanism.....	100
Plate 53. Transmission Adjustments.....	102
Plate 54. Removal and Disassembly of Transmission.....	104
Plate 55. Disassembly of Transmission.....	105
Plate 56. Disassembly of Transmission.....	106
Plate 56A. Adjustment of Gear Shift Lever.....	106A

Wheels, Rims and Tires

General Description.....	107
Service Information.....	106B, 107
Specifications.....	109
Plate 57. Wheel and Rim Details.....	108
Plate 58. Removing Tire from Drop Center Rim.....	110
Plate 59. Installing Tire on Drop Center Rim.....	111

Supplementary Introduction

THE information presented in the Cadillac-LaSalle "B" series Shop Manual will in nearly all instances apply to the "C" series cars. There are, however, certain cases where the construction, adjustment or specification of a "C" series unit differs from the corresponding "B" series unit.

In order to make the "B" Shop Manual fully applicable to the "C" series cars as well as the "B" series, supplementary pages have been issued for insertion in the "B" manuals. While these pages are presented primarily to cover the differences in the "C" series cars, they also contain new information on the "B" series as well as the "A" series cars.

The supplementary pages can be identified by the date "August 1933" printed in the lower margin close to the binding edge.

FRONT AXLE

General Description

The front axles used on Cadillac and LaSalle cars are of the reverse Elliot type. They are of the same general construction, but differ slightly in minor details. The 345-B, 355-B and 370-B axles are identical but differ from the 452-B axle in dimensions and the drop of the I-beam. The 452-B steering arms are also slightly longer because of the larger brakes and for this reason the cross rod is shorter than on the other models.

The steering knuckles pivot on adjustable ball bearings at both the top and the bottom. The lower bearing takes the combined thrust and radial load and the upper one takes radial load only. The knuckle bolts and bearings are entirely outside of the brake dust shields. This construc-

tion prevents any possibility of grease from the knuckles getting on the brakes.

The front wheels are also carried on ball bearings which are adjustable.

The steering cross-rod joints are of the ball and socket type. The joints are fitted to a definite tightness because friction at this point has an important effect in steadying the front wheels. That is, the point of contact between the pivot and the seats, together with the heavy springs for holding the seats against the pivot, makes it possible to control the friction at the joint so as to absorb road shock without causing hard steering.

The service operations and adjustments of the front axle are the same on all cars.

Service Information

1. Caster Angle

The caster angle on all models is $2\frac{1}{2}$ to $3\frac{1}{2}$ °. Wedge plates are to be used when necessary between the front springs and the spring seats on the I-beam to give this caster.

Test the caster with a suitable gauge with the car on a level floor to determine the correct wedge plate to use. Place the thick edge of the plate toward the rear.

The following wedge plates may be secured from the factory Parts Division:

1° Wedge Plate—Part No. 873787

$1\frac{1}{2}$ ° Wedge Plate—Part No. 876813

2. Straightening Bent Parts

Because of their location, the parts of the front axle are more subject to damage by accident than any other part of the chassis. Front axle service, therefore, involves the inspection of parts for alignment and possible straightening.

Heat-treated parts should not be straightened if they are sprung out of alignment more than 5°. To straighten such parts while cold is likely to result in strains and sometimes in cracks not visible to the naked eye. Straightening with heat destroys the effect of previous heat treatment and may result either in overheating, making the steel soft and weak, or in underheating which will make it brittle and easily broken.

Parts which are not heat-treated may be straightened cold if not sprung out of alignment more than 10°.

Welding of parts subjected to severe strain should never be permitted. A welded part is never as strong as the original,

unbroken metal and the heat required for the welding process changes the structure of the metal around the weld, making it coarse and weak.

3. Steering Cross-Rod Joint Adjustment

The tightness of the cross-rod joint should be such that a pull of 10 to 18 pounds at the end of a 6-in. wrench is necessary to turn the pivot in the socket. This test is made by disconnecting the pivot from the steering arm, reinstalling the retaining nut on the pivot and turning the pivot with a wrench as shown in Fig. 3, Plate 1. The pivot should be well lubricated when making this test.

If the spring tension is insufficient, it can be adjusted by installing thin shims under the take-up spring.

4. Stop Screw Adjustment

The left-hand stop screw should be adjusted to keep the inner wall of the tire $\frac{3}{8}$ to $\frac{7}{8}$ in. away from the steering connecting rod.

Prior to steering gear units 11-1256 on the 345-B and 12-1245 on the 355-B and 370-B, a greater clearance may be necessary in order to prevent the sector from bottoming against the housing in the steering gear when turning to the left. The left-hand stop screw should be adjusted so that it comes into play just before the sector bottoms in the housing, making sure that the clearance is not less than that specified above.

The right-hand stop screw should be adjusted to give a clearance of not less than $2\frac{3}{4}$ in. between the tire and the frame on all cars.

FRONT AXLE




Plate 1. Front Axle Details

FRONT AXLE—Service Information—Specifications

5. Steering Knuckle Bearing Adjustment

The adjustment of the steering knuckle bearings can be checked by lifting the wheel up and down with a bar. In case of looseness, the adjusting plug should be tightened. Use a wrench with a handle 12 to 15 in. long and tighten the adjusting plug as tight as possible by hand. Do not loosen the adjustment except to eliminate binding in the steering.

6. Front Wheel Bearing Adjustment

The procedure to follow in adjusting the front wheel bearings is first to make sure that the wheel is all the way on the spindle. Then tighten the adjusting nut as tight as possible by hand using a wrench with a handle 12 to 15 in. long, after


which back off the nut one third turn or two flats. If the locking device cannot be placed in position without changing the adjustment, tighten instead of loosen the adjusting nut until it can be secured with the locking device. It is preferable to have the adjustment on the tight side rather than the loose side provided it is not necessary to tighten the nut more than one half the distance to the next cotter pin slot.

It is also a good plan to turn the wheels toward the right side when adjusting the left wheel bearings and toward the left side when adjusting the right wheel bearings to assure full release of the brakes.

CAUTION: When adjusting the front wheel bearings, care should be taken not to mistake play in the knuckle bolts for play in the wheel bearings.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Camber of front wheel (angle with vertical), Fig. 1 Plate 2—				
With car weight on wheels.....	$\frac{3}{4}$ -1°	$\frac{3}{4}$ -1°	$\frac{3}{4}$ -1°	$\frac{3}{4}$ -1°
With car weight off wheels.....	1½°	1½°	1½°	1½°
Angle between steering knuckle bolt and vertical—				
With car weight on wheels.....	8¼-8½°	8¼-8½°	8¼-8½°	8¼-8½°
With car weight off wheels.....	7¾°	7¾°	7¾°	7¾°
Angle between steering knuckle bolt and wheel spindle.	99¼°	99¼°	99¼°	99¼°
Caster angle (See Note 1).....	2½-3½°	2½-3½°	2½-3½°	2½-3½°
Angle between spring seats and vertical plane of I-beam	90°	90°	90°	90°
I-beam twist—allowable variation between ends (misalignment between steering knuckle bolts) (See Note 2).....	½°	½°	½°	½°
Road clearance under front axle.....	8½"	8½"	8½"	8½"
<i>Measure with new tires inflated to 40-45 lbs. and no load in car.</i>				
Steering cross-rod end spring—				
Free length.....	$\frac{23}{32}$ "	$\frac{23}{32}$ "	$\frac{23}{32}$ "	$\frac{23}{32}$ "
Compression in pounds when compressed to $\frac{9}{16}$ in.....	200-225	200-225	200-225	200-225
<i>Springs must not show any set when compressed with coils touching.</i>				
Steering cross-rod joint—				
Adjustment (See Note 3), Fig. 1, Plate 1.....
Pivot balls out of round—worn limit, not over.....	.010"	.010"	.010"	.010"
Pull necessary to turn pivot in socket (See Fig. 3, Plate 1)	10-18 lbs.	10-18 lbs.	10-18 lbs.	10-18 lbs.
Steering knuckle bearing adjustment (See Note 5).....
Stop screw adjustment (clearance between tire and nearest point of possible interference) (See Note 4)	$\frac{5}{8}$ - $\frac{7}{8}$ "	$\frac{5}{8}$ - $\frac{7}{8}$ "	$\frac{5}{8}$ - $\frac{7}{8}$ "	$\frac{5}{8}$ - $\frac{7}{8}$ "
Toe-in of front wheels, Fig. 7, Plate 2.....	$\frac{1}{16}$ - $\frac{3}{16}$ "	$\frac{1}{16}$ - $\frac{3}{16}$ "	$\frac{1}{16}$ - $\frac{3}{16}$ "	$\frac{1}{16}$ - $\frac{3}{16}$ "
Tread.....	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "
Type.....	Reverse Elliot	Reverse Elliot	Reverse Elliot	Reverse Elliot
Unit number location.....
All models—On top of R. H. spring pad.				
Wheel bearing adjustment (See Note 6).....



Front Axle Specifications

	345-B	355-B (Except 156 in. W.B.)	370-B (Except 156 in. W.B.)	355-B, 370-B (156 in. W.B.)	452-B
A-B-C	See "Camber" under "Specifications," Page 9 for these dimensions				
D-E	"D" should be $\frac{1}{16}$ in. less than "E"				
F	$2\frac{1}{2}$ - $3\frac{1}{2}$ °	$2\frac{1}{2}$ - $3\frac{1}{2}$ °	$2\frac{1}{2}$ - $3\frac{1}{2}$ °	$2\frac{1}{2}$ - $3\frac{1}{2}$ °	$2\frac{1}{2}$ - $3\frac{1}{2}$ °
G-H	"G" should equal "H"				
I	$6\frac{7}{16}$ "	$6\frac{7}{16}$ "	$6\frac{7}{16}$ "	$6\frac{11}{16}$ "	$6\frac{11}{16}$ "
J	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$1\frac{1}{8}$ "	$1\frac{1}{8}$ "
K	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$\frac{29}{32}$ "
L	$1\frac{11}{16}$ "	$1\frac{11}{16}$ "	$1\frac{11}{16}$ "	$2\frac{1}{16}$ "	$2\frac{1}{16}$ "
M	$7\frac{1}{2}$ "	$7\frac{1}{2}$ "	$7\frac{1}{2}$ "	$8\frac{5}{16}$ "	$8\frac{5}{16}$ "
N	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$\frac{29}{32}$ "	$1\frac{1}{8}$ "	$1\frac{1}{8}$ "
O	$\frac{11}{16}$ "	$\frac{11}{16}$ "	$\frac{11}{16}$ "	$\frac{15}{32}$ "	$\frac{15}{32}$ "
P-Q	"P" should be $\frac{1}{16}$ — $\frac{3}{16}$ in. less than "Q" measured against tire side wall 8 in. above floor.				

Plate 2. Front Axle Alignment, Camber and Caster

REAR AXLE

General Description

Cadillac and LaSalle rear axles are of the three-quarter floating type. They are similar in construction but differ somewhat in dimensions and in gear ratios.

The construction of the rear axle for the 345-B, 355-B and 370-B cars is identical with the exception of the gear ratio. The 370-B ratios are slightly lower than the corresponding ratios for the 345-B and 355-B.

The 452-B rear axle is of the same design as that of the other models but the gear ratios are different and the axle is somewhat larger to accommodate the heavier car.

The rear axle housing on all models is of the banjo type and carries not only the driving parts but also the rear brake mechanism. It is designed for underslung springs.

The differential is of the two-pinion type with bronze washers to take the thrust of the side gears and the differential pinions.

The differential is carried on tapered roller bearings while ball bearings are used for the driving pinion.

The differential carrier is reinforced by a plate installed between the differential cover and the axle housing and fitting over the cap bolts. This reinforcement adds considerably to the rigidity of the differential carrier.

The driving thrust of the rear axle is transmitted through the torque tube to the ball and socket joint which is attached to the rear end of the transmission.

The axle shafts are keyed to the driving hubs to which the wheels are bolted. This arrangement allows the use of a single annular type ball bearing in each rear wheel to take the load. This construction is typical of the three-quarter floating principle.

Baffle plates are used in the axle housing to keep excessive lubricant from getting into the wheel bearings. Two baffles are used for each shaft, one near each end. There is also a threaded bushing in the outer end of each housing tube which functions as an oil return.

The service operations and adjustments of the rear axle are the same on all models.

Service Information

1. Differential Carrier Installation

Before differential carrier assemblies are shipped by the Parts Division, all lubricant is washed out of the bearings. It is important, therefore, to lubricate the pinion shaft bearings before the assembly is installed, or they are liable to be damaged before the differential lubricant works its way up to them.

Place assembly on end with gears up, and pour about a pint of differential lubricant on the pinion. Leave the assembly in this position until the lubricant has run down through the back bearing and has thoroughly lubricated the front bearing. The assembly is now ready for installation.

After installation, the differential case should, of course, be filled to the proper level.

2. Gear Adjustment

The pinion and ring gear are properly adjusted at the factory, and this adjustment should not be changed. If adjustments or replacements are ever necessary, the entire differential carrier assembly should be replaced and the old one, together with its original shims, sent to the Factory Parts Division for exchange.

Use a Puller (Tool No. HM 109404) when removing the propeller shaft from the pinion shaft. Do not use a hammer in removing the shaft or the pinion shaft may be damaged.

REAR AXLE




Plate 3. Rear Axle Details and Alignment

REAR AXLE—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Axle housing out of true, not over..... <i>Use front wheel alignment gauge to check alignment of rear wheels</i>	$\frac{3}{32}$ "	$\frac{3}{32}$ "	$\frac{3}{32}$ "	$\frac{3}{32}$ "
Axle shaft length, left side (overall).....	$33\frac{1}{16}$ "	$33\frac{1}{16}$ "	$33\frac{1}{16}$ "	$33\frac{1}{16}$ "
Axle shaft length, right side (overall).....	$35\frac{11}{16}$ "	$35\frac{11}{16}$ "	$35\frac{11}{16}$ "	$35\frac{11}{16}$ "
Axle shaft out of true, not over.....	$\frac{1}{32}$ "	$\frac{1}{32}$ "	$\frac{1}{32}$ "	$\frac{1}{32}$ "
Differential carrier installation (See Note 1).....
Gear adjustment or replacement (See Note 2).....
Gear ratios—				
High.....	4.36 : 1	4.36 : 1	4.60 : 1	4.31 : 1
Low.....	4.60 : 1	4.60 : 1	4.80 : 1	4.64 : 1
Lubrication..... See Lubrication Section
Propeller shaft length (overall)—				
130-in. wheelbase.....	$55\frac{37}{32}$ "
136-in. wheelbase.....	$61\frac{37}{32}$ "
134-in. wheelbase.....	$59\frac{3}{32}$ "	$54\frac{9}{16}$ "
140-in. wheelbase.....	$65\frac{3}{32}$ "	$60\frac{9}{16}$ "
143-in. wheelbase.....	$54\frac{9}{16}$ "
149-in. wheelbase.....	$60\frac{9}{16}$ "
Propeller shaft out of true, not over.....	.010"	.010"	.010"	.010"
Propeller shaft, side clearance between splines and hub of universal joint				
New limits.....	.001-.005"	.001-.005"	.001-.005"	.001-.005"
Worn limits, not over.....	.006"	.006"	.006"	.006"
Road clearance (minimum) under rear axle..... <i>To be measured with tires inflated to 40 lbs. and no load in car.</i>	$7\frac{5}{8}$ "	$7\frac{5}{8}$ "	$8\frac{1}{8}$ "	$8\frac{1}{8}$ "
Tread.....	61"	61"	61"	61"
Type of axle.....	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.
Unit number location..... All models—Rear surface of housing at lower R. H. side

REAR AXLE—Service Information

3. Installation of Pinion Shaft Oil Retainer

Late "C" series cars have an oil retainer on the pinion shaft between the torque tube and the differential carrier to prevent the rear axle lubricant from leaking into the torque tube and eventually into the transmission in localities where steep grades are common. The retainer assembly consists of a double plate spot welded at two points containing a felt washer, and a bearing retaining nut with a spiral oil return groove cut in the outer surface. Cars having this oil retainer can be identified by an inspection of the rear axle as the retainer if used will be plainly visible between the torque tube and the front end of the differential carrier.

This retainer assembly, Part No. 1081881, and bearing retaining nut, Part No. 891890, may be installed on early "C"

series and "B" series cars. To install the retainer first remove the rear axle assembly from the car, and then remove the torque tube and propeller shaft from the axle assembly. Remove both bearing retaining nuts, locking washer and thrower washer from the front end of the pinion shaft. Discard the wide retaining nut and oil thrower washer, but save the narrow locking nut and the locking washer.

Place a few drops of oil on the felt washer and install the retainer with the well containing the felt extending toward the front of the car as shown Plate 3-A. Next, install the bearing retaining nut on the pinion shaft with the hexagonal shoulder toward the front of the car, then install the locking washer and locking nut on the front end of the pinion shaft. The propeller shaft and torque tube may then be assembled and the axle installed in the car.

Replacement and Adjustment of Rear Axle Ring Gear and Drive Pinion

In order to assure quiet operation and long life of Cadillac and LaSalle rear axles, it has been the practice of the Cadillac Motor Car Co. to handle all replacement and adjustment operations on the ring gear and drive pinion on an exchange basis. This was done to insure such accuracy as could be maintained only by careful matching of parts from a sufficiently large stock. Improvements in materials and in gear cutting methods have, however, made it possible to produce rear axle gears that can be satisfactorily serviced in the field. Accordingly the Factory Parts Division are now supplying ring gears and pinions in matched sets for service on V-8 and V-12 both "B" and "C" series cars.

While the practice of replacing the differential carrier assembly has been discontinued on these car models it is still in effect on the V-16. In case the rear axle gears need replacing or adjusting on V-16 cars, the entire differential carrier assembly should be replaced and the old one returned to the factory on the regular exchange basis as in the past.

When the ring gear and drive pinion are replaced on the V-8 and V-12 cars, the double-row ball bearing on the front end of the drive pinion shaft should also be replaced. Experience has proved that trouble may develop from wear on this bearing, whenever the gears are worn sufficiently to require replacement, if the bearing is not replaced at the same time the gear replacement is made.

It is also advisable to replace the cork gasket on the retainer for the front pinion bearing and, in cars which have the late type axle oil retainer, the felt washer should be replaced. In this connection, whenever the axle is down for inspection or replacement of gears, the retainer nut should be inspected and the grooved type installed whenever the plain type is found.

Complete instructions for replacing and adjusting the rear axle gears on V-8 and V-12 cars are given below:

Removal and Disassembly

The replacement of the rear axle ring gear and drive pinion necessarily requires the removal and disassembly of the differential gear assembly. To remove this unit, it is necessary first to remove the rear axle assembly from under the car. Then the axle shafts, the torque tube, the propeller shaft, the differential cover and reinforcement plate are removed, after which the differential gear assembly is dismounted or taken off of the differential carrier. See Fig. 1, Plate 3A.

The differential gear assembly is disassembled in the following order:

1. Remove caps for differential side bearings and take out adjuster rings.
2. Remove differential unit.
3. Remove ring gear from differential case and gear mount.
4. Remove drive pinion, bearings, front bearing retainer and bearing spacer.

NOTE—Do not lose or damage the shims between the front bearing retainer and the front end of the differential carrier.

5. Wash parts in gasoline or kerosine and dry with air after which check all parts carefully.

The differential pinions and side gears may be removed simply by removing the retaining screw in the pinion shaft and driving out this shaft. It is not necessary to remove these gears, however, for replacing the ring gear and drive pinion.

Examine the bearings, the bearing mounts, and the differential gears. They should be smooth, free from pits and the gears and bearings should not be chipped or broken.

The flange of the differential case should also be checked for wobble and eccentricity: it should run true laterally and radially within .001 in. or .004 in. when tested on the back of the ring gear. A convenient way of making this test is to install the differential case and bearings in position in the carrier and check the flange with a dial indicator clamped to the carrier or bearing cap studs using holder HM91220.

The hubs of the differential side gears should have no more than .005 in. radial clearance in the differential case. End-play in these gears should not exceed .020 in.

The two differential pinion gears should have a clearance of not more than .010 in. on the pinion shaft and not more than .020 in. backlash with the side gears.

Reassembly and Installation

Reassembly of the differential gear assembly is accomplished in the following order:

1. Install ball bearings, bearing spacer, front bearing retainer and bearing retaining nuts on drive pinion shaft, being sure to get the retainer back of the front bearing and with this bearing fitted in the cup of the retainer.

REAR AXLE—Service Information

2. Install drive pinion and bearings in differential carrier, being sure to install the spacing shims between the front bearing retainer and the front end of the differential carrier. Make an initial adjustment on the drive pinion as explained in section "Adjustment of Drive Pinion." Tighten bearing retaining nuts on the front end of the drive pinion shaft and lock them in position.

NOTE—Lubricate the drive pinion bearings when installing them to insure initial lubrication.

3. Install differential side gears and pinions (provided these gears were removed).

4. Install ring gear on differential case. Tighten retaining screws securely using an 18-inch wrench and lock with wire. Wire two screws together, installing the wire in such a way that tension of the wire on the screws will tend to tighten the screws rather than loosen them.

5. Install differential unit in position in differential carrier, after which install the adjuster rings and the bearing caps.

6. Make initial adjustment of gear mesh. See section "Adjustment of Ring Gear."

7. Install the axle shafts, lubricating the felt washers in the wheel.

8. Install rear axle under car.

9. Adjust gear mesh as explained under "Testing Ring Gear for Proper Tooth Contact."

10. Install reinforcement plate, differential cover and fill differential to proper level with recommended transmission and rear axle lubricant.

Adjustment of Gear Mesh

In the design of the rear axle provision is made for adjusting the drive pinion and ring gear so that the teeth may be meshed correctly, and for locking all adjustments securely. Ordinarily old gears that have been running noisy for some time cannot be adjusted satisfactorily to eliminate the noise. In such cases it is necessary to replace the gears with new ones.

A ring gear and drive pinion are shown in Fig. 3 Plate 3A, set in the proper running position, and in this position all tooth dimensions, theoretically, converge to cone centers




Fig. 1. Checking adjustment of differential side bearings. A pull of 8 to 10 pounds should be required to turn the ring gear.




Fig. 2. Checking backlash between ring gear and drive pinion with dial indicator and holder, Tool No. HM-91220. Backlash should be .004 to .012 in.

"A." In this position, only the pitch lines of the ring gear and drive pinion coincide; and although all other proportions of tooth shape converge toward the cone centers of the gears, they are in no place parallel to the pitch line.

It is, therefore, evident that the shifting of gears from the correct position, results in throwing the pitch lines out of parallel and changing the contact of the gear and pinion from a full contact toward either the toe or the heel of the ring gear. (See Figs. 5 and 6, Plate 3A.) If the ring gear is moved away from the drive pinion the contact is moved toward the heel; if the gear is moved closer to the pinion, the contact is moved toward the toe of the gear teeth. The reason for this is that when the ring gear is moved away from the pinion the heel of the tooth will be last in mesh. If the gear is moved toward the pinion, the backlash or clearance is first taken up at the toe.

Before an attempt is made to adjust the gear mesh, the rear axle lubricant should be drained and the gears cleaned.

Adjustment of Drive Pinion

An initial adjustment is made on the drive pinion when putting the differential and pinion assembly together by installing the proper number of shims between the front pinion bearing retainer and the front end of the differential carrier use sufficient shims to give a total thickness of .075 to .090 in. These shims are supplied by the Factory Parts Division in thickness of .010 in., .015 in., and .035 in.

The final adjustment of the drive pinion is made according to the tooth contact as explained under "Testing Ring Gear for Proper Tooth Contact."

Adjustment of Differential Side Bearings

To adjust the differential side bearings, it is necessary first to remove the locking plates for the adjuster rings and to loosen the bearing caps slightly. The adjusters are then turned, using tool No. HM72799 to tighten the bearings so that a pull of 8 to 10 pounds, measured at the circumference of the ring gear, is required to turn this gear. This test can be made with a spring scale hooked on one of the ring gear teeth as shown in Fig. 1 on this page. An initial pull of about 15 pounds will be required to start the gear, but as soon as it is started the pull should drop to 8 to 10 pounds.

After the adjustment is completed, the bearing caps must be tightened and the locking plates installed.

REAR AXLE




Fig. 1
Rear Axle Gear Assembly




Fig. 2
Backlash between drive pinion and ring gear should be .004 to .012 in. Check with dial indicator




Fig. 3—Correct Ring Gear Tooth Contact






Fig. 5—Excessive Toe Contact — Ring Gear Tooth

To correct contact increase backlash between gears (keeping it under .012 in.) by moving ring gear away from drive pinion

Fig. 6—Excessive Heel Contact — Ring Gear Tooth

To correct contact decrease backlash between gears (keeping it over .004 in.) by moving ring gear toward drive pinion

REAR AXLE—Service Information

Adjustment of Ring Gear

The adjustment of the ring gear is made by moving the ring gear and differential case sideways. This is accomplished by turning the adjuster rings (Use Tool No. HM72799) for the differential side bearings an equal amount as required. Although the ring gear tooth contact is the next important consideration, the backlash should be checked before checking for tooth contact, as both backlash and tooth contact are controlled by the same adjustment and backlash must be kept within the specified limits of .004 to .012 in. while adjusting the tooth contact.

When checking the backlash the axle shafts should be pulled out of the differential side gears and the drive pinion held stationary. The amount of backlash can be measured by means of a dial indicator with holder, tool No. HM91220, clamped to the axle housing and in contact with a tooth on the ring gear as shown in Fig. 2, page 13B. If the backlash is within these limits the gears can be checked for proper meshing.

Correct meshing of the ring gear and drive pinion can best be determined by painting the working surface of the ring gear teeth with red lead mixed with gasoline as a thinner, or Prussian blue as explained under "Testing Ring Gear for Proper Tooth Contact."

After the correct position for the ring gear is found, the adjustment of the bearings should be checked. The bearing caps are then tightened and the locking plates and differential cover are installed, after which the differential should be properly lubricated.

Testing Ring Gear for Proper Tooth Contact

Correct meshing of the gears can best be determined by first painting the working surfaces of the ring gear teeth with red lead thinned with gasoline, or Prussian blue, and turning the ring gear several revolutions by hand and then noting the tooth contact obtained on the ring gear under load. When the gears are turned the red lead or Prussian blue is wiped off at the point where the teeth of the ring gear and pinion mesh.

It is important to make this test by hand first so that an initial adjustment can be made if the gears are not correctly meshed. The tooth form may easily be ruined by running the gears under load when not correctly meshed.

To test the gear mesh under load the rear wheels should be raised off the floor and driven in both directions with the engine. The necessary load can be obtained by applying the brakes. **Care should be taken in making this test not to run the ring gear more than ten or twelve revolutions at a time before checking the tooth contact.** If the bearings and gears are in proper adjustment, the lengthwise tooth contact on the ring gear, which is the contact along the length of the tooth, and the profile tooth contact on the ring gear, which is the contact from top to bottom of the tooth, will appear as shown in Fig. 3, Plate 3A (a) for the forward speeds and as shown in (b) for the reverse speed.

It will be noted that the tooth contact for the forward speeds under light load is at the small end or "toe" of the tooth. This is necessary due to spring in the housing and the bearings under driving loads in the forward speeds, under

which condition the tooth contact will shift toward the large end or "heel" of the tooth. Under no conditions should the tooth contact on the ring gear under light load be at the heel of the tooth, as a heavy load on the gears in any of the forward speeds would tend to concentrate the load at this point.

In reverse, the tooth contact does not shift as far toward the heel under load as the driving contact. It is, therefore, permissible to have the contact on the reverse side more nearly at the center of the tooth than is the case on the driving side.

The profile contact, or the contact from top to bottom, on the face and flank of the tooth, may appear at any position throughout the length of the tooth. For proper meshing of gears the greater part of the profile contact on the ring gear should be about the middle of the tooth at the pitch line slightly below the outer edge. Referring to Fig. 3, it will be noted that the contact surface for the ideal condition extends only slightly below the pitch line and almost to the edge of the tooth. If the contact surface favors a lower position on the flank of the ring gear tooth as is shown in Fig. 4, the profile contact is too low. If, on the other hand, the contact surface is totally above the pitch line and also shows a decided contact on the top point or face of the tooth, the profile contact is too high.

To correct a low profile or flank contact, move the drive pinion away from the ring gear. This adjustment will increase the backlash and it may be necessary to move the ring gear toward the drive pinion to keep the backlash within the limits. Changing the position of the ring gear will alter the lengthwise contact on the tooth and to obtain correct tooth contact, illustrated in Fig. 3 (a) and (b), several adjustments for lengthwise and profile contact, may be required.

To correct a high profile or face contact, move the drive pinion toward the ring gear. This will decrease the backlash and it may be necessary to move the ring gear away from the pinion to maintain the proper amount of backlash. Changing the position of the ring gear will change the lengthwise contact on the tooth and to obtain a correct tooth contact, illustrated in Fig. 3 (a) and (b) several adjustments for lengthwise and profile contact may be required. After obtaining the proper tooth contact under load, check the backlash to see if it is within the limits.

When the "toe" contact on both the driving and reverse sides of the tooth is extended too close to the end of the tooth as shown in Fig. 5 (a) and (b) respectively, increase the backlash between the gears, keeping it under .012 in. by moving the ring gear away from the drive pinion. This may also change the profile or top-to-bottom contact slightly which should be changed by adjusting the pinion.

To correct an excessive "heel" contact on both the driving and reverse sides of the tooth, illustrated in Fig. 6 (a) and (b) respectively, decrease the backlash between the gears, keeping it over .004 in. by moving the ring gear toward the drive pinion. This may change the profile contact slightly as when correcting a "toe" contact, which will also necessitate changing the pinion adjustment.

If the tooth contact obtained under load varies widely from the tooth contact illustrated and described, it would indicate that the gears are worn. In this event, the gears should be replaced.

BODY

After removing the moulding screws (the invisible screws can be located by running a screwdriver up and down the glass-run channel), the garnish moulding can be removed by pulling out at the top and lifting up if the bayonet type lock is used or by releasing the trigger with a screwdriver if the trigger type is used. See Plates 6 and 7 for location and type of fastening.




Fig. 1
Garnish moulding removed to show bayonet locks and invisible plates.




Fig. 2
Trigger Lock
To unlock, move trigger in direction indicated by arrow.




Fig. 3
Rubber rollers for holding front door glass rigid in open positions.




Fig. 4
Adjustment of Windshield Regulator Board

Before adjusting the regulator board, remove the windshield moulding, the sun visor and the two screws on the right-hand end of the header board. Then loosen the trim, so that the screws in the support bracket at each end of the regulator board will be accessible.

BODY

General Description

The bodies are of the same rugged construction on both Cadillac and LaSalle cars but differ in appointments, trim, beading and other minor details.

In much of the frame-work construction glued joints are eliminated and metal brackets are used to hold the wood parts in place without touching each other. This arrangement reduces the possibility of squeaks.

The body panels are of one-piece design with no separate mouldings. The drip mouldings are stamped into the roof rail panel, forming an integral part of it. This construction eliminates the possibility of wood rot, squeaks and Duco chipping at these points.

The body is insulated against drumming noise and engine heat. The inside of the cowl from the dash back to the pillar, is covered with $\frac{3}{8}$ -in. felt insulation cemented securely in place. To insulate against engine heat, the 345-B body has $\frac{1}{8}$ -in. insulation inside of the dash, while the other models have $1\frac{1}{4}$ in. insulation between the dash and the "dummy" dash or cover.

Comfort in the driver's compartment is further assured by ventilation through a large ventilator in the top of the cowl. The openings in the toe-boards for the controls are closed with tight fitting rubber grommets. There is also a $\frac{3}{8}$ -in. felt pad under all carpets and under the front and rear seat cushions. All doors and body panels have special composition insulation cemented to the inside of the panels.

The front seat cushion is in two parts, only the driver's half being adjustable. The adjusting mechanism is controlled by a crank. Marshall springs are used throughout.

The body is mounted on rubber shims. However thin fabric pads are used wherever necessary for proper body alignment.

DOORS

Two hinges are used on each door. Each hinge is provided with two bronze bushings and a chromium plated hinge pin. All-Weather Phaetons have Fleetwood type barrel hinges, while the hinges on the open models are all concealed.

The dove tails are self-adjusting, thus facilitating door alignment.

The door locks are of such design as to permit the locking of all doors, including the right front door, from the inside.

To lock a door from the inside the remote control handle should be lifted up. To prevent the driver from locking himself out all doors are arranged so that the inside locking mechanism is automatically released by the movement of the lock bolt when the door is closed.

To lock the car from the outside, all doors except the right front door must first be locked from the inside by lifting the remote control handle. The right front door is then locked with the key on the outside in the conventional manner.

The outside door handles are fastened with a set screw through the face of the lock. This screw is concealed underneath the chromium plated lock escutcheon plate.

The inside door handles (window regulator handle, windshield regulator handle and remote control handles) are serrated on their shafts and locked in place by a small plunger located inside of the handle hub.

WINDOWS

The glass in the front doors of all closed cars operates between two rubber rollers at the lower side of the window opening. These windows also have a vertical guide and do not depend on the glass run channels for support.

The glass run channels are made in one piece, eliminating the possibility of noise at the joints. The channels have chromium-plated edges and inserts of special carpet material.

The garnish mouldings are made in one piece and are supported with invisible fastenings. Because these fastenings are invisible, it is very necessary to know where they are located on the various mouldings before proceeding to remove the moulding.

In general the method is to hold the bottom of the garnish moulding with a lock of either the bayonet or trigger type. The sides and top of the mouldings on Fleetwood bodies are held by plates which slip under the glass run channels and are held by screws through the channels. On the Fisher bodies the screws go through the garnish moulding and are plainly visible.

WINDSHIELD

The windshields on all closed cars are of the VV type. The side and top windshield garnish moulding is in one piece and is held in place by visible screws on Fisher bodies and invisible

BODY




Fig. 1

Typical Body Mountings

Tighten body bolt just enough to flatten lock washer. Check alignment of doors during this operation. Use thin fabric shims on top of rubber shims when necessary to align doors.




Fig. 3

Set screw for outside door handle is concealed under lock escutcheon plate. Plate must be removed to remove door handle.




Fig. 2

View of door hinge with insert showing bronze bushings.




Fig. 4

Removing Inside Door Handle

The inside door handles and windshield regulator handle are serrated on their shafts and locked in place by a small plunger located inside of the handle hub. To remove the handle it is necessary to release the plunger with the special tool shown above.

BODY—General Description—Service Information

plates on Fleetwood bodies. The top and back panels on both body types are held in place by invisible fastenings.

The windshield cleaner is of the swinging arm type with two arms operated in tandem by a single motor on the outside of the windshield

regulator board. The tandem linkage is between the windshield regulator board and the steel header.

The rear view mirror is of the ball-joint type and is fastened to the lower edge of the windshield regulator board on the closed cars.

Service Information

1. Adjusting Window Guide Roller

The guide rollers at the lower edge of the front door windows are adjusted by removing the garnish moulding and moving the inside roller closer to or farther away from the window glass. When properly adjusted the roller should press against the glass just enough to hold it. If the roller is adjusted so tight that it slides instead of turning, the glass may be marked. In some cases when the roller must be backed off, it will necessitate cutting some material from the garnish moulding to allow sufficient clearance for the roller.

2. Body Bolts for Service

In order to minimize the number of body bolt sizes necessary to stock, the body bolts for service are supplied in standard lengths of $3\frac{1}{2}$, $5\frac{1}{2}$ and $7\frac{5}{8}$ inches. Not all bolts used in production are of these lengths. Therefore, when replacing body bolts, it is necessary to measure the old bolts and select new ones of corresponding lengths or of lengths nearest to that of the old bolts. The bolts selected should be long enough to permit proper adjustment which is necessary with the rubber body shims.

3. Care of Top Coverings

The only attention required by top coverings, aside from periodic inspection for checks and possible leaks, is an occasional cleaning with clear water.

The use of top dressings on the top is not recommended, either to restore the lustre or to prevent leaks. Neither is a top dressing recommended as a preventive of deterioration, as most dressings contain some sort of solvent that causes the top covering to deteriorate.

Grease and oil will also damage top material. It is important therefore to avoid the use of oils of any nature, including kerosene, mineral oils, vegetable oils, animal oils or waxes. For this reason also, avoid the use of oil in eliminating squeaks in the roof construction.

4. Cleaning Khaki Top Materials

Top dressing of any kind and cleaning fluids containing oil, naphtha, gasoline, energine, strong chemicals, or any other liquid which will dissolve rubber, should never be used on the khaki top material of convertible and open models. As these tops are made of double texture material impregnated with rubber, such preparations would disintegrate the rubber content and ruin the fabric.

The safest cleaning method is to use warm water and a sponge or brush; if necessary, Ivory soap may be applied sparingly, but care must be taken that all the soap is washed off. Most of the soiled spots can be cleaned up by using only a piece of clean art gum or pure gum rubber.

It is also important to see that the top material is thoroughly dry before the top is lowered.

5. Cleaning Car Upholstery

Care must be exercised in cleaning upholstery material and floor carpets used in car interiors. Some of the fabrics are impregnated with a rubber backing, originally applied as a solution, which binds the nap securely. Use of too much cleaning fluid tends to dissolve this backing, thus loosening the nap.

To avoid this, cleaning fluids should be used sparingly on any upholstery, especially pile. An additional safeguard is the use of factory-approved fluids which are selected for their factor of safety as well as for efficiency in cleaning.

Water stains on upholstery material can easily be removed by brushing off the material thoroughly and then cleaning it with a cloth dampened with Cadillac cleaner. The cleaner should be used sparingly. Let the upholstery dry and smooth over lightly with a very hot iron applied through a damp cloth.

6. Cleaning Chromium-Plated Parts

While chromium-plated parts do not require repeated polishing like nickel, they should be cleaned occasionally to restore the lustre and protect the plating from deterioration.

It is particularly important to clean the plated parts on the chassis, which are exposed to the road elements. In winter, salt and calcium chloride, used on the streets to remove ice, are splashed upon the car, and in summer, the same is true of dust-laying chemicals. Frequent cleaning will prevent these chemicals from acting on the plating.

Chromium-plated parts which have been subjected to the action of chemicals of this sort may require more than cleaning, depending upon the length of time and the strength of the chemicals. In such cases, polishing with a good metal polish will usually remove the discoloration and restore the lustre. Wiping with a cloth dampened in kerosene will help to protect the plating from further deterioration.

Discoloration of chromium-plated parts under the action of chemicals used on roads and pavements, is not an abnormal condition and is not an indication of defective plating.

7. Door Bumper Adjustment

Adjustment of the doors is made by means of different lengths of rubber bumpers. Three lengths of bumpers are available and can be used interchangeably as necessary to suit each individual case.

On the first cars shipped, no bumper plates are provided on the doors and the following bumpers must be used:

Identification Number		
First-type Bumper	on Bumper	Part No.
Short bumper	107A	4002339
Medium bumper	107C	4023568
Long bumper	107B	4024073

Later cars have bumper plates, Part No. 4220157, on the doors to increase the tension of the bumper on the doors in the closed position.

The second-type bumpers listed below must be used with these plates:

Identification Number		
Second-type Bumper	on Bumper	Part No.
Short bumper	208	4018317
Medium bumper	209	4003348
Long bumper	210	4026044

Second-type bumpers may be used on early cars by installing bumper plates on the doors. These may be installed where the bumper strikes the door by drilling the screw hole using

BODY—Service Information

the bumper plate as a template and attaching the plate with the screws provided with the plate under Part No. 4220157. Bumpers of the length suitable for the particular cars should be selected.

No attempt should be made to use the first-type bumpers on later cars with the bumper plates as a different shaped bumper is required. Neither should the second-type bumper be used on early cars without the bumper plate as they will not have the proper tension on the doors.

8. Installing Cowl Bead

The cowl bead is attached by concealed fastenings. Two types of these fastenings have been used.

On the first bodies assembled the bead is held at each end by a long bolt which goes through the sill and screws into a tapped plate close to the end of the bead. On later bodies a stud is used which is a part of the bead itself. This stud goes through the same hole in the sill that was used for the bolt on the first type bead and is anchored with a nut.

When installing a new cowl bead only the second type should be used. The bolt or nut holding the bead in place can be reached with a universal wrench. If the stud extends through the nut too far, it should be cut off.

When installing a bead, the bolt or nut should be drawn up just enough to hold the bead snugly in place. If drawn too tight, the end of the bead may buckle or break.

9. Installing Outside Door Handles

When the door handles are installed on a car, a small spring washer, Part number 4023713, is installed on the shaft to take up end play. Ordinarily, when the handle is removed, the washer remains in place on the end of the handle, but in some cases it may remain inside and drop down in a crevice.

If the door handle is removed for any reason, care should be taken to see that the washer is in place when the handle is reinstalled, or a new washer should be installed.

10. Installing Hood Corner Protectors

When installing the rubber hood corner protectors it is important that the button be pulled all the way through the hole in the hood. The proper method of installing these protectors is first to slip the flange over the edge of the hood and then pull the button through the hole in the hood with a pair of narrow long-nosed pincers. Both edges of the button should be squeezed together when pulling the button through the hole. If only one edge of the button is grasped, the edge may be torn as it is pulled through.

11. Installing Window Regulator Handle on Left Front Door

The proper position for the window regulator handle on the left front door is parallel with the remote control handle in the unlocked position when the window is turned all the way up. This is necessary with first type cars to eliminate the possibility of interference between the driver's hand on the steering wheel and the knob of the window regulator handle.

If it is found that the window regulator handle is not in this position, it should be removed and properly reinstalled. Before taking the handle off, run the window up as far as it will go. Release the spring retaining pin in the handle using tool number B-127. Reinstall the handle in such a position that it will be parallel with the remote control handle when it is in the unlocked position.

12. Removing Windshield Weather Strip

The rubber strip in which the windshield is imbedded in the closed position has a chromium plated bead rolled on to its front edge and this bead is attached to the bead running around the entire windshield by a piece of connecting wire inserted in the ends. A part of the rubber strip itself is held in a recess in the top of the cowl bar.

If this rubber is to be removed for any reason, first remove the ash receiver and the windshield moulding above the instrument panel. Then raise the windshield to clear the rubber and insert a flat tool under the rubber at about the center of the strip and from the front side of the car.

Raise the strip carefully and pull the chromium plated bead away from the wire which holds it to the bead on the sides of the windshield. Use particular care not to kink the bead when lifting it in this manner.

To reinstall the rubber strip, keep the bead bowed slightly and insert the corner wires in the ends of the bead, gently pressing the strip into place. When the strip is in place, seal the ends securely against the side windshield panels with a sufficient amount of "rubber dough" to prevent leakage.

13. Door Garnish Moulding Fastenings on All-Weather Phaeton and Convertible Coupes

On all-weather phaetons, the door garnish mouldings are held in place by three trigger locks on the front doors and by two trigger locks on the rear doors.

The door garnish mouldings on Convertible Coupes are held in place by three trigger locks.

BODY—Type and Job Numbers

FISHER AND FLEETWOOD BODY TYPE AND JOB NUMBERS

When ordering chassis parts affected by wheelbase, the BODY JOB NUMBER must be given the same as when ordering body parts

Body Type	Job Number	Wheelbase	Body Type	Job Number	Wheelbase
345-B (LaSalle)			Fleetwood Bodies—Continued		
Fisher Bodies			†5-Pass. Convertible Coupe.....	5085	140"
2-Pass. Coupe.....	32-678	130"	5-Pass. Sedan.....	32-12-209	140"
2-Pass. Convertible Coupe.....	32-668	130"	†5-Pass. Imperial Cabriolet.....	5030FL	140"
5-Pass. Town Coupe.....	32-672	130"	†5-Pass. Sedan—metal back.....	5031S	140"
5-Pass. Sedan.....	32-659	130"	5-Pass. Town Car with Opera		
5-Pass. Town Sedan.....	32-652	136"	Seats—leather back.....	32-12-225	140"
7-Pass. Sedan.....	32-662	136"	†5-Pass. Imperial Sedan with		
7-Pass. Imperial Sedan.....	32-663	136"	Solid Rear Quarter—leather		
355-B (Cadillac)			back.....	5055	140"
Fisher Bodies			†5-Pass. Imperial Sedan with Fold-		
2-Pass. Roadster.....	32-8-155	134"	ing Rear Quarter—leather back	5055C	140"
2-Pass. Coupe.....	32-8-178	134"	†5-Pass. Imperial Sedan—metal		
2-Pass. Convertible Coupe.....	32-8-168	134"	back.....	5031	140"
5-Pass. Sedan.....	32-8-159	134"	†7-Pass. Phaeton.....	5057	140"
5-Pass. Phaeton.....	32-8-256	140"	7-Pass. Sedan.....	32-12-212	140"
5-Pass. Phaeton with Sliding			†7-Pass. Imperial Sedan.....	5030	140"
Windshield.....	32-8-280	140"	†7-Pass. Imperial Sedan.....	5065	140"
5-Pass. All-Weather Phaeton.....	32-8-273	140"	7-Pass. Imperial Sedan.....	32-12-213	140"
5-Pass. Sport Phaeton.....	32-8-279	140"	*7-Pass. Imperial Sedan.....	5075H4	140"
5-Pass. Coupe.....	32-8-272	140"	7-Pass. Town Car—leather back.	32-12-227	140"
5-Pass. Sedan.....	32-8-259	140"	7-Pass. Town Car—metal back..	32-12-226	140"
5-Pass. Town Sedan.....	32-8-252	140"	†7-Pass. Imperial Cabriolet.....	5075FL	140"
7-Pass. Sedan.....	32-8-262	140"	452-B (Cadillac)		
7-Pass. Imperial Sedan.....	32-8-263	140"	Fisher Bodies		
Fleetwood Bodies			2-Pass. Roadster.....	32-16-155	143"
5-Pass. Two-Door Close Coupled			2-Pass. Coupe.....	32-16-178	143"
Town Coupe.....	32-8-222	140"	2-Pass. Convertible Coupe.....	32-16-168	143"
5-Pass. Sedan.....	32-8-209	140"	5-Pass. Sedan.....	32-16-159	143"
5-Pass. Town Car with Opera			5-Pass. Phaeton.....	32-16-256	149"
Seats—leather back.....	32-8-225	140"	5-Pass. Phaeton with Sliding		
7-Pass. Sedan.....	32-8-212	140"	Windshield.....	32-16-280	149"
†7-Pass. Transformable Cabriolet	4925	140"	5-Pass. All-Weather Phaeton.....	32-16-273	149"
7-Pass. Imperial Sedan.....	32-8-213	140"	5-Pass. Sport Phaeton.....	32-16-279	149"
*7-Pass. Imperial Sedan.....	4975-H-4	140"	Fleetwood Bodies		
†7-Pass. Imperial Sedan.....	4985	140"	5-Pass. Two-door Close Coupled		
7-Pass. Town Car—leather back.	32-8-227	140"	Town Coupe.....	32-16-222	149"
7-Pass. Town Car—metal back..	32-8-226	140"	†5-Pass. Convertible Coupe.....	5185	149"
370-B (Cadillac)			†5-Pass. Imperial Sedan.....	5129	149"
Fisher Bodies			†5-Pass. Imperial Cabriolet.....	5130FL	149"
2-Pass. Roadster.....	32-12-155	134"	5-Pass. Sedan.....	32-16-209	149"
2-Pass. Coupe.....	32-12-178	134"	†5-Pass. Sedan—metal back.....	5131S	149"
2-Pass. Convertible Coupe.....	32-12-168	134"	†5-Pass. Special Sedan.....	5140B	149"
5-Pass. Sedan.....	32-12-159	134"	5-Pass. Town Car with Opera		
5-Pass. Phaeton.....	32-12-256	140"	Seats—leather back.....	32-16-225	149"
5-Pass. Phaeton with Sliding			†5-Pass. Imperial Sedan—metal		
Windshield.....	32-12-280	140"	back.....	5131	149"
5-Pass. All-Weather Phaeton.....	32-12-273	140"	†5-Pass. Imperial Sedan with Solid		
5-Pass. Sport Phaeton.....	32-12-279	140"	Rear Quarter—leather back....	5155	149"
5-Pass. Coupe.....	32-12-272	140"	†5-Pass. Imperial Sedan with Fold-		
5-Pass. Sedan.....	32-12-259	140"	ing Rear Quarter—leather back	5155C	149"
5-Pass. Town Sedan.....	32-12-252	140"	†5-Pass. Imperial Cabriolet.....	5156C	149"
7-Pass. Sedan.....	32-12-262	140"	7-Pass. Sedan.....	32-16-212	149"
7-Pass. Imperial Sedan.....	32-12-263	140"	7-Pass. Imperial Sedan.....	32-16-213	149"
Fleetwood Bodies			*7-Pass. Imperial Sedan.....	5175H4	149"
5-Pass. Two-Door Close Coupled			7-Pass. Town Car—leather back.	32-16-227	149"
Town Coupe.....	32-12-222	140"	7-Pass. Town Car—metal back..	32-16-226	149"
370-B (Cadillac)			†7-Pass. Transformable Cabriolet.	5125	149"
Fisher Bodies			†7-Pass. Imperial Landulet.....	5165	149"
2-Pass. Roadster.....	32-12-155	134"	†8-Pass. Imperial Sedan.....	5177	165"
2-Pass. Coupe.....	32-12-178	134"			
2-Pass. Convertible Coupe.....	32-12-168	134"			
5-Pass. Sedan.....	32-12-159	134"			
5-Pass. Phaeton.....	32-12-256	140"			
5-Pass. Phaeton with Sliding					
Windshield.....	32-12-280	140"			
5-Pass. All-Weather Phaeton.....	32-12-273	140"			
5-Pass. Sport Phaeton.....	32-12-279	140"			
5-Pass. Coupe.....	32-12-272	140"			
5-Pass. Sedan.....	32-12-259	140"			
5-Pass. Town Sedan.....	32-12-252	140"			
7-Pass. Sedan.....	32-12-262	140"			
7-Pass. Imperial Sedan.....	32-12-263	140"			
Fleetwood Bodies					
5-Pass. Two-Door Close Coupled					
Town Coupe.....	32-12-222	140"			

*Same as regular Fleetwood bodies but with 4 inches more headroom.

†Special bodies.

BODY




Fig. 1. Front door, all models—Fisher body

- 7 Visible screws in garnish moulding
- 1 Trigger lock under garnish moulding




Fig. 2. Rear door, Cadillac—Fisher body

- 7 Visible screws in garnish moulding
- 1 Bayonet lock under finishing panel




Fig. 3. Rear door and rear quarter, La Salle—Fisher body

- Rear quarter, Cadillac—Fisher body
- 7 Visible screws in garnish moulding
- 1 Bayonet lock under garnish moulding




Fig. 4. Partition, Imperial Model—Fisher body

- 7 Visible screws in garnish moulding
- 3 Bayonet locks in back panel
- 1 Trigger lock at center of top panel; also 1 plate at each end




Fig. 5. Windshield, all closed models—Fisher body

- 9 Visible screws in garnish moulding
- 6 Plates in finishing panel; also 2 screws in center under the panel
- 2 Clips in lower garnish moulding inside ash receiver hole; also 1 plate at each end
- Windshield, all models—Fleetwood body
- Same as Fisher except lower screw in garnish moulding at each side is replaced with plate and invisible screws




Fig. 6. Front door, all models except Imperial and Town Car—Fleetwood body

- 6 Invisible plates under glass channel runs at top and rear side of window
- 2 Bayonet locks under finishing panel

Plate 6. Location and Type of Moulding Fastenings—Fisher and Fleetwood Bodies—(See note 13)

BODY




Fig. 1. Front door, Imperial and Town Car—Fleetwood body

6 Invisible plates under glass channel runs at top and rear side of window
1 Trigger lock under garnish moulding




Fig. 2. Rear door, all models—Fleetwood bodies

4 Invisible plates under glass channel runs
2 Bayonet locks under finishing panel




Fig. 3. Rear quarter, all models—Fleetwood body

4 Invisible plates under glass channel runs
2 Bayonet locks under finishing panel




Fig. 4. Partition, Imperial Model—Fleetwood body

9 Invisible plates under glass channel run
3 Bayonet locks under back panel
1 Trigger lock at center of top panel; also 1 plate at each end




Fig. 5. Arm rest, all models—Fleetwood body

1 Bayonet lock at center; also small brad in lower corner of panel. To remove panel drive brad through panel and lift up




Fig. 6. Front seat, all models—Fleetwood body

3 Bayonet locks under back panel
3 Trigger locks under top panel

BODY—Type and Job Numbers

FISHER AND FLEETWOOD BODY TYPE AND JOB NUMBERS FOR "C" SERIES CARS

Body Type	Job Number	Wheelbase	Body Type	Job Number	Wheelbase
345-C (LaSalle)			Fisher Bodies—Continued		
Fisher Bodies			2-Pass. Convertible Coupe.....	33-12-168	134"
2-Pass. Coupe.....	33-678	130"	5-Pass. Phaeton.....	33-12-256	140"
2-Pass. Convertible Coupe.....	33-668	130"	5-Pass. All-Weather Phaeton....	33-12-273	140"
5-Pass. Town Coupe.....	33-672	130"	5-Pass. Coupe.....	33-12-272	140"
5-Pass. Sedan.....	33-659	130"	5-Pass. Sedan.....	33-12-259	140"
5-Pass. Town Sedan.....	33-652	136"	5-Pass. Town Sedan.....	33-12-252	140"
7-Pass. Sedan.....	33-662	136"	7-Pass. Sedan.....	33-12-262	140"
7-Pass. Imperial Sedan.....	33-663	136"	7-Pass. Imperial Sedan.....	33-12-263	140"
355-C (Cadillac)			Fleetwood Bodies		
Fisher Bodies			5-Pass. Sedan.....	33-12-209	140"
2-Pass. Roadster.....	33-8-155	134"	5-Pass. Town Car with Opera		
2-Pass. Coupe.....	33-8-178	134"	Seats—leather back.....	33-12-225	140"
2-Pass. Convertible Coupe.....	33-8-168	134"	7-Pass. Sedan.....	33-12-212	140"
5-Pass. Phaeton.....	33-8-256	140"	7-Pass. Imperial Sedan.....	33-12-213	140"
5-Pass. All-Weather Phaeton....	33-8-273	140"	7-Pass. Town Car—leather back..	33-12-227	140"
5-Pass. Coupe.....	33-8-272	140"	7-Pass. Town Car—metal back..	33-12-226	140"
5-Pass. Sedan.....	33-8-259	140"			
5-Pass. Town Sedan.....	33-8-252	140"	452-C (Cadillac)		
7-Pass. Sedan.....	33-8-262	140"	Fisher Bodies		
7-Pass. Imperial Sedan.....	33-8-263	140"	2-Pass. Roadster.....	33-16-155	143"
Fleetwood Bodies			2-Pass. Coupe.....	33-16-178	143"
5-Pass. Sedan.....	33-8-209	140"	2-Pass. Convertible Coupe.....	33-16-168	143"
5-Pass. Town Car with Opera			5-Pass. Phaeton.....	33-16-256	149"
Seats—leather back.....	33-8-225	140"	5-Pass. All-Weather Phaeton....	33-16-273	149"
7-Pass. Sedan.....	33-8-212	140"			
7-Pass. Imperial Sedan.....	33-8-213	140"	Fleetwood Bodies		
7-Pass. Town Car—leather back..	33-8-227	140"	5-Pass. Sedan.....	33-16-209	149"
7-Pass. Town Car—metal back..	33-8-226	140"	5-Pass. Town Car with Opera		
370-C (Cadillac)			Seats—leather back.....	33-16-225	149"
Fisher Bodies			7-Pass. Sedan.....	33-16-212	149"
2-Pass. Roadster.....	33-12-155	134"	7-Pass. Imperial Sedan.....	33-16-213	149"
2-Pass. Coupe.....	33-12-178	134"	7-Pass. Town Car—leather back..	33-16-227	149"
			7-Pass. Town Car—metal back..	33-16-226	149"

BODY—General Description—Service Information

General Description

The bodies on the "C" series cars are of the same rugged construction but differ in appointments and other minor details. They embody a number of new features including the Fisher No-Draft (I. C. V.) ventilating system.

The No-Draft ventilating system includes pivoting glass panels in the front door and rear quarter windows on all 5- and 7-passenger sedans and the rear doors on Town sedans and Town cars, and the cowl ventilator which is baffled and drained in such a way as to be completely rain-proof. The ventilating panels are controlled by handles or cranks conveniently located just below the window. The rear quarter windows are stationary. All window ventilator controls are worm-gearred for easy operation.

There are two types of front doors, which differ in the window and ventilator construction. With the first type doors, it is necessary to lower the window glass far enough to disengage it from the ventilating panel before the ventilating panel can be opened or closed. The window glass, however, can be raised or lowered as desired.

The second type doors have a stationary division channel between the ventilator and the window glass so that the ventilating panels can be opened or closed independently of the window glass.

The garnish mouldings are similar to those used on the "B" cars but the method of retaining them in place differs in that there are no invisible fastenings at the sides and top. Visible screws are used at these points for holding the garnish mouldings in position.

The trigger type lock is employed at the lower side of the garnish mouldings on all door windows while a bayonet lock is used at the rear quarter windows.

The garnish moulding finishing panels are separate from the garnish mouldings on the "C" series Cadillac bodies. These panels on early cars are held in place by bayonet locks such as used on the garnish mouldings. On later cars, hanger plates are also used in addition to the bayonet locks for fastening the finishing panels in place.

Service Information

14. Replacing Ventilator Glass

Replacement of the ventilator glass is the same on all cars and can be accomplished without removing the ventilator assembly or disturbing the garnish moulding or control handle. Since the glass is a tight press fit in the channel, special tools should be used for removing and installing it.

The removal of the ventilator glass requires the use of a puller, Part No. B-176. If the ventilator glass is to be reinstalled or used again, friction tape should be used between the puller clamp and the glass to prevent the clamp from marring or scratching the glass surface.

The glass is installed by pushing it into the channel using the replacing tool, Part No. B-175. Before installing a ventilator glass, first place 2-inch strips of glass filler over the top and bottom edges of the glass, arranging the strips at the rear end of the edge so that they will come under the ends of the channel when the glass is installed in position. Then wrap the three edges of the glass that go in the channel with a single strip of the glass filler. This filler is a special tape obtainable from the Factory Parts Division in rolls of any length desired. Two thicknesses of this filler tape are available. Thin filler can be secured under Part No. 4035726 and medium filler under Part No. 4035727. If necessary, in extreme cases, two thicknesses of thin filler can be used.

After wrapping the glass with the filler, spring the two ends of the glass channel slightly together or toward each other and start the glass in the channel a few inches by hand, placing the glass in the lower end first and then forcing it into the upper end.

If either the top or the bottom edge of the glass feeds in faster than the other one when forcing the glass into the channel, the replacing tool should be adjusted up or down to change the pressure point, bringing it closer to the edge which is lagging. The lagging edge should also be tapped gently with a block of wood and hammer to assist in forcing the glass evenly into the channel. The glass should be pressed in even with both ends of the glass channel.

The ends of the channel are then pressed down on the glass and the ends of the glass filler trimmed off even with the edge of the channel.

If the weather strip loosens from the retainer, it should be cemented in place with FS-681 ventilator cement and allowed to dry for at least an hour under pressure.

15. Removing Ventilator Control Handle

Two different types of control handles are used for operating the No-Draft ventilators. The early handles are of the T-type while the later handles are of the crank type. Two methods of mounting these handles are used. One type of mounting is used when the regulator control shaft passes through the belt finishing panel and the other type is used on cars where the finishing panel is omitted.

With the first type mounting the handle is fastened to the finishing panel by means of lugs or wood screws and merely slides on the regulator shaft when the panel is installed in position. This handle is, therefore, removed and installed with the finishing panel.

BODY





Fig. 1

First Type Front Door
with garnish moulding and trim removed

Fig. 2
Second Type Front Door
with garnish moulding and trim removed



BODY—Service Information

The removal of this type handle from the finishing panel is only a matter of straightening out or grinding off the lugs or removing the screws and pulling it out of the panel.

With the second type mounting the handle locks to the regulator control shaft with a small plunger located inside the hub. The removal of this type handle requires the use of the same special tool No. HMB-127 for releasing the lock plunger, as for the inside door handles.

16. Fastenings for Door Finishing Panels

The door finishing panels used on later "C" series Cadillac cars are held in place by two hangar plates in addition to the bayonet type fastenings used on earlier cars. These hangar plates are attached by means of screws to the rear face of the finishing panel and over the regulator board, and the screws holding the plates to this board must be removed to take out the panel. This construction assures against loosening.

In any case of the door finishing panel loosening up on early cars these hangars can be easily installed. The parts required for each panel are as follows:

No. Req.	Name	Part No.
2	Hangar plate	4038003
6	Screws	129186

17. Position of Door Handles

Attention should be given to the position of the various handles on the doors for the greatest convenience of the operator.

All handles should be placed so that they lock in the closed position on the downward swing. This gives the operator the most advantageous leverage in locking the ventilators to prevent leaks.

The door window regulator handles should be placed in such a position that they point away from the I. C. V. handle when the window is all the way up. This position affords more clearance between the ventilator handle and the window regulator handle when the window is all the way up or down.

18. Replacing Ventilator Assembly

The replacement of the ventilator assembly necessarily requires the removal of the old ventilator from the car and the installation of the new one. This necessitates the removal and installation of the garnish moulding, the belt finishing panel (on cars using finishing panels) and the trim. It is not necessary, however, to remove the trim panel entirely but merely to loosen it around the window and lock board, or regulator board as in the case of the rear quarter windows, and pull it away from the door or body far enough to provide easy access to the ventilator and board assemblies.

19. Replacing Door Ventilators

The removal and installation of the door ventilator and regulator assemblies are practically the same on all cars. There are, however, slight differences in operation between the first and second type front doors and also between the second type front doors and the rear doors. The removal and installation of these assemblies should be performed in the following way. See Plates 7A and 7B.

1. Remove garnish moulding. This includes the auxiliary moulding strip between the ventilator and the window glass on rear doors.
2. Remove belt finishing panel. (Cars provided with finishing panels.)
3. Remove ventilator control handle. (Cars not provided with belt finishing panels.)
4. Remove inside door handles.

5. Loosen trim around window and slightly below lock board and pull away from door far enough to make lock board accessible.

6. Remove filler board at top of lock board. (Front doors only.)

7. Remove nail in each end of rubber weather strip. (First type front doors only.)

8. Remove retaining screws in weather strip retainer (ten screws in front door and six in rear door). Screws are indicated by short arrows in Fig. 1.

9. Remove ventilator assembly by pulling out at the top and lifting up to disengage drive shaft from regulator.

10. Remove lock board, including corner blocks, and regulator.

The installation of the ventilator assemblies and regulators is accomplished in the opposite order of their removal.

When installing the first type front door ventilator assembly, be sure to install the metal clip at the top end of the weather strip and to nail both ends of the weather strip in place. Also seal the ventilator assembly in place with FS-745 rubber dough.

When installing the garnish moulding, it is necessary to work the lip or flange of the ventilator weather strip out over the garnish moulding. This is rather difficult to do without damaging the weather strip or moulding except by the use of a heavy string or cord. See Fig. 3, Plate 7B. To use the string, a knot is first tied in each end and the string then wrapped around the weather strip inside of the flange close to the retainer. The garnish moulding is next installed and pressed firmly against the weather strip. With the garnish moulding held in this position, the string is pulled out starting at one end, pulling the flange out over the garnish moulding. Care should be exercised to remove the string gently; otherwise the weather strip may be damaged.

20. Replacing Rear Quarter Window Ventilator

The removal and installation of the rear quarter window ventilators is practically the same as on the doors. The ventilator regulator, however, is more accessible as it is mounted on a small board which is easily removed. See Fig. 2, Plate 7B. The ventilator assembly and regulator are removed as follows:

1. Remove garnish moulding and belt finishing panel. (Cars provided with finishing panels.)
2. Remove ventilator control handle.
3. Loosen trim around window and regulator board directly below window.
4. Remove weather strip from vertical channel between ventilator and window glass, pulling it out from the center first.
5. Remove four retaining screws in weather strip retainer. Screws are indicated by short arrows.
6. Remove ventilator assembly by pulling out at top and lifting up to disengage drive shaft from regulator.
7. Remove regulator mounting board and take off regulator if necessary.

The regulator and ventilator assemblies are installed in the reverse order of their removal.

The ventilator assembly should be sealed in place with FS-745 rubber dough.

To install the weather strip between the ventilator glass and the window glass, install the ends first and then force the remainder of the strip in position, keeping the ends in line with those of the ventilator weather strip.

When installing the garnish moulding, the weather strip flange around both the ventilator and the window must be worked out over the moulding. This can be accomplished by using a heavy string in the same manner as on the front and rear door ventilators, as explained in Note 19.

BODY




Fig. 1

Rear door with garnish moulding and trim removed




Fig. 2

Rear quarter window with garnish moulding and trim removed




Fig. 3

When installing garnish moulding use string or cord to pull flange of weather strip out over moulding. Pull string gently to avoid damaging garnish moulding

BODY—Service Information

21. Replacing Window Glass

The construction of the door and body windows differ somewhat from each other, making it necessary to use a different procedure for removing and installing them. Their removal and installation, however, is not difficult when the proper procedure is known and followed.

The replacement of the window glass can be performed without disturbing the No-Draft ventilator assembly.

Front Door Windows

To remove the window glass from both the first and second type front doors, proceed as follows:

1. Remove garnish moulding, belt finishing panel and inside door handles, including the ventilator control handle.
2. Loosen trim around window and slightly below lock board filler board.
3. Remove filler board and lock pillar corner block at top of board.
4. Loosen trim at bottom of door just far enough up to reach the window lift cam (See Figs. 1 and 2, Plate 7A) at the lower edge of the glass with the glass in its lowest position. Removal of the trim entirely is not recommended as it would then be necessary to relocate the trim on the door when installing it.
5. Remove retaining screws in lift cam and pull cam slightly away from bracket on glass channel.
6. Remove first screw at lower end of glass run channel. (First type front doors only.)
7. Remove glass run channel from second type front doors; Also loosen vertical division channel at bottom end and swing out slightly to clear glass.
8. Raise glass all the way up out of the window opening, pulling the top edge out just enough to clear the door.
9. Remove metal channel from old glass for installation on new glass whenever the glass is to be replaced.

Install the front door glass in the opposite order of its removal. Install the garnish moulding as explained in Note 19.

Rear Door Windows

The removal and installation of the rear door window glass can be accomplished simply by removing the garnish moulding and the glass run channel, running the glass up and disengaging the glass channel from the window regulator operating arm.

If the glass is to be replaced, the metal channel should be removed from the old glass and installed on the new glass.

The glass is installed in the opposite way from its removal. The garnish moulding, however, should be installed as explained in Note 19.

Rear Quarter Windows

The rear quarter windows are stationary and their replacement is merely a matter of removing and installing the glass and channel assembly. The removal of the glass and channel assembly is accomplished by pulling it out of the window opening through the inside of the body after first removing the garnish moulding, loosening the trim around the window and removing the retaining screws in the glass channel. These screws are indicated by the short arrows in Fig. 2, Plate 7B.

The glass is installed in the reverse order of its removal except that the glass channel should be sealed in place with

FS-745 rubber dough. The garnish moulding should also be installed as explained in Note 19.

Back Window

The back window glass and channel assembly is retained in place by the garnish moulding which is installed under pressure. To remove the glass, therefore, it is simply a matter of removing the garnish moulding after turning the retaining screws all the way out, and pulling the window and channel assembly out towards the front of the car. Before doing this be sure to remove the rear seat cushion to avoid damaging it.

The glass channel should be removed from the old glass for installation on the new glass whenever the glass is to be replaced.

When installing the rear window glass and channel assembly seal it in place with No. 60 more-tite bedding putty. Also make sure that the rubber weather strip showing outside of the car is even all around the window opening. Any unevenness can be corrected by shimming on the inside. The garnish moulding is then installed and pressed firmly against the glass while fastening it in place.

Tool, Part No. B-177, should be used to press the garnish moulding firmly in place while installing the retaining screws. Care should be taken when using this tool not to exert too much pressure against the pillar posts as they may be sprung, preventing the doors from closing properly.

22. Replacing Windshield Glass

The windshield is of the solid, non-adjustable type on all closed bodies. The glass is carried in a rubber weather strip which is held in place by the garnish moulding. The windshield glass is removed as follows:

1. Remove garnish moulding. (Do not disturb lower panel on top rear face of instrument board.)
2. Remove metal clips on pillars, which hold windshield glass in place.
3. Pull top of glass back to clear header board and lift out of lower weather strip.

The windshield glass is installed in the following manner:

1. Place a little vaseline on the lower edge of the glass and install it in the lower weather strip.


Additional help may be required to enter the glass in the weather strip channel as it is necessary to open the channel from both sides of the glass with screw drivers or some other form of flat tool.

2. Push top of glass forward into position and install metal clips to keep it in place.

3. Seal lower right and left corners of windshield where cutouts are made for wiper tube and aerial lead-in wire. To do this plug the openings with cotton, pressing it firmly in place. Also pack some additional cotton in back of the weather stripping for about two inches up from the lower edge of the glass. Then coat the cotton with FS-745 rubber dough. It is also advisable to seal the windshield glass in position by coating the front side and edges of the glass channel with rubber dough.

4. Install garnish moulding.

In order to make the windshield leak-proof, the garnish moulding must be pressed firmly against the weather strip while fastening it in place. This can be accomplished by using tool, Part No. B-177 braced against the front side of the door. Too much pressure should not be applied against the garnish moulding as it might damage the moulding or the pillars or break the glass.



BRAKES

General Description

Cadillac-LaSalle brakes are of the internal type with two self-energizing shoes on each of the four brakes. The floating or upper brake shoes are energized with the forward motion of the car. For this reason they do most of the braking and are made of aluminum alloy. The anchored or lower shoes are energized with the backward movement of the car. Therefore, they do less braking and are made of steel.

The aluminum alloy shoes naturally expand more than the steel shoes under the heat generated by the use of the brakes. This compensates for the tendency of the drums to expand away from the shoes. The result is that Cadillac brakes are just as effective toward the bottom of a long hill as they are when first applied at the top.

The cam operating the shoes, is mounted on a pivoted bracket so as to be self-centralizing and thereby compensate for unequal wear on the brake linings.

The cam end of each brake shoe has a pivoted link which rests against the brake operating cam. Thus, instead of a sliding contact between the cam and the brake shoes, there is a rolling contact between the cam and the pivoted links. This construction prevents wear on the cam and the ends of the brake shoes.

The cam has a splined shaft on which is mounted an especially designed operating lever. The hub of this lever is broached to fit over the splined shaft and is connected to the casing of the cam lever by an adjustable link. When the nut on the outer end of the link is turned, the hub turns with relation to the lever itself, thereby changing the position of the brake operating cam. This construction permits the simplest known method of brake adjustment.

The front brakes are operated by a cable extending through the frame side bars to the brake assembly on the wheels. This cable is

carried in a reinforced, flexible casing or conduit, and is connected at the rear to a short pull rod which in turn is connected to a lever on the rocker shaft.

The foot pedal operates the brakes on four wheels, while the hand brake lever operates the rear brakes only. Thus only one set of shoes is needed for both braking systems.

The service operations and adjustments of the brakes are the same on all cars except the 370-B and 452-B cars. The only difference is that these cars are equipped with a vacuum brake assister.

VACUUM BRAKE ASSISTER

A vacuum brake assister is used on the 370-B and 452-B cars. It is connected at the rear to the center cross member of the frame, and at the front end to a lever on the pedal shaft and is operated by vacuum from the intake manifolds. The force thus developed is applied to the lever on the pedal shaft, and is added to the force applied by the driver to the pedal. Although the assister is connected to the brake pedal, it does not interfere with the pedal action, and the foot brakes can be applied whether the engine is running or not. Also, the assister does not affect the adjustments of the brakes or any of the brake connections up to the pedal.

The control is positive, the valves being regulated by the movement of the pedal itself. The assister develops power only while the brake pedal is moving forward. As soon as the pedal stops, the assister ceases to build up any force and merely helps to hold the position which has been reached. The assister releases automatically when the pedal is released.

The general design of the brake assister and the various stages of its operation are shown on Page 26.

Service Information

1. Regrinding Brake Drums

Cast-iron brake drums supplied by the Parts Division, for all model cars with the shoe type brakes, are finish-machined at the Factory before being shipped. This eliminates the necessity of finish-machining the drum after installing it on the wheel. Careful alignment of the drum on the hub, however, is of particular importance.

There is a limit to the amount of metal that can safely be removed from a drum when regrinding. The drums must not be ground out more than .030 inch over the original limit of the inside diameter. When brake drums are too thin, the excessive heat that frequently develops will cause them to distort and warp. Also the enlarged inner diameter of the drum may prevent proper action of the cams.

Note: Disconnect brake pull rod and assister from pedal lever to adjust eccentric bushing.




Fig. 1
Eccentric Bushing Adjustment




Fig. 3
Valve Rod Adjustment




Fig. 4
Operating Tube Adjustment
With Tube Connected to Pedal




Fig. 2
Operating Tube Clevis Adjustment




Fig. 5
Pull Rod Adjustment

BRAKES—Service Information—Specifications

The thickness of the drums may be measured either in the groove near the outer flange or at the thin section back of the reinforcement. The table gives the minimum thickness at both points, "at groove" representing the thickness within the groove, and at thin section back of reinforcement representing the thickness of the drum on the side of the reinforcement nearest to the wheel.

2. Snapping Noise in Diaphragm of Brake Assister

The rubber diaphragm in the assister sometimes makes a snapping noise when the brake pedal is operated. This noise is due to the diaphragm being twisted, and results from the clevis on the operating tube not being properly lined up before it is connected to the pedal lever.

If the clevis on the tube does not line up so that the pin can be inserted without turning the tube, the lock nut should be loosened and the clevis readjusted. Since the rubber diaphragm is all that holds the tube, it is easy to turn the tube to line up the clevis, but if this is done, the diaphragm will be twisted and cause the snapping noise referred to.

It is not necessary to disconnect the assister to correct this. Simply loosen the lock nut at the clevis and turn the tube slightly, by means of the vacuum connection, until the proper alignment is secured.

3. Leaking Atmospheric Valves

If the atmospheric valves do not seat tightly, part of the effect of the vacuum is lost and the assister will not exert the normal amount of force. To test for this condition, first note how much pressure must be applied to the brake pedal to make a given stop with the transmission in neutral and the engine idling. Then repeat the test with the transmission in neutral but with the ignition switched off.

If there is no difference in the pedal pressure between the two tests, then the assister is not functioning properly.

In such cases, the groove cut in the shank of the atmospheric valve for the rubber washer which forms the seat, may have a burr or fin which prevents the washer from entering the groove and causes it to buckle. This can be corrected by removing the burr and making sure that the washer fits all the way in the groove and lies flat on the inner face of the valve.

4. Chatter or Jerking on Brake Assister

Chattering or jerky operation of the brake assister is generally caused by misalignment of the assister with the brake pedal, or by improper action of the atmospheric valves.

Misalignment of the assister is usually encountered only after installing a new assister and very rarely gives any trouble on assisters installed at the factory.

To check the alignment, take the pin out of the clevis at the front of the operating tube and hold the front end of the assister just below the pedal levers. The alignment between the clevis and the pedal lever should be such that the clevis can be pushed up into place without striking the levers.


If the above test shows that the assister is not in proper alignment, remove the assister and file off the sides of the lug on the back of the cylinder to secure proper alignment. In many instances, proper alignment may be secured by simply filing out the sides of the pin hole in this lug.

If the brake assister appears to be in correct alignment with the pedal, take the assister apart and install new atmospheric valves, Part No. 881475.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Braking area (foot brakes)—total in square inches.....	238	238	238	274.6
Braking power division.....	60% front 40% rear	60% front 40% rear	60% front 40% rear	60% front 40% rear
Clearance between lining and drum (approximately)..... <i>Clearance secured by turning adjusting nut on cam lever</i>	.007"	.007"	.007"	.007"
Clearance between pedal and under side of toe-board.....	$\frac{1}{4}$ - $\frac{3}{8}$ "	$\frac{1}{4}$ - $\frac{3}{8}$ "	$\frac{1}{4}$ - $\frac{3}{8}$ "	$\frac{1}{4}$ - $\frac{3}{8}$ "
Drums (See Note 1)—				
Inside diameter.....	14.996-15.004"	14.996-15.004"	14.996-15.004"	15.996-16.004"
Out of round, not over.....	.007"	.007"	.007"	.007"
Thickness at thin section.....	.488-.554"	.488-.554"	.488-.554"	.488-.554"
Lining—				
<i>Full moulded lining used on rear brakes and semi-moulded on front brakes.</i>				
Length per wheel.....	29 $\frac{3}{4}$ "	29 $\frac{3}{4}$ "	29 $\frac{3}{4}$ "	31 $\frac{5}{8}$ "
Thickness.....	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{1}{16}$ "
Width.....	2"	2"	2"	2 $\frac{1}{4}$ "
Pull back (lever retracting) springs—front and rear brakes—				
Free length inside loops (approximately).....	3 $\frac{3}{4}$ "	3 $\frac{3}{4}$ "	3 $\frac{3}{4}$ "	3 $\frac{3}{4}$ "
Tension in pounds stretched to 4 $\frac{1}{2}$ in. between loops.....	10-12 lbs.	10-12 lbs.	10-12 lbs.	10-12 lbs.
Type.....	Mechanical	Mechanical	Mechanical with Vacuum Assister	Mechanical with Vacuum Assister

Plate 10. Diagrams Showing Operation of Vacuum Brake Assister—Cadillac
370-B and 452-B



BRAKES

Note: Unless brake connections are known to be O.K. check them as shown in Plate 8 before proceeding with cam adjustments.




Fig. 1
Typical Front Brake

Fig. 2
Typical Rear Brake




Fig. 3
Front Brake Adjustment

Loosen cam bracket locking nut and apply brakes firmly to centralize cam bracket. Tighten nut before releasing brakes.

Check for equalization between right and left. If O.K., turn down all four adjusting nuts same number of turns until pedal travel is approximately 2-1/4 inches. (1-1/6 turns equals 1 inch pedal travel).

If equalization is not O.K., first turn down nuts until all four brakes just drag; then back off nuts same number of turns to give proper pedal travel. Recheck for equalization and make further adjustment if necessary.




Fig. 4
Rear Brake Adjustment




Fig. 5
Cam Lever With Half of Casing Removed




Plate 11A. Diagrams Showing Operation of Vacuum Brake Assister—
Cadillac 355-C—LaSalle 345-C

BRAKES—General Description—Service Information

General Description

The brakes on the "C" series cars are the same as on the corresponding "B" cars with the exception that a brake assister is used on the Cadillac 355-C and the LaSalle 345-C.

A coil spring also surrounds each brake drum on all "C" cars to give additional cooling surface and to absorb any noise produced by vibration in the drum.

Because of a difference in the length of the operating tube, the 355-C assister unit is not interchangeable with that used on the 345-C.

Aside from the brake assister on the 355-C and 345-C cars, all adjustments of the brakes and brake connections remain the same as on the "B" cars.

Service Information

5. Lubrication of Brake Assister

Early V-12 and V-16 cars are provided with a ratchet type grease cup for lubricating the brake assister. With this ratchet type grease cup, lubrication is necessary every 1000 miles.

To lubricate the assister, simply fill the grease cup with light cup grease (G-2½) and turn down a few turns every 1000 miles. It is extremely important that the G-2½ cup grease be used during cold weather. When wheel bearing lubricant is used at this point, difficulty is sometimes experienced in extremely cold weather with the lubricant hardening and interfering with the smooth operation of the assister.

Later cars are equipped with a wick oiler for lubricating the brake assister. With this type oiler the lubrication require-

ments are different, an engine oil of S. A. E. viscosity 20 being required every 6000 miles.

This new type wick oiler, part No. 885268 can be used on any 370 and 452 brake assister. To install, simply remove the grease cup and screw the oiler in place, tightening the hex securely. The brake assister pull rod should be removed and cleaned of all the old grease. After reassembling, the oiler reservoir should be filled with S. A. E. 20 engine oil and screwed in place. Lubrication is then required only on the regular number 6 and 12 lubrication operations.

The brake assister on the 345-C and 355-C cars requires the same lubrication as the clutch power cylinder on the "B" models. That is, one ounce of S. A. E. No. 10 oil or light machine oil of weight similar to shock absorber oil should be injected in the front chamber of the cylinder through the plugged opening in the cylinder head every 6000 miles.




Plate 11B. Brake Assister Adjustments—Cadillac 355-C—LaSalle 345-C

CLUTCH




Fig. 1

Sectional View of Cadillac 355-B Clutch and Flywheel. Typical of all models.




Fig. 2

Clutch Disassembled

Do not touch these nuts to remove or disassemble clutch or at any other time




Fig. 3

Rear view of clutch showing double-lever release mechanism.




Fig. 4

View of Clutch Release Mechanism




Fig. 5

Clutch Release Lever Assembly

CLUTCH

General Description

The clutch used on Cadillac and LaSalle cars is of the dry-plate type with three driving plates and two driven discs. The center driving plate carries four driving studs which extend through both the front and rear plates.

The rear plate is a part of the spring pressure plate assembly which also includes the double-lever release mechanism. This double-lever control compensates for springiness in the levers and pressure plate, insuring uniform engagement of the clutch over the entire surface of the facings.

The driven discs for the 345-B, 355-B and 370-B clutches have curved spokes to give the same flexibility as the larger discs with the longer straight spokes used in the 452-B clutch.

The factory does not supply any of the component parts of the various pressure plate assemblies, inasmuch as specially designed equipment is necessary to adjust the assembly properly. The only individual parts furnished for the clutch are the driven discs. When any of the other parts need replacing, it will be necessary to install a complete clutch assembly.

The mounting of the clutch is extremely simple. It is necessary to take off only four nuts to remove the entire clutch assembly from the flywheel.

The clutch pedal stop screw is located above the pedal hub instead of below as on previous models. With this type stop any wear or backlash in the trunnion pin does not affect the movement of the clutch pedal pad. Therefore, the amount of pedal play represents only the movement of the clutch release bearing.

The service operations of the clutch and the adjustments of the clutch control are the same on all cars.

CONTROLLED FREE WHEELING

All cars are equipped with "controlled" free wheeling. This is the name given to the automatic vacuum-operated control for the clutch. This device consists of a piston and cylinder connected to the clutch release mechanism and operated by the vacuum from the intake manifold. The vacuum is controlled through valves connected to a control button on the toe-board and to the accelerator pedal. The design is such as to vary the rate of engagement of the clutch according to the speed with which the accelerator pedal is depressed.

The relative positions of the clutch control parts is shown in Plate 14, Page 32. The vacuum or power cylinder is attached at the rear end to the center cross member of the frame and the piston is connected to the clutch release mechanism. The power cylinder is connected through a control valve to the intake manifold, which furnishes the necessary vacuum. The force thus developed is applied to a lever which is connected to the clutch release rod for disengaging the clutch. Although the power cylinder is connected to the clutch release mechanism, it does not interfere with the pedal action and the clutch can be operated entirely independently of the automatic control.

POWER CYLINDER

The power cylinder has a piston which divides the housing into two chambers. The front, or air chamber, is open to the atmosphere through three passages: (1) the air by-pass in the piston rod, (2) the atmospheric valve in the cylinder head and (3) the bleeder line leading to the bleeder valve in the control valve unit. The rear, or vacuum chamber, is connected to the intake manifold through the cut-out and accelerator plunger valves in the control valve.

The air by-pass in the piston rod is simply a long slot. Its operation is controlled by the movement of the piston and permits a rapid discharge of air from the air chamber when the piston is moving forward up to the point at which the clutch begins to engage. After this point is reached the only escape for air from the air chamber is through the bleeder valve.

The atmospheric valve in the cylinder head permits a rapid refilling of the air chamber in the cylinder when the clutch is disengaged.

CONTROL VALVE

The control valve consists of three plungers: the bleeder plunger, the accelerator plunger and the cut-out plunger. The bleeder and accelerator plungers are connected together to the accelerator pedal. The cut-out plunger is operated by the control button.

The control is positive, the valves being actuated by the movement of the control button and the accelerator pedal. The power cylinder develops power only so long as the driver keeps the control button depressed. As soon as the

CLUTCH




Fig. 1
Typical Clutch Control

Adjust clutch pedal stop screw to give 1/4-3/8 in. clearance between pedal and under side of toe-board.

Feeler gauge inserted between upper facing and center driving plate.
Center driving plate and disc assembly supported on blocks under lower driven disc.
Do not reface discs; replace disc and facing assembly.




Fig. 2

Measuring total clearance between clutch facings and center driving plate.
This total clearance should be held to .025-.040 in., .030 in. being recommended.

To remove discs, take off nuts on 6 hub bolts.
1-15/32 in. on 345-B, 355-B and 370-B
1-13/32 in. on 452-B

Spacers should be installed between driven disc and clutch hub as necessary to give proper clearance between facings and center driving plate. Unnecessary to have spacer between each disc and hub.




Fig. 3

Replace driven discs if distance between outer end of release levers and plane of rear face on spring pressure plate is less than the amount given on the illustration




Fig. 4

Driven discs with curved spokes must be properly installed. The spokes should lead out from the hub in a clockwise direction when viewed from the flywheel side of the clutch.

CLUTCH—General Description—Service Information

driver releases this button the vacuum operated control does not function and the clutch can be operated in the conventional way with the clutch pedal.

The bleeder plunger regulates the flow of air out of the air chamber of the power cylinder after the air by-pass in the piston rod is closed, just as the clutch starts to engage. The amount of air bled out of the power cylinder at this time depends on the number of bleeder holes uncovered by the bleeder plunger and the speed of the plunger movement, the position and movement of which, in turn, depends on the position and movement of the accelerator pedal.

Therefore, a slow downward movement of the accelerator pedal permits a slow escape of air from the air chamber in the power cylinder and gives a correspondingly slow engagement of the clutch. A faster downward movement of the accelerator pedal will uncover the bleeder holes faster, permitting a more rapid escape of air from the air chamber in the power cylinder and consequently, a quicker clutch engagement. Thus the rapidity with which the clutch is engaged is controlled by the movement of the accelerator pedal, insuring smooth clutch engagement under all conditions.

The accelerator pedal must not be pushed down while the control button is depressed, until the car is to be started. This means that the accelerator pedal cannot be used to speed up the engine while waiting for traffic. If the engine is not warm enough to run at normal idling speed, the hand

throttle should be advanced or the regular clutch pedal should be used until the engine is warm.

While the accelerator plunger moves with the bleeder plunger, it functions in conjunction with the cut-out plunger to open the vacuum chamber in the power cylinder to the intake manifold or to the atmosphere. Each of these plungers acts both as a valve and an air by-pass.

When the control button is depressed with the accelerator in the released position, the valve ports in both the accelerator and cut-out plungers are in line, completing the vacuum passage between the intake manifold and the power cylinder. The vacuum then pulls the piston back and disengages the clutch.

Depressing the accelerator (with the control button down) closes the vacuum line and opens the vacuum chamber to the atmosphere, permitting the chamber to refill as the clutch is engaged.

Releasing the accelerator (with the control button down) opens the vacuum line again and disengages the clutch.

The accelerator pedal must be completely released between shifts. It is the first half-inch of travel of the accelerator pedal that operates the clutch control valve and unless the accelerator pedal is allowed to come all the way back, the clutch will not automatically disengage.

Releasing the control button likewise closes the vacuum line and opens the vacuum chamber to the atmosphere, allowing the clutch to engage.

Service Information

1. Mounting of Clutch Control Mechanism

The hook-up of the free-wheeling control button and the accelerator pedal requires the pivoting of the bell-cranks on the toe and floor board. The toe-board is in one section and, since the control button is attached to this unit, it should not be moved unless absolutely necessary. The floor board, however, is in two sections. The accelerator pedal control is pivoted to the large right-hand section, but the panel at the extreme left-hand side may be removed without affecting any adjustment. If the sections to which these units are attached are moved the controls will require readjustment.

2. Removal of Transmission

Extreme care must be taken when removing the transmission to support the rear end so as to hold the transmission in perfect alignment with the clutch until the clutch connection shaft has been pulled all the way out of the clutch hub.

If the rear end of the transmission is allowed to drop down or is raised too high while the clutch connection shaft is still in the clutch hub, the clutch driven discs will be sprung out of shape. This must be avoided.

3. Vent Holes in Control Valve Boot

On some of the first cars shipped, the rubber boot, Part No. 891917, protecting the clutch control valves does not have holes in it to allow the proper passage of air for venting the vacuum chamber when the clutch is being engaged.

On cars now being shipped, the boot has three 1/4-inch holes in the lower side of the boot.

Without these holes, the engagement of the clutch is delayed. In case of improper action of the clutch control, the rubber boot should be inspected to make sure it has these holes before any adjustments are changed.

Plate 14. Power Clutch Control Adjustments






Fig. 1
General Arrangement and Adjustments of Free-wheeling Control Units



If adjusting groove (See Fig. 4, is machined in accelerator plunger, adjust accelerator to bring groove flush with front side of control valve body at point of throttle closing.

Fig. 2
Accelerator and Bleeder Plunger Adjustments




Fig. 3
Sectional View of Free-wheeling Control Power Cylinder




Fig. 4
Sectional Views of Free-wheeling Control Valve

Plate 16. Diagrams Showing Operation of Power Clutch Control




Fig. 1

Clutch Engaged

Control button and accelerator are released.




Fig. 2

Clutch Disengaging

Control button is depressed, opening vacuum line.




Fig. 3

Clutch Disengaged




Fig. 4

Clutch Engaging

Accelerator is partly depressed, closing vacuum line and opening bleeder line.




Fig. 5

Clutch Engaged




Fig. 6

Control Button Released

Both chambers in power cylinder are open to the atmosphere and movement of the accelerator has no effect on the operation of the clutch.

CLUTCH—Service Information—Specifications

4. Installation of Second Type Clutch on Early 452-C Cars

A second type clutch and flywheel are used on 452-C cars beginning with engine unit 50-24. The change made in the clutch is the removal of the starter ring gear from the clutch center plate to the flywheel, which construction is similar to that used on the V-8 and V-12 cars. The part number of this second type clutch is 3500109 and that of the flywheel is 1096192.

This second type clutch is furnished for replacement on all 452 cars, the "A" and "B" series as well as the "C" series. Installation on all except 452-C cars after engine unit 50-23 will also necessitate the installation of the second type flywheel with starter gear.

As the flywheels supplied under part number 1096192 are

for use on "A" and "B" as well as "C" series cars, they are stamped with two sets of ignition timing marks. These marks can be readily identified, however, as the IG/A mark for the "A" and "B" cars is $1\frac{1}{4}$ inches ahead of center, whereas the IG/A mark for the "C" series is $\frac{1}{2}$ inch ahead of center. The IG/A marks can be further identified by the stampings "A and B model" and "C model" respectively.

5. Clutch Balance

Before a clutch leaves the factory, it is properly balanced and each of the three plates are marked in line so that the plates can be lined up without rebalancing any time the clutch is disassembled. The marking consists of a circle in which a letter may appear. If the circles on each of the three plates are lined up whenever the clutch is reassembled after disassembly, there should be no difficulty experienced of an out of balance condition.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Clearance between—				
Driving plates and driving pins				
New limits.....	.002-.0045"	.002-.0045"	.002-.0045"	.002-.0045"
Worn limit, not over.....	.008"	.008"	.008"	.008"
Hub and splines on clutch connection shaft				
New limits.....	.0005-.002"	.0005-.002"	.0005-.002"	.0005-.002"
Worn limit, not over.....	.005"	.005"	.005"	.005"
Release bearing sleeve and extension on transmission bearing cap				
New limits.....	.001-.004"	.001-.004"	.001-.004"	.001-.004"
Worn limit, not over.....	.006"	.006"	.006"	.006"
Pedal and bottom of toe-board.....	$\frac{1}{4}$ -" $\frac{3}{8}$ "	$\frac{1}{4}$ -" $\frac{3}{8}$ "	$\frac{1}{4}$ -" $\frac{3}{8}$ "	$\frac{1}{4}$ -" $\frac{3}{8}$ "
Disc facings—				
Area—total in square inches.....	219.1	219.1	219.1	243.3
Diameter inside.....	$5\frac{1}{2}$ "	$5\frac{1}{2}$ "	$5\frac{1}{2}$ "	$6\frac{1}{2}$ "
Diameter outside.....	10"	10"	10"	$10\frac{1}{8}$ "
Number used.....	4	4	4	4
Thickness.....	.135-.145"	.135-.145"	.135-.145"	.135-.145"
Driven disc with facings—				
Number used.....	2	2	2	2
Thickness.....	.325-.350"	.325-.350"	.325-.350"	.335-.360"
New limits.....	.260"	.260"	.260"	.260"
Worn limit, not over.....				
Driving plates, number of.....	3	3	3	3
Mounting of clutch control mechanism (See Note 1).....				
Pedal (clutch) free play.....	$1\frac{1}{4}$ -" $1\frac{1}{2}$ "	$1\frac{1}{4}$ -" $1\frac{1}{2}$ "	$1\frac{1}{4}$ -" $1\frac{1}{2}$ "	$1\frac{1}{4}$ -" $1\frac{1}{2}$ "
Pressure springs, number of.....	12	12	12	12
Removal of transmission (See Note 2).....				
Spring, retracting for clutch pedal—				
Free length inside loops.....	$6\frac{1}{4}$ "	$6\frac{1}{4}$ "	$6\frac{1}{4}$ "	$6\frac{1}{4}$ "
Tension in pounds stretched to $10\frac{3}{4}$ in. between loops.....	34 to 38	34 to 38	34 to 38	34 to 38
Type.....	Plate	Plate	Plate	Plate
Vent holes in control valve boot (See Note 3).....				

COOLING SYSTEM




Fig. 1

The shroud ring should be raised or lowered whenever the fan belt is adjusted to keep the fan centered in the ring.




Fig. 2

The fan belt should be adjusted so a pull of 8-10 lbs. is necessary to bring outer faces of belt within 5 in. of each other—Cadillac 370-B, 452-B.




Fig. 3

Correct adjustment of fan belt—Cadillac 355-B—LaSalle 345-B

Joints should be aligned so that control rod does not bind at either end.




Fig. 4

Front view of radiator showing thermostat and shutter control.





Fig. 5

Radiator Support

COOLING SYSTEM

General Description

The general arrangement of the cooling system on the LaSalle and Cadillac 8 differs somewhat from that of the 12- and 16-cylinder cars.

On the LaSalle and Cadillac 8, the fan revolves on "Durex" bearings lubricated with oil from the oil pressure regulator. The passage for the oil return is through the hollow fan bracket. On the 370-B and 452-B cars, the fan is carried on ball bearings, which are lubricated by hand through a fitting at the rear end of the fanshaft.

The fan runs within an adjustable shroud ring installed on the radiator as shown in Fig. 1, Plate 17. This ring prevents the recirculation of air under the hood, thus increasing the flow of air through the radiator.

A "built-in" chromium plated grille is used in front of the radiator and is a part of the radiator casing. It adds greatly to the appearance of the car and is easily cleaned. The radiator is of the "full-bonded fin" construction.

The 370-B and 452-B cars are provided with condenser tanks in the cooling system. These tanks are located on the right-hand frame side bar and are connected to the radiator overflow pipe. It is necessary, of course, to have all water connections, as well as the radiator cap, perfectly tight in order that the condenser tank may operate satisfactorily.

The condenser tank is not standard equipment on LaSalle and Cadillac 8, but can be installed if desired.

The water pump used on the 8-cylinder engines is of the single outlet type, and is mounted on the front of the timing chain case, while that on the 370-B and 452-B engines is of the double outlet type, and is mounted on the right-hand side of the crankcase, back of the generator. On this pump, one outlet leads to each cylinder block.

The water pump on the 370-B and 452-B cars is driven from the rear end of the generator through a short shaft having a flexible coupling at each end.

Service Information

1. Radiator Filling Level

The recommended level to which the Cadillac 355-B and LaSalle radiators should be filled is approximately half-way to the top of the upper tank or one-half way up on the thermostat bulb. It is especially important not to fill the radiator too full in the winter, because expansion will cause a loss of anti-freeze solution through the overflow.

2. Flushing Cooling System

The cooling system should be flushed out every 6000 miles to prevent the excessive accumulation of sediment and scale.

Disconnect lower hose from radiator and attach flushing hose to radiator outlet. The water pressure for this flushing operation should not exceed 20 to 25 pounds or the radiator may be damaged. The flushing should be continued until water runs clean from the lower hose connection.

3. Using Soluble Oil in Cooling System

The use of water soluble oil in the cooling system is recommended as an aid in keeping the system clean by reducing sludge and retarding rust formation.

When soluble oil has not previously been used in the cooling system of a Cadillac or LaSalle car, about $\frac{1}{2}$ pint should be used. If the oil has been used previously, upon draining and refilling, $\frac{1}{4}$ of a pint (six ounces) is sufficient to keep the cooling system in good condition.

When soluble oil is first used in the system, a thin protective film is deposited over the cooling surfaces. Any excess oil mixes with the cooling liquid and, although a slight amount has a tendency to prevent foaming by increasing the surface

tension of the liquid, too much will result in violent foaming with consequent loss of cooling liquid.

Before adding soluble oil to cars already in service, the cooling system should be thoroughly cleaned and flushed. Soluble oil itself is merely a preventive; its cleaning properties are negligible. With the cooling system clean, the soluble oil will have a chance to do its work; otherwise the formation of rust, although retarded to some extent, will continue under the scale already formed.

It is not necessary to add soluble oil each time water is added. The 6 ounces added after the cooling system has been drained and flushed is sufficient until the next draining.

Soluble oil has no anti-freeze qualities in itself but it will blend satisfactorily with any approved anti-freeze. The same proportions of anti-freeze should be maintained with or without the use of the oil.

Important—Hydrometer readings are affected by the soluble oil and allowances must be made for the difference. If an alcohol or methanol solution is used its freezing temperature will be five degrees higher than indicated by the hydrometer. For instance, if the hydrometer reading indicates 0° F. the corrected reading would be 5° above zero. In the case of a glycerine or ethylene glycol solution, however, the five degrees should be subtracted making the solution good to 5° below when the hydrometer indicates 0° F.

4. Test for Radiator Thermostat

To test the thermostat, immerse it in water of the correct temperature. Do not permit the water to enter the thermostat or come in contact with its inner surface. The plunger should start to move at not less than 149° and should finish its stroke ($\frac{1}{16}$ in.) at not over 173°.

COOLING SYSTEM

Turn down and refill with water pump lubricant every 1,000 miles




Fig. 1

Sectional View of Water Pump—
Cadillac 355-B-C LaSalle 345-B-C

Turn down and refill with water pump lubricant every 1,000 miles




Fig. 2

Sectional View of Water Pump—
Cadillac 370-B, 370-C before engine unit 40-301, 452-B

Turn down and refill with water pump lubricant every 1,000 miles




Fig. 3

Sectional View of Water Pump
Cadillac 370-C beginning engine unit 40-301, 452-C




Fig. 4

Cadillac 370-B-C Water Pump Drive
Typical of 452-B-C

Fibre disc couplings should have at least 1/32 in. total play or clearance endwise between discs and driving flanges. Water pump should be lined up to give equal clearance at all points between fibre discs and driving flange

Loosen clamp screws before adjusting drive chain
(See Plate 28, Fig. 4)




Fig. 5

Water Pump Mounting—
Cadillac 355-B-C LaSalle 345-B-C

Plate 18. Water Pump Details and Drive Adjustment

COOLING SYSTEM—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Fan				
Belt—				
Length (center to center).....	8½"	8½"	14"	14"
Width.....	7⁄8"	7⁄8"	7⁄8"	7⁄8"
Blades—				
Pitch at tip of blade (spiral blades).....	31°	31°	31°	31°
Number used.....	6	6	6	6
Diameter.....	20¾"	20¾"	20¾"	20¾"
Ratio of fan R.P.M. to engine R.P.M.....	9/10 to 1	9/10 to 1	9/10 to 1	9/10 to 1
Hose Connections				
Cylinder to radiator (top), (2 used)—				
Diameter, inside.....	1¼"	1¼"	1¼"	1¼"
Length.....	13¼"	13¼"	7¼"	7¼"
Cylinder to elbow (2 used)—				
Diameter, inside.....	2¼"	2¼"		
Length.....	1¼"	1¼"		
Elbow to pump—				
Diameter, inside.....	1½"	1½"		
Length.....	16½"	16½"		
Pump to radiator (two used on 370-B, 452-B)				
Diameter, inside.....	17⁄8"	17⁄8"	1¾"	1¾"
Length.....	10¾"	10¾"	4"	4"
Radiator				
Anti-freeze solution—				
Alcohol or methanol required for 10° F.....	9.25 qts.	9.25 qts.	8.50 qts.	10 qts.
Specific gravity at 60° F.				
Alcohol—denatured No. 5.....	.967	.967	.967	.967
Methanol.....	.972	.972	.972	.972
% by volume.....	35	35	35	35
Alcohol or methanol required for 0° F.....	10 qts.	10 qts.	9.25 qts.	10.75 qts.
Specific gravity at 60° F.				
Alcohol—denatured No. 5.....	.957	.957	.957	.957
Methanol.....	.964	.964	.964	.964
% by volume.....	38	38	38	38
Alcohol or methanol required for -10° F.....	11.75 qts.	11.75 qts.	10.75 qts.	12.75 qts.
Specific gravity at 60° F.				
Alcohol—denatured No. 5.....	.948	.948	.948	.948
Methanol.....	.957	.957	.957	.957
% by volume.....	45	45	45	45
Alcohol or methanol required for -20° F.....	13.25 qts.	13.25 qts.	12.25 qts.	14.25 qts.
Specific gravity at 60° F.				
Alcohol—denatured No. 5.....	.935	.935	.935	.935
Methanol.....	.950	.950	.950	.950
% by volume.....	51	51	51	51
Alcohol or methanol required for -30° F.....	15 qts.	15 qts.	13.75 qts.	16 qts.
Specific gravity at 60° F.				
Alcohol—denatured No. 5.....	.926	.926	.926	.926
Methanol.....	.944	.944	.944	.944
% by volume.....	57	57	57	57
<i>This table is based on use of 188 proof denatured alcohol or of anti-freeze methanol 155 proof.</i>				
Area of radiator core in square inches.....	483	483	483	519
Capacity of cooling system (See Note 1).....	6½ gal. ✓	6½ gal. ✓	6 gal. ✓	7 gal. ✓
Flushing cooling system (See Note 2).....				
Manufacturer's number, location of.....				
Rear of lower tank on R. H. side.....				
Soluble oil in cooling system, Using (See Note 3).....				
Thermostatic Shutter Control (See Note 4).....				
Water Pump				
Clearances between—				
Impeller and pump body				
New limits.....	.055-.070"	.055-.070"	.070-.085"	.070-.085"
Worn limit, not over.....	.080"	.080"	.095"	.095"
Pump shaft and bushings				
New limits.....	.001-.003"	.001-.003"	.001-.003"	.001-.003"
Worn limit, not over.....	.005"	.005"	.005"	.005"
End play in pump shaft				
New limits.....			.0065-.025"	.0065-.025"
Worn limit, not over.....			.050"	.050"

ELECTRICAL SYSTEM




Plate 19. Generator and Starting Motor Details

ELECTRICAL SYSTEM

General Description

Cadillac and LaSalle electrical systems are of the same general arrangement except the ignition and lighting circuits. The ignition systems are necessarily different because of the difference in the number of cylinders in the eight, twelve and sixteen cylinder engines. The lighting is practically the same on all models except the 345-B.

The Delco storage batteries used on the Cadillac and LaSalle are of large capacity with the cells arranged side by side. The 345-B and 355-B batteries have 17 plates, while the 370-B and 452-B batteries have 21 and 25 plates, respectively.

The battery on all models is carried in the right front fender. The cover over the battery forms a part of the fender and is held in place by four screws, one in each corner. A corresponding compartment and cover are provided on the left side of the car for tire chains.

The Delco-Remy generators used on Cadillac and LaSalle cars are of the ventilated type with third-brush thermostatic control. They are mounted on the right hand side of the engine and are chain driven. The cut-out relay is mounted in the circuit control box on the dash. See Fig. 1, Plate 20.

HORNS

Both the Cadillac and the LaSalle are equipped with two horns, one under each head lamp. The horns are matched and should be serviced in pairs.

The horns are operated through a magnetic relay which in turn is operated by the horn button. Instead of a heavy wire being used between the horn button and the horns heavy wires are used only between the horns and the relay which is in the circuit control box. A smaller wire is used between the horn button and the relay. This eliminates the passing of a heavy current through the horn button and minimizes the voltage drop in the wiring, giving a more nearly uniform voltage at the horns.

IGNITION

On Cadillac 8 and LaSalle cars the ignition system is of the same general arrangement. On the 370-B and 452-B cars, the ignition systems are also similar, each consisting of two separate circuits, one for each cylinder block, controlled by the same switch. Each circuit has its own coil, contact points, condenser and set of distributor terminals.

The ignition coil for the 8 cylinder cars is mounted on the driver's side of the dash. On the 370-B and 452-B cars, the coils are mounted in recesses in the upper tank of the radiator where they are protected from moisture and excessive heat.

The distributors are fully automatic, no manual advance being provided.

The 370-B and 452-B distributors have a special double-end rotor which distributes the high tension current to the right hand cylinders from one end, and to the left hand cylinders from the other end. The end which takes care of the right hand cylinders is connected to the terminal in the center of the distributor cap. The other end of the rotor, which provides for the left hand cylinders, is connected to the off-center coil terminal.

The contacts at the end of the 370-B distributor rotor are not exactly 180° apart because of the alternate 45° and 75° firing intervals of the engine. A 45° interval (on the crankshaft) comes after each of the right hand cylinders fires and a 75° interval comes after each of the left hand cylinders fires.

The cylinders in all engines are numbered from the front, according to location rather than firing order. The 345-B and 355-B engines have the even numbered cylinders on the left side and the odd numbered cylinders on the right side. On the 370-B and 452-B the numbering system is just the reverse to that of the 8 cylinder engines with the even numbered cylinders on right and the odd numbered on the left.

The contact arms operate alternately and are mounted at an angle of 30° for the Cadillac 8 and LaSalle, and at 22-1/2° for the 370-B and 452-B.

The breaker cam on the 345-B and 355-B is integral with the distributor shaft and the timing of the contact arm for the right hand cylinders is done by rotating the distributor on its support. A pointer and graduated dial indicates the amount the distributor is moved. The right hand contact arm in the 370-B and 452-B distributor is timed either by turning the cam or rotating the distributor. The left hand arm on all models is mounted on an adjustable plate and is timed by an eccentric adjustment which must be synchronized with that of the other arm. Adjustment of this plate does not disturb the contact point gap.

The breaker cam has four lobes on the Cadillac 8 and LaSalle distributors, six on the 370-B and eight on the 452-B.

The automatic spark control mechanism is the same on all models.

ELECTRICAL SYSTEM




Fig. 1

Circuit Control Box


The circuit control box is located on the dash under the cowl.

Before attempting to adjust horn, check for following conditions which will affect horn tone:

Low Battery—Horn will not give proper tone with engine not running.

Poor Connections—Horn does not give good tone under any driving conditions.

④ Turn adjusting nut to secure current consumption of 5.5-6.5 amps. tested with precision ammeter. Turn nut 1/10 turn at a time and lock before trying horn.



① Remove cover and tighten diaphragm flange screws and nuts.

③ Remove projector and loosen lock nut. Then turn disc all the way to right and tighten lock nut.

② Turn adjusting nuts to give uniform air gap of .022-.026 in. across armature.

⑤ Loosen nut and turn disc to left until it touches collar, then back off 1/4 turn and lock. If horn has coarse high pitch turn disc to right away from collar, and to left toward collar if pitch is too low. Projector must be in place to test horn.

Fig. 2

Horn Adjustments

Test each horn separately and tune up the one which is most out of adjustment. Then adjust the other horn to a tone that harmonizes with the first.

ELECTRICAL SYSTEM—General Description—Service Information

The starting motors used are of the same general construction, differing principally in the size and number of poles. Those used on the 8-cylinder cars are of the four pole type, while those on the 12- and 16-cylinder cars are of the six pole type. Four brushes are standard on all starting motors.

The starting motor cranks the engine through internal reduction gears.

The driven gear on the engine is mounted on the flywheel on the 345-B, 355-B and 370-B and on the center clutch driving plate on the 452-B.

WIRING

The general arrangement of the chassis wiring

is the same in all models. The wires are grouped in a braided varnished harness and wherever possible are carried in a corner of the side bar.

The stop and back-up lamps are connected in the ignition circuit and are protected by a fuse in the circuit control box.

A feature of the electrical system is the circuit control box. This box is located in the rear of the dash under the cowl and contains the circuit breaker, the generator cut-out relay, the horn relay and the fuse for the stop light and back-up light circuit. It also serves as a junction box for the wire connections.

Service Information

1. Connections for Electrical Accessories.

When installing additional electrical equipment, such as radios, heaters, spot lights, cigar lighters, etc., it is important to make sure that they are properly connected so that they will not interfere with the normal operation of the circuit breakers and at the same time protect the circuit in case of a short or ground.

When spot lights or other special lighting equipment, except cigar lighters and radios, are installed, it is best to connect them to the No. 1 terminal on the circuit breaker, which takes the current through the lock-out breaker. If, however, too many such accessories are installed, the breaker will open due to the excessive load.

In such cases it is advisable to connect some of the equipment to the No. 3 terminal on the circuit breaker, which is the feed from the ammeter. Any circuits connected to the No. 3 terminal are accordingly unprotected circuits; that is, the current for these circuits will not go through the breakers at all. Cigar lighters and "A" battery connections for radios unless otherwise recommended in the instructions accompanying the unit should be connected directly to the discharge terminal of the ammeter.

2. Battery Terminal Corrosion

See that the battery terminals are clean and free from corrosion. Warm water, poured slowly over the corroded battery terminals will dissolve the copper sulphate that has been deposited so that it can be brushed off and flushed away easily. The terminals and battery posts should be wiped with a cloth saturated with household ammonia or a solution of water and bicarbonate of soda (baking soda). These alkaline solutions will neutralize any acid that may be present on the parts to be cleaned. **Do not allow any of the alkaline solution to get into the cells of the battery.** After the parts are cleaned they should be given a heavy coat of vaseline or grease to retard further corrosion.

3. Battery Electrolyte Tests

The Electrolyte (battery solution) should be tested with a hydrometer. The specific gravity as registered by the hydrometer should be 1.270 to 1.290 at 60° F. when the battery is fully charged. A gravity reading of 1.150 or below indicates that the battery is entirely discharged and it should be removed from the car and recharged.

Whenever a reading under 1.250 is due to a temporary abnormal demand for current through excessive use of lights or starter, the charging rate should be sufficient to bring the battery up to a fully charged condition again. On the other hand, if the current requirements have been normal and it appears that the charging rate is not high enough to meet the requirements of the electrical system, the generator should be adjusted for a slightly higher charging rate but not to exceed

the maximum rate recommended for that generator. If the electrolyte tests below 1.225, the battery should be recharged from an outside source.

4. Adding water to Storage Battery.

The correct level for the battery electrolyte is just below the bottom of the filler tubes. If the liquid comes above the bottom of the tubes it may be forced up and overflow because of pressure generated within the battery by its "gassing."

Inspect the battery every 1000 miles during the winter and every 500 miles (or every two weeks) during the summer, to make sure the electrolyte is up to the proper level. Only distilled water or fresh water kept in a glass, rubber or porcelain lined container, should be used to replace liquid lost through evaporation.

If electrolyte has been lost through overflow or spilling, it should be replaced by a competent battery repair man.

5. Ball Bearing Service

When the ball bearings are removed from the generator or distributor, they should be thoroughly cleaned by spinning them in gasoline or kerosene and blowing out with compressed air until all foreign matter and grease are removed. The bearings should then be oiled immediately with clean engine oil and inspected.

Inspect each bearing by rotating it by hand with pressure on the outer race. If the bearing feels smooth under pressure and rotates easily it should be reinstalled in the car. If the bearing feels rough and does not rotate easily, it should be replaced with a new one.

Before installing the ball bearing in the car, it should be packed solid with a high melting point sodium base grease (Fiske No. 220-A, or its equivalent), which lubrication should be good for approximately 15,000 miles.

6. Running Engine with Storage Battery Disconnected

If it should ever be necessary to operate the engine without the battery connected in the circuit, the generator must be grounded first or it will be damaged. One end of the grounding wire should be connected to the front binding post on the cut-out and the other connected to the ground under one of the cut-out mounting screws.

7. Dictograph Phone Replacement

The phone units in Fleetwood Imperial and Town cars are installed in matched pairs. If it is ever necessary to replace either unit, they should both be removed and a new matched pair installed in their places.

In the event of weak signals with pairs known to be properly matched, check carefully for loose connections and possible shorts or grounds in the wiring caused by staples or tacks.

ELECTRICAL SYSTEM




Plate 21. Ignition Distributor

ELECTRICAL SYSTEM—Specification

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Accessories, connections of electrical (See Note 1).....
Battery				
Delco type number.....	17 BW	17 BW	21 CW	25 AW
Capacity—				
20 hour rate.....	130	130	160	190
20 min. rate.....	156	156	195	234
Charging rate on bench—				
Start in amperes.....	10	10	10	10
Finish in amperes.....	8	8	8	8
Corrosion at terminals (See Note 2).....
Plates, number of.....	17	17	21	25
Specific gravity of battery electrolyte solution (See Note 3).....
Terminal grounded.....	Positive	Positive	Positive	Positive
Voltage—rated.....	6	6	6	6
Water, addition of (See Note 4).....
Circuit Control Box				
Delco-Remy type number.....	480Z	480Z	480Z	480Z
<i>This box contains the circuit breakers, the generator cut-out relay and the horn relay.</i>				
Circuit breaker—				
Lockout opens—No. of amperes.....	25-30	25-30	25-30	25-30
Vibrator starts—No. of amperes.....	25-30	25-30	25-30	25-30
Fuse for stop lamps—				
Capacity.....	10 amps.	10 amps.	10 amps.	10 amps.
Cut-out relay—				
Air gap between armature and core.....	.014-.021"	.014-.021"	.014-.021"	.014-.021"
<i>Hold contacts together lightly while measuring air gap.</i>				
Contact gap.....	.015-.025"	.015-.025"	.015-.025"	.015-.025"
Operation				
Contacts close—No. of volts approximately... <i>Corresponding armature speed 420 R. P. M.; car speed 8-10 M. P. H.</i>	7.5	7.5	7.5	7.5
Contacts open—At discharge, in amperes	0-2.5	0-2.5	0-2.5	0-2.5
Generator				
Delco-Remy type number.....	927-S	927-S	931-D	931-D
Car speed for maximum normal charging (approximately).....	22 m.p.h.	22 m.p.h.	23 m.p.h.	23 m.p.h.
Armature				
Commutator out of round, not over.....	.002"	.002"	.002"	.002"
End-play in ball bearing (Side movement between races), not over (See Note 5).....	.012"	.012"	.012"	.012"
Brushes				
Limit of wear (See Fig. 1, Plate 19).....
Spring tension in ounces.....	20-28	20-28	20-28	20-28
Charging rate on bench—in amperes				
700 R. P. M. at 7.2-7.4 volts—Cold.....	7	7	7	7
1400 R. P. M. at 8.2-8.6 volts—Cold.....	19-21	19-21	19-21	19-21
1600 R. P. M. at 7.3-7.7 volts—Hot.....	10-15	10-15	10-15	10-15
Charging rate on car—In amperes (Maximum—Cold). <i>Measured with testing Ammeter at Generator terminal</i>	22-24	22-24	22-24	22-24
Current regulation.....
All models—Third brush thermostat control				
Ratio of generator R. P. M. to engine R. P. M.....	1.35 to 1	1.35 to 1	1.40 to 1	1.40 to 1
Running engine with storage battery disconnected (See Note 6).....
Starts to charge (cut-out contacts close)—Armature speed in R. P. M. at 7.5 volts.....	525	525	550	550
Stops charging (cut-out contacts open)—Amperes discharge.....	0-2	0-2	0-2	0-2
Thermostat operating temperature..... <i>Resistance in series with field coil.</i>	175° F.	175° F.	175° F.	175° F.
Voltage—rated.....	6	6	6	6

ELECTRICAL SYSTEM





Fig. 1
Typical Timer Distributor Adjustments



ELECTRICAL SYSTEM—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Horn				
Delco-Remy (Klaxon) type number.....	K-26 { 1379 1380	K-22 { 1160 1161	K-22 { 1160 1161	K-22 { 1160 1161
Adjustment— Air gap between armature and field core.....	.025"	.025"	.025"	.025"
Current consumption in amperes.....	7-8	7-8	7-8	7-8
Number used.....	2	2	2	2
Ignition				
COIL				
Delco-Remy type number.....	528-G	528-G	530-K	530-K
Current consumption in amperes Engine running.....	2.5	2.5	2.5	2.5
Engine stopped.....	2	2	2	2
DISTRIBUTOR				
Delco-Remy type number.....	662-Y	662-Y	004092	004093
Angle between contact arms.....	30°	30°	22½°	22½°
Contact point gap.....	.018-.024"	.018-.024"	.018-.024"	.014-.018"
Firing order.....	NOTE: Cylinders are numbered from the front, alternating between the two sides. On 345-B and 355-B, No. 1 is right front; on 370-B and 452B, No. 1 is left front.			
345-B, 355-B—1-2-7-8-4-5-6-3				
370-B—1-4-9-8-5-2-11-10-3-6-7-12				
452-B—1-8-9-14-3-6-11-2-15-10-7-4-13-12-5-16				
Radial (side) play in distributor shaft ball bearing, not over (See Note 5).....			.002"	.002"
Spark advance (degrees on flywheel)— Automatic (Maximum).....	18°	18°	32°	32.5°
Tension of contact arm spring—In ounces.....	17-21 { 9° 12' 1½"	17-21 { 9° 12' 1½"	17-21 { 15° 1½"	17-21 { 10½° 1½"
Timing mark (IG/A) ahead of center.....				
SPARK PLUGS				
A. C. type number.....	D-8	D-8	D-8	D-8
Cooler plug to remedy pre-ignition.....	D-7 or D-6	D-7 or D-6	D-7 or D-6	D-7 or D-6
Hotter plug to remedy fouling.....	D-9 or D-10	D-9 or D-10	D-9 or D-10	D-9 or D-10
Coated with Duco.....				
Any Duco on the spark plugs should be removed with thinner or alcohol.				
Gap.....	.025-.028"	.025-.028"	.025-.028"	.025-.028"
Thread.....	Metric, 18 mm.	Metric, 18 mm.	Metric, 18 mm.	Metric, 18 mm.
IGNITION SWITCH				
Delco-Remy type number.....	426-T	426-T	426-T	426-T
Starting Motor				
Delco-Remy-type number.....	728-P	728-P	000495	000495
Armature				
Clearance between shaft and bearings (bushings), not over.....	.010"	.010"	.010"	.010"
Commutator out of round, not over.....	.002"	.002"	.002"	.002"
End play, not over.....	.025"	.025"	.025"	.025"
Brushes				
Number used.....	4	4	4	4
Clutch spring on splined shaft				
Free length (approximately).....	2¼"	2¼"	2¼"	2¼"
Compression in pounds at 1 in.....	46-52	46-52	46-52	46-52
Engine cranking speed.....	90-100 R.P.M.	90-100 R.P.M.	80 R.P.M.	80 R.P.M.
Gear Ratios				
Ratio between armature pinion and sliding gear.....	2-1/14:1	2-1/14:1	1-2/3:1	1-2/3:1
Ratio between sliding gear and flywheel.....	12-5/9:1	12-5/9:1	12-5/9:1	12-5/9:1
Ratio between armature pinion and flywheel.....	26:1	26:1	26:1	26:1
Gears				
Number of teeth in armature pinion.....	14	14	15	15
Number of teeth in driven gear on sliding gear shaft.....	29	29	25	25
Number of teeth in sliding gear.....	9	9	9	9
Number of teeth in flywheel gear.....	113	113	113	113
Number of poles.....	4	4	6	6
Telephone				
(See Note 7).....				

ELECTRICAL SYSTEM




Plate 23. LaSalle 345-B Wiring Diagram

ELECTRICAL SYSTEM




Plate 24. Cadillac 355-B, 370-B and 452-B Wiring Diagram

ELECTRICAL SYSTEM




Plate 25. Ignition Wiring Diagram

ELECTRICAL SYSTEM—General Description—Service Information

General Description

The electrical system on the "C" series cars is practically the same as on the corresponding "B" models. The only differences are in the distributor and the spark plugs.

Beginning with engine unit 30-3607, the 345-C and 355-C engines are equipped with a second-type distributor with a single set of contact points and an eight lobe cam. This distributor can be identified by the type No. 661-P.

The distributor unit used on the V-8 engines before engine unit 30-3607 is the same as provided for the "B" series cars.

The advance mechanism in the 370-C and 452-C distributors incorporates new advance characteristics to compensate for the higher engine compression ratios used in these cars. Otherwise these distributors are the same as used on the "B" models. The "C" distributors can be identified by the type numbers 004110 for the 370-C and 004111 for the 452-C.

The spark plugs used on all "C" series cars are of the "G-7" type. These plugs are especially designed with a pointed porcelain at the electrode end for heavy duty work in extremely high compression engines.

Service Information

8. Ignition Timing

The method of timing the "C" series engine is the same as on the corresponding "B" cars. The contact gap for both the distributor and the spark plugs on all "C" cars except the V-8 beginning engine unit 30-3607 is also adjusted the same as on the "B" models. The distributor contact gaps for the V-8 engines using the 661-P distributor is .012 to .017 in. With the single arm type 661-P distributor there is nothing to be synchronized or checked relative to the second firing point. All remaining adjustments, however, are the same as with the stationary contacts in the earlier distributors of the double-arm type. See Plate 25A.

9. Winter Care of Storage Battery

The condition of the storage battery is one of the most important factors in easy starting. Even with winter lubricants, the engine is stiffer in cold weather and more power is required to turn it over. At the same time, the drain on the battery is increased in winter because, in addition to the greater power required in starting, the days are shorter requiring greater use of lights, and heaters with electric blowers are frequently used. All of this simply means that the battery must be in top condition from the start and must be kept in that condition throughout the cold weather season.

Battery trouble in any weather can be avoided with a little care and attention. The battery is a perishable item, and gradually deteriorates during any period of inactivity. This deterioration is shown in a gradual dropping of the specific gravity of the solution in the cells.

Ordinarily a battery not in use requires a freshening charge every 30 to 60 days to prevent rapid deterioration. A regular schedule for charging works out most satisfactorily, but in any case, a close check should be kept on the condition of the battery through records of the specific gravity of each cell taken every two weeks. The battery should be charged whenever the specific gravity drops below 1.225.

Batteries in cars on display or in storage can be charged without removing the battery from the car by using any good portable charger. The charger should be connected to the storage battery or the negative terminal on the charger can be connected to the ammeter on "B" and "C" series cars with the generator cut-out relay in the circuit control box. If the car is to remain in storage for any considerable time, however, it is advisable to remove the battery and turn it over to the battery department for care and attention.

The battery must be kept fully charged or nearly so and the proper level of the liquid must be maintained if the battery is to perform satisfactorily. Ordinarily with the car in use the generator will keep the battery charged but there is only one way to make sure and that is to test the battery at regular intervals.

If the specific gravity is 1.250 or above, the battery may be safely assumed to be in satisfactory condition.

If the reading is below 1.225 the battery should in every case be removed and charged.

10. Cautions on Adjusting Charging Rate

Setting the generator charging rate is not a cure-all for electrical troubles of a car indicated by a low battery, and careless setting to the maximum charging rate may result in generator troubles much more serious than recharging the battery occasionally from an outside source.

Ordinarily the maximum charging rate should be more than enough to keep the battery fully charged, but whenever it is necessary to set the generator at its maximum, special precautions must be taken to keep the armature from burning out.

The car ammeter must not be relied upon when setting the generator anywhere near its maximum limit. There are two discrepancies in the car ammeter for which allowances must be made if it is to be used at all in setting the charging rate.

1. The ammeter does not show the actual generator output, but shows the difference between the output and the ignition current which is about $2\frac{1}{2}$ amperes per coil.

2. The car ammeter is not a precision instrument and the possible error may amount to as much as 2 amperes.

With allowances made for the ignition and the possible error therefore, the difference between the actual generator output and the reading of the ammeter may amount to $4\frac{1}{2}$ amperes on V-8 cars and 6 to 7 amperes on V-12 and V-16 cars.

From this it can readily be seen that the only safe way to set the charging rate near the maximum is to use a precision ammeter connected at the generator. On "B" and "C" series cars the charging rate should not exceed 22-24 amperes cold, measured at the generator.


Equally essential to the accuracy of this adjustment is a fully charged battery. If the battery in the car is partly run down, the generator charging rate will increase as the battery becomes more fully charged, resulting in the output exceeding the safe limit.

It is extremely important in setting the generator to the maximum charging rate that a fully charged battery be used in the car and that the output be measured with a precision ammeter connected at the generator.

It is also a good plan to inspect the battery terminals to make sure that they are clean and tight. Loose or corroded terminals will increase the voltage to such an extent that the entire electrical system will be overheated and the generator, lamp filaments and contact points may be burned out.

A similar condition may be found in any case where, through overheating, the solder holding the armature wires to the commutator has been melted and thrown out. In such cases, the armature wires may be loosened by centrifugal force at high speeds, making poor contact and permitting the charging rate to drop excessively even though at ordinary speeds the charging rate is sufficient. This condition in the armature may not always show up as an open circuit in a bench test, but if the commutator shows signs of having thrown the solder, the commutator should be resoldered.

ELECTRICAL SYSTEM



Note: Recondition contact points or install new ones as necessary before timing ignition.

Contact Point Gap
(Second-type distributor)
LaSalle 345-C } .012-.017 in.
Cadillac 355-C }




Fig. 2
Flywheel Timing Mark

Plate 25A. Ignition Timing—Cadillac 355-C and LaSalle 345-C
Using Type 661-P Distributor

ENGINE

General Description

The LaSalle and Cadillac V-8 engines are identical in construction. The intake manifold is arranged to supply all cylinders with exactly the same amount of fuel mixture. Each of the four end cylinders receive fuel through separate individual passages. The intake manifold is heated by the exhaust gas in the exhaust header.

These engines, as well as the 12- and 16-cylinder engines, are mounted in rubber at six points—one at each side at the front, one at each side at the rear of the crankcase and two at the rear of the transmission. The support brackets at the front end of the engine are at the sides of the front cover and rest on supports integral with the front frame cross member. The supports at the rear of the crankcase are attached to the frame side bars and those at the rear of the transmission to the center cross member of the frame.

The 370-B and 452-B engines are of the same general design. The 452-B engine has four more cylinders and a $\frac{1}{8}$ in. smaller bore than the 370-B.

A harmonic balancer is used on the front end of the 370-B and 452-B crankshaft in addition to counter weights forged integral with the crankshaft checks.

The angle between the cylinders on these engines is only 45°. This gives ample room on the outside of the cylinder blocks for manifolds and carburetors.

The 370-B and 452-B engines have overhead valves which are provided with an automatic adjusting mechanism. This mechanism automatically maintains practically zero valve clearance and effectively overcome the objectionable noise usually characteristic of this type of valve.

The general arrangement of this valve mechanism is shown in Plate 31, Page 62.

The engine lubrication is full force feed to all bearings including the valve rocker arms. The oil filter is connected in the line leading to the valve mechanism to eliminate any possibility of foreign matter getting into the dashpots of the valve mechanism and interfering with their operation.

The compression ratio of the 370-B and 452-B may be changed by merely using a cylinder head gasket of different thicknesses. To change to lower compression a special cylinder head gasket with a sheet steel insert of a definite thickness between the layers of asbestos should be used. This makes it possible to change to a lower compression at a very slight cost wherever the fuel situation demands it.

This method of changing the compression ratio is not practical on L-head engines, because of the construction of the combustion chamber, and by the fact that it involves less expense to change cylinder heads on an L-head engine.

The 12- and 16-cylinder engines are the only Cadillac engines on which the factory sanctions carbon burning. When this operation is performed properly, the results are quite satisfactory in these engines. On V-8 engines, however, where it is a simple operation to remove the cylinder heads without interfering with the valve mechanism, the carbon can be removed to better advantage by scraping.

The windshield wiper vacuum pump used on all models is of the diaphragm type and acts only as a booster to augment the manifold suction for operating the windshield wiper at higher engine speeds. It is located in the same position as the vacuum pump formerly used to supply fuel.

Service Information

1. Camshaft Installation

Beginning with engine unit 11-1148 on 345-B and 12-1126 on 355-B cars, a second type camshaft is used. This camshaft calls for a different setting of the valve stem clearance.

On cars before these engine unit numbers with the first type camshaft, the valve tappets should be adjusted to .004 in. for inlet valves and .006 in. for exhaust valves.

On cars with the second-type camshaft the clearance should be .006 in. for inlet valves and .008 in. for exhaust valves.

The second-type camshaft can be identified by a "Z" in a circle stamped on the hub of the front bearing. When the camshaft is in the car, this mark can be seen through the opening in the crankcase after removing the distributor mounting support.

2. Removing Camshaft from 370-B and 452-B Engine

When removing the camshaft from these engines, two important points in procedure must not be overlooked. The

vacuum pump and the distributor drive shaft must be removed before any attempt is made to draw out the camshaft.

The gear on the distributor drive meshes with a gear on the camshaft. An attempt to remove the camshaft without first removing the distributor drive shaft will damage the driven gear by striking against the blank sides of the camshaft gear.

3. Connecting Rod Alignment

The alignment of Cadillac and LaSalle connecting rods by straightening is not recommended as the rod is liable to return to its former shape because of the toughness of the alloy steel used in its construction.

In an emergency, if straightening must be resorted to, the rod is more liable to hold its shape if it is bent a little farther than necessary and then bent back again until it is straight to offset the tendency of the metal to assume its original shape.

ENGINE




Fig. 1
Sectional View of Engine




Fig. 2
Cross-sectional View of Engine

ENGINE—Service Information

4. Assembly of Connecting Rods

When assembling connecting rods to the crankshaft, be sure that the numbers on the rods are towards the bottom of the engine and that they correspond with the numbers of the caps. The chamfered side of the bearing should be next to the crankshaft cheek.

The pistons should also be assembled on the rods with the piston pin locking screw on the same side of the rod as the flange.

5. Fitting Piston Pins

When pressing pins into or out of piston, always place locking screw side of piston down to prevent forcing piston out of round.

Burnish piston pin bushings using tool No. HMJ-250-2. Fit pins dry. Pins should turn freely in bushings with no perceptible play or looseness.

In production, piston pins are a tight press fit in the lock screw side of the piston. It is not expected that this press fit will always be duplicated in service and snug push fit should be satisfactory.

6. Connecting Rod Clearance

Check clearance in connecting rod bearing with dial indicator (Tool No. HM-196-B) and holder.

Do not attempt to adjust connecting rod bearings. If clearance exceeds limits given install new or rebabbited rod and return old one to factory for exchange. No credit will be allowed on rods if cap or rod has been dressed down.

The same conditions govern the return of rods which have been rebabbited by outside repair shops and which are damaged or bear punch or file marks used for identification purposes. Mechanics should attach numbered metal tags to the rods as they are removed from the engine, or lay them in trays in the right order to identify them instead of marking them with a punch or file.

7. Removing and Installing Piston Pin Bushings

The removal and installation of the split-type piston pin bushings requires the use of special tools. A kit of tools (Tool No. HMJ-250) is furnished for this purpose.

The bushing should be removed in an arbor press and should be started by giving the handle of the press a sudden jerk instead of a steady pull. After the bushing is started it will move out quite freely. The connecting rod should then be thoroughly cleaned of all chips and dirt.

The bushing cannot be pressed into the connecting rod in the usual manner. Instead, it is pressed in the rod and expanded with an expanding bar to press the bronze into very close contact with the steel rod. It is then burnished, leaving a long hard-wearing bearing surface.

To install a piston pin bushing, proceed as follows:

(1) Install the bushing in the side of the connecting rod having the large chamfer in the bearing for the crank pin. Make sure that the oil hole in the bushing is in line with the oil hole in the connecting rod and the split is at right angles to the length of the rod.

(2) Press bushing in rod using bushing replacer, tool No. HMJ-250-3. Use a 2 or 3 ton bench arbor press.

(3) Expand the bushing with Expanding Bar (tool No. HMJ-250-1). If the bushing protrudes through the connecting rod, file it flush with the rod before burnishing.

(4) Burnish bushing by passing burnishing tool No. HMJ-250-2 through the bushing. When expanding or burnishing a bushing, use a heavier bench arbor press of about 4 tons capacity.

Use kerosene as a lubricant when expanding and burnishing the bushing.

If the bushing moves during the burnishing process, it is too loose and another one should be used.

If the proper clearance between the piston pin and the bushing is not secured after the burnishing tool is passed through the bushing, the burnishing operation should be repeated to increase the size of the piston pin hole.

The press plate (Tool No. HMJ-250-4) should be used for expanding and burnishing the bushing. This plate has two holes—one which is used for assembling, expanding and burnishing and the other for removing the bushing.

After installing the bushing the parts should be thoroughly cleaned and the oil passages blown out with air to remove chips and dirt.

8. Main Bearing Clearance

Use dial indicator and special fixture (Tool No. HM 65530) for checking bearing clearances. If bearings are found to be worn beyond specified limits they should be replaced. Replacement bearings are furnished to exact size and do not require reaming or scraping. No shims or liners are used on the main bearings and no attempt should be made to take them up if worn.

Always install new wooden plugs in grooves in sides of rear main bearing cap to prevent oil leaks around the cap.

9. Cleaning Oil Filter on 370-B and 452-B

A Cuno disc-type self-cleaning oil filter is used on the 370-B and 452-B cars.

The oil, in circulating through the filter, passes between thin rotating discs, stacked one upon another, and separated a few thousandths of an inch by a series of thin stationary plates. The filtering discs are mounted on a shaft which extends above the filter and is connected to the starter pedal in such a way that the discs are rotated a partial turn each time the starter pedal is depressed.

When the filtering discs are rotated the accumulated sediment is scraped off by the stationary plates and falls to the bottom of the tank.

The only attention required is the draining of the tank every 6000 miles.

10. Piston Clearances

Use Tool HM 119929, with a .0025 in. feeler ribbon, 1/2 in. wide and a spring scale, for checking piston clearances. Piston must not be over .002 in. out of round. Clearances should be measured between skirt of piston and cylinder wall half way between wrist pin holes with piston half way down on its stroke and wrist pin hole parallel with crankshaft. Both piston and cylinder walls should be clean and free from oil. If the clearance is correct, a pull of 4 to 9 lbs on 345-B and 355-B engines and 6 to 9 lbs on 370-B and 452-B engines will be necessary to withdraw the feeler.

11. Burning Carbon on 370-B and 452-B Cars

While the most satisfactory way of removing carbon from automobile engines is by scraping, the labor involved in removing the cylinder heads with the overhead valve mechanism on the V-12 and V-16 engines sometimes renders scraping impracticable. Burning the carbon, if properly done, will give good results on these engines at a much lower cost to the owner.

If this method is used, the carbon should be allowed to burn slowly to obtain the best possible results. Quick burning will do only a partial job. The rate of combustion can be controlled by the proper regulation of the oxygen supply to the combustion chamber.

While the carbon is being burned, particular care must be taken to prevent injury either to the valves or to the external fittings on the engine. The proper procedure is as follows:

Remove the spark plug wires and distributor cover, or use a suitable asbestos cover plate to protect them during the burning operation.

Remove all spark plugs.

The next step is a matter of extreme importance, that is, to be sure the valves are both closed on the cylinder being burned. If the valves are not closed, they are very likely to be overheated, causing them to warp.

The only positive way to make sure the valves are closed is to use a test light and crank the engine to the firing point on that cylinder. See Fig. 4, Plate 30.

Allow the carbon to burn slowly until it has all been burned.

Burn out all of the left hand cylinders first, in the order in which they fire; then burn the right hand cylinders. The firing order, is, of course, indicated on the distributor cover.

Removal of carbon in the V-8 engines should be done by scraping as in the past.

ENGINE






Fig. 1

Bottom View of Engine With Oil Pan Removed.

Connecting rod and piston assemblies can be removed through bottom of crankcase without disturbing cylinder heads





Clear Diameter of Inlet Valve—1 1/2 in.




Clear Diameter of Exhaust Valve—1 1/2 in.

Fig. 2

Valve Specifications

Fig. 3
Valve Arrangement

Note:
Lubricate cam slides
before installing in
engine.

Fig. 4
Valve and Cam Slide Assembly

ENGINE—Service Information—Speeds

12. Fitting Oil Rings

In fitting new rings, the edge clearance should be from perfectly free to a clearance of .002 in. maximum, measured with a .002-in. feeler inserted opposite the solid section of the ring. The ring must be pressed into the groove when this measurement is taken.

13. Servicing the Vacuum Pump

Service on the vacuum pump can be obtained from A. C. service stations. However, replacement of the valves and the diaphragm can be accomplished simply by taking the pump apart. Do not under any circumstances separate the two parts of the housing without holding the pump head securely because the pressure of the diaphragm return spring is approximately 75 lbs. If care is not taken in removing the screws which hold the pump together, the top will fly off and possibly cause serious personal injury to some one.

14. Care of Valve Silencers

The automatic valve silencers used on the 370-B and 452-B cars are built to very close limits. The mechanism must, therefore, be kept clean and free from particles of carbon and other foreign matter.

Whenever the valve cover is removed and the valve silencers are exposed, they should be covered to prevent dust and dirt from lodging on the mechanism and finding its way into the dashpots. Small particles of dirt or carbon becoming lodged in the mechanism may cause noisy operation.

Other possible causes for improper operation of the valve silencers are:

1. Leakage of the check valve.
2. Incorrect clearance between the plunger and the cylinder walls.
3. Damage due to improper installation.

Leakage of the check valve in the plunger is most generally due to particles of foreign matter being lodged on the seat of

the valve. This can ordinarily be corrected by washing it carefully with gasoline and blowing it out with compressed air.

To assure the check valve being seated properly, it should be revolved on its seat by hand.

Incorrect clearance between the plunger and the cylinder wall may result from the interchanging of the plungers. It should be noted that the plungers and dashpots are marked to insure correct assembly. The number of marks etched on the plunger should correspond with the number of marks appearing on the dashpot casting.

15. Valve Adjustment

Beginning with engine unit 11-1148 on 345-B and 12-1126 on 355-B cars a camshaft with a new contour is used. This camshaft calls for a different setting of the valve stem clearance and may be identified by a "Z" in a circle stamped on the hub of the front bearing. When the camshaft is in the engine, this mark can be seen through the opening in the crankcase after removing the distributor mounting support.

On cars with the earlier type camshaft before these engine unit numbers the valve tappets should be adjusted to .004 for inlet valves and .006 for exhaust valves.

On cars with the latter type camshaft the clearance should be .006 for inlet valves and .008 for exhaust valves.

The Parts Division will supply only the second type camshaft for replacement.

Valve clearances should be adjusted while the engine is cold. Valves should always be readjusted after tightening cylinder block hold down nuts.

Valve adjustments should be made very carefully. A careless adjustment may cause a variation of 10° in valve timing.

Service men must watch the order of the inlet and exhaust valves on the 345-B and 355-B engines both when adjusting and when grinding valves, as it differs from that previously used on V-8 engines. This new valve arrangement is shown in Fig. 3, Page 27.

Engine Speeds

Engine Speeds in Revolutions per Minute for Various Gear Ratios and Rolling Radii at a Car Speed of 60 Miles per Hour

Rear Axle Gear Ratio	Rolling Radius of Tire	Engine Speed in R. P. M.	Rear Axle Gear Ratio	Rolling Radius of Tire	Engine Speed in R. P. M.
4.31 to 1	14 $\frac{1}{4}$	3055	4.60 to 1—Continued	15 $\frac{3}{4}$	2950
	14 $\frac{1}{2}$	3000		16	2905
	14 $\frac{3}{4}$	2950		16 $\frac{1}{4}$	2860
	15	2900		16 $\frac{1}{2}$	2815
	15 $\frac{1}{4}$	2850		16 $\frac{3}{4}$	2770
	15 $\frac{1}{2}$	2805		17	2730
	15 $\frac{3}{4}$	2760	4.64 to 1	14 $\frac{1}{4}$	3290
	16	2720		14 $\frac{1}{2}$	3230
	16 $\frac{1}{4}$	2680		14 $\frac{3}{4}$	3175
	16 $\frac{1}{2}$	2640		15	3120
	16 $\frac{3}{4}$	2600		15 $\frac{1}{4}$	3070
	17	2560		15 $\frac{1}{2}$	3025
4.36 to 1	14 $\frac{1}{4}$	3090		15 $\frac{3}{4}$	2975
	14 $\frac{1}{2}$	3035		16	2925
	14 $\frac{3}{4}$	2985		16 $\frac{1}{4}$	2885
	15	1935		16 $\frac{1}{2}$	2840
	15 $\frac{1}{4}$	2885		16 $\frac{3}{4}$	2795
	15 $\frac{1}{2}$	2840		17	2750
	15 $\frac{3}{4}$	2795	4.80 to 1	14 $\frac{1}{4}$	3400
	16	2750		14 $\frac{1}{2}$	3340
	16 $\frac{1}{4}$	2710		14 $\frac{3}{4}$	3285
	16 $\frac{1}{2}$	2670		15	3230
	16 $\frac{3}{4}$	2630		15 $\frac{1}{4}$	3175
	17	2590		15 $\frac{1}{2}$	3125
4.60 to 1	14 $\frac{1}{4}$	3260		15 $\frac{3}{4}$	3075
	14 $\frac{1}{2}$	3200		16	3025
	14 $\frac{3}{4}$	3150		16 $\frac{1}{4}$	2980
	15	3095		16 $\frac{1}{2}$	2935
	15 $\frac{1}{4}$	3045		16 $\frac{3}{4}$	2890
	15 $\frac{1}{2}$	3000		17	2850

ENGINE




Fig. 1

Sectional View of Generator and Water Pump Drive

To remove chain, remove camshaft sprocket from hub.




Fig. 2

Front End Chains

Timing marks on sprockets must line up.




Fig. 3

Remove sprocket and driver through rear opening.




Fig. 4

Adjusting Generator and Water Pump Drive Chain.

To adjust chain, loosen pivot screw and clamp screws, force support over until chain is tight, then slack off support 1/8 in.

ENGINE—Specifications

Subject and Remarks	LaSalle		Cadillac	
	345-B	355-B	370-B	452-B
Angle between cylinder blocks.....	90°	90°	45°	45°
Bore.....	3 $\frac{3}{8}$ "	3 $\frac{3}{8}$ "	3 $\frac{1}{8}$ "	3"
Compression ratio—				
Standard.....	5.37 to 1	5.37 to 1	5.35 to 1	5.35 to 1
Optional.....	5.7 to 1	5.7 to 1	5.08 to 1	5.08 to 1
Horsepower—				
Rated (taxable).....	36.45	36.45	46.9	57.5
Developed at 3000 R. P. M.....	115	115
Developed at 3400 R. P. M.....	135	165
Model.....	345-B	355-B	370-B	452-B
Stroke.....	4 $\frac{1}{8}$ "	4 $\frac{1}{8}$ "	4"	4"
Piston displacement in cubic inches.....	353	353	368	452
Points of suspension, number of.....	6	6	6	6
Valve arrangement.....	L-head	L-head	I-overhead	I-overhead
Camshaft (See Note 1)				
Bearing clearance				
New limits.....	.0027-.0037"	.0027-.0037"	.0011-.0026"	.0011-.0026"
Worn limits, not over.....	.005"	.005"	.005"	.005"
Bearings out of round, not over.....	.005"	.005"	.005"	.005"
Diameter and length of bearings—				
No. 1 (front).....	1 $\frac{1}{8}$ x 1.802"	1 $\frac{1}{8}$ x 1.802"	2 x 3"	2 x 3"
No. 2.....	2.3392 x 1.00"	2.3392 x 1.00"	2 $\frac{1}{8}$ x 1 $\frac{3}{8}$ "	2 $\frac{1}{8}$ x 1 $\frac{3}{8}$ "
No. 3.....	2.3392 x 1 $\frac{1}{8}$ "	2.3392 x 1 $\frac{1}{8}$ "	2 $\frac{1}{8}$ x 1 $\frac{3}{8}$ "	2 $\frac{1}{8}$ x 1 $\frac{3}{8}$ "
No. 4 (rear except on 452-B).....	1 $\frac{5}{8}$ x 1 $\frac{1}{8}$ "	1 $\frac{5}{8}$ x 1 $\frac{1}{8}$ "	2 $\frac{1}{8}$ x 2 $\frac{1}{8}$ "	2 $\frac{1}{8}$ x 1 $\frac{3}{8}$ "
No. 5 (rear 452-B).....	2 $\frac{1}{8}$ x 2 $\frac{1}{8}$ "
End play in camshaft				
New limits.....	.005-.015"	.005-.015"	.004-.008"	.004-.008"
Worn limit, not over.....	.020"	.020"	.015"	.015"
Number of bearings.....	4	4	4	5
Removing camshaft (See Note 2).....
Chains				
Camshaft chain—				
Adjustment.....	None	None	Automatic	Automatic
Number of links.....	54	54	110	110
Pitch.....	1 $\frac{1}{2}$ "	1 $\frac{1}{2}$ "	3 $\frac{1}{8}$ "	3 $\frac{1}{8}$ "
Type—Morse No.....	766	766	766 Duplex	766 Duplex
Width.....	1 $\frac{3}{4}$ "	1 $\frac{3}{4}$ "	1 $\frac{1}{2}$ "	1 $\frac{1}{2}$ "
Generator and water pump drive chain				
Adjustment				
Slack measured at top of sprocket housing....	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "
Number of links.....	58	58
Pitch.....	1 $\frac{1}{2}$ "	1 $\frac{1}{2}$ "	Only one chain used. See "Camshaft Chain" for details.	
Type—Morse No.....	766	766		
Width.....	1 $\frac{1}{4}$ "	1 $\frac{1}{4}$ "		
Connecting Rods				
Alignment (See Note 3).....
Assembly (See Note 4).....
Center to center length.....	10 $\frac{1}{2}$ "	10 $\frac{1}{2}$ "	9 $\frac{1}{4}$ "	9 $\frac{1}{4}$ "
Clearance between—				
Bushings and piston pin (See Note 5).....
Lower bearing and crank pin (See Note 6)				
New limits.....	.001-.0025"	.001-.0025"	.001-.0025"	.001-.0025"
Worn limit, not over.....	.006"	.006"	.006"	.006"
Diameter and length of connecting rod bearings.....	2 $\frac{3}{8}$ x 1 $\frac{3}{8}$ "	2 $\frac{3}{8}$ x 1 $\frac{3}{8}$ "	2 $\frac{1}{2}$ x 1 $\frac{1}{8}$ "	2 $\frac{1}{2}$ x 1 $\frac{1}{8}$ "
End play in lower bearing				
New limits.....	.006-.012"	.006-.012"	.006-.012"	.006-.012"
Worn limit, not over.....	.015"	.015"	.015"	.015"
Piston pin lubrication.....
Force feed—connecting rods rifle-bored.....
Removing and installing piston pin bushing (See Note 7).....
Crankshaft and Main Bearings				
Crank pin diameter.....	2.375"	2.375"	2.500"	2.500"
Crank pin out of round, not over.....	.004"	.004"	.004"	.004"
Diameter and length of main bearing journals—				
No. 1 (front).....	2 $\frac{3}{8}$ x 1 $\frac{1}{8}$ "	2 $\frac{3}{8}$ x 1 $\frac{1}{8}$ "	2 $\frac{5}{8}$ x 2 $\frac{3}{8}$ "	2 $\frac{5}{8}$ x 2 $\frac{3}{8}$ "
No. 2.....	2 $\frac{3}{8}$ x 1 $\frac{5}{8}$ "	2 $\frac{3}{8}$ x 1 $\frac{5}{8}$ "	2 $\frac{5}{8}$ x 1 $\frac{3}{8}$ "	2 $\frac{5}{8}$ x 1 $\frac{3}{8}$ "
No. 3 (rear on 345-B, 355-B).....	2 $\frac{3}{8}$ x 2 $\frac{1}{8}$ "	2 $\frac{3}{8}$ x 2 $\frac{1}{8}$ "	2 $\frac{5}{8}$ x 1 $\frac{1}{2}$ "	2 $\frac{5}{8}$ x 1 $\frac{1}{2}$ "
No. 4 (rear on 370-B).....	2 $\frac{5}{8}$ x 1 $\frac{3}{8}$ "	2 $\frac{5}{8}$ x 1 $\frac{3}{8}$ "
No. 5 (rear on 452-B).....	2 $\frac{5}{8}$ x 3 $\frac{1}{8}$ "
Diameter and length of crankpin journal.....	2 $\frac{3}{8}$ x 2 $\frac{3}{4}$ "	2 $\frac{3}{8}$ x 2 $\frac{3}{4}$ "	2 $\frac{1}{2}$ x 2 $\frac{1}{4}$ "	2 $\frac{1}{2}$ x 2 $\frac{1}{4}$ "

ENGINE




Plate 29. Cross-sectional View of Cadillac 370-B. Typical of Cadillac 452-B except Number of Cylinders

ENGINE—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Crankshaft and Main Bearings—Cont'd				
End play in crankshaft				
New limits.....	.001-.005"	.001-.005"	.001-.005"	.001-.005"
Worn limit, not over.....	.010"	.010"	.010"	.010"
Harmonic balancer used.....	No	No	Yes	Yes
Length of crankshaft—overall.....	28 $\frac{3}{32}$ "	28 $\frac{3}{32}$ "	35 $\frac{1}{16}$ "	44 $\frac{1}{16}$ "
Length of crankshaft—front to rear bearings inclusively.....	23 $\frac{3}{32}$ "	23 $\frac{3}{32}$ "	30 $\frac{3}{32}$ "	39 $\frac{3}{32}$ "
Main bearing clearance (See Note 8)				
New limits.....	.001-.0015"	.001-.0015"	.001-.0015"	.001-.0015"
Worn limit, not over.....	.004"	.004"	.004"	.004"
Main bearing journal out of round, not over.....	.005"	.005"	.005"	.005"
Number of main bearings.....	3	3	4	5
Lubrication				
Crankcase capacity.....	8 qts.	8 qts.	9 qts.	10 qts.
Thinning lubrication with kerosene.....
See Lubrication Section.				
Oil Filter				
Make.....	A. C.	A. C.	Cuno	Cuno
Cartridge type.....	A. C.	A. C.
Cartridge replacement (See Note 9).....	12,000 mi.	12,000 mi.
Remove and clean oil pan and screen at same time.				
Oil Pump				
Backlash between spiral drive gears, not over.....	.018"	.018"	.018"	.018"
Clearance between—				
Bushings and drive shaft				
New limits.....	.001-.0025"	.001-.0025"	.001-.0025"	.001-.0025"
Worn limits, not over.....	.010"	.010"	.010"	.010"
Idle gear bushing and shaft				
New limits.....	.001-.0025"	.001-.0025"	.001-.0025"	.001-.0025"
Worn limit, not over.....	.005"	.005"	.005"	.005"
Pump body and gears				
New limits.....	.003-.005"	.003-.005"	.003-.005"	.003-.005"
Worn limit, not over.....	.008"	.008"	.008"	.008"
End play in pump gears				
New limits.....	.003-.008"	.003-.008"	.002-.004"	.002-.004"
Worn limit, not over.....	.020"	.020"	.015"	.015"
End play in spiral gear on drive shaft				
New limits.....	.005-.015"	.005-.015"	.009-.015"	.009-.015"
Worn limit, not over.....	.020"	.020"	.020"	.020"
Gasket thickness, pump cover.....	.009-.011"	.009-.011"
Pressure Regulator				
Adjustment.....	None	None	None	None
Clearance between plunger and housing				
New limits.....	.003-.006"	.003-.006"	.003-.006"	.003-.006"
Worn limit, not over.....	.008"	.008"	.008"	.008"
Pressure, normal when oil is warm—				
30 M.P.H.....	30 lbs.	30 lbs.
60 M. P. H.....	30 lbs.	30 lbs.
Spring				
Free length (approximately).....	1 $\frac{3}{4}$ "	1 $\frac{3}{4}$ "	1 $\frac{3}{4}$ "	1 $\frac{3}{4}$ "
Pressure at 1 $\frac{1}{16}$ in.....	{ 1 lb. 14 oz.- 2 lb. 2 oz.	{ 1 lb. 14 oz.- 2 lb. 2 oz.	{ 1 lb. 14 oz.- 2 lb. 2 oz.	{ 1 lb. 14 oz.- 2 lb. 2 oz.
Valve opens at.....	11 lbs.	11 lbs.	14 lbs.	14 lbs.
Pistons and Cylinders				
Cylinder bore out of round, not over.....	.001"	.001"	.001"	.001"
Piston out of round, not over.....	.001"	.001"	.001"	.001"
Piston clearance at top land, not less than.....	.016"	.016"	.012"	.0125"
Piston clearance at skirt (See Note 10)—new limit.....	.0023-.0028"	.0023-.0028"	.0023-.0028"	.0028-.0033"
Cylinder bore, standard.....	3 $\frac{3}{8}$ "	3 $\frac{3}{8}$ "	3 $\frac{3}{8}$ "	3"
All bores in same block are held within .002 in. of each other.				
Cylinder bore oversize.....
Oversize cylinders are honed to fit the pistons with which they are supplied.				
Carbon burning (See Note 11).....

ENGINE




Plate 30. Bottom View of Engine and Cylinder Details—Cadillac 370-B and 452-B

ENGINE—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Pistons and Cylinders—Cont'd				
Limits on pistons				
Standard No. 1 on V-8—A on 370-B and 452-B...	3.372-3.3725"	3.372-3.3725"	3.1225-3.123"	2.9970-2.9975"
No. 2 on V-8—B on 370-B and 452-B...	3.3725-3.3730"	3.3725-3.3730"	3.123-3.1235"	2.9975-2.9980"
No. 3 on V-8—C on 370-B and 452-B...	3.3730-3.3735"	3.3730-3.3735"	3.1235-3.1240"	2.9980-2.9985"
No. 4 on V-8—D on 370-B and 452-B...	3.3735-3.3740"	3.3735-3.3740"	3.1240-3.1245"	2.9985-2.9990"
Marked "STD No. 1" etc.—measured at bottom of skirt.				
Piston Pins				
Clearance between—				
Pin and bushing (See Note 5).....
Pin and piston (See Note 5).....
Diameter—standard.....	$\frac{7}{8}$ "	$\frac{7}{8}$ "	$\frac{7}{8}$ "	$\frac{7}{8}$ "
Piston Rings				
Clearance between ring and sides of grooves in piston				
New limits.....	.0011-.0026"	.0011-.0026"	.0011-.0026"	.0011-.0026"
Worn limit, not over.....	.004"	.004"	.004"	.004"
Gap between ends				
New limits				
Compression rings.....	.005-.010"	.005-.010"	.005-.010"	.005-.010"
Oil rings.....	.003-.011"	.003-.011"	.003-.011"	.003-.011"
Worn limit, not over.....	.025"	.025"	.025"	.025"
Number of compression rings.....	2	2	2	3
Number of oil rings (See Note 12).....	2	2	2	1
Install oil rings with chamfer at top.				
Width of rings—				
Upper compression.....	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "
Lower compression (Two on 452-B).....	$\frac{1}{8}$ "	$\frac{1}{8}$ "	$\frac{1}{8}$ "
Upper oil.....	$\frac{3}{32}$ "	$\frac{3}{32}$ "	$\frac{1}{8}$ "
Lower oil.....	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{1}{8}$ "	$\frac{3}{16}$ "
Engine unit number location.....
All models—left rear engine support.				
Vacuum Pump Service				
(See Note 13).....
Valve Mechanism				
Clearance between—				
Camslide and guide				
New limits.....	.001-.0025"	.001-.0025"	.001-.0025"	.001-.0025"
Worn limits, not over.....	.005"	.005"	.005"	.005"
Camslide roller and pin				
New limits.....	.0017-.003"	.0017-.003"	.0017-.003"	.0017-.003"
Worn limit, not over.....	.004"	.004"	.004"	.004"
Furnished only in complete assemblies of camslide with button, roller and screw.				
Valve Silencers, care of (See Note 14).....
Valves, Exhaust				
Clearance between—				
Stem and guide				
New limits.....	.0025-.0045"	.0025-.0045"	.001-.0025"	.001-.0025"
Worn limit, not over.....	.006"	.006"	.005"	.005"
Stem and camslide (See Note 15).....	Automatic	Automatic
Before engine unit 11-1148.....	.006"
Beginning engine unit 11-1148.....	.008"
Before engine unit 12-1126.....006"
Beginning engine unit 12-1126.....008"
Adjust while engine is cold.				
Clear diameter (port opening).....	$1\frac{1}{2}$ "	$1\frac{1}{2}$ "	$1\frac{5}{16}$ "	$1\frac{5}{16}$ "
Length—overall.....	$6\frac{1}{2}$ "	$6\frac{1}{2}$ "	$6\frac{3}{4}$ "	$6\frac{3}{4}$ "
Lift.....	$\frac{23}{64}$ "	$\frac{23}{64}$ "	$\frac{11}{32}$ "	$\frac{11}{32}$ "
Material.....	Silchrome steel	Silchrome steel	Silchrome steel	Silchrome steel
Seat angle.....	45°	45°	45°	45°
Seat width.....	$\frac{5}{8}$ "	$\frac{5}{8}$ "	$\frac{5}{8}$ "	$\frac{5}{8}$ "
Stem diameter.....	$\frac{3}{8}$ "	$\frac{3}{8}$ "	$\frac{3}{8}$ "	$\frac{3}{8}$ "

ENGINE




Plate 31. Valve Details-- Cadillac 370-B and 452-B

ENGINE—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Valves, Inlet				
Clearance between—				
Stem and guide				
New limits	.0015-.0035"	.0015-.0035"	.001-.0025"	.001-.0025"
Worn limit, not over	.006"	.006"	.006"	.006"
Stem and camslide (See Note 15)			Automatic	Automatic
Before engine unit 11-1148	.004"			
Beginning engine unit 11-1148	.006"			
Before engine unit 12-1126		.004"		
Beginning engine unit 12-1126		.006"		
Adjust while engine is cold				
Clear diameter (port opening)	1 1/2"	1 1/2"	1 5/8"	1 5/8"
Length—overall	6 1/2"	6 1/2"	6 9/16"	6 9/16"
Lift	2 3/4"	2 3/4"	1 1/2"	1 1/2"
Material	Tungsten steel	Tungsten steel	Tungsten steel	Tungsten steel
Seat angle	30°	30°	45°	45°
Seat width	1 1/8"	1 1/8"	5/16"	5/16"
Stem diameter	2 3/8"	2 3/8"	3 1/2"	3 1/2"
Valves Springs				
Free length—				
Inner valve spring			1.944"	1.944"
Outer valve spring	2.800-2.820"	2.800-2.820"	2.215-2.235"	2.347-2.378"
Pressure in pounds, inner valves—				
Compressed to 1.751 in. (valve closed)			18-21 lbs.	18-21 lbs.
Compressed to 1.407 in. (valve open)			49-54 lbs.	49-54 lbs.
Pressure in pounds, outer valves—				
Compressed to 2.5 in. (valve closed)	77-81 lbs.	77-81 lbs.		
Compressed to 1.922 in. (valve closed)			48-52 lbs.	
Compressed to 1.875 in. (valve closed)				42-47 lbs.
Compressed to 2.148 in. (valve open)	164-178 lbs.	164-178 lbs.		
Compressed to 1.578 in. (valve open)			111-120 lbs.	
Compressed to 1.531 in. (valve open)				87-92 lbs.
Spring must not show any set when compressed with coils touching.				
Valve Timing				
Intake opens—before top center (.006 in. clearance on 345B, 355B)	6°	6°	T. D. C.	T. D. C.
Intake closes—after bottom center (.006 in. clearance on 345-B, 355-B)	42°	42°	44°	44°
Exhaust opens—before bottom center (.008 in. clearance on 345-B, 355-B)	38°	38°	39°	39°
Exhaust closes—after top center (.008 in. clearance on 345B, 355B)	2°	2°	5°	5°

ENGINE




Fig. 1

Slack in timing chain is taken up by idler sprocket moving toward camshaft




Fig. 2

Resetting Chain Adjuster




Fig. 3

Exploded View of Automatic Chain Adjuster




Fig. 4

Exploded View of Generator Driver

ENGINE




Fig. 1

Removal of Piston Pin

Always remove and install piston pin in direction indicated by arrows.




Fig. 2

Connecting rods for all models are rifle bored for lubrication of piston pin.




Fig. 3

Sectional View of Vacuum Pump and Drive




Fig. 4

Front Engine Support




Fig. 6

Sectional View of Rear Engine Support




Fig. 5

Rear Engine Support. Typical of all models.

For transmission rear support see Plate 54, Fig. 3, in Transmission Section.

ENGINE




Plate 34. Oiling System—Cadillac 355-B—LaSalle 345-B

ENGINE




Plate 35. Oiling System—Cadillac 452-B, Typical of 370-B

ENGINE—Service Information

16. Compression Ratios

The compression ratios of the 370-C and 452-C engines as shown below are greater than on the corresponding "B" series engines

H. C. (Optional)	H. H. C. (Standard)
370-C—5.4 to 1	5.6 to 1
452-C—5.4 to 1	5.7 to 1

The increase in compression ratios necessitates a change in the ignition timing, and the flywheel marks have been changed accordingly. That is, the IG/A marking on the 370-C and 452-C is 4° or approximately $\frac{1}{2}$ in. ahead of center.

The compression ratio of the 370-C and 452-C engines can be altered the same as in the "B" models by changing the cylinder head gaskets. See Note 17.

17. Interchangeability of 370 and 452 Cylinder Heads and Gaskets

The cylinder heads provided on 370-C and 452-C cars are designated HHC and the lower compression ratios are obtained by the use of special gaskets in the same way as on 370-B and 452-B cars. The "C" series head is interchangeable on "A," "B" and "C" series cars and only the "C" series heads will be supplied by the Factory Parts Division for all 370 and 452 cars. The part numbers of the "C" series heads are 1096172 for 370 cars and 1096173 for 452 cars. These heads can be identified by the letter "C" in a circle stamped under the "HHC." On later cars the "HHC" is eliminated and the letter "C" in a circle is the only mark appearing.

The earlier type heads should not be used on "C" series cars since the "C" series heads are of a considerably higher compression ratio than the heads formerly provided for 370-A and B and 452-A and B cars. The use of these earlier heads

would necessitate a change of the distributor and the timing marks on the flywheel. The HC ratio of the "C" series head corresponds to the HHC ratio on "A" and "B" series cars and the difference is equally great on LC and HC ratios of these models.

The same gaskets are used on "C" model cars to obtain the various compression ratios with the "C" series heads as with the "HHC" heads used on "B" model cars and on some "A" model cars. In order to use the "C" series head on "A" or "B" series cars, however, it has been necessary to provide thicker gaskets under new part numbers so that the standard "A" and "B" series LC, HC and HHC ratios can be maintained on these cars, regardless of the increased compression of the "C" series heads. It is important that the new (thicker) gaskets, indicated in the table, be used when "C" series heads are used on "A" or "B" series cars so it will not be necessary to change the timing.

At the beginning of production on "A" series cars, separate heads, machined to the required thickness, were used to provide HC and LC ratios. The ratios of these heads cannot be changed to any of the standard ratios by the use of special gaskets. Since a number of these heads are still in use, it is important that the heads be carefully identified before attempting to change the ratio by the use of the special gaskets.

Since any one of several heads have been used interchangeably on "A" and "B" series cars, it may sometimes happen that the heads on the right and left-hand blocks of a car differ and in such cases different gaskets will be required for these heads to maintain the same ratio for both banks of cylinders. It is therefore important that the identity of both heads be determined when replacing gaskets. Ordinarily, if the markings on both heads are similar, it may be assumed that both heads are of the same type.

Table of Cylinder Heads and Gaskets

Series Where Used	Cylinder Head Part Number	Identification		Part Number of gasket required to obtain ratios originally specified for various models		
		Marking	Thickness	LC ratio	HC ratio	HHC ratio
370-A and 370-B	1091383†	LC	5 $\frac{5}{32}$ "	889361 (4.9 to 1)**
	1091440†	HC	5 $\frac{7}{64}$ "*	889361 (5.2 to 1)*
	1091133†	HHC	5 $\frac{1}{16}$ "	894392 (4.9 to 1)	894339 (5.1 to 1)	889361 (5.4 to 1)
	1096172	HHC ⊙ or ⊙	5"	889408 (4.9 to 1)	894392 (5.1 to 1)	894339 (5.4 to 1)
370-C	1096172	HHC ⊙ or ⊙	5"	894392 (5.1 to 1)	894339 (5.4 to 1)	889361 (5.6 to 1)
452-A and 452-B	1090245†	B or LC	5 $\frac{1}{16}$ "	881027 (4.9 to 1)**
	1090486†	HC	5 $\frac{1}{32}$ "*	881027 (5.1 to 1)*
	1090240†	HHC	4 $\frac{31}{32}$ "	896503 (4.9 to 1)	896450 (5.1 to 1)	881027 (5.4 to 1)
	1096173	HHC ⊙ or ⊙	4 $\frac{37}{64}$ "	883608 (4.9 to 1)	883609 (5.1 to 1)	896450 (5.4 to 1)
452-C	1096173	HHC ⊙ or ⊙	4 $\frac{37}{64}$ "	896503 (5.1 to 1)	896450 (5.4 to 1)	881027 (5.7 to 1)

†No longer furnished for service.

*Not available with cylinder head indicated.

ENGINE—Service Information

In most cases, the cylinder heads are plainly marked so that they may be easily identified, but the safest method is to determine the thickness of the head as measured from the top flange to the surface which rests against the gasket. Both means of identification are given in the table of gaskets presented on page 67A.

When the part number of a cylinder head is definitely established, the proper gasket to use in order to obtain the desired ratio may be determined by referring to the table.

In any case where the "C" series head with the "C" series gasket, part number 889361, is installed on 370-A or B cars, it will be necessary to install V-16 push rods, part number 84244, in place of the original V-12 rods to compensate for the difference in thickness of the heads. This is in addition to the changes in the timing required.

18. Two Types of Pistons Used in 345-C and 355-C Engines

Beginning with engine unit No. 30-990 on 345-C and 355-C engines, the pistons are of a different design than those used prior to this number. The changes in the pistons are in the rings and the lands between the ring grooves as shown in Fig. 1 on this page.

The ring change is in the second groove from the top. This groove is now $\frac{1}{8}$ in. wide and contains two $\frac{3}{32}$ in. compression rings which are effective in preventing blowby and the consequent loss of power.

The two lands between the compression rings and the upper oil ring are chamfered toward the top to aid in keeping down the oil consumption. The top land at the top of the piston is also grooved to prevent as much as possible the dissipation of heat to the rings and the lower part of the piston.

Only these second type pistons are supplied for service in the standard, .015 in. and .030 in. sizes for all "A," "B" and "C" series cars. Likewise these pistons will be supplied with all factory reground .015 in. and .030 in. oversize cylinder blocks, not only for these series cars but for the earlier models beginning with the Cadillac 341-A and LaSalle 340.

19. Worn Limits for Cylinder Block

When ordering first or second oversize cylinder blocks from the factory, care should be exercised in determining the amount of wear on the blocks returned for exchange as this wear on the replaced blocks should determine the size of blocks to order.

If the standard size cylinder blocks show less than .012 in. wear or out-of-round they may be returned in exchange for first oversize blocks. If the wear exceeds .012 in. but is less than .027 in., second oversize blocks should be ordered for installation on the car.

20. New Type Chain Housing Oil Seal on 345-C and 355-C Engines

Beginning with engine unit 30-1256 on V-8 cars, a new type oil seal is provided in the chain housing around the water pump drive. This new seal consists of a felt and cork packing in addition to the metal retainers which are retained in this construction. The design of the oil seal is such that it cannot be installed on engines prior to this engine unit number.

21. Adjustment of Valve Spring Pressure on V-12 and V-16 Engines

The relation between valve spring pressure and valve travel on V-12 and V-16 engines is such that each .010 inch of travel is equivalent to 2.73 pounds of pressure. In consequence, the seating pressure of the valves may be reduced considerably by the slight increase in travel occasioned by a valve refacing and reseating operation. Reduced valve seating pressures




Fig. 1. View showing piston construction and ring arrangement, beginning with engine unit 30-990 on 345-C and 355-C engines.

would, moreover, affect engine performance to a noticeable degree, especially in making cold-weather starting more difficult, and in some cases might cause the valves to burn.

To control the valve seating pressure it should accordingly be checked after valve refacing operations on V-12 or V-16 engines. Tool, Part No. J-444 should be used for making this test.

The correct seating pressure for the valves on V-12 and V-16 engines, with both valve springs properly installed, is from 48 to 63 pounds. If the pressure is less than 48 pounds, one or more spacers should be installed under the valve spring retainers. A spacer .040 inch thick is available for this purpose, under Part No. 889407. Each spacer will raise the seating pressure 10.9 pounds.

Each valve should be tested separately and one or more spacers installed as required. In case of an extremely low seating pressure, the valve springs should be checked against the specifications given on page 63 to make sure that they have not lost tension and shortened in use.

22. Making Later Changes in Early Vacuum Pumps

Beginning with engine number 2002446 on 345-C cars and engine number 3001589 on 355-C cars, a vacuum pump of slightly different design is used to aid in preventing loss of engine oil. These changes are in the location of the vent hole in the lower pump body, the spring above the diaphragm and in the diaphragm.

The vent hole in the lower pump body is on the right side in the first type pump and on the left side in the second type pump as viewed from the top.

The second type spring above the diaphragm can be identified by the number of coils, the first type springs have twelve coils whereas the second type springs have fifteen coils. The new diaphragm is made of improved material. Only this type diaphragm is carried by the Factory Parts Division.

These changes should be made in any 345 or 355 "B" or "C" series cars before the engine numbers given whenever the diaphragm is found cracked or broken or the pump is contributing to excessive oil consumption.

Although these changes do not apply to the vacuum pump on V-12 and V-16 engines, it is recommended that a new diaphragm, (Part No. 856331) and a lighter spring (Part No. 856358) be installed in cases of diaphragm breakage but under no circumstances should an attempt be made to change the location of the vent hole in V-12 and V-16 vacuum pumps.

ENGINE—Service Information

The necessary parts for making these changes in the V-8 series engines can be secured from the Factory Parts Division under the following part numbers:—1521501—an assembly including the second type diaphragm, spring and a plug for the old vent hole; and 877852, the cork gasket for installation between the flange of the pump body and the crankcase.

These changes can be made in the first type pump as follows:

1. Test vacuum pump for oil leakage by disconnecting the intake manifold pipe at the pump and remove the nipple to which this pipe is connected. If there is any trace of oil in this nipple, these changes should be made.

2. Remove vacuum pump from engine.

3. Disassemble vacuum pump. Be sure to hold upper part of pump while removing the retaining screws to prevent the spring from throwing the diaphragm and upper part of the pump body.

4. Plug the old vent hole in the lower pump body, using the

brass ball supplied in the kit. Peen the housing over the ball to hold it in place.

5. Drill a new $\frac{1}{4}$ in. vent hole 180° or half way around the pump directly opposite the old hole. Be careful to drill this hole straight to avoid its breaking out at the side of the housing.

6. Reassemble pump, using the new parts. First of all, install the various parts in their proper positions and install the retaining screws loosely. Then put the pump in a vise between protecting wooden blocks and tighten the vise until the distance from the lower side of the pump base to the bottom of the plunger shaft for V-8 pumps is $1\frac{1}{8}$ in. and $1\frac{1}{2}$ in. on V-12 and V-16 pumps and then tighten the retaining screws securely.

7. Reinstall pump on engine, using new cork gasket whenever oil leakage is noticed at this point.

8. Make a center punch mark for identification in the center of the pump body cover.

EXHAUST SYSTEM

General Description

The arrangement of the exhaust systems on the Cadillac V-8 and the LaSalle cars is the same. The exhaust manifolds are connected at the top to the manifold header to which is connected a single exhaust pipe leading to the muffler.

The exhaust gases pass from the cylinders through the manifolds to the header and out through the exhaust pipe. The flow of hot gases through the header heats the fuel mixture quickly to assist in more thorough vaporization of the fuel.

Two entirely separate exhaust systems are used on both the Cadillac 370-B and 452-B, one system for each block of cylinders. Each of these exhaust systems includes an exhaust manifold, an exhaust pipe, a muffler and a tail pipe.

The 370-B exhaust manifolds are in two sections and the 452-B manifolds are in three sections to allow for expansion. These sections are connected by tight fitting leak-proof sleeves.

The front section of the 370-B exhaust manifold carries the upper part of the intake header. The center section of the 452-B manifolds contains part of the heat chamber for heating the gases passing from the carburetor to the intake manifold.

All mufflers have an asbestos lining between two shells which are welded together at the ends. The purpose of the asbestos lining is to enable the muffler to stand the extreme heat.

A tuning chamber is built into the 370-B and 452-B mufflers to reduce exhaust noises. This chamber acts on the same principle as the tuning chamber in the carburetor intake silencer.

In addition to the muffler on the 345-B, 355-B cars, a silencing chamber consisting of a piece of pipe about two feet long is mounted above and connected to the tail pipe as shown in Fig. 2, Plate 36. This chamber acts on the same principle as the tuning chamber in the 370-B and 452-B muffler. This tuning chamber is also used on the 452-B tail pipe in addition to the tuning chamber already in the muffler.

The exhaust pipe on the 345-B and 355-B is covered with a heavy asbestos insulation to prevent excessive heat under the hood and in the body.

Rubber cushions are used between the muffler support brackets and the frame on all models to prevent the exhaust vibrations being transmitted to the body.

Service Information

1. Crackling Noises in Manifolds

Some 452-B engines when new, give out a crackling noise after a long run when the ignition is shut off. This noise will be heard only in some new engines and is caused by the contraction of the manifold sections as the exhaust manifolds cool. This condition will not injure the engine and is automatically eliminated after the manifolds and blocks have taken a permanent set.

To correct this condition smooth up the faces and corners of the manifold flanges with emery paper and spread thinly a paste made up of graphite and oil, over the contacting surfaces. Finally pull up the flange nuts tightly but without excessive strain.

2. Installing Exhaust Manifold Gaskets

Exhaust manifolds are subject to such extreme variations

in temperature that the metal expands and contracts to a considerable degree. This results in "creeping" on the manifold gaskets which has no undesirable effect unless the bolts are drawn up too tight.

The manifold bolts should be tightened while the engine is running and should be drawn up just enough to stop all exhaust leaks. If the bolts are tightened too securely, the "creeping" of the manifold may rip the copper of the gasket and permit the gasket to burn out.

The possibility of V-12 and V-16 intake and exhaust gaskets blowing out can be greatly reduced by coating them with graphite before installing. Coating the gaskets with graphite makes it easier for the manifold to expand and contract without pulling or wrinkling the gasket which may in some cases cause the gasket to blow out.

EXHAUST SYSTEM




Fig. 1

Metal covering cut away to show asbestos insulation—Cadillac 355-B - La Salle 345-B




Fig. 2

Tuning Chamber on Tail Pipe—Cadillac 355-B
452-B - La Salle 345-B




Fig. 3

Cut-away View of Muffler—Cadillac 355-B-
La Salle 345-B




Fig. 4

Sectional View of Muffler Showing
Tuning Chamber—Cadillac
370-B, 452-B




Fig. 5

Front Muffler Support

The rear muffler support is of similar construction and is adjusted in the same manner as the front support.

FENDERS




Fig. 1

Radiator grille cut away to show casing brace rod assembly to which the front fender tie rods are attached

To remove radiator and casing assembly, first remove fender tie rods by disconnecting them from radiator casing, headlamp brackets and fenders. Brace rod will remain in position in radiator casing

To insure proper alignment of fender tie rods when re-installing radiator and casing assembly, attach tie rods to headlamp brackets before fastening them to radiator casing. Adjust tie rods to proper length by turning them in or out of radiator casing bracket





Fig. 2

View showing front fender tie rod

Plate 36A. Front Fender Tie Rods—"C" Series Cars

FRAME



Frame Dimensions

	345-B	355-B (Except 156 in. W.B.)	370-B (Except 156 in. W.B.)	355-B, 370-B (156 in. W.B.)	452-B
A	36 $\frac{1}{4}$ "	36 $\frac{1}{4}$ "	36 $\frac{1}{4}$ "	36 $\frac{1}{4}$ "	36 $\frac{1}{4}$ "
B-C	"B" should equal "C" at any point along frame				
D-E	"D" should equal "E"				
F	27 $\frac{3}{8}$ "	27 $\frac{3}{8}$ "	27 $\frac{3}{8}$ "	27 $\frac{3}{8}$ "	27 $\frac{3}{8}$ "
G	7 $\frac{1}{8}$ "	7 $\frac{1}{8}$ "	7 $\frac{1}{8}$ "	7 $\frac{1}{8}$ "	7 $\frac{1}{8}$ "
H	56 $\frac{1}{4}$ "	56 $\frac{1}{4}$ "	56 $\frac{1}{4}$ "	58 $\frac{1}{4}$ "	58 $\frac{1}{4}$ "
I	8 $\frac{1}{4}$ "	8 $\frac{1}{4}$ "	8 $\frac{1}{4}$ "	8 $\frac{1}{4}$ "	8 $\frac{1}{4}$ "
J	9 $\frac{1}{8}$ "	9 $\frac{1}{8}$ "	9 $\frac{1}{8}$ "	9 $\frac{1}{8}$ "	9 $\frac{1}{8}$ "
K	38 $\frac{5}{8}$ "	38 $\frac{5}{8}$ "	38 $\frac{5}{8}$ "	41 $\frac{1}{8}$ "	41 $\frac{1}{8}$ "
L	2 $\frac{11}{16}$ "	2 $\frac{11}{16}$ "	2 $\frac{11}{16}$ "	2 $\frac{11}{16}$ "	2 $\frac{11}{16}$ "
M	7 $\frac{3}{32}$ "	7 $\frac{3}{32}$ "	7 $\frac{3}{32}$ "	7 $\frac{3}{32}$ "	7 $\frac{3}{32}$ "

Plate 37. Frame Alignment

FRAME

General Description

Cadillac and LaSalle frames are of the double drop type. They are of the same construction on all models, differing only in dimensions. Unusually deep side bars and box-type cross-members add materially to the rigidity of the frame, particularly at the front end.

The front cross-member is heavily reinforced to stiffen the frame against flexing and extends back far enough to support the front end of the engine. The side bars are 9 in. deep on the 345-B, 355-B and 370-B and 10 in. deep on the 452-B. Box type sections reinforce the side bars between

the front outriggers and the front cross members.

The two center cross-members are also of a box-shaped section. The first of these two cross-members supports the rear end of the engine through the transmission ball-joint socket. At the rear end of the frame are two pressed steel cross-members.

The running board brackets are of heavy channel section. Only one bracket is used for each running board as the rear ends are supported by the rear fenders.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Car				
Chassis model designation.....	345-B	355-B	370-B	452-B
Chassis unit number location.....				
All models—rear of L. H. side of radiator cross member.				
First serial number.....	1,100,001	1,200,001	1,300,001	1,400,001
Length of car—overall (approximately)				
5 Wheels—				
130 in. W. B.....	204 $\frac{1}{8}$ "		207 $\frac{1}{8}$ "	
134 in. W. B.....		207 $\frac{1}{8}$ "		
136 in. W. B.....	210 $\frac{1}{8}$ "		213 $\frac{1}{8}$ "	
140 in. W. B.....		213 $\frac{1}{8}$ "		
143 in. W. B.....				216 $\frac{1}{8}$ "
149 in. W. B.....				222 $\frac{1}{8}$ "
6 Wheels—				
130 in. W. B.....	209 $\frac{1}{8}$ "		212 $\frac{1}{8}$ "	
134 in. W. B.....		212 $\frac{1}{8}$ "		
136 in. W. B.....	215 $\frac{1}{8}$ "		218 $\frac{1}{8}$ "	
140 in. W. B.....		218 $\frac{1}{8}$ "		
143 in. W. B.....				221 $\frac{1}{8}$ "
149 in. W. B.....				227 $\frac{1}{8}$ "
Wheelbase (nominal).....	130", 136"	134", 140"	134", 140"	143", 149"
Width of car overall (approximately).....	76 $\frac{1}{8}$ "	76 $\frac{1}{4}$ "	76 $\frac{1}{4}$ "	76 $\frac{1}{4}$ "
Frame				
Chassis (unit) number location.....				
345-B, 355-B and 370-B,—L. H. side radiator cross member near frame side bar.				
452-B—L. H. side radiator cross member near frame side bar.				
Number of cross members.....	5	5	5	5
Side bar—				
Depth.....	9"	9"	9"	10"
Thickness.....	$\frac{5}{32}$ "	$\frac{5}{32}$ "	$\frac{5}{32}$ "	$\frac{5}{32}$ "
Width—top and bottom.....	2 $\frac{1}{2}$ "	2 $\frac{1}{2}$ "	2 $\frac{1}{2}$ "	2 $\frac{1}{2}$ "
Measurements taken at deepest part of frame.				
Width of frame at—				
Front.....	29 $\frac{1}{2}$ "	29 $\frac{1}{2}$ "	29 $\frac{1}{2}$ "	29 $\frac{1}{2}$ "
Rear.....	38"	38"	38"	38"

GASOLINE SYSTEM




Fig. 1
Sectional View of Carburetor, Intake
Silencer and Air Cleaner

Turn adjusting screw clockwise to enrich mixture and counter-clockwise to lean mixture. Adjust for smooth idling.

Fig. 2
Carburetor Adjustments

With choke arm in correct position, under side of thermostat should be $\frac{1}{32}$ – $\frac{1}{8}$ in. above face of choke arm. Check thermostat setting at room temperature (65–85°F) with carburetor cold. To adjust loosen locking screws and move thermostat on shaft.

Lower face at end of choke arm should be in line with center of shaft and small hole in outer end of choke lever. Adjust by loosening locking screws and moving arm on shaft.




Fig. 3
Choke and Auxiliary Air Thermostat
Adjustments

GASOLINE SYSTEM

General Description

The general arrangement of the gasoline system is the same on all cars. The 370-B and 452-B system differs slightly however, as each of these cars has two carburetors.

The gasoline line from the rear supply tank is mounted outside of the frame where the air sweeping by tends to cool the gasoline and thereby prevent the possibility of vapor lock. Sharp bends and low spots in the fuel line have also been eliminated by running the line as nearly straight as possible from the tank to the fuel pump.

CARBURETOR

The 345-B and 355-B carburetors are of the same general construction typical of those used on previous car models and the method of adjusting is the same on both models.

The 370-B and 452-B carburetors are of the expanding air valve type. They are simple in construction with no thermostats and have only one adjustment, which controls the mixture by varying the flow of fuel rather than the air.

The carburetors used on the 370-B and 452-B are identical with the exception of the size of the metering pin. A No. 10 metering pin is used in the 370-B carburetors and a No. 12 in the 452-B carburetors. Otherwise the carburetors on these car models are fully interchangeable. Right and left carburetors differ in the control levers. The name plate marking identifies the type of carburetor; 370-B carburetors are Type R-13 and L-13; 452-B carburetors are Type R-14 and L-14. The carburetor consists chiefly of two units, namely, the main metering unit and the auxiliary unit.

The *main metering unit* consists of a pair of air valves or vanes, hinged at their lower ends and opening upwards to admit air to the mixing chamber. These vanes have fingers which engage a central aspirating tube, raising it as the vanes open. This aspirating tube is attached to a spring loaded hollow stem and piston working in a dashpot, the piston carrying the fuel metering orifice in its lower end. An adjustable tapered metering pin projects into this orifice.

The *auxiliary unit* combines an auxiliary power jet, an accelerating pump, and a priming passage for starting. The operation of the auxiliary unit is controlled by the registering of ports in the starting sleeve, which line up with passages in the throttle body. The starting sleeve rotates with the starting lever (choke lever) and the

pump plunger and piston move downward as the throttle is opened.

OPERATION

For *normal running* the fuel enters the carburetor float bowl through the strainer and float needle valve, and is maintained at constant level by the float and float needle valve. This level of fuel should be $\frac{13}{16}$ to $\frac{15}{16}$ in. below top of float bowl casting.

Air enters the carburetor through the air inlet and lifts the vanes as it passes upwards into the mixing chamber. The weight of these vanes combined with the pressure exerted by the dashpot spring causes a partial vacuum to exist in the mixing chamber, which draws fuel from the aspirating tube. The quantity of the fuel flowing is controlled by the tapered metering pin; at idle speed the vanes are almost closed and the metering pin almost fills the orifice in the air valve piston. As the vanes rise to admit more air, the aspirating tube also rises and the metering orifice becomes larger due to the taper on the metering pin. This combination maintains the correct ratio of fuel and air for average running.

For *maximum power* at any speed a richer mixture is required than is necessary for part throttle running. The power jet supplies the required extra fuel while the throttle is held open beyond the point which would give a road speed of about 60 miles per hour. At this throttle position the pump plunger has travelled downward and has shut off the air vent to the power jet, therefore, the suction on the discharge nozzle draws fuel from the pump cylinder up through the hollow stem of the pump plunger and through the power jet into the mixing chamber. At part throttle positions below 60 miles per hour road speed this power jet does not supply fuel since it is vented to the outside air through the air vent hole in the upper part of the starting sleeve.

The quantity of fuel drawn from the power jet is controlled by the air bleed hole in the pump plunger stem.

For *rapid acceleration* it is necessary to supply a momentarily rich mixture. This extra fuel is supplied by means of the accelerating pump.

A rapid opening of the throttle causes a rapid downward movement of the pump plunger and piston, forcing fuel up through the hollow stem of the pump plunger and out through the discharge

GASOLINE SYSTEM




Fig. 1

Sectional View of Carburetor

Note: Adjustment for engine idling speed should precede carburetor adjustments. Adjust throttle stop screws to make engine idle at about 320 R.P.M.




Fig. 2

Cross-section of Carburetor




Fig. 3

Carburetor Adjustments

Adjust kicker screw to give .005-.010 in. clearance between screw and kicker rod. Before making this adjustment be sure that starting lever is in normal running position.

Turn adjusting screw clockwise to lean mixture and counter-clockwise to enrich mixture. Adjust for smooth idling.

Tool No. HM 109626




Fig. 4

Gauge for equalizing carburetor adjustments

GASOLINE SYSTEM—General Description—Service Information

nozzle into the mixing chamber. The fuel in the pump cylinder cannot escape back into the float chamber because of the check valve in the bottom of the pump cylinder.

In general—for steady driving conditions up to 60 miles per hour on level roads the fuel is all supplied from the aspirating tube. When the throttle is opened suddenly an additional charge of fuel is supplied from the accelerating pump, and if the throttle is held open as for hard pulling or high speed, extra fuel continues to flow from the pump discharge nozzle through the power jet.

FUEL PUMP

The fuel feed on all models is by a fuel pump. This pump is operated by a push (driving) rod riding against a cam on the distributor shaft and is located at the front of the engine on the left, in the coolest position under the hood.

The principal moving element of the fuel pump is a diaphragm actuated through a series of levers and rods as shown in Fig. 2, Plate 40. The operation is as follows. When the push rod is moved in and out by the action of the driving cam, it in turn operates the rocker arm which is pivoted at the lower end. The rocker arm pulls the pull rod and diaphragm assembly down, creating a vacuum in the pump chamber which draws gasoline from the rear tank into the sediment bowl and through the strainer and inlet valve into the pump chamber.

The diaphragm is moved upward on the return stroke by pressure of the diaphragm spring. On this stroke the gasoline is forced from the pump

chamber through the outlet valve, into the vapor dome and thence to the carburetor.

When the carburetor bowl is filled and the inlet needle valve closes, a back pressure is created in the fuel pump chamber. This pressure holds the diaphragm down against the pressure of the diaphragm spring, and keeps it in this position until more fuel is needed in the carburetor and the needle valve opens.

The rocker arm is in two pieces, operating as a single part when the diaphragm is working up and down. However, when fuel is not required and the link or lower part of the operating lever is held down at one end by the diaphragm pull rod, the lever or upper part operates in the usual way. This is made possible by the fact that the lever operates against the link only in the downward direction, the upward movement of both parts being accomplished by spring pressure. A second spring is provided for keeping the lever in contact with the driving rod at all times.

INTAKE SILENCER

An intake silencer is used on all models. The silencer silences the roar of the intake at certain engine speeds under open throttle. There are no moving parts or baffle plates on these silencers and they require no attention in service.

A feature of the air silencer is the copper gauge air cleaner which is designed to catch any dust or lint in the air before it is drawn into the carburetor. It is automatic in operation and requires no attention other than periodic cleaning.

Service Information

1. Gasoline Gauge Adjustment

If the gasoline gauge does not register correctly and the variation from accuracy is the same over the entire scale, a readjustment of the float on the tank unit should correct the trouble. The float adjusting screw at the side of the float rod gear is accessible, if the tank unit of the gauge system is removed from the tank.

Accurate readings between 0 and 4 gals. should not be expected.

2. Equalizing Carburetor Adjustments—370-B, 452-B

The adjustments of the two carburetors on the 370-B and 452-B cars should be equalized to secure smooth running of the engine. The best method to follow is to use an equalizing gauge as shown in Fig. 4, Plate 39. The gauge is connected to the intake manifolds after both the brake assister and vacuum lines are disconnected. The throttle rod must also be disconnected from the right-hand carburetor.

A preliminary adjustment of the metering pins and throttle on both carburetors is then made to bring the idling speed at approximately 320 R. P. M.

To determine whether or not the engine is running at the correct idling speed, remove the oil filler cap from one of the valve covers and hold a finger on one of the valve rocker arms so that the movements of the rocker arm may be counted. At 320 R. P. M. the valve will open forty times in fifteen seconds.

Make sure that the gauge hangs straight and check the level of the mercury in the tube. When the metering pins and throttle stop screws are properly adjusted, both columns of mercury should be at the same height and the engine should run smoothly at 320 R. P. M.

If the columns of mercury are not at the same level and the engine speed is too fast, reduce the speed by backing off the throttle stop screw on the side on which the mercury column is the lower. If the speed is too slow, turn the throttle stop screw in a little on the side on which the mercury column is higher.

If the mercury columns are at the same level and the engine speed is too fast or too slow, adjust both throttle stop screws, turning them exactly the same amount to secure the correct idling speed, at the same time keeping the mercury columns at the same level.

Re-check the metering pin adjustments and idling speed on both carburetors, making sure that the mercury columns are maintained at the same level.

Adjust the right-hand throttle control rod to exactly the right length so that the clevis pin can be slipped into place without changing the engine speed.

A further check should be made on the throttle adjustment by running the engine at approximately 1000 R. P. M. and noting the mercury level in the gauge. If the columns are not practically level, a slight readjustment of the right-hand

GASOLINE SYSTEM




Fig. 1
Fuel Pump

Pump housing must not be disassembled unless necessary special tools for reassembly are available.





Fig. 2
Sectional View of Fuel Pump and Drive

To clean cover simply wipe off with cloth before installing on gauze unit.



Clean gauze unit by washing in gasoline to remove all dirt from gauze and dry with an air hose. Then dip in light engine oil and allow to drain before reinstalling on silencer. Install gauze unit on silencer with louvers pointing down.

Note:
Do not wash intake silencer or cover containing fabric pad.

For normal driving in cities and on hard surfaced roads, clean air cleaner once every 6,000 miles. Under extreme conditions, such as continuous driving on dusty roads or in localities where there is considerable dust in the air, cleaning may be required as frequently as every 2,000 miles.

Fig. 3
Exploded view of Air Cleaner

GASOLINE SYSTEM—Service Information—Specifications

throttle control rod will be necessary. Finally run the engine again at idling speed and check the mercury columns again. A very slight readjustment of the throttle control rods may be necessary to bring them to the proper level again.

If an equalizing gauge is not available, the following method may be used to equalize the carburetor adjustment.

Disconnect the coil wire for the right-hand cylinder block. Adjust the metering pin of the left-hand carburetor in the same manner as when using mercury tube and set the throttle stop screw so the engine will just turn over without stalling.

Then disconnect the coil wire for the left-hand cylinder block and adjust the metering pin and the stop screw on the right-hand carburetor in a similar manner.

With the metering pins and throttle stop screws on both carburetors properly adjusted, the engine should idle at about 320 R. P. M.

Inasmuch as some air is drawn into the manifold of the carburetor being adjusted through the vacuum brake assister connection on the opposite intake manifold, the foregoing adjustment will probably be slightly rich when all cylinders are operating. To correct this, it may be necessary to screw up slightly each metering pin adjustment. This can best

be checked by listening to exhaust and making final adjustment with both sides firing.

When a satisfactory adjustment of both carburetors has been secured, adjust the length of the right-hand throttle control rod very carefully, so that the pin will slip into place without affecting the throttle opening on either carburetor. This adjustment must be made very accurately so as not to disturb the throttle equalization. While testing the car on the road, the above adjustments should be rechecked to be sure they are satisfactory.

3. Servicing the Fuel Pump.

The service operations which can be performed on the fuel pump without special tools are the cleaning of the filter and the replacement of the filter parts, the vapor dome, and the inlet and outlet valves. Under no circumstances should the pump housing be disassembled unless the necessary special tools for reassembly are available.

Service on the fuel pump can be obtained from A. C. service stations, which have special tools and spare parts.

Distributors and larger Dealers are advised to keep a pump on hand for exchange to render prompt service. Distributors who wish to make all pump repairs themselves can secure the necessary tools from any A. C. service station.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Air cleaner and intake silencer, make of.....	A.C.	A.C.	A.C.	A.C.
Feed.....
All models—A.C. fuel pump.
Gasoline line location.....
All models—outside of left frame side bar.
Gasoline gauge (electric) make of (See Note 1).....	A.C.	A.C.	A.C.	A.C.
Tank capacity (supply).....	30 gal.	30 gal.	30 gal.	30 gal.
Carburetor				
Adjustments, equalizing (See Note 2).....
Float setting.....	$\frac{1}{16}$ "	$\frac{1}{16}$ "
Size.....	2"	2"	1½"	1½"
Size of metering pin.....	10	12
Size of nozzle (Nozzle No.).....	19	19
Thermostats—				
Air valve free movement with choke on.....	None	None
Throttle pump control operates.....	110-115°	110-115°
Throttle shaft end play				
New limit, not over.....	.0015"	.0015"	.0015"	.0015"
Worn limit, not over.....	.005"	.005"	.005"	.005"
Type.....	Air valve	Air valve	Expanding air valve	Expanding air valve
Unit number location.....
345-B, 355-B—Top front flange at R. H. side
370-B, 452-B—Top side of top flange under gasket
Fuel pump service (See Note 3).....

LIGHTING SYSTEM




Fig. 1
Headlamp Mounting—
Cadillac 355-B, 370-B and 452-B




Fig. 3

To aim headlamp, first set lamp so that flutes on lens are straight up and down. Then turn lamp sidewise or up and down to give light beam shown in Figs. 3 or 7, Plate 42. Hold lamp in this position and tighten nut securely, after which test lamp again to make sure it is properly aimed. Cover one lamp while working on other one.




Fig. 2
Headlamp Mounting—
LaSalle 345-B




Fig. 4

Removing bulb shield for gaining access to bulb

To remove the map lamp bulb the bulb shield must first be removed as follows: Pull lamp out part way to bring end of threaded shaft on plunger flush with rear edge of lamp cylinder. Then turn bulb shield slowly until hole in plunger comes opposite one in cylinder. Next insert nail or its equivalent in hole to keep plunger from turning and remove bulb shield by unscrewing it from cylinder. The bulb shield has a right-hand thread.

LIGHTING SYSTEM

General Description

SUPER-SAFE headlighting is used on all Cadillac models. The LaSalle lighting system is of the conventional type used on previous Cadillac and LaSalle cars. The LaSalle headlamps are of the fixed focus type and are alike, using fluted lenses and 32-32 candle-power double filament bulbs.

The SUPER-SAFE lighting system is used exclusively by Cadillac and actually comprises two independent lighting systems, one for the right-hand and one for the left-hand lamp. The lamps are purposely made so that the doors, lenses or reflectors cannot be interchanged. The same type of bulb, however, is used in both lamps.

The basis of the SUPER-SAFE lighting system is the bulb (Mazda 3001) with three filaments, one 32 candle-power and two 21 candle-power. The bulbs are placed in position in the two headlamps so that the 32 candle-power filament is uppermost in the left-hand lamp and at the bottom in the right-hand lamp. The slots in the sockets are so arranged that it is impossible to insert the bulbs in the wrong position.

The headlamps are wired so as to give four combinations of lighting, namely: City Passing, City Driving, Country Passing and Country Driving.

For *City Passing*, both headlamps give a depressed beam illuminating the right side of the road. This beam does not glare but it gives adequate illumination.

When in the *City Driving* position, both headlamps give a non-glaring beam of sufficient illumination for dark streets. This beam complies with all city regulations.

In the *Country Passing* position, the left headlamp with two filaments lighted, gives intense illumination of the right side of the road close in front of the car. This illuminates clearly any ditches or obstacles, while the right headlamp gives a moderate tilted non-glaring beam straight ahead.

For *Country Driving*, the left headlamp gives normal illumination, moderately tilted while the right headlamp, with two filaments lighted illuminates the road far ahead. This combination of light gives more and better placed illumination than is possible with conventional type headlamps, even when 32 candle-power bulbs are used.

The standard "Country Driving" beam projected by SUPER-SAFE headlamps is designed to add to the safety of night driving by directing a moderate amount of light above the headlamp level.

The elevated beam shows the way uphill and around turns, and illuminates road signs and other objects which have most of their light reflecting surface above the road level.

This added light has been ruled to be illegal in the states listed below. Cadillac cars shipped into these states have the "Country Driving" beam (upper beam) modified to eliminate this stray light. On cars for California, Oregon and Washington, the No. 9 terminal on the lighting switch is eliminated to prevent the use of the 32 candle-power beam in the right headlamp. The standard lighting switch must not be used in these three states.

The beam modification for the remaining states consists in rendering the 32 candle-power beam in the right headlamp inoperative by the use of a special switch lever at the top of the steering wheel. Owners of cars thus modified should be cautioned against any attempt to restore to use the filament thus eliminated.

Drivers from other states who are in a position to enjoy the added safety feature at home should refrain from using the "Country Driving" position when visiting the states listed below in which the added light is illegal.

Massachusetts	New York	Washington
Virginia	Connecticut	Oregon
Maryland	Rhode Island	Minnesota
Pennsylvania	New Hampshire	Vermont
New Jersey	Maine	Ontario, Can.
Iowa	California	

The headlamps are supported by brackets mounted on the front fenders. The wiring connections at the headlamps are made through a male and female plug inside the headlamp supports. Three wires enter the right headlamps and two enter the left headlamp. The wire tips have different length shanks to indicate their respective positions in the plug. The plugs are also indexed into the retainers which in turn are indexed into the lamp sockets. Thus, the connections must be properly made before the various parts will fit into their respective places.

LIGHTING SYSTEM






Fig. 1

Three-filament Bulb for SUPERSAFE Headlamps




Right SUPERSAFE CITY UPPER BEAM correctly aimed for unloaded car.

Aim right headlamp so that light beam centers on right vertical line on screen directly ahead of lamp so that upper edge of beam registers on lower horizontal line.



Modified right COUNTRY UPPER BEAM correctly aimed for loaded car in states which do not permit the use of the standard Country Upper Beam.

Aim right headlamp so that light beam centers on right vertical line on screen directly ahead of lamp so that upper edge of beam registers on upper horizontal line at level of headlamp center.



Left SUPERSAFE CITY UPPER BEAM correctly aimed for unloaded car.

Aim left headlamp so that left side of light beam coincides with left vertical line and upper edge of beam is on upper horizontal line.

Fig. 3

Aiming practices vary in different states so that no single set of instructions is applicable. The aiming practice described above is the one advocated by the Cadillac Motor Car Company as likely to result in maximum safety and comfort to all concerned. Where some other practice is specified by law or regulation, follow it.




Fig. 6




Fig. 2

Adjustment set-up showing proper position of car with reference to screen and accurate method of locating level of headlamp centers on screen. Locate car on a reasonably level surface with headlamps aimed toward and twenty-five feet from screen. Draw a horizontal line on screen at level of headlamp centers, located by sighting over two uprights, 40-1/2 inches long, placed opposite the wheels as shown above. This is extremely important. Draw a second line 3 inches below the first. Locate center point on lines by sighting through center of rear window and over center of radiator cap. Draw vertical lines 16 inches to either side of this center point, directly ahead of each lamp.




Fig. 4

Composite CITY UPPER BEAM pattern on properly marked adjustment screen




Fig. 5

SUPERSAFE CITY UPPER BEAM with lens removed

Fixed-focus headlamps need no focusing but better results will be obtained if the switch is turned to the "City Upper Beam" position and several bulbs are tried until one is obtained which produces a beam pattern like that shown above with the hot spot as bright and as near the top of the beam as possible.




Fig. 7

LaSalle 345-B Light Beams

Light beams with lamp properly aimed. After adjusting one lamp, repeat adjustment on other lamp.

LIGHTING SYSTEM—Gen. Description—Ser. Information—Specifications

The rear lamps on all cars are combination tail and stop lamps. Each lamp has two bulbs, one 3-candle-power for the tail light, and one 15-candle-power, which serves for both the stop and back-up lights. The larger bulb is lighted by the switch on the brake pedal bracket for the stop light, and by a new switch on the transmission for backing.

The rear lamp is fitted with a special ruby lens with a reflex area around the outer edge for reflecting the light of an approaching car when

the rear lights are out. Incorporated in the center of this ruby lens is a special blue lens directly in line with the 15-candle-power bulb. This blue lens is illegal in California and cars shipped into this state are provided with a small ruby lens instead of the blue lens.

The blending of the blue light with the ruby produces a brilliant hue which attracts immediate attention. The lower half of the blue portion of the lens is thinner in section than the upper half, providing ample illumination for backing.

Service Information

1. Stop and Back-up Lamp Connections.

The feed wire for the stop and back-up lamp is connected to the ignition switch and the circuits are protected by a fuse in the apparatus box.

These lamp circuits are connected to the ignition switch to prevent excessive load on the battery in case the car is parked in reverse or the stop light remains on after the brake pedal is depressed by application of the hand brake lever.

When checking the stop and back-up lamp circuit for shorts or burned out bulbs, make sure that the ignition switch is turned on.

2. Cleaning Headlamp Reflectors

Great care should be exercised in polishing the headlamp

reflectors to preserve the reflecting qualities. A good cleaning paste can be made by mixing rouge or talcum powder with alcohol. Dry lamp black and alcohol are just as satisfactory and may be more convenient. Apply the paste with a clean soft cloth and rub from the center outward in straight lines. Never polish reflectors with a circular motion because the fine circular lines break up the light rays and appreciably reduce the illumination.

3. Headlamp Misalignment Frequently Caused by Pushing Car

Misalignment of headlamps is oftentimes caused by workmen pushing against the headlamps when moving the car. The headlamps should never be used for this purpose.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Bulb Data				
Voltage—all bulbs.....	6-8	6-8	6-8	6-8
Back-up and stop lamp— (See Note 1)				
Candle power.....	15	15	15	15
Contact.....	Single	Single	Single	Single
Mazda No.....	87	87	87	87
Dome (closed cars)—				
Candle power.....	6	6	6	6
Contact.....	Single	Single	Single	Single
Mazda No.....	81	81	81	81
Fender lamp—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Headlamp—				
Candle power.....	32-32	21-21-32	21-21-32	21-21-32
Contact.....	Double	Triple	Triple	Triple
Mazda No.....	1000	3001	3001	3001
Instrument (dash) lamps—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63

LIGHTING SYSTEM—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Bulb Data—Cont'd				
Map reading lamp—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Rear quarter lamp—				
Candle power.....	6	6	6	6
Contact.....	Single	Single	Single	Single
Mazda No.....	81	81	81	81
Tail lamp—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Headlamps				
Cleaning reflectors (See Note 2).....
Misalignment (See Note 3).....
Lens diameter.....	10½"	8½"	8½"	8½"
Overall diameter.....	11"	9½"	9½"	9½"
Switches				
Delco-Remy type number—				
Back-up.....	440-E	440-E	440-E	440-E
Lighting.....	486-H	486-S	486-S	486-S
Stop light.....	474-R	474-R	474-R	474-R
Stoplight switch adjustment.....
Switch in "ON" position with brake pedal depressed ¾ to 1 in.				

LUBRICATION

Service Information

1. Extreme Pressure Lubricants for Rear Axle and Transmission

There are on the market gear lubricants known as extreme pressure lubricants which are designated by the letters "E. P." following their S. A. E. classification.

These lubricants have been developed for the lubrication of gears. Some of these lubricants should not be used in units that have bronze parts, as they produce an etching action on bronze and will cause it to corrode under severe conditions. Other "E. P." lubricants, however, have been developed that are satisfactory from the standpoint of corrosion.

As all Cadillac and LaSalle cars have bronze parts in the transmission and later cars have bronze thrust washers in the differential, extreme pressure lubricants should not be used unless approved by the Cadillac Motor Car Co.

2. Thinning Gear Lubricant with Kerosine

Gear lubricant for the transmission and differential need be thinned only at the beginning of cold weather if a sufficient quantity of kerosine is added to take care of the lowest expected temperature. The lubricant for the steering gear should not be thinned.

3. Special Items for Lubrication Diagrams

The following items cannot be placed on the regular 1000-

mile schedule, so they should be performed at the recommended intervals.

Every day—Check level of liquid in radiator.

Every week—Check tire pressure.

When cold weather starts—Replace lubricant in rear axle and transmission, except 452-C transmission, with lighter lubricants or thin the summer lubricant with kerosine.

The engine oil should be drained and replaced with lighter oil as specified or thinned with the proper amount of kerosine.

Flush radiator and add anti-freeze solution in proportions recommended in the Operator's Manual.

At beginning of warm weather—Drain light or thinned lubricant and replace with fresh lubricant of the proper viscosity for summer driving.

Every 6000 miles—Check level of special oil in shock absorbers.

Every 6000 miles—Remove plug at bottom of oil filter on Cadillac V-12 and V-16 cars and drain out sludge. This can be done on the car by shielding exhaust pipe.

Every 12000 miles—Replace oil filter cartridge on Cadillac V-8 and LaSalle. Remove and clean engine oil pan and screen at same time.

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Engine—				
Capacity.....	8 qts.	8 qts.	9 qts.	10 qts.
Lubricant recommended (S. A. E. viscosity)				
Summer.....	40-50	40-50	40-50	40-50
Winter.....	20	20	20	20
Extreme Pressure Lubricants (See Note 1)				
Fan.....				
345-B, 355-B—Overflow from pressure regulator.				
370-B, 452-B—Gun lubricated with chassis grease.				
Kerosine, thinning gear lubricant with (See Note 2).....				
Rear Axle—				
Capacity in pints.....	6	6	6	6
Lubricant recommended (S. A. E. viscosity).....	200 at 210° F.	200 at 210° F.	200 at 210° F.	200 at 210° F.
Fill to level of overflow opening.				
Special items (See Note 3).....				
Transmission—				
Capacity in pints.....	4½	4½	4½	4½
Fill to level of overflow opening.				
Lubricant recommended (S. A. E. Viscosity).....	200 at 210° F.	200 at 210° F.	200 at 210° F.	200 at 210° F.

Lubricants

	Cadillac No.	Gen. Motors No.
Chassis lubricant (Grease for Alemite fittings).....	G-11	4612-M
Engine oil.....	See recommendations, Page 85	
Transmission and rear axle lubricant—		
Summer (except 452-C transmission).....	A-200	4510-M
Winter (except 452-C transmission).....	A-110	4519-M
452-C transmission (all year).....	A-0200	4593-M
Steering gear lubricant.....	A-0200	4593-M
Water pump grease.....	G-13	4614-M
Wheel and clutch release bearing lubricant.....	G-12	4613-M

LUBRICATION



LUBRICATION SCHEDULE

CADILLAC V-8 355-B

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____

DATE DELIVERED _____

DO NOT WAIT FOR SCHEDULE LUBRICATIONS BEFORE ADDING ENGINE OIL. THE OIL LEVEL SHOULD BE CHECKED EVERY 100 TO 150 MILES AND OIL ADDED IF THE INDICATOR BALL IS BELOW "FULL." THIS IS ESPECIALLY IMPORTANT ON CARS DRIVEN AT HIGH SPEEDS.		LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE											
			1 1000	2 2000	3 3000	4 4000	5 5000	6 6000	7 7000	8 8000	9 9000	10 10000	11 11000	12 12000
LUBRICATION NOS. 6 AND 12 LUBRICATION NOS. 3 AND 9 LUBRICATION NOS. 2, 4, 8 AND 10 LUBRICATION NOS. 1, 5, 7 AND 11	ADD LIQUID TO RADIATOR	WATER OR ANTI-FREEZE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	ADD ENGINE OIL AS NECESSARY	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	STARTER, GENERATOR AND DISTRIBUTOR OIL CUPS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	BRAKE AND RIDE REGULATOR PINS AND CONNECTIONS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	ACCELERATOR, ROCKER SHAFT	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	DOOR HARDWARE	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	GREASE GUN CONNECTIONS	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	WATER PUMP GREASE CUP	WATER PUMP LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	CLUTCH RELEASE FORK	WHEEL BEARING LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	*ADD WATER TO STORAGE BATTERY	DISTILLED WATER	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	CHECK TIRE INFLATION		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	DRAIN AND REPLACE ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	CLUTCH RELEASE BEARING	WHEEL BEARING LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	TRANSMISSION—ADD LUBRICANT	TRANSMISSION LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	REAR AXLE—ADD LUBRICANT	REAR AXLE LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	STEERING GEAR—ADD LUBRICANT	STEERING GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	FREE-WHEELING CONTROL VALVE AND CYLINDER	LIGHT MACHINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	FRONT BRAKE LEVERS	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	SPRING COVERS	GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	WHEEL BEARINGS	WHEEL BEARING LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	SPEEDOMETER DRIVE SHAFT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	**REFILL SHOCK ABSORBERS	SPECIAL OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	**FLUSH COOLING SYSTEM		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	**REPLACE OIL FILTER CARTRIDGE, CLEAN OIL PAN AND SCREEN		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
				EVERY 12,000 MILES										

*IN SUMMER INSPECT BATTERY EVERY 500 MILES OR AT LEAST EVERY 2 WEEKS.

**RECOMMENDED BUT NOT INCLUDED IN LUBRICATIONS 6 AND 12.

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:

THIN REAR AXLE AND TRANSMISSION LUBRICANT—AS REQUIRED FOR LOW TEMPERATURES.

DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING.

RECORD ON OTHER SIDE

Plate 43. Lubrication Schedule and Record Card—Cadillac 355-B.
Typical of LaSalle 345-B

LUBRICATION—Engine Oil Recommendations

ENGINE OIL RECOMMENDATIONS

Type of Service	Summer All Temperatures Above 32° F.	Winter		
		Between 32° and 15° Above	Between 15° Above and 15° Below Zero	Colder than 15° Below Zero
Average Driving (No prolonged high speed driving)	S. A. E. viscosity 40 or 50	S. A. E. viscosity 20	S. A. E. viscosity 10 or S. A. E. viscosity 20 thinned with 1 qt. kerosine to 7 qts. oil	S. A. E. viscosity 10 thinned with 1 qt. kerosine to 7 qts. oil or S. A. E. viscosity 20 thinned with 2 qts. kerosine to 6 qts. oil
Prolonged High Speed Driving	<p>These oils are <i>not</i> suitable for prolonged high speed driving. Change to oil shown below before starting on long trip at speeds above 45 m. p. h.</p> <p>Cadillac Approved "Heavy Duty" Oils—Summer and Winter</p> <p>These are oils having an S. A. E. viscosity of 40-50-60 which are required to meet certain specifications in order to demonstrate their fitness for prolonged high speed driving.</p> <p>NOTE: Approved lubricants vary in their suitability for winter use. If an oil with a high cold viscosity or pour test is used in winter and the car is not kept in a heated garage, add from one to two quarts of kerosine after a long drive at high speed before the car is stored for the night. Also when draining the crankcase, add from one to two quarts of kerosine to the fresh oil, unless starting immediately on a long trip at high speeds.</p>			

IMPORTANT

The Lubrication Charts presented on pages 86 and 88 for the "B" series cars, can be made applicable to the corresponding "C" series cars by making the following changes:

Cadillac 355-C and LaSalle 345-C

Clutch Control (Controlled Free-wheeling) not used.

Brake Assister—Remove plug in cylinder head and inject 1 ounce of S. A. E. No. 10 oil or light machine oil of weight similar to shock absorber oil every 6000 miles.

Shock Absorber Links—No lubrication necessary on LaSalle 345-C cars.

Front Brake Lever—Alemite fitting provided—Apply chassis lubricant at connection with grease gun every 1000 miles.

Special Item—Clean curled hair in brake assister air cleaner by washing with high test gasoline. For normal driving in cities and on hard surfaced roads clean air cleaner once each year. Under extreme conditions, such as continuous driving on dusty roads or in localities where there is considerable dust in the air, cleaning may be required two or more times a year.

Cadillac 370-C and 452-C


Clutch Control (Controlled Free-wheeling) not used.

Brake Assister—For cars ("A," "B" and "C" series) provided with ratchet type grease cup: Fill grease cup with light cup grease (Cadillac No. G-2½—General Motors No. 4534-M) and turn down a few turns every 1000 miles.

Brake Assister—For cars ("A," "B" and "C" series) provided with wick oiler: Fill oiler reservoir with S. A. E. No. 20 engine oil every 6000 miles.

Front Brake Lever—Alemite fitting provided: Apply chassis lubricant at connection with grease gun every 1000 miles.

LUBRICATION



LUBRICATION



LUBRICATION SCHEDULE

CADILLAC 370-B

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____

DATE DELIVERED _____

		LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE											
			1 1000	2 2000	3 3000	4 4000	5 5000	6 6000	7 7000	8 8000	9 9000	10 10000	11 11000	12 12000
LUBRICATION NOS. 6 AND 12	LUBRICATION NOS. 3 AND 9	DO NOT WAIT FOR SCHEDULE LUBRICATIONS BEFORE ADDING ENGINE OIL. THE OIL LEVEL SHOULD BE CHECKED EVERY 100 TO 150 MILES AND OIL ADDED IF THE INDICATOR BALL IS BELOW "FULL." THIS IS ESPECIALLY IMPORTANT ON CARS DRIVEN AT HIGH SPEEDS.												
		ADD LIQUID TO RADIATOR	WATER OR ANTI-FREEZE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		ADD ENGINE OIL AS NECESSARY	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		STARTER, GENERATOR AND DISTRIBUTOR OIL CUPS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		BRAKE AND RIDE REGULATOR PINS AND CONNECTIONS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		ACCELERATOR AND CHOKE ROCKER SHAFT	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		DOOR HARDWARE	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		GREASE GUN CONNECTIONS	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		WATER PUMP GREASE CUP	WATER PUMP LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		CLUTCH RELEASE FORK AND BRAKE ASSISTER	WHEEL BEARING LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		*ADD WATER TO STORAGE BATTERY	DISTILLED WATER	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		CHECK TIRE INFLATION		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	LUBRICATION NOS. 1, 5, 7 AND 11	DRAIN AND REPLACE ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		CLUTCH RELEASE BEARING	WHEEL BEARING LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		TRANSMISSION—ADD LUBRICANT	TRANSMISSION LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		REAR AXLE—ADD LUBRICANT	REAR AXLE LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		STEERING GEAR—ADD LUBRICANT	STEERING GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		FREE-WHEELING CONTROL VALVE AND CYLINDER	LIGHT MACHINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		FRONT BRAKE LEVERS	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		SPRING COVERS	GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		WHEEL BEARINGS	WHEEL BEARING LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		SPEEDOMETER DRIVE SHAFT	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		FAN	CHASSIS LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		DRAIN OIL FILTER AND FLUSH COOLING SYSTEM		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
**REFILL SHOCK ABSORBERS	SPECIAL OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
**CLEAN OIL PAN AND SCREEN		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		

*IN SUMMER INSPECT BATTERY EVERY 500 MILES OR AT LEAST EVERY 2 WEEKS.

**RECOMMENDED BUT NOT INCLUDED IN LUBRICATIONS 6 AND 12.

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:

THIN REAR AXLE AND TRANSMISSION LUBRICANT—AS REQUIRED FOR LOW TEMPERATURES.

DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING.

RECORD ON OTHER SIDE

Plate 45. Lubrication Schedule and Record Card—Cadillac 370-B.
Typical of 452-B

LUBRICATION




Plate 46. Lubrication Chart—Cadillac 370-B. Typical of 452-B

SPRINGS AND SHOCK ABSORBERS

General Description

SPRINGS

The springs are of the same construction on both Cadillac and LaSalle cars with the exception of size. Metal covers are used on all springs and are provided with connections for lubricating the springs.

The eye leaf of the front springs is turned up to form the front eye and down to form the rear eye. This is done to give more clearance at the shackles.

The steering modulator is incorporated at the front end of the left front spring on all cars. This device is described in more detail in the steering gear section.

A rubber bumper is installed on the frame over the front springs back of the center line of the axle. The purpose of this is to increase the caster slightly when the front springs strike the bumper, and thus help to offset the decrease in caster angle which accompanies deflection of the spring.

The spring shackle bolts and bushings are of a new design in which the bolt is threaded into the bushing. The threads not only hold the spring sidewise, but also provide a much greater bearing surface to support the vertical load. They automatically compensate for normal wear and thus, no adjustment is necessary. This threaded type construction eliminates the possibility of binding and side slap due to excessive end play.

Both the shackle bolt and the bushing are made of hardened steel.

Efficient lubrication of the spring shackles is assured as the threads act not only as a reservoir to retain the lubricant but they also distribute it to every part of the bearing surface.

In order to make the links interchangeable, they are made to receive the bolts in opposite directions; that is, each link receives the large end of one bolt and the small end of the other bolt.

SHOCK ABSORBERS

The dash controlled shock absorbers are of the two-way type and are of the same general construction on all cars.

The action of the shock absorbers is regulated by a lever mounted on the instrument panel, which, operating through a system of rods and levers, regulates the spring pressure on the control valves in the shock absorbers.

The degree of control is adjustable to five different positions and is indicated at all times by a dial gauge on the instrument panel.

The design is such that the "Free" position gives a soft "boulevard" ride. The "Firm" position gives the maximum control necessary at high speeds on rolling, gravel roads.

Service Information

1. Spring Arch

Spring arch is the distance from the center line of the bushings to the surface of the spring seat next to the axle. The spring seat surface is at the bottom of top mounted springs and at the top of underslung springs.

To measure the spring arch invert the spring on a timber or I-beam of sufficient length laid across a platform scale and apply a load by means of a jack braced against a joist or timber above. The load specification for each spring is given in the spring chart on Page 91.

2. Shock Absorber Should Contain Proper Amount of Oil

The first thing to be done in cases of complaint on springs or shock absorbers is to check the level of the oil in the shock absorbers.

Only after it is known that all shock absorbers contain the proper amount of oil should any other tests be made to determine the cause of unsatisfactory riding qualities.

SPRINGS AND SHOCK ABSORBERS




Fig. 1
Modulator on Front End of Left
Front Spring




Fig. 2
Rear Spring Front Shackle

Remove clamping screws in both links to remove or adjust shackle bolts.




Fig. 3
Cut-away View of Spring Shackle




Fig. 4
Front Spring Rear Shackle

The rear shackle for the front spring must be set to a specific dimension to prevent interference between the shackle links and the frame. This is necessary because the frame tapers at this point and the frame bracket is offset with respect to the frame side bar.

SPRINGS AND SHOCK ABSORBERS—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Springs				
Type.....	Semi-Elliptic	Semi-Elliptic	Semi-Elliptic	Semi-Elliptic
Length—				
Front.....	39"	39"	39"	42"
Rear.....	58"	58"	58"	60"
Width—				
Front.....	2 $\frac{1}{4}$ "	2 $\frac{1}{4}$ "	2 $\frac{1}{4}$ "	2 $\frac{1}{4}$ "
Rear.....	2 $\frac{1}{4}$ "	2 $\frac{1}{4}$ "	2 $\frac{1}{4}$ "	2 $\frac{1}{2}$ "

SPRING CHART

(See Note 1)

Car Model	Spring Arch		Number of Leaves	†Part Number	†Number on Springs
	*Arch in In.	Load in Lbs.			
Front Springs					
345-B, 355-B.....	2 $\frac{1}{8}$ "	1050	9	1096022	891381
370-B.....	2 $\frac{1}{8}$ "	1225	9	1096023	891383
452-B.....	2 $\frac{5}{8}$ "	1300	10	1096024	896391
355-B and 370-B (156" W. B.).	2 $\frac{1}{8}$ "	1200	9	1096071	891390
345-B, 355-B					
Rear Springs					
345-B, 355-B					
2-Pass. Cars, 5-Pass. Coupes	1 $\frac{1}{4}$ "	1150	9	1096025	891391
5-Pass. Cars (except 5-Pass. Coupes).....	1 $\frac{1}{4}$ "	1300	10	1096026	891392
7-Pass. Cars (except 156" W.B.)	1 $\frac{1}{4}$ "	1375	11	1096084	891394
370-B					
2-Pass. Cars, 5-Pass. Coupes	1 $\frac{1}{4}$ "	1150	9	1096025	891391
5-Pass. Cars (except 5-Pass. Coupes.....	1 $\frac{1}{4}$ "	1375	10	1096083	891395
7-Pass. Cars (except 156" W.B.).....	1 $\frac{1}{4}$ "	1475	11	1096027	891393
452-B					
2-Pass. Cars, 5-Pass. Coupes	1 $\frac{1}{4}$ "	1225	9	1096028	896400
5-Pass. Cars (except 5-Pass. Coupes.....	1 $\frac{1}{4}$ "	1425	10	1096029	896401
7-Pass. Cars.....	1 $\frac{1}{4}$ "	1600	10	1096030	896402
355-B and 370-B (156" W. B.).	1 $\frac{1}{4}$ "	1575	10	1096072	896409

*Measure to bottom of front springs and to top of rear springs.

†Parts Division numbers of seven figures apply to springs with covers and appear only on springs furnished for service. The spring number appears on all springs.

SPRINGS AND SHOCK ABSORBERS




Fig. 1

Front Shock Absorber and Anchorage

Location and Identification of Shock Absorber Valves				
Valve	Front Shock Absorber		Rear Shock Absorber	
	Part No.	Identification	Part No.	Identification
Bumper	47678-D	5	47677-D	1
Snubber	*47677-D	1	*47678-D	5
Control	*47707-D	Steel finish	*47704-D	Copper finish
	*47704-D	Copper finish	*47706-D	Nickel finish

*Used on 345-B, 355-B and 370-B

†Used on 452-B *Also 452-B Front

Adjust clevis on pull rod to locate operating lever in proper position as explained in Fig. 5.

Place hand control lever in No. 3 or central position before adjusting regular connections

Dial Gauge on Instrument Panel

Adjust clevis on pull rod to locate relay levers in approximate vertical position with control lever in No. 3 position.

Idler levers should be in approximate vertical position with control lever in No. 3 position.

With control lever in No. 3 position, adjust yoke if necessary to change position of idler levers.

With control lever in No. 3 position, adjust clevis to bring outer end of front operating levers approximately 1/2 in. ahead of center line at right angles to frame. Rear operating levers should be set 1/2 in. back of center toward rear of car.



With the connections properly adjusted and the control lever in No. 3 position, loosen clamping screws on operating levers and turn operating shafts all the way up in the shock absorbers. Then move hand control lever to No. 5 position and tighten all four clamping screws.

Fig. 5

Adjustment of Shock Absorber Control Valve
Adjustment of connections when necessary, should precede adjustment of control valve

Refill with Delco Shock Absorber Oil. Fill to lower edge of hole.

If more than a small amount of oil is required, it indicates that air may be mixed with the oil due to the low level. This air must be expelled before normal action will be restored. To do this, set hand control lever at No. 5 position, disconnect link attached to axle and move shock absorber arm up and down by hand to circulate oil from cylinder to cylinder. Normal action is indicated by uniform resistance being offered by arm through full range of movement.




Fig. 2

Rear Shock Absorber and Anchorage




Fig. 3

Sectional View of Shock Absorber

When installing new check valves be sure to get them in the correct position as indicated in the above table. Also use second-type check valves as identified by the No. 1 or 5 on the spring seat washer.

Turn operating shaft clockwise in right shock absorbers and counter-clockwise in left shock absorbers as viewed from under the car.

Adjust clevis on pull rod to locate operating lever in proper position as explained in Fig. 5.

Fig. 4

General Arrangement of Ride Regulator Control

Proper adjustment of connections is necessary in order that each of the four shock absorbers be in exact step or agreement with the others. Adjust all connections with control lever in No. 3 position.

SPRINGS AND SHOCK ABSORBERS—Gen. Description—Service Information

General Description

The spring equipment on the "C" series cars is the same as on the "B" models.

The shock absorbers are the same on the "C" series Cadillac cars as on the "B" models with the exception of the control valve assembly, which is of the two-stage type. An additional or auxiliary spring is provided on the control valve to give more rigid control in the No. 4 and 5 positions of the dash ride regulator. This auxiliary spring is effective only for the last .040 in. of valve travel.

The shock absorbers used on the LaSalle 345-C are of slightly different design from those used on the Cadillac cars but they operate on identically the same principle. The LaSalle shock absorber connections are of the fabric type requiring no lubrication.

The lubrication of the "C" series shock absorbers is the same as on the "B" models. See Plate 48, page 92.

Service Information

3. Interchanging "B" and "C" Series Shock Absorbers

Only "C" series shock absorbers are furnished by the Factory Parts Division for "B" and "C" series cars. These shock absorbers can be made to apply to any "B" or "C" cars by changing the control valve to correspond to the control valve used in the shock absorber being replaced. The 345-C shock absorbers, however, may be used only on 345-C cars. See chart, page 92B, showing interchangeability of shock absorbers.

The "C" series shock absorbers, as furnished by the Factory Parts Division, are equipped with the two-stage control valve which may be identified by the inner spring in addition to the outer spring. By removing this valve, which is located under the control lever, and installing the control valve used in the shock absorber being replaced, the late type "C" series Cadillac shock absorbers may be used on all "B" and "C" series Cadillac cars.

In addition to the two two-stage control valves, four of the single-stage type are required to make the shock absorbers furnished interchangeable on "B" and "C" series cars. These valves may be identified by the finish of the springs as follows:

TWO-STAGE TYPE

1060148.....	Copper finish
1060149.....	Steel finish

SINGLE-STAGE TYPE

047704.....	Copper finish
047706.....	Nickel finish
047707.....	Steel finish
047708.....	Copper oxide finish

Since the control valve serves for both bumper and rebound action, it is important that the valve be placed in the shock absorber in the proper position to insure the proper action on the rebound. The valve should be placed in the shock absorber in such a way that the hollow end is toward the inside and the solid end is toward the outside. With the two-stage valve, this means that the end containing the inner spring should be toward the outside of the shock absorber.

All 452-B as well as 452-C shock absorbers should be equipped with the two-stage control valves. Some 452-B cars, however, may be found equipped with single-stage valves and in such cases all four control valves should be changed, using valve, Part No. 1060149, in the front and Part No. 1060148 in the rear shock absorbers.

Two check valves are furnished for service, but replacement should ordinarily be with valves of the same type as the ones removed. Any change in the arrangement of the check valves as furnished on the car and in the shock absorbers supplied for service should be made only in individual cases to correct specific difficulties.

The two check valves may be distinguished by the number stamped on the spring seat washer. The check valves furnished are as follows:

Part No.	Identification
047677	Stamped 1
047678	Stamped 5




Fig. 1

Sectional View of Shock Absorber—
Cadillac 355-C, 370-C, 452-C




Fig. 2

Sectional View of LaSalle 345-C
Shock Absorber

Plate 48A. Shock Absorbers—"C" Series Cars

SPRINGS AND SHOCK ABSORBERS

CHART SHOWING
INTERCHANGEABILITY OF "B" AND "C" SERIES SHOCK ABSORBERS

SERIES (Chassis Unit Nos.)	SHOCK ABSORBERS Part No. and Location	VALVE ARRANGEMENT		
		Control Valve	Check Valves	
			Bumper (Iden- tification)	Snubber (Iden- tification)
345-B all cars	040619 Right Front	Remove 1060149	047678	047677
355-B except 156" W. B.	040617 Left Front	Install 047707 (Steel Finish)	(marked 5)	(marked 1)
355-C before chassis unit 30-47	040621 Right Rear	Remove 1060148	047677	047678
370-B except 156" W. B.	040623 Left Rear	Install 047704 (Copper Finish)	(marked 1)	(marked 5)
370-C before chassis unit 40-32				
	040619 Right Front	Remove 1060149	047678	047677
355-B 156" W. B. only	040617 Left Front	Install 047704 (Copper Finish)	(marked 5)	(marked 1)
370-B 156" W. B. only	040621 Right Rear	Remove 1060148	047677	047678
	040623 Left Rear	Install 047706 (Nickel Finish)	(marked 1)	(marked 5)
345-C before chassis unit 20-266	1054077 Right Front	Remove 1060149	047678	047678
	1054075 Left Front	Install 047708 (Copper Oxide)	(marked 5)	(marked 5)
Also	1054081 Right Rear	Remove 1060148	047678	047678
345-C from chassis unit 20-280 to 20-311	1054079 Left Rear	Install 047706 (Nickel Finish)	(marked 5)	(marked 5)
345-C from chassis unit 20-265 to 20-280	1054077 Right Front	1060149 as furnished	047678 (marked 5)	047678 (marked 5)
	1054075 Left Front			
	1054081 Right Rear	1060148 as furnished	047678 (marked 5)	047678 (marked 5)
Also	1054079 Left Rear			
345-C after chassis unit 20-310				
	040619 Right Front	1060149 as furnished	047678 (marked 5)	047677 (marked 1)
355-C after chassis unit 30-46	040617 Left Front			
370-C after chassis unit 40-31	040621 Right Rear	1060148 as furnished	047677 (marked 1)	047678 (marked 5)
*452-B } all cars	040623 Left Rear			
452-C }				

*Replace control valves of any 452-B shock absorbers having single-stage type.

STEERING GEAR

General Description

STEERING GEAR

Cadillac and LaSalle steering gears are of the hour-glass type. The 452-B steering gear differs from the other Cadillac units in dimensions only. The LaSalle differs from the others in the lighting switch, the length of the column and the mounting flange.

The steering gear is mounted with the sector shaft inclined upward at an angle with the frame to provide sufficient clearance and proper alignment of the steering connecting rod with the steering arm.

The steering wheel has three spokes to give

full vision of the instrument panel. It has a steel core with the hub, the spokes and the rim welded into one piece. The core is covered with hard rubber composition, which construction gives a sturdy yet light, easily gripped wheel.

STEERING MODULATOR

The steering modulator is designed to prevent shimmy and steering wheel whip. To accomplish this the front shackle of the left front spring floats between two pairs of stiff coil springs. With this arrangement, the modulator springs absorb the road shocks which might otherwise be transmitted to the steering wheel.

Service Information

1. Steering Gear Complaints

In case of complaints on hard steering or nervousness, first check the front tires to see that they are properly inflated and installed correctly to preserve proper wheel balance. Also check the wheel balance and adjust as necessary.

Hard steering is more often caused by incorrectly adjusted steering connections than by improper steering gear adjustment. Therefore, before adjusting the steering gear to take

care of a complaint of hard steering, be sure to check the steering knuckles and connections to make sure that they are perfectly free.





Steering wheel nervousness is in many cases due to improper adjustment of the steering modulator. In a case of this complaint, therefore, always inspect this adjustment before attempting to adjust the steering gear itself.

If these operations do not correct the difficulty, the steering gear should be readjusted.


Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Connecting Rod (Drag Link)				
Joint springs—				
Free length.....	$\frac{31}{16}$ "	$\frac{31}{16}$ "	$\frac{31}{16}$ "	$\frac{31}{16}$ "
Pressure in pounds when compressed to $\frac{7}{8}$ in.	175-225	175-225	175-225	175-225
Steering Gear				
Complaints (See Note 1).....				
Clearance between—				
Sector shaft and eccentric bushing				
New limits.....	.00075-.0025"	.00075-.0025"	.00075-.0025"	.00075-.0025"
Worn limits, not over.....	.005"	.005"	.005"	.005"
Ratio (steering gear only).....	17 to 1	17 to 1	17 to 1	17 to 1
Steering wheel diameter.....	18 $\frac{1}{2}$ "	18 $\frac{1}{2}$ "	18 $\frac{1}{2}$ "	18 $\frac{1}{2}$ "

STEERING GEAR



Zero Marks on Steering Gear Arm and Sector Shaft



STEERING GEAR—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Steering Gear—Cont'd				
Turning radius—				
<i>Radius of circle swept by tread center of front tire</i>				
Left				
130 in. W. B.	21' 6"	22' 0"	23' 0"
134 in. W. B.	23' 1"	23' 2"	24' 6"
136 in. W. B.	25' 5"
140 in. W. B.	27' 0"
143 in. W. B.
149 in. W. B.
Right				
130 in. W. B.	21' 1"	21' 10"	22' 0"
134 in. W. B.	22' 8"	22' 4"	22' 4"
136 in. W. B.	23' 5"
140 in. W. B.	24' 2"
143 in. W. B.
149 in. W. B.
Type.....	Hour-glass worm and sector	Hour-glass worm and sector	Hour-glass worm and sector	Hour-glass worm and sector
Unit number location.....
All models—on top of steering gear housing				
Steering Modulator				
Springs—				
Free length (approximately).....	1½"	1½"	1½"	1½"
Pressure in pounds when compressed to 1⅜ in....	95-105	95-105	95-105	95-105

STEERING GEAR

Note: Adjustment of steering connections, knuckle bolts and wheel bearings, inspection of steering cross rod and connecting-rod springs, checking caster, alignment and balance of front wheels, lubricating steering system and checking tire inflation should precede adjustment of steering gear. Remove steering connecting-rod before adjusting steering gear.

Rock wheel as indicated by arrows.





Fig. 1

The modulator shackle should move freely when tested in this manner

Fig. 2
Steering
Modulator

If one of these springs is found broken or weak, install a complete set of four new springs.





Fig. 3

Binding due to incorrect alignment of steering column can be corrected by adjusting support on instrument board.

- ① Back worm adjusting nut off slightly after loosening clamp bolt at the top.



- ③ Turn steering wheel to extreme right and tighten worm adjusting nut until a pull of 2-3 lbs. at rim of steering wheel is necessary to move the wheel toward the left. Check pull after tightening clamp bolt.

Fig. 5

Adjustment for Up-and-Down Play in Worm

Note: If front wheels do not point straight ahead when worm is on high point of sector, change position of steering arm on sector shaft.






Fig. 4

Checking pull necessary to turn steering wheel



Do not loosen these bolts when adjusting worm and sector backlash.

- ④ Turn eccentric to adjust backlash between worm and sector and to give a pull of 5-6 lbs. on steering wheel with sector on high point.

Fig. 6

Adjustments for End Play in Sector Shaft and Backlash Between Worm and Sector

Tire Inflation

ORDINARY DRIVING

All Wheels — — 40 lbs.

HIGH SPEEDS

Front Wheels — — 45 lbs.

TRANSMISSION

General Description

The Synchro-mesh transmission is used on both Cadillac and LaSalle cars and is of the same construction on all models.

The synchronizing mechanism consists primarily of two cone-type friction clutches, one for intermediate and one for high gear. Each clutch consists of a sliding drum lined with a bronze ring and a steel cone on the gear.

The synchronizing drums are operated by rocking yokes pivoted on eccentrics which are fastened to adjusting quadrants on the outside of the transmission case. These quadrants are graduated as a guide to the amount of movement. Moving these plates up or down shortens or lengthens the yoke travel.

The rocking movement of the yokes is accomplished through cams machined on the shifter shaft. These cams engage the rollers of the two plungers which can be moved up and down in cylinders, or dashpots, filled with oil, in the upper part of the yokes.

The synchronizing mechanism is not necessary on the low and reverse gears because shifting into

the low and reverse speed positions is only required when the car is standing still.

Helical gears are used to give complete running silence in all forward speeds, low as well as second. The teeth of these gears are cut at an angle of 45 degrees, giving maximum overlap, and are accurately ground and lapped after hardening, insuring quiet operation under all running conditions.

Gear silence is further assured by the use of large anti-friction bearings which hold the gears rigidly in alignment. The constant-mesh gears on the main shaft run on tapered roller bearings, while the main shaft and countershaft are carried in large ball bearings.

The rear end of the transmission is used as an additional point of support for the engine. This support consists of two arms on the ball joint socket at the rear of the transmission. These arms have flat serrated surfaces which engage similar surfaces on supports mounted in rubber on the frame. Each arm is attached to the support by two through bolts.

Service Information

1. Transmission Requires New Lubricant in Spring-time

The lubrication schedule specifies that transmission lubricant should be drained and replaced at the beginning of warm weather.

This is particularly important on synchro-mesh transmissions because if it is not done, the thinned lubricant will affect the operation of the synchronizing mechanism. The transmission may clash if the lubricant is too thin.

In servicing a transmission for shifting, the very first thing to do is to make sure that the proper amount of the correct lubricant is used.

2. Installation of Speedometer Cable Flange

Two different distances between centers of speedometer driving gear and driven gear are used, one for pinions with 15 to 19 teeth and one for pinions with 20 to 24 teeth. To make this possible, the end of the speedometer cable is eccentric. In one position the cable gives the correct center distance for pinions with 15 to 19 teeth. When revolved 180 deg. the cable gives the correct center distance for pinions with 20 to 24 teeth. The flange on the cable end has the

figures "15-19" on one side and "20-24" on the other side. The cable should always be turned so that the figures corresponding to the number of teeth on the pinion are at the top.

3. Determining Correct Speedometer Gear by Rolling Radius

Occasionally there are owners who desire to install on their cars tires of a different make from standard, or tires of special sizes. Any change in the make or sizes of the tires affects the speedometer reading and, in many cases, a new speedometer gear will be necessary.

It is impossible to specify the correct gear merely from the nominal size of the tire. Tires of various makes differ. It is necessary to know the "rolling radius" in order to determine the correct speedometer gear.

To find the rolling radius of any tire, simply measure the distance from the center of the hub cap of a rear wheel to the pavement.

Before doing this, however, make sure that the tires are inflated to the normal pressure of 40 pounds and that the car is weighed down to its normal load.

Once the rolling radius is known, the correct gear can be determined by referring to the specification table.

TRANSMISSION




Plate 51. Sectional View of Transmission, Typical of all Models

TRANSMISSION—Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Gear ratios—				
Low speed	2.40 to 1	2.40 to 1	2.40 to 1	2.40 to 1
Second speed	1.47 to 1	1.47 to 1	1.47 to 1	1.47 to 1
High speed (direct drive)	1 to 1	1 to 1	1 to 1	1 to 1
Reverse speed	2.49 to 1	2.49 to 1	2.49 to 1	2.49 to 1
Lubrication (See Note 1)				
See Lubrication Section				
Unit number location				
All models—on flange next to flywheel bell housing at upper L. H. side.				
Mainshaft Assembly				
Clearance between—				
Splines on mainshaft and splineways on drums.				
New limits0065-.009"	.0065-.009"	.0065-.009"	.0065-.009"
Worn limit, not over015"	.015"	.015"	.015"
Splines on mainshaft and splineways in sliding gear coupling.				
New limits0005-.0015"	.0005-.0015"	.0005-.0015"	.0005-.0015"
Worn limits005"	.005"	.005"	.005"
Splines on mainshaft and splineways in sleeve for gear.				
New limits000-.001"	.000-.001"	.000-.001"	.000-.001"
Worn limit, not over003"	.003"	.003"	.003"
Splines on mainshaft sleeve and splineways in reverse gear.				
New limits0005-.0015"	.0005-.0015"	.0005-.0015"	.0005-.0015"
Worn limit, not over005"	.005"	.005"	.005"
Clutch connection shaft out of true, not over0025"	.0025"	.0025"	.0025"
Main shaft out of true, not over0025"	.0025"	.0025"	.0025"
Reverse Idler Gear Assembly				
Clearance between bushing and shaft				
New limits0008-.0023"	.0008-.0023"	.0008-.0023"	.0008-.0023"
Worn limit, not over004"	.004"	.004"	.004"
Reaming size for bushing938-.939"	.938-.939"	.938-.939"	.938-.939"
End play in gear, not over025"	.025"	.025"	.025"
Shifting Mechanism				
Clearance between shifter fork and shifter gear or sliding coupling				
New limits012-.020"	.012-.020"	.012-.020"	.012-.020"
Worn limit, not over035"	.035"	.035"	.035"
Shifter shaft lock spring				
Free length (approximately)	1 $\frac{3}{16}$ "	1 $\frac{3}{16}$ "	1 $\frac{3}{16}$ "	1 $\frac{3}{16}$ "
Pressure in pounds when compressed to $\frac{3}{4}$ in.	20-23	20-23	20-23	20-23
Yoke Assembly				
Clearance between—				
Guide block and drum (R. H. high and L. H. second speeds)				
New limits002-.006"	.002-.006"	.002-.006"	.002-.006"
Worn limit, not over010"	.010"	.010"	.010"
Guide block and drum (R. H. second and L. H. high speeds)				
New limits007-.011"	.007-.011"	.007-.011"	.007-.011"
Worn limit, not over015"	.015"	.015"	.015"
Plunger and yoke bore				
New limits002-.006"	.002-.006"	.002-.006"	.002-.006"
Worn limit, not over008"	.008"	.008"	.008"
Plunger main spring—				
Free length (approximately)	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "
Pressure in pounds when compressed to $\frac{9}{16}$ in.	24-26	24-26	24-26	24-26
Plunger valve spring—				
Free length (approximately)	$\frac{5}{8}$ "	$\frac{5}{8}$ "	$\frac{5}{8}$ "	$\frac{5}{8}$ "
Pressure in pounds when compressed to $\frac{1}{16}$ in.	2 $\frac{3}{4}$ -3 $\frac{1}{4}$	2 $\frac{3}{4}$ -3 $\frac{1}{4}$	2 $\frac{3}{4}$ -3 $\frac{1}{4}$	2 $\frac{3}{4}$ -3 $\frac{1}{4}$
Yoke return spring—				
Free length inside loops (approximately)	2 $\frac{3}{16}$ "	2 $\frac{3}{16}$ "	2 $\frac{3}{16}$ "	2 $\frac{3}{16}$ "
Tension in pounds when stretched to 2 $\frac{1}{8}$ in.	8-8 $\frac{1}{2}$	8-8 $\frac{1}{2}$	8-8 $\frac{1}{2}$	8-8 $\frac{1}{2}$
Yoke throw from neutral to applied position	$\frac{3}{32}$ - $\frac{5}{32}$ "	$\frac{3}{32}$ - $\frac{5}{32}$ "	$\frac{3}{32}$ - $\frac{5}{32}$ "	$\frac{3}{32}$ - $\frac{5}{32}$ "

TRANSMISSION




Plate 52. Transmission Synchronizing Mechanism

TRANSMISSION—Specifications—Speedometer Pinion Chart

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Universal Joint				
Clearance between—				
Crosses and bushings				
New limits.....	.0025-.004"	.0025-.004"	.0025-.004"	.0025-.004"
Worn limit, not over.....	.006"	.006"	.006"	.006"
Yoke and ball member bushing				
New limits.....	.005-.007"	.005-.007"	.005-.007"	.005-.007"
Worn limit, not over.....	.010"	.010"	.010"	.010"
Speedometer Gears				
Cable flange (See Note 2).....				
Driving gear (7 teeth)				
Part number.....	848176	848176	848176	848176
Rolling radius, determining (See Note 3).....				

SPEEDOMETER PINION CHART

Car Model	Gear Ratio	Number of Teeth on Pinion	Part Number	Rolling Radius
452-B (7.50 x 18 in. Tires)	4.31 to 1	21	848123	{ 14 to 14 $\frac{3}{8}$ in. (Fast) 14 $\frac{3}{8}$ in. 14 $\frac{3}{8}$ to 14 $\frac{5}{8}$ in. (Slow)
		20	848122	{ 14 $\frac{5}{8}$ to 15 in. (Fast) 15 in. 15 to 15 $\frac{3}{8}$ in. (Slow)
		19 (Standard)	848178	{ 15 $\frac{3}{8}$ to 15 $\frac{7}{8}$ in. (Fast) 15 $\frac{7}{8}$ in. 15 $\frac{7}{8}$ to 16 $\frac{1}{8}$ in. (Slow)
		18	848177	{ 16 $\frac{1}{8}$ to 16 $\frac{3}{4}$ in. (Fast) 16 $\frac{3}{4}$ in. 16 $\frac{3}{4}$ to 17 $\frac{1}{8}$ in. (Slow)
		17	848179	{ 17 $\frac{1}{8}$ to 17 $\frac{3}{4}$ in. (Fast) 17 $\frac{3}{4}$ in. 17 $\frac{3}{4}$ to 18 in. (Slow)
		22	848124	{ 13 $\frac{1}{2}$ to 13 $\frac{7}{8}$ in. (Fast) 13 $\frac{7}{8}$ in. 13 $\frac{7}{8}$ to 14 $\frac{1}{8}$ in. (Slow)
345-B, 355-B (7.00 x 17 in. Tires)	4.36 to 1	21	848123	{ 14 $\frac{1}{8}$ to 14 $\frac{1}{2}$ in. (Fast) 14 $\frac{1}{2}$ in. 14 $\frac{1}{2}$ to 14 $\frac{3}{4}$ in. (Slow)
		20 (Standard)	848122	{ 14 $\frac{3}{4}$ to 15 $\frac{1}{4}$ in. (Fast) 15 $\frac{1}{4}$ in. 15 $\frac{1}{4}$ to 15 $\frac{1}{2}$ in. (Slow)
		19	848178	{ 15 $\frac{1}{2}$ to 16 in. (Fast) 16 in. 16 to 16 $\frac{1}{4}$ in. (Slow)
		18	848177	{ 16 $\frac{1}{4}$ to 16 $\frac{1}{2}$ in. (Fast) 16 $\frac{1}{2}$ in. 16 $\frac{1}{2}$ to 16 $\frac{3}{4}$ in. (Slow)
		23	848125	{ 13 $\frac{5}{8}$ to 14 in. (Fast) 14 in. 14 to 14 $\frac{1}{4}$ in. (Slow)
		22 (Standard on 345-B, 355-B)	848124	{ 14 $\frac{1}{4}$ to 14 $\frac{5}{8}$ in. (Fast) 14 $\frac{5}{8}$ in. 14 $\frac{5}{8}$ to 14 $\frac{7}{8}$ in. (Slow)

TRANSMISSION





Fig. 1

Quadrants for adjusting yoke travel

To adjust yoke travel, move two quadrants for each yoke equal distances and locate them in same position to keep yoke pivots in proper alignment.

Use pry bar with shoulder to prevent burring edges of oil supply hole. Use just enough pressure to engage drum with cone.



Measure travel of yoke from neutral to extreme rear position to determine clearance between rear drum and cone. Repeat in opposite direction on front yoke for front drum and cone.

Second-speed Yoke with Plunger, Part No. 1096038.

3/32 - 5/32 in. Travel

Fig. 2

Measuring Yoke Travel

Remove transmission cover to check yoke travel. Adjust yoke travel by moving quadrants as shown in Fig. 1.




Fig. 3

First-type yokes have the pin slots in line with direction of travel. Second-type yokes have the slots at right angles to the direction of travel between the oil reservoir and dashpot. Only second-type yokes are supplied for service.

For first-type second- and high-speed yokes.

For second-type second speed yoke

For earlier car models




Fig. 4

Service plungers, Part No. 1096037, are furnished with pin unassembled so that pin can be installed in proper position for first- or second-type yokes or for earlier car models. Install pin in position indicated for model on which plunger is to be used.

TRANSMISSION—Speedometer Pinion Chart

SPEEDOMETER PINION CHART—Continued

Car Model	Gear Ratio	Number of Teeth on Pinion	Part Number	Rolling Radius
452-B (7.50 x 18 in. Tires)	4.64 to 1	21 (Standard on 370-B)	848123	14 $\frac{7}{8}$ to 15 $\frac{3}{8}$ in. (Fast) 15 $\frac{3}{8}$ in. 15 $\frac{3}{8}$ to 15 $\frac{5}{8}$ in. (Slow)
		20	848122	15 $\frac{5}{8}$ to 16 $\frac{1}{8}$ in. (Fast) 16 $\frac{1}{8}$ in. 16 $\frac{1}{8}$ to 16 $\frac{3}{8}$ in. (Slow)
		19	848178	16 $\frac{3}{8}$ to 17 in. (Fast) 17 in. 17 to 17 $\frac{3}{8}$ in. (Slow)
		23	848125	13 $\frac{3}{4}$ to 14 $\frac{1}{8}$ in. (Fast) 14 $\frac{1}{8}$ in. 14 $\frac{1}{8}$ to 14 $\frac{3}{8}$ in. (Slow)
		22	848124	14 $\frac{3}{8}$ to 14 $\frac{3}{4}$ in. (Fast) 14 $\frac{3}{4}$ in. 14 $\frac{3}{4}$ to 15 in. (Slow)
		21	848123	15 to 15 $\frac{1}{2}$ in. (Fast) 15 $\frac{1}{2}$ in. 15 $\frac{1}{2}$ to 15 $\frac{3}{4}$ in. (Slow)
		20 (Standard)	848122	15 $\frac{3}{4}$ to 16 $\frac{1}{4}$ in. (Fast) 16 $\frac{1}{4}$ in. 16 $\frac{1}{4}$ to 16 $\frac{1}{2}$ in. (Slow)
		19	848178	16 $\frac{1}{2}$ to 17 $\frac{1}{8}$ in. (Fast) 17 $\frac{1}{8}$ in. 17 $\frac{1}{8}$ to 17 $\frac{1}{2}$ in. (Slow)
		24		13 $\frac{5}{8}$ to 14 in. (Fast) 14 in. 14 to 14 $\frac{1}{4}$ in. (Slow)
		23	848125	14 $\frac{1}{4}$ to 14 $\frac{5}{8}$ in. (Fast) 14 $\frac{5}{8}$ in. 14 $\frac{5}{8}$ to 14 $\frac{7}{8}$ in. (Slow)
		22 (Standard)	848124	14 $\frac{7}{8}$ to 15 $\frac{1}{4}$ in. (Fast) 15 $\frac{1}{4}$ in. 15 $\frac{1}{4}$ to 15 $\frac{1}{2}$ in. (Slow)
		21	848123	15 $\frac{1}{2}$ to 16 in. (Fast) 16 in. 16 to 16 $\frac{1}{4}$ in. (Slow)
370-B (7.50 x 17 in. Tires)	4.80 to 1	20	848122	16 $\frac{1}{4}$ to 16 $\frac{3}{4}$ in. (Fast) 16 $\frac{3}{4}$ in. 16 $\frac{3}{4}$ to 17 $\frac{1}{4}$ in. (Slow)

TRANSMISSION

Remove these nuts to dismount transmission.

Pilots are used for guiding the transmission during its removal and installation to prevent springing the clutch discs.




Fig. 1

Removing Transmission from Engine

When reinstalling the transmission, the front engine support bolts may be loosened to permit the rubber cushions at all supports to equalize; the transmission rear support through bolts are then tightened and the front engine support bolts adjusted as explained in Plate 33, Fig. 4.

Cover
Oil trough for lubricating universal joint

High-speed Yoke

Second-speed Yoke

Drain lubricant before disassembling transmission.

Stop

Fig. 2

Quadrants

The first step in disassembling the transmission is to remove the cover and synchronizing yokes. The remaining operations are performed in the manner and order shown in the following illustrations.

Use tool No. HM 109217 to remove retaining screw

Use puller Tool No. HM 109416-12 to remove universal joint




Fig. 3

Universal Joint Housing and Transmission Rear Support Disassembled
To adjust ball and socket joint, remove gaskets until friction can be felt and then add one .005 in. gasket. Oil grooves in bushing must cross on right side and open toward top and bottom of ball.

TRANSMISSION




Fig. 4 (Left)
Removing retaining screws to remove
universal joint housing




Fig. 5 (Right)
Exploded View of Universal Joint Housing
and Countershaft Rear Bearing Washer





Fig. 6 (Left)
Removing reverse idler gear

Disconnect tube to re-
move release bearing

Fig. 7 (Right)
Removing snap ring from clutch
connection bearing



TRANSMISSION




Fig. 8

Clutch connection and main shaft assemblies moved toward rear of transmission case to unmesh gears




Fig. 9

Removing main shaft assembly from top of case

The main shaft is disassembled by pulling off splined sleeve together with the low and second-speed gears and bearings.




Fig. 10

Removing countershaft gear assembly from top of case

TRANSMISSION—Service Information

4. Replacing Reverse and Low Speed Sleeve in "B" Series Cars

The sleeve, part number 892490, on the main shaft for the first and reverse speed gear of the "B" series transmission, has been furnished in two lengths. Sleeves of one length are $3\frac{3}{4}$ in. long while the other is $\frac{1}{8}$ in. longer.

When the longer sleeve is installed in place of the shorter, it may not be possible to get sufficient travel on the second speed synchronizing drum without first removing the $\frac{1}{8}$ in. spacer, part number 890493, located between the rear end of the sleeve and the rear main shaft bearing.

Whenever the sleeve is removed from a transmission for replacement, it should be compared with the new sleeve and if the new sleeve is $\frac{1}{8}$ in. longer, the spacer should be removed. The longer sleeve fully compensates for the spacer.

5. Installing Second-Type Gear Shift Levers

Beginning with transmission unit 30-2250, a second type gear shift lever is used. This lever differs from the first type lever in that the knob on the lower end is .010 in. oversize and has its sides machined flat to fit more accurately in the shifter shaft notches and thus prevent side-play. Only this second type lever is being furnished by the Factory Parts Division under Part No. 890567 for both "B" and "C" series transmissions.

When installing this lever in the transmission top cover, the lower end of it must be fitted into the notches in the shifter shafts. An accurate fitting is essential to quiet operation.

A clearance of .000 to .002 in. must be maintained between the side of the knob of the lever and the second and high speed shifter shaft when in the low and reverse speed position and between the knob and the low and reverse speed shifter shaft when in the second and high speed position. See figure below.

If binding occurs between the low and reverse speed shifter shaft and the lever knob when in the second or high speed position, dress down the side of the gear shift lever knob. If binding occurs at the second and high speed shifter shaft when in the low or reverse speed position, grind the notch deeper in the low and reverse speed shifter shaft.

Care should be taken to avoid removing too much metal when dressing down the lever knob or the shifter shaft. Not more than .002 in. clearance should be allowed.

It is important that these clearances be checked while the lock springs for the shifter shaft are assembled in the transmission cover. Also fit the lever in the second and high speed position before fitting the low and reverse speed position.

Whenever a transmission top cover is removed for the installation of a new transmission control lever, the low and reverse shifter shaft should be inspected to see whether the nut that holds the shifter fork on the shaft is locked by means of a lock washer or a cotter pin. If a lock washer is used, the washer and nut should be removed and a $\frac{1}{2}$ in. x 20 castellated nut, part number 122761, installed. The shaft should be drilled and a cotter pin installed to lock the nut in place. A loose nut at this point may sometimes cause a vibration rattle in the transmission.




Plate 56A. Adjustment of Gear Shift Lever

WHEELS, RIMS and TIRES—Service Information

4. Front Wheel Bearing Adjustment

The procedure to follow in adjusting the front wheel bearings is first to make sure that the wheel is all the way on the spindle. Then tighten the adjusting nut as tight as possible by hand using a wrench with a handle 12 to 15 in. long, after which back off the nut one third turn or two flats. In other words, if the locking device cannot be placed in position without changing the adjustment, tighten instead of loosen the adjusting nut until it can be secured with the locking device. It is preferable to have the adjustment on the tight side rather than the loose side provided it is not necessary to tighten the nut more than $\frac{1}{2}$ the distance to the next cotter pin slot.

It is also a good plan to turn the wheels toward the right side when adjusting the left wheel bearings and toward the left side when adjusting the right wheel bearings to assure full release of the brakes.

CAUTION: When adjusting the front wheel bearings, care should be taken not to mistake play in the knuckle bolt for play in the wheel bearings.

5. Removing and Installing Wire Wheel Trim Rings

The removal and installation of the chromium plated trim rings on wire wheels is a simple operation and requires the use of only two special tools which can be made in any service station.

For removing the rings, all that is needed is a screw driver with the blade bent at a 90° angle about two inches from the end, and ground down to a thin flat edge as shown in Fig. 1. By slipping this edge under the ring and prying up at several points, the ring can be easily removed with little or no damage to the finish of the wheel.




Fig. 1. Bent screwdriver for removing wire wheel trim rings.

A padded block is all that is required for installing the rings. A block of wood about 6 in. x 3 in. x $\frac{3}{4}$ in. should be shaped at one end to fit the curve of the ring and this end covered with a piece of leather or felt to protect the finish of the wheel. See Fig. 2. The leather or felt should extend high enough

along the sides of the block so that there will be no possibility of the wood touching the wheel. Any nails, screws or tacks used to hold the padding should be countersunk to protect the wheel finish.

To install the ring, simply place it in the proper position on the wheel and tap it into place using the block. It should be tapped carefully around the entire circumference to prevent




Fig. 2. Padded block for installing wire wheel trim rings.

damage. If sufficient care is taken, little or no scratching of the wheel finish should result.

6. Removing and Installing Large Hub Caps on 452-C

The large hub caps used on 452-C cars are held in place in the same manner as the hub caps used on V-8 and V-12 cars and may be removed and installed in the same way except that the sponge rubber in the disc must be compressed sufficiently to allow the lugs to engage or disengage. To remove, simply turn the hub cap to the left until the catch is felt to release and then pull straight out.

To install the hub cap, place it in such a position that the lugs of the cap fit into corresponding notches in the hub and, pressing the hub cap firmly against the wheel, turn the hub cap its full limit—about one-sixth of a turn to the right.

It is important that the hub cap be pressed firmly against the wheel when installing in order to compress the sponge rubber in the disc enough to permit the hub cap lugs to catch securely. If the hub cap is not securely caught and turned the limit, it may come off and be lost.

Owners should be cautioned to watch filling station attendants who remove the hub caps to inflate the tires, to make sure that the hub caps are correctly installed and firmly caught.

WHEELS, RIMS AND TIRES

General Description

WHEELS AND RIMS

The wheels are of small diameter, the rim diameter being 17 in. on the 345-B, 355-B and 370-B and 18 inches on the 452-B.

Two types of wheels, wire wheels and demountable wood wheels, are furnished. Wire wheels are standard. Disc wheels are not supplied; instead, detachable discs are furnished for installing on the wire wheels to give the appearance of disc wheels. The wood wheels are interchangeable on the same hubs and carriers as the wire wheels.

Drop center rims are used. These rims have a strong section and are free from noises.

TIRES

The tires are of unusually large cross section, especially designed for the drop center rims. The correct pressure for these tires is 40 pounds front and rear. A pressure of 45 pounds should be carried in the front tires on cars driven at high speeds.

Service Information

1. Front Wheel Bearing Adjustment

The ball bearings in the front wheels should not be adjusted too tight. They should be adjusted so that a very slight amount of play or looseness may be discerned. The procedure to follow is first to make sure that the wheel is all the way on. Then turn the adjusting nut up by hand as far as possible and back it off to the second cotter pin slot. In other words, if the locking device cannot be placed in position without changing the adjustment, loosen instead of tighten the adjusting nut until it can be secured with the locking device.

CAUTION: When adjusting the front wheel bearings, care should be taken not to mistake play in the knuckle bolt for play in the wheel bearings.

2. Mounting Wheels

When mounting the road wheels, it is important that the retaining nuts be drawn up evenly so that the wheel rests squarely on the mounting surface before turning the nuts down tight. If this precaution is not taken the wheels may run out slightly, resulting in wobbling and increased tire wear.

The mounting nuts on the wheel should be drawn up in the same way as those on the demountable rims formerly used, drawing up the nut directly opposite the one last drawn up until all have been drawn up equally. After all the nuts have been drawn up in this manner they should be securely tightened. If this procedure is followed, there should be no run-out.

In mounting the wheels, provision has been made for holding the mounting nuts securely in place by machining both the cones of the nuts and the sockets of the wheel mounting flange to a slightly elliptical shape. Thus, when the nuts are drawn up tightly and the long axis of the nut cone fits the long axis of the socket, the nut is held securely.

When the nut is being drawn up, an increase in resistance will be apparent as the long axis of the nut is across the short axis of the cone. In some cases the resistance may be sufficient to seemingly indicate that the nut is secure. After the opposite nut has been tightened, however, tension may be reduced sufficiently to permit making another half or even full turn of the first nut.

3. Tire and Wheel Balancing

The tires are balanced to offset the weight of the valve stems. If a tire is removed it must be reinstalled in its original position with respect to the rim, otherwise the tire and wheel will be unbalanced. A small red or black dot is accordingly branded in the rubber on the side of each tire. This mark must be placed in line with the valve stem.

Replacement tires procured on the open market are not always balanced to the same degree of accuracy. Therefore, when new tires are installed to replace the original tires on cars used in high-speed service, it is recommended that they be tested for balance and the wheels rebalanced, if necessary, in order to avoid the possibility of tramp or shimmy at high speeds.

This balance can ordinarily be effected by shifting the tire around in relation to the tube so that the valve stem will be at the lighter side of the tire.

In case the wheel itself is out of balance, the wheel must be rebalanced. This may be done as follows:

Remove the wheel from the axle. Remove the felt washers and clean out the grease from the bearing. Mount the wheel upright on a suitable stand (a steering knuckle clamped in a vise will do) and test the wheel by rocking it slowly, allowing it to stop itself. When the wheel stops, the heavier point will be at the bottom. Mark this point and the uppermost point of the wheel; then turn the wheel until these points are in a horizontal position. Add test weights or clay to the light side until the wheel balances in the horizontal position. Remove the clay or test weight and weigh it. Weigh out an equal amount of solder and sweat it on the rim of the wheel, or on the spoke in the case of wire wheels, as near the light point as possible.

When this is accomplished, if the wheel has been balanced with the tire off, the tire must be installed in the proper position to preserve this balance. The wheel bearings should then be repacked with approved wheel bearing grease and the felt washers reinstalled before putting the wheel on the car again.

WHEELS, RIMS AND TIRES




Fig. 1

Detachable Disc for Installation on Wire Wheel to give appearance of Disc Wheel. Wood Wheels are interchangeable on same hubs and carriers as wire wheels.




Fig. 2

Sectional View of Tire and Drop Center Rim




Fig. 3

Typical Front Wheel Hub




Fig. 4

Typical Rear Wheel Hub

WHEELS, RIMS AND TIRES—Specifications

Specifications

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Bearings				
Adjustment (See Note 1).....
Wheels and Rims				
Brake drum out of round, not over.....	.005"	.005"	.005"	.005"
<i>Checked with drum mounted on wheel.</i>				
Felloe out of true (radial or lateral run-out), not over.....	$\frac{1}{32}$ "	$\frac{1}{32}$ "	$\frac{1}{32}$ "	$\frac{1}{32}$ "
Mounting Wheels (See Note 2).....
Rim				
Type.....	Drop center	Drop center	Drop center	Drop center
Diameter.....	17"	17"	17"	18"
Width.....	4.00"	4.00"	4.19"	4.19"
Tires				
Balancing mark location.....
<i>Mark on tire should be placed in line with valve stem</i>				
Balancing tires and wheels (See Note 3).....
Pressure in pounds—				
Normal				
Front.....	40	40	40	40
Rear.....	40	40	40	40
Size.....	7.00 x 17"	7.00 x 17"	7.50 x 17"	7.50 x 18"

WHEELS, RIMS AND TIRES




Fig. 1 (Left). Starting the first tire bead over the rim flange

Deflate the tube completely and remove the rim nut on the valve stem. Loosen both beads from the bead seats, using a tire tool if necessary. Stand on the tire, opposite the valve stem, with the feet about 15 in. apart, to force the bead into the rim well.

Fig. 2 (Right). Prying short lengths of the first tire bead over the rim flange

Insert two tire tools, about 8 in. apart, between the bead and the rim flange near the valve. Leaving one tool in position, pry short lengths of the bead over the flange with the other until the entire bead has been removed.





Fig. 3 (Left). Removing the wheel from the second tire bead

Remove the inner tube before attempting to remove the second bead. Raise the wheel to an upright position, insert a tire tool between the second bead and the rim flange at the top side of the wheel and pry the wheel out of the tire. This operation will be simplified if the soft tip of the bead is first coated with vegetable oil soft soap.

WHEELS, RIMS AND TIRES




Fig. 1 (Left). Installing the first tire bead over the rim flange

Coat both beads of the tire with vegetable oil soft soap before reinstalling the tire. Inflate the tube until barely rounded out and insert in the tire with the stem at the tire balancing mark. Place the tire on the rim, guiding the valve through the hole, and apply the rim nut loosely. Push the bottom bead down into the well at the valve and force the remaining portion of the bead over the rim flange, using a tire tool if necessary.

Fig. 2 (Right). Installing the second tire bead over the rim flange

Force the top bead over the rim flange and into the well at the point opposite the valve. Kneeling on this side of the tire to hold it in the well, pry short lengths of the remaining portion of the bead, working around the rim until the entire bead is in place. Always keep as much of the top bead in the well as possible while prying the remainder of the bead.





Fig. 3 (Left). Testing tube for pinching

Remove the rim nut and push the valve stem back into the casing as far as possible without letting go of the stem to make certain that the tube is not pinched under the bead; then reapply the rim nut. With the wheel flat on the floor, inflate the tire slowly, making sure that both sides of the tire are centered on the rim.

1972


PRELIMINARY SERVICE INFORMATION

CADILLAC 345-B, 370-B, 442-B

LASALLE 345-B

345-B, 370-B, 442-B

DO NOT REMOVE




FILE COPY
DO NOT REMOVE

Service Department
CADILLAC MOTOR CAR COMPANY
DETROIT, MICHIGAN

PRELIMINARY SERVICE INFORMATION

CADILLAC 355-B, 370-B, 452-B
LASALLE 345-B



FILE COPY
1957 SERVICE

Service Department
CADILLAC MOTOR CAR COMPANY
DETROIT, MICHIGAN

CONTENTS

	<i>Page</i>
Front Axle	3
Rear Axle	4
Body	6
Brakes	13
Clutch	15
Cooling System	21
Electrical System	22
Engine	27
Exhaust System	32
Frame	33
Gasoline System	34
Lighting System	40
Lubrication	43
Springs and Shock Absorbers	46
Steering Gear	48
Transmission	49
Wheels, Rims and Tires	53
Tools	56
Specifications	57 to 63, inclusive

Copyright, 1932
Cadillac Motor Car Co.,
Detroit, Mich.
U. S. A.

Front Axle

Assembly	}	*(345-B, 355-B, 370-B, (452-B)
Brake Dust Shields		
Steering Cross-rod		
I-beam		
Steering Arm		
Steering Knuckles--Same on all models.		

The front axles on the 345-B, 355-B and 370-B are alike and are similar in construction to the Cadillac 355-A axle. See Fig. 1. The important differences are in the width of the tread and the brake dust shields.

Toe-in, camber and caster specifications are the same as on the corresponding "A" series cars. The steering knuckles are not interchangeable with the "A" series knuckles because of slight differences in angles. Wedge plates are to be used when necessary between the front springs and the spring seats on the I-beam, to give the proper caster.

The wheel tread has been increased to 59 $\frac{7}{8}$ in. on all models to give a smaller turning radius.

A change has been made in the steering cross-rod joint. The pivot seats have a different curvature and are under heavier spring tension. The joint is now fitted to a definite tightness as the friction at this point has an important effect in steadying the front wheels.

The tightness of the cross-rod joints should be such that a pull of 12 to 25 pounds at the end of a 6-in. wrench is necessary to turn the pivot in the socket. This test




Fig. 1. Sectional view of front wheel hub and steering knuckle with details of front brake control

*Assemblies and parts listed at the beginning of each group are interchangeable on models listed together in parentheses.

CONTENTS

	<i>Page</i>
Front Axle	3
Rear Axle	4
Body	6
Brakes	13
Clutch	15
Cooling System	21
Electrical System	22
Engine	27
Exhaust System	32
Frame	33
Gasoline System	34
Lighting System	40
Lubrication	43
Springs and Shock Absorbers	46
Steering Gear	48
Transmission	49
Wheels, Rims and Tires	53
Tools	56
Specifications	57 to 63, inclusive

Copyright, 1932
Cadillac Motor Car Co.,
Detroit, Mich.
U. S. A.

is made by disconnecting the pivot from the steering arm, reinstalling the retaining nut on the pivot and turning the pivot with a wrench as shown in Fig. 2. The pivot should be well lubricated when making this test.

The spring tension can be adjusted by installing thin shims as necessary. If the spring tension is too great, shims should be installed between the cap and the housing. To increase the spring tension, shims should be installed under the take-up spring.

The 452-B front axle is of the same construction as the axle used on the other models except for dimensions and the drop of the I-beam. The steering arms are slightly longer because of the larger brakes and for this reason the cross-rod is shorter than in the other models.

Except as noted all service operations and adjustments on the front axle are the same as on the "A" series cars.




Fig. 2. A pull of 12 to 25 pounds at the end of a 6 in. wrench should be necessary to turn the pivot in the socket at the cross-rod joints

Rear Axle

Assembly	{	(345-B, 355-B) (370-B) (452-B)
Differential Carrier Assembly		
Housing Assembly --(345-B, 355-B, 370-B) (452-B)		
Axle Shafts--Same on all models.		

The rear axles have been completely redesigned to reduce unsprung weight to a minimum. A new process of heat treatment has made it possible to reduce the size of the gears and make the axle smaller and lighter and, at the same time, stronger than before.

The differential carrier has been strengthened by heavier webbing. See Fig. 3. Bronze washers are used to take the thrust of the differential side gears and pinions the same as in the late "A" series axles.

The tread has been increased to 61 inches on all models.

The oil seals and oil seal tubes have been eliminated in the new axles. Instead, baffle plates in the axle housing, fitting closely around the shafts, serve to keep excessive lubricant from getting into the wheel bearings. Two baffles are used for each shaft, one near each end. There is also a threaded bushing in the outer end of each housing tube which functions as an oil return. The threads in this bushing take the place of those formerly machined on the inner end of the axle shafts.

The differential carrier in the new axles is reinforced by a plate installed between the differential cover and the axle housing and fitting over the cap bolts. This reinforcement adds considerably to the rigidity of the differential carrier. See Fig. 4.

A tube has also been added to the breather to prevent clogging from the accumulation of dirt on the differential carrier. It extends from the breather down to the under side of the carrier.

The construction of the 370-B rear axle is the same as that of the 345-B and 355-B axle with the exception of the gear ratios. The 370-B ratios are slightly lower than the corresponding ratios for the 8-cylinder cars.

The 452-B rear axle is of the same construction as that of the other models but the gear ratios are different and the axle is somewhat larger to accommodate the heavier car.

Service operations on the rear axle are the same as on the "A" series cars.

Engine speeds for "A" and "B" series cars with various gear ratios and tire sizes

Car Model	Gear Ratio	Tire Size	Engine Speed at 60 M. P. H.
345-A } 355-A }	4.54:1	$\begin{pmatrix} 6.50 \times 19'' \\ 7.00 \times 18'' \end{pmatrix}$	3000
345-B } 355-B }	4.36:1	7.00 x 17"	2990
345-A } 355-A }	4.91:1	$\begin{pmatrix} 6.50 \times 19'' \\ 7.00 \times 18'' \end{pmatrix}$	3250
345-B } 355-B }	4.60:1	7.00 x 17"	3145
370-A 370-B	4.54:1 4.60:1	7.50 x 18" 7.50 x 17"	2910 3040
370-A 370-B	4.91:1 4.80:1	7.50 x 18" 7.50 x 17"	3150 3175
452-A 452-B	4.39:1 4.31:1	7.50 x 19" 7.50 x 18"	2725 2760
452-A 452-B	4.75:1 4.64:1	7.50 x 19" 7.50 x 18"	2950 2970

FILE COPY
DO NOT REMOVE




Fig. 3. Sectional view of rear axle with details




Fig. 4. The reinforcement plate in the rear axle adds rigidity to the differential carrier

The bodies on the new models are entirely new both in appearance and construction details. They have a large number of new features of special interest to service.

In much of the frame-work construction glued joints have been eliminated, and metal brackets are used to hold the wood parts in place without touching each other; this arrangement reduces the possibility of squeaks.

The body panels are of improved one-piece design, there being no separate mouldings. The drip mouldings are stamped into the roof rail panel, forming an integral part of it. This construction eliminates all possibility of wood rot and squeaks at these points.

The insulation of the body against drumming noise has been further improved. Instead of using a coat of plastic material, the inside of the cowl from the dash, back to the pillar, is covered with a $\frac{3}{8}$ -in. felt insulator glued securely in place.

The insulation against engine heat is also effective. The 345-B body has a $\frac{3}{16}$ in. insulator inside of the dash, while the other models have a $1\frac{1}{4}$ in. insulator between the dash and the "dummy" dash or cover. Comfort in the driver's compartment is further assured by ventilation through a large ventilator in the top of the cowl. The openings in the toe-boards for the controls are closed with tight fitting rubber grommets. There is also a $\frac{3}{8}$ in. felt pad under all carpets and under the front and rear seat cushions. All

Gear Ratios

The new axle gear ratios are higher than the corresponding ratios formerly used to offset the effect of the smaller tires. The new gear ratios are as follows:

	345-B	355-B	370-B	452-B
High	4.36 : 1	4.35 : 1	4.60 : 1	4.31 : 1
Low	4.60 : 1	4.60 : 1	4.80 : 1	4.64 : 1

The table page 5 shows that the engine speed at 60 miles per hour for the new gear ratios is approximately the same as for corresponding "A" series ratios. In specifying gear ratios, best results will be secured by selecting the new ratios listed just below the ratio customarily specified for the same type of "A" series car.

Body

doors and body panels have a new type of insulation, which is glued to the inside of the panels.

Extensive changes have also been made in the seat cushion construction. The rear cushion is 1 in. deeper and Marshall springs are used throughout. The front seat cushion is in two parts, only the driver's half being adjustable. The adjusting mechanism operates on the same principle as on the "A" series but is controlled by a crank instead of a T-handle.

The body mountings are of the same type as those used on the 370-A cars, except that rubber shims are used instead of fabric pads at the two front bolts on




Fig. 5. General arrangement of the driving compartment




Fig. 6. The driving compartment is well insulated against engine heat

New improved locks are used, which permit the locking of all doors, including the right front door, from the inside.

To lock a door from the inside the remote control handle is lifted up. To prevent the driver from locking himself out all doors are arranged so that the inside locking mechanism is automatically released by the movement of the lock bolt when the door is closed.

To lock the car from the outside, all doors except the right front door must first be locked from the inside by lifting the remote control handle. The right front door is then locked with the key on the outside in the conventional manner.

A new method of retaining the outside door handles is used. The handle is fastened with a set screw through the face of the lock, rather than a screw in the end of the shank. This screw is concealed underneath the chromium plated lock facing plate. To reach the retaining screw it is necessary to remove this

Fig. 7. (Right). Bronze bushings and chromium plated hinge pins reduce the possibility of hinges rusting and sticking





Fig. 8. (Below). Tools (No. HMB-99) for servicing hinge pin bushings



each side. The body bolts should be tightened just enough to flatten the lock washers.

Doors

The door hinges are heavier and only two of these heavy hinges are required on each door.

Two bronze bushings are used in each hinge and all hinge pins are chromium plated (See Figs. 7 and 8). Lubrication is facilitated by an oil hole (Fig. 9) on the inside of each hinge, accessible with the door open. All-Weather Phaetons have improved Fleetwood type barrel hinges, while the hinges on the open models are all concealed.

New type self-adjusting dove tails are another new feature on the doors, a construction which will greatly facilitate door alignment.

facing plate by removing the two screws that hold it, turning the lock handle to bring the lock bolt flush with the face of the lock, and swinging the lock plate out to disengage the prongs at the inside edge of the facing. The set screw can then be taken out to release the lock handle. See Fig. 10.

The inside door handles (window-regulator handle, windshield regulator handle and remote control handles) are serrated on their shafts and locked in place by a small plunger located inside of the handle hub. The removal of these handles requires a special tool (Fig. 11) for releasing the locking plungers. Tool No. HMB-127 is supplied for this purpose.

Windows

The window regulators on all the new models have been strengthened and improved to insure easier operation. The regulators are serviced in the same manner as those in the "A" cars. Because the front edge of the front door windows is on the same angle as the windshield, these windows have a vertical guide and do not depend on the glass run channels.




Fig. 9. The oil hole in the hinge is on the inside and may be reached by opening the door

The glass in the front doors of all closed cars operates between two rubber rollers at the lower side of the window opening. The inside roller is fastened to the top edge of the regulator board and must be removed to remove the window glass. See Fig. 12.

The glass run channels are made of one piece, eliminating possibility of noise at the joints. The channels are of a new type, with chromium plated edges and sponge rubber inserts covered with cloth.

An important feature of the new models is the use of one-piece garnish mouldings with invisible fastenings. Because the fastenings are invisible it is very necessary to know where they are located on the




Fig. 10. Door handles are held in place by a set screw concealed under the lock facing plate

various mouldings before proceeding to remove the moulding.

In general the method is to hold the bottom of the garnish moulding with a lock of either the bayonet or trigger type. The sides and top of the mouldings on Fleetwood bodies are held by plates which slip under the glass run channels and are held by screws through the channels. On the Fisher bodies the screws go through the garnish moulding and are plainly visible. The bayonet type lock is shown in Fig. 13 and the trigger type in the insert.




Fig. 11. Special tool No. HMB-127 is necessary for removing all inside handles in closed cars

After removing the moulding screws, which can be located by running a screwdriver up and down the channel, the garnish moulding can be removed by pulling out at the top and lifting up if the bayonet type lock is used or by releasing the trigger with a screwdriver if the trigger type is used. Various combinations of screws and fastenings are used on the different windows and body styles. The diagrammatic sketches in Figs. 14 to 25, inclusive, indicate the location and type of fastening.

The window glass is removed in the same way as on the "A" cars after the garnish moulding and the inside roller at the top edge of the regulator board are removed.

Windshield

The windshields on all closed cars are of the VV type. The windshield regulator is of the same general construction as the "A" models, but with major improvements.

The windshield is removed in the same manner as on the "A" cars after the garnish mouldings and regulator board are removed.

To remove the windshield garnish moulding and regulator board proceed as follows:

1. With Fisher bodies, remove the nine visible screws from the top and sides of the garnish moulding. On Fleetwood bodies, raise the windshield and remove the concealed screw from the lower ends of the channel. Also remove the visible screws from the garnish moulding.
2. Remove garnish moulding.
3. Remove inside visor on L. H. side by taking out two screws extending through the regulator board. (Visor special equipment on R. H. side.)
4. Remove two screws at R. H. end of regulator board.
5. Remove windshield wiper motor.
6. Loosen trim from bottom of regulator board.
7. Lift trim and remove four screws in regulator board. (There are two screws on each side about 10 inches from center of board.)
8. Remove regulator board.

The windshield cleaner is of the swinging arm type with two arms operated in tandem by a single motor




Fig. 12. Front doors have two rubber rollers for holding the window glass rigid in the open positions

on the inside of the windshield regulator board. The tandem linkage is between the windshield regulator board and the steel header. To service it, the regulator board must be removed.

The rear view mirror is of the ball-joint type and is fastened to the lower edge of the windshield regulator board on the closed cars. To remove the mirror bracket it is necessary to remove the windshield garnish moulding.




Fig. 13. View of door window garnish moulding removed to show invisible plates and bayonet locks. Insert shows trigger lock construction used on some bodies.




Fig. 14. Front door, all models—Fisher body
7 Visible screws in garnish moulding
1 Trigger lock under garnish moulding




Fig. 15. Rear door, Cadillac—Fisher body
7 Visible screws in garnish moulding
1 Bayonet lock under finishing panel




Fig. 16. Rear door and rear quarter, LaSalle—Fisher body
Rear quarter, Cadillac—Fisher body
7 Visible screws in garnish moulding
1 Bayonet lock under garnish moulding




Fig. 17. Partition, Imperial Model—Fisher body
7 Visible screws in garnish moulding
3 Bayonet locks in back panel
1 Trigger lock at center of top panel; also 1 Plate at each end




Fig. 18. Windshield, all closed models—Fisher body
9 Visible screws in garnish moulding
6 Plates in finishing panel; also 2 screws in center under the panel
2 Clips in lower garnish moulding inside ash receiver hole; also 1 plate at each end
Windshield, all models—Fleetwood body
Same as Fisher except lower screw in garnish moulding at each side is replaced with plate and invisible screws




Fig. 19. Front door, all models except Imperial and Town Car—Fleetwood body
3 Invisible plates under glass channel runs at top and rear side of window
2 Screws through door facing at front side of window
2 Bayonet locks under finishing panel




Fig. 20. Front door, Imperial and Town Car—Fleetwood body

- 3 Invisible plates under glass channel runs at top and rear side of window.
- 2 Screws through door facing at front side of window
- 1 Trigger lock under garnish moulding




Fig. 21. Rear door, all models—Fleetwood bodies

- 4 Invisible plates under glass channel runs
- 2 Bayonet locks under finishing panel




Fig. 22. Rear quarter, all models—Fleetwood body

- 3 Invisible plates under glass channel runs
- 2 Bayonet locks under finishing panel




Fig. 23. Partition, Imperial Model—Fleetwood body

- 7 Invisible plates under glass channel run
- 3 Bayonet locks under back panel
- 1 Trigger lock at center of top panel; also 1 plate at each end




Fig. 24. Arm rest, all models—Fleetwood body

- 1 Bayonet lock at center; also small brad in lower corner of panel. To remove panel drive brad through panel and lift up




Fig. 25. Front seat, all models—Fleetwood body

- 3 Bayonet locks under back panel
- 3 Trigger locks under top panel

BODY STYLES AND JOB NUMBERS

Fisher Bodies

When ordering chassis parts affected by wheelbase, the *Body Job Number* must be given the same as when ordering body parts.

BODY TYPE	JOB NUMBER	WHEELBASE
345-B (LaSalle)		
2-Pass. Coupe.....	32-678	130"
2-Pass. Convertible Coupe.....	32-668	130"
5-Pass. Town Coupe.....	32-672	130"
5-Pass. Sedan.....	52-659	130"
5-Pass. Town Sedan.....	32-652	136"
7-Pass. Sedan.....	32-662	136"
7-Pass. Imperial Sedan.....	32-663	136"
355-B (Cadillac)		
2-Pass. Roadster.....	32-8-155	134"
2-Pass. Coupe.....	32-8-178	134"
2-Pass. Convertible Coupe.....	32-8-168	134"
5-Pass. Sedan.....	32-8-159	134"
5-Pass. Phaeton.....	32-8-256	140"
5-Pass. Phaeton with Sliding Wind- shield.....	32-8-280	140"
5-Pass. All-Weather Phaeton.....	32-8-273	140"
5-Pass. Sport Phaeton.....	32-8-279	140"
5-Pass. Coupe.....	32-8-272	140"
5-Pass. Sedan.....	32-8-259	140"
5-Pass. Town Sedan.....	32-8-252	140"
7-Pass. Sedan.....	32-8-262	140"
7-Pass. Imperial Sedan.....	32-8-263	140"

BODY TYPE	JOB NUMBER	WHEELBASE
370-B (Cadillac)		
2-Pass. Roadster.....	32-12-155	134"
2-Pass. Coupe.....	32-12-178	134"
2-Pass. Convertible Coupe.....	32-12-168	134"
5-Pass. Sedan.....	32-12-159	134"
5-Pass. Phaeton.....	32-12-256	140"
5-Pass. Phaeton with Sliding Wind- shield.....	32-12-280	140"
5-Pass. All-Weather Phaeton.....	32-12-273	140"
5-Pass. Sport Phaeton.....	32-12-279	140"
5-Pass. Coupe.....	32-12-272	140"
5-Pass. Sedan.....	32-12-259	140"
5-Pass. Town Sedan.....	32-12-252	140"
7-Pass. Sedan.....	32-12-262	140"
7-Pass. Imperial Sedan.....	32-12-263	140"
452-B (Cadillac)		
2-Pass. Roadster.....	32-16-155	143"
2-Pass. Coupe.....	32-16-178	143"
2-Pass. Convertible Coupe.....	32-16-168	143"
5-Pass. Sedan.....	32-16-159	143"
5-Pass. Phaeton.....	32-16-256	149"
5-Pass. Phaeton with Sliding Wind- shield.....	32-16-280	149"
5-Pass. All-Weather Phaeton.....	32-16-273	149"
5-Pass. Sport Phaeton.....	32-16-279	149"

Brakes

Brake Drums } (345-B, 355-B, 370-B) (452-B)
 Brake Shoes }
 Vacuum Assister—(370-B, 452-B)

The new brakes are similar to the "A" series brakes but no brake parts are interchangeable between the "A" and "B" models. The 345-B, 355-B, and 370-B brakes are the same except for the length of the pull rods and the brake assister on the 370-B. The 452-B brakes are larger.

A new hook-up (Fig. 27) is used for the front brakes which eliminates the "Cardan" shaft on which the operating lever was formerly mounted. The cable is now connected directly to a control lever on the brake dust shield. The brake cable operates in a reinforced, flexible casing or conduit and is connected at the rear to a short pull rod which in turn is connected to the rocker shaft lever. This construction eliminates a number of wearing parts.

The articulated or upper brake shoes are aluminum and are the same length as on the "A" models but the lead tips are eliminated. The lower shoes are now of steel and are the same length as the upper shoes. The front and rear shoes are interchangeable.

A new lining, multibestos LX flexible moulded, has been developed to give the best results with cast-iron drums. This lining will be interchangeable with previous models having cast-iron drums but it should not be used with steel drums. It will be supplied in

rolls the same as the previous lining. The lining is 2 in. wide on all models except the 452-B which uses a 2½ in. lining.

Brake drums on all models are electric furnace molybdenum iron, the same as used on 370-A and 452-A models. Brake drums are 15 in. in diameter on all models except 452-B which are 16 in.

The same vacuum assister used on the 370-A and 452-A models is used on the corresponding new models and the adjustment should be made in the same manner.

The brake rocker shafts for both front and rear brakes are mounted on the rear side of the center frame cross member and the front rods pass above the cross member. See Fig. 28. New type rubber stops are also used.

The brake adjustments are the same as on the corresponding "A" series cars except the dimensions for locating the correct position of the cam lever. The dimensions are shown in Fig. 27. The position of the front cam lever should be determined by measuring from the center of the yoke pin at the front end of the cable to the front face of the cable support on the dust shield.




Fig. 26. The braking area has been increased by making the lower shoe longer




Fig. 27. The new brake system differs from that of the "A" series principally in the front brake hook-up

All service operations on the new brakes are the same as on the corresponding "A" models with the exception of the front brake cable control. To remove the cable, first disconnect it from the front control lever and remove the support cap to free the cable from the dust shield. Then remove the set screw at the rear end of the cable outside of the frame. Disconnect the cable from the pull rod by unscrewing the hexagonal end of the cable with a wrench. The connection between the cable and the pull rod is inside of the frame channel.

Lubrication of the brake linkage is the same as for the series "A" brakes, with the exception of the brake cam bearings and the front brake cables. These do not require lubrication except when the brakes are relined.

To lubricate the cam bearings it is necessary to remove the cam and pack the bearings with chassis grease. The brake cables are lubricated by disconnecting the rear end from the pull rod and forcing chassis grease into the casing. An adapter (Tool No. HMJ-254 is supplied for this purpose).




Fig. 28. Rocker shafts for both front and rear brakes are located at the rear side of the center cross member

Clutch

Assembly (345-B, 355-B, 370-B, 452-B)

Clutch

The new clutch is essentially the same as the plate clutch formerly used, but it is larger, and has a number of refinements which give smoother operation and longer life. See Fig. 29.

The 345-B, 355-B and 370-B clutches are of the same size, and use the disc shown in Fig. 30. The 452-B clutch is still larger, using a 11 in. disc. All disc facings are wider than those formerly used.

The driving plates are heavier than those in the "A" models and are made from molybdenum-duplex iron, which is practically proof against scoring.

In addition to the increased size, the clutch operation has been improved by a double-lever release mechanism and other minor changes which compensate for springiness in the levers and pressure plate, insuring uniform engagement of the clutch over the entire surface of the facings. See Fig. 31.

A new type pedal stop is used for holding the clutch pedal in the released position. The stop screw is now above the pedal hub, as shown in Fig. 32 instead of below the hub as in the "A" series.

With this type stop any wear or backlash in the

trunnion pin does not affect the movement of the clutch pedal pad. Therefore, the amount of pedal play represents only the movement of the clutch release bearing.

The stop screw should be adjusted to give the pedal $1\frac{1}{4}$ - $1\frac{1}{2}$ in. free play, measured at the pedal pad.




Fig. 29. The clutch is larger and includes a number of refinements to give smoother operation and longer life




Fig. 30. The clutch facings are $2\frac{1}{4}$ in. wide on all models

Service operations on the clutch are the same as on the 'A' series cars.

Note: The clutch used on the new 8- and 12-cylinder cars has also been used on 370-A cars beginning with engine unit 10-5086. This clutch can be used on the 345-A, 355-A and 370-A cars which have the flywheel drilled to accommodate the longer studs. These studs project farther forward than on the previous type of clutch.

Controlled "Free-Wheeling"

The new cars are equipped with "controlled" free-wheeling. This is the name given to the automatic vacuum-operated control for the clutch. This device consists of a piston and cylinder connected to the clutch release mechanism, and is operated by the vacuum from the intake manifold. The vacuum is controlled through valves connected to a control button on the toe-board and to the accelerator pedal. The design is such as to vary the speed of engagement of the clutch according to the speed with which the accelerator pedal is depressed.




Fig. 31. A double-lever release mechanism is used on the new clutches

The relative position of the clutch control parts is shown in Fig. 33. The vacuum or power cylinder is attached at the rear end of the center cross member of the frame and the piston is connected to the clutch release mechanism. The power cylinder is connected through a control valve to the intake manifold, which furnishes the necessary vacuum. The force thus developed is applied to a lever which is connected to the clutch release rod for disengaging the clutch. Although the power cylinder is connected to the clutch pedal, it does not interfere with the pedal action and the clutch can be operated entirely independent of the automatic control.

POWER CYLINDER

The power cylinder (Figs. 34 and 35) has a conventional piston which divides the housing into two




Fig. 32. The stop screw for the clutch pedal is located above the pedal hub

chambers. The front, or air chamber, is open to the atmosphere through three passages: (1), the air by-pass in the piston rod, (2) the atmospheric valve in the cylinder head and (3), the bleeder line leading to the bleeder valve in the control valve unit. The rear, or vacuum chamber, is connected to the intake manifold vacuum line through the cut-out and accelerator plungers in the control valve.

The air by-pass in the piston rod is simply a long slot. Its operation is controlled by the movement of the piston and permits a rapid discharge of air from the air chamber when the piston is moving forward up to the point at which the clutch begins to engage. After this point is reached the only escape for air from the air chamber is through the bleeder valve or by seepage around the piston.

The atmospheric valve in the cylinder head permits a rapid refilling of the air chamber in the cylinder when the clutch is disengaged.




Fig. 33. General arrangement of the free-wheeling control units

CONTROL VALVE

The control valve (Fig. 36) consists of three plungers: the bleeder plunger, the accelerator plunger and the cut-out plunger. The bleeder and accelerator plungers are connected together to the accelerator pedal. Their operation is positive in both directions. The cut-out plunger is operated in one direction by the




Fig. 34. Sectional view of free-wheeling control power cylinder

control button and its return movement is accomplished by means of a spring.

The control is positive, the valves being actuated by the movement of the control button and the accelerator pedal. The power cylinder develops power only so long as the driver keeps the control button depressed. As soon as the driver releases this button the vacuum operated control does not function and the clutch can be operated in the conventional way with the clutch pedal.

The bleeder plunger regulates the flow of air out of the air chamber of the power cylinder after the air by-pass in the piston rod is closed, just as the clutch starts to engage. The amount of air bled out of the power cylinder at this time depends on the number of bleeder holes uncovered by the bleeder plunger and the speed of the plunger movement, the position and movement of which in turn depends on the position and movement of the accelerator pedal.

Therefore, a slow downward movement of the accelerator pedal permits a slow escape of air from the air chamber in the power cylinder and gives a corresponding slow engagement of the clutch. A faster downward movement of the accelerator pedal will uncover the bleeder holes faster, permitting a




Fig. 35. Exploded view of free-wheeling control power cylinder

more rapid escape of air from the air chamber in the power cylinder and consequently, a faster clutch engagement. Thus the rapidity with which the clutch is engaged is controlled by the movement of the accelerator pedal, insuring smooth clutch engagement under all conditions.

While the accelerator plunger moves with the bleeder plunger, it functions in conjunction with the cut-out plunger to open the vacuum chamber in the power cylinder to the intake manifold or to the atmosphere. Each of these plungers has a vacuum valve and an air by-pass.

When the control button is depressed with the accelerator in the released position, the ports in both the accelerator and cut-out plungers are in line, com-




Fig. 36. Free-wheeling control valve

pleting the vacuum passage between the intake manifold and the power cylinder. The vacuum then pulls the piston back and disengages the clutch.

Depressing the accelerator (with the control button down) closes the vacuum line and opens the vacuum chamber to the atmosphere, permitting the chamber to refill as the clutch is engaged.

Releasing the accelerator (with the control button down) opens the vacuum line again and disengages the clutch.

Releasing the control button likewise closes the vacuum line and opens the vacuum chamber to the atmosphere, allowing the clutch to reengage.




Fig. 37. Clutch engaged with control button and accelerator released

SEQUENCE OF OPERATIONS

Figures 37 to 42, inclusive, show the various stages in the operation of the vacuum operated clutch control. In Fig. 37 the control button and accelerator are both released and the clutch is engaged. It will be seen that the bleeder line is closed by the bleeder plunger and the vacuum line by the cut-out plunger. The vacuum chamber in the power cylinder is open to the atmosphere through the by-pass in the cut-out plunger.

In Fig. 38 the control button has been depressed, opening the vacuum line and the clutch has started to disengage. Air is flowing into the air chamber of the power cylinder through the atmospheric valve. The bleeder line is closed by the bleeder plunger.

Fig. 39 shows the clutch fully disengaged. The plungers in the control valve are in the same position as in Fig. 38 with the vacuum line open.

In Fig. 40, the control button is still depressed and




Fig. 38. Clutch disengaging. Control button is depressed, opening vacuum line

the accelerator is being depressed to engage the clutch. The accelerator plunger has closed the vacuum line and has opened the vacuum chamber to the atmosphere. The bleeder plunger has opened the air chamber to the atmosphere. The by-pass in the piston rod has reached the cylinder head and is closed so that the only escape for the air in the air chamber is through the bleeder line. The speed at which the clutch engages depends upon the number of bleeder holes opened.

Fig. 41 shows the clutch fully engaged with both the control button and the accelerator depressed. Both chambers in the power cylinder are open to




Fig. 39. Clutch disengaged

the atmosphere and the piston is held forward by the pressure of the clutch springs.

In Fig. 42, the control button is released, with the accelerator depressed and the clutch engaged. With the control button in this position, both chambers of the power cylinder are open to the atmosphere and the movement of the accelerator has no effect on the operation of the clutch.

Adjustments

The adjustments of the clutch control must be made strictly in the order outlined below. See Fig. 43.

CAUTION: It is important that the carburetor be properly adjusted for smooth engine idling. Adjust the throttle stop screw to make the engine idle at about 320 R.P.M.




Fig. 40. Clutch engaging. Accelerator is partly depressed, closing vacuum line and opening bleeder line




Fig. 41. Clutch engaged

1. Adjust the control button so that when it is in the released position against the underside of the toe board, the cut-out plunger will be all the way forward against the operating lever.

2. Check the accelerator in the wide open (depressed) position. When the carburetor throttle is wide open against the stop, the underside of the tip of the accelerator pedal must be $\frac{3}{8}$ in. from the top of the toe-board with the carpet and pad out. Adjustment for this accelerator position is made in the throttle rod between the accelerator and the cross shaft on the engine.

3. Check the accelerator for free play in the closed (released) position. This is the play or backlash between the point of throttle closing and the fully




Fig. 42. With control button released both chambers in power cylinder are open to the atmosphere and movement of the accelerator has no effect on the operation of the clutch

released position of the accelerator. The accelerator must have $\frac{1}{8}$ in. free play. The adjustment for this play is made in the operating lever for the bleeder and accelerator plungers. These plungers must be in the forward position when making this adjustment.

On some cars there is a groove machined around the accelerator plunger, which should be used instead of the $\frac{1}{8}$ in. dimension when adjusting the accelerator free play. Adjust the accelerator pedal to bring the groove in the accelerator plunger flush with the front side of the control valve body at the point of throttle closing.

When making the accelerator adjustment for free play, watch for binding between the operating lever and the accelerator plunger. Correct any binding at this point by loosening the accelerator bracket and moving it as necessary to line up between the lever and the plunger.

4. Check the clutch pedal free play. This must be $1\frac{1}{4}$ to $1\frac{1}{2}$ in. Also check the pedal clearance under toe-board which must be $\frac{1}{4}$ to $\frac{3}{8}$ in.

5. With the engine idling at the correct speed and the brakes fully released (not dragging), check the adjustment of the piston rod of the power cylinder. To do this, hold the control button down, shift into low or reverse gear and then let up on the control button. Make this test on a level road. The car should start almost at once with smooth clutch engagement if the piston rod is in correct adjustment.

If the clutch grabs, with the connections to the bleeder valve tight, shorten the piston rod to give smooth engagement. If the start is delayed lengthen the piston rod to give the best results.

Do not use the accelerator in making this test and as a general rule do not change the piston rod adjustment more than one-half turn at a time.

6. The bleeder adjustment should be checked next but not until the foregoing adjustments are correctly made, and the pipe connections are free from leaks.

To check the bleeder adjustment, hold down on the control button and shift into low gear; while holding




Fig. 43. Clutch control adjustments

the button down make a normal start with the accelerator. If the clutch grabs or the engine speeds up too much before the clutch engages, check the length of the bleeder valve by measuring from the center of the pin to the front face of the plunger. (See Fig. 43). This distance should be 1 to $1\frac{1}{16}$ in. If incorrect, adjust the valve and recheck by again starting in low gear. Shorten the bleeder valve if the clutch grabs or lengthens it if the engine speeds up too much before the clutch engages. This is a very fine adjustment and should be made by giving

the bleeder valve one-half turn at a time. If it seems necessary to go outside of the 1 to $1\frac{1}{16}$ in. measurement look for other troubles.

After a good low speed start is obtained, check by "Free Wheeling" at 25 M. P. H. and then opening the accelerator normally. There must be no more than normal clutch slippage under these conditions. If the clutch slips too much, it will probably be necessary to lengthen the bleeder valve but care must be used not to lengthen it enough to bring its length very far outside of the $1\frac{1}{16}$ in. limit.

Cooling System

Fan Assembly	}	(345-B, 355-B) (370-B, 452-B)
Water Pump		
Thermostat	}	Same on all models
Shutter Assembly		
Condenser—(370-B, 452-B)		
Radiator—(345-B) (355-B) (370-B) (452-B)		

Improvement has been made in the cooling system of all models. The cooling efficiency has been increased particularly at idling and in the low engine speed range by redesigning the radiator and the fan.

Fan

The new fan has been designed to operate at higher speeds without objectionable noise, thus increasing its capacity and improving the cooling efficiency at idling and low engine speeds. It is driven at 90% engine speed.

The fan has also been moved to a new position closer to the radiator. Its efficiency has been further increased by the addition of an adjustable shroud ring installed on the radiator as shown in Fig. 44. This ring prevents the recirculation of air under the hood, thus increasing the flow of air through the radiator.

The fans are lubricated in the same manner as on the corresponding "A" models: the 345-B and 355-B by oil from the oil pressure regulator; the 370-B and 452-B by G-11 chassis lubricant, replenished every 6000 miles.

The fan belt is adjusted in exactly the same manner as on the "A" series cars, by raising or lowering the fan to the correct position. After adjusting the fan belt, it is also necessary to move the shroud ring up or down on the radiator to center the fan in it. This adjustment is made by loosening the two clamp screws on either side of the radiator and moving the shroud to the correct position.

Radiator

The radiator has been improved to increase the transfer of heat from the water to the air. The core

is 4 in. deep and is of a "full-bonded fin" construction which is a new development.

The same type of radiator anchorage is used on the "B" cars as that on the "A" cars, but it is of different dimensions.




Fig. 44. The shroud ring should be raised or lowered whenever the fan belt is adjusted to keep the fan centered in the ring

The radiator shutters and automatic control have been redesigned for the new type radiators. They are, however, similar in construction and operate the same way as those on the "A" cars. The same shutter assembly and thermostat control is used on all four models.

A new type "built-in" chromium plated grille is used in front of the radiator and is a part of the radiator casing. It adds greatly to the appearance of the car and is easily cleaned.

The front license plate is located in a new position on the bumper, giving an unobstructed view of the radiator and a slight gain in cooling. Larger louvers in the engine side pans also help to increase air circulation through the radiator.

Water Pump

The new water pump assemblies are of the same construction as those on the corresponding series "A"

cars. The 345-B and 355-B water pumps are interchangeable with the corresponding series "A" pumps with the exception of the inlet flange. The 370-B and 452-B water pumps are fully interchangeable with the corresponding "A" assemblies.

Condenser

The condenser tank on the 370-B and 452-B has also been redesigned and is of the flat type, similar to the 370-A tank, but is of different dimensions. The new condenser tanks are installed on the 370-B and 452-B frames in approximately the same position as on the corresponding "A" models.

In other respects the cooling system of the 370-B and 452-B cars is the same as on the corresponding "A" models.

The condenser system may be secured as special equipment on the 345-B and 355-B cars.

Electrical System

Generator	}	(345-B, 355-B) (370-B, 452-B)
Ignition Coils		
Starting Motor		
Storage Battery	}	(345-B, 355-B) (370-B) (452-B)
Ignition Distributor		
Horns—		(345-B) (355-B, 370-B, 452-B)
Circuit Control Box—		Same on all models.

The electrical system is of the same general arrangement on all the new cars, except the ignition and lighting circuits. The ignition systems are necessarily different because of the difference in the number of cylinders in the eight, twelve and sixteen cylinder engines. The lighting is practically the same on all models except the 345-B.

Storage Battery

New type Delco storage batteries are used. The battery capacity has been increased on each model giving a greater factor of safety for cold starting, for the new headlamps and for additional electrical equipment which may be added to the car. The 345-B and 355-B batteries have 17 plates, while the 370-B and 452-B batteries have 21 and 25 plates, respectively. See Fig. 45.

The battery on all models is carried in the right front fender as shown in Fig. 46. The cover over the battery forms a part of the fender and is held in place by four screws, one in each corner. A corresponding compartment and cover are provided on the left side of the car for tire chains.

Generator

The new generators (Fig. 47) are of the ventilated type with greater capacity than those formerly used. They may be set up to 24 amperes total output at generator without danger of burning out the armature.




Fig. 45. The 345-B and 355-B batteries have 17 plates, the 370-B 21 plates and the 452-B 25 plates




Fig. 46. The battery is located in a compartment in the right-hand front fender

This increase in capacity is made possible by the reduction in operating temperature due to the forced ventilation of the inside of the generator.

The general construction of the new generator is similar to that of the series "A" generators, the chief difference being in the addition of the ventilating feature and the installation of the cutout relay in the circuit control box on the dash (See Fig. 53).

The generator used on the 8-cylinder cars differs from that on the 370-B and 452-B only in length and windings. The mounting and drive is the same on the "B" cars as on the corresponding late series "A" models, except that the generator speed has been increased approximately 12% to compensate for free wheeling and the addition of electrical accessories.

All service operations on the generators are performed in exactly the same manner as on the "A" series cars. However, the clamp for the third-brush plate on the 370-B and 452-B generators is now held by a long hexagonal screw instead of the short round headed screw formerly used. This screw should be turned with a wrench when loosening the clamp for adjusting the charging rate.

Horns

Two horns are now used on the LaSalle car as well as on the Cadillac models. The new horn housings are designed to harmonize with the appearance of the car. The horn power plant, however, is of the same construction and is adjusted in the same manner as on the series "A" cars.

A new system of horn wiring is used in the "B" cars. The horns are now operated through a relay (Fig. 53) which in turn is operated by the horn button. Instead

of a heavy wire being used between the horn button and the horns as in the "A" series cars, heavy wires are now used only between the relay which is in the circuit control box, and the horns. A smaller wire is used between the horn button and the relay. This eliminates the passing of a heavy current through the horn button and minimizes the voltage drop in the wiring, giving a more nearly uniform voltage at the horns.

Ignition

The ignition systems are new and are alike on the 345-B and 355-B. The 370-B system is like that on the 452-B except the provision for the different number of cylinders to which current is distributed.

The new distributors are fully automatic, no manual advance being provided. To retard the ignition for cranking by hand, the distributor must be rotated on its support.




Fig. 47. Forced ventilation reduces the operating temperature of the generator and permits a higher maximum output




Fig. 48. The 345-B wiring diagram differs from the other "B" models principally in the lighting system. The ignition wiring is the same as on the 345-A.

The advance mechanism is the same on all models and is similar to the 370-A.

The 345-B and 355-B ignition coils are installed on the rear of the dash under the cowl while the 370-B and 452-B coils are mounted in the radiator as in the "A" series cars. None of the coils used on the "B" cars are interchangeable with those on the "A" cars because of the difference in the mounting brackets.

The flywheel has the usual IG/A marks to indicate the proper timing for full advance. These marks are located as follows in relation to dead center marks:

345-B, 355-B	$1\frac{3}{16}$ in. ahead of center.
370-B	$1\frac{1}{8}$ in. ahead of center.
452-B	$1\frac{1}{4}$ in. ahead of center.

A new system of numbering the cylinders of the 345-B and 355-B engines is used. The cylinders are numbered in the same manner as those on the 370-A and 452-A except that the new 8-cylinder engines have the odd-numbered cylinders on the right side. Number 1 cylinder is, therefore, on the right-hand side and the firing order becomes 1-2-7-8-4-5-6-3. This system of numbering is consistent and easy to remember because the No. 1 cylinder is always nearest the radiator. See Fig. 49.

The 345-B and 355-B are timed in an entirely new manner. The cam on these models is integral with the distributor shaft and the timing is done by simply rotating the distributor on its support instead of by adjusting the cam in relation to the shaft. A pointer and graduated dial indicates the amount the distributor is moved. See Fig. 50.

The adjustments for contact point gap and synchronization (Fig. 52) are the same as on the corresponding "A" models and must be made before timing the ignition. The contact point gap on the "B" models is as follows:

345-B, 355-B	.018-.022 in.
370-B	.018-.024 in.
452-B	.014-.018 in.

Ordinarily, the pointer should indicate zero for the standard ignition setting. However, this is not always true, and a slight variation of the pointer in either direction does not necessarily indicate an incorrect setting.

The 370-B and 452-B are timed in the same manner as the corresponding "A" models as the distributor cam is adjustable.




Fig. 49. Cylinder numbering system for V-8 engine. No. 1 cylinder is in right hand block nearest the radiator.

No provision is made for cranking the 452-B by hand. To time the ignition on this model it is necessary to jack up the car and turn the engine by a rear wheel with the transmission in high gear.

Starting Motor

The new starting motors are of the same general construction as those on the series "A" cars, but are not interchangeable with them. The operating levers are new and the switch is of the fixed type and requires no adjustment. It is also mounted at a slightly different angle from those on the series "A" cars.




Fig. 50. 345-B and 355-B engines are timed by rotating the distributor on its support instead of by adjusting the cam in relation to the shaft




Fig. 51. The 355-B, 370-B and 452-B electrical circuits are identical. The ignition wiring is the same as in the "A" series cars.

Wiring

The general arrangement of the chassis wiring is similar to that on the series "A" cars but instead of the conduits formerly used, the wires are now grouped in a braided varnished harness. The wires wherever possible are now carried in a corner of the side bar.

A new feature of the electrical system is the circuit control box (Fig. 53). This box is located on the rear of the dash under the cowl and contains the circuit breaker, the generator cut-out relay, the horn relay and the fuse for the stop light and back-up light circuit. It also serves as a junction box for the wire connections, the terminal block used in the "A" cars being eliminated.




Fig. 52. Top view of V-8 distributor with cap removed




Fig. 53. A new feature of the electrical wiring is the circuit control box on the dash under the cowl.

The circuit breaker and the cut-out relay are of the same type and construction as those used on the "A" models except a slight change in the mounting bracket for mounting them in the control box. The circuit breaker is mounted at the top and just above the cut-out relay.

The horn relay is of the magnetic type and is mounted in the circuit control box just below the cut-out relay.

Engine

345-B, 355-B

The 345-B and 355-B engines (Fig. 54) are entirely new and are more powerful than previous Cadillac 8-cylinder engines. With no increase in piston displacement, the maximum horsepower has been increased over 20%—from 95 to 115 which is reached at 3,000 R. P. M. This has been accomplished by developments in the manifolding and carburetion.

The new intake manifolds are arranged to supply all cylinders with exactly the same amount of fuel mixture. Each of the four end cylinders receive fuel through separate individual pipes. See Fig. 55.

The intake manifold is heated by the exhaust gas

in the exhaust header. The automatic heat control valve has been eliminated, the control in the new manifolds being inherent in the design.

The exhaust manifolds are also of a new design and contribute to greater power. They carry the exhaust gases directly to the rear, thus reducing back pressure and heat under the hood.

The new engines have six-point suspension, following the manner of the "A" series Cadillac cars. The mountings have been considerably strengthened, however. See Fig. 56. The adjustment of the support bolts is made in the same manner as in the "A" cars by turning the nuts down until there is no more play




Fig. 54. Side view of V-8 engine showing new features

in the bolts, and then turning them down exactly one and one-half turns further before putting the cotter pins in place.

Internally, the new V-8 engine is essentially of the same general construction as the series "A" engine. However, the new pistons are $\frac{5}{16}$ in. longer to give




Fig. 55. The new manifolding supplies all cylinders with equal amounts of fuel mixture

increased bearing surface above the pin. The weight of the piston remains the same as the "A" models, as the additional length is compensated for by the larger flat section at the ends of the pin. The upper oil ring is now $\frac{5}{32}$ in. wide instead of $\frac{1}{8}$ in. as formerly used. Both oil rings have a single wide slot to prevent clogging with carbon. See Fig. 57.

A new split type of piston pin bushing is used. It is made from thin flat bronze stock. These thin bushings cannot be pressed into the rods in the usual way but must be inserted loosely and expanded by means of a burnishing tool (Fig. 62). This presses the bronze into intimate contact with the steel of the rod and leaves a hard, dense surface with long wearing qualities. Another important factor is the quality of the bushing to retain a more nearly uniform clearance under high temperatures.

The AC oil filter is mounted on the left side of the crankcase in the same manner as on the 370-A.

370-B, 452-B

These engines are essentially the same as the "A" models but are refined in details. The 370-B engine is shown in Fig. 58.

The diameter of the piston pin has been increased to $\frac{7}{8}$ in. in both the 370-B and the 452-B. The oil rings are of the same type as used on the 8-cylinder engines.

The changes in the vacuum pump and the engine supports described for the 8-cylinder engines also apply to these engines.

The crankcase ventilator is of the same type as that used on the "A" series cars, and is interchangeable with it. The screen should be removed and cleaned every 6000 miles.

No major change has been made on many of the parts such as the crankshaft, the cylinder blocks, the oil pan and the flywheel housing which are of the same design and fully interchangeable with the corresponding "A" series parts. Standard 370-B cylinder heads are also interchangeable with the 370-A "HHC" cylinder heads.




Fig. 56. View of rear engine support




Fig. 57. 345-B and 355-B piston, showing the new type oil rings

The harmonic balancer has been improved and is interchangeable on both engines.

Compression Ratios

Two compression ratios are optional on all engines. The ratios of the various engines are as follows:

345-B—355-B	
Standard	5.38
Optional	5.70
370-B	
Standard	5.30
Optional	5.08
452-B	
Standard	5.35
Optional	5.00

A new method of changing the compression ratios is used on the 370-B and 452-B. This is accomplished by merely changing the cylinder head gasket. See Fig. 59. The standard gasket will give approximately the same compression ratio as the "HHC" on the "A" models.

To change to "HC" compression on the 12- and 16-cylinder engines, a special cylinder head gasket is used. This gasket has a steel shim of a definite thickness between the layers of asbestos. This makes it possible to change to a lower compression with a slight cost wherever the fuel situation demands it.




Fig. 58. Side view of 370-B engine

This method of changing the cylinder head gasket to change the compression ratio is not practical on L-head engines, because of the construction of the combustion chamber. This is offset by the fact that it involves less work to change a cylinder head on an L-head engine.

Lubrication

The engine lubrication system is the same as on the corresponding "A" models with the exception of the new type oil filter on the 370-B and 452-B. See Fig. 60.




Fig. 59. The compression ratio on 370-B and 452-B cars can be lowered by using a special cylinder head gasket having a metal insert

A Cuno disc-type, self-cleaning oil filter is used on these models.

The oil, in circulating through the filter, passes between thin rotating discs, stacked one upon another, and separated a few thousandths of an inch by a series of thin stationary plates. The filtering discs are mounted on a shaft which extends above the filter and is connected to the starter pedal in such a way that the discs are rotated a partial turn each time the starter pedal is depressed.

When the filtering discs are rotated the accumulated sediment is scraped off by the stationary plates and falls to the bottom of the tank.

The only attention required is the draining of the tank every 6000 miles.

Vacuum Pump

A new type vacuum pump is used on the series "B" cars to act as a booster to augment the manifold suction for operating the windshield wiper. It is of the diaphragm type, and is located in the same position as the vacuum pump formerly used to supply fuel. The diaphragm push rod is operated by a special cam on the rear end of the camshaft in place of the eccentric previously used. See Fig. 61.

As the push rod is moved upward by the cam, it actuates the diaphragm, expelling the air from the chamber above the diaphragm out through the outlet valve into the intake manifold.

The diaphragm is forced downward by the return spring as the cam is rotated to its low point, creating a suction in the chamber above the diaphragm. Air is then drawn through the inlet valve from the windshield wiper.

When the manifold vacuum is greater than the vacuum created by the pump, air will flow from the windshield wiper through both valves of the pump and the operation of the windshield wiper will be the same as if the pump were not installed. However, when the intake manifold vacuum is low—that is, when the car is accelerating or operating at high speeds—the vacuum created by the pump will be the greater and will operate the wiper.

AC service stations will service the vacuum pump. However, replacement of the valves and the diaphragm can be accomplished simply by taking the pump apart. Do not under any circumstances separate the two parts of the housing without holding the pump head securely because the pressure of the diaphragm return spring is approximately 75 lbs. If care is not taken in removing the screws which hold the pump together, the top will fly off which might cause serious injury to some one.

Service Information

All service operations on the new cars should be performed in the same manner as on the "A" series with the exception of the removal and installation of the new split type piston pin bushings. A kit of special tools (Tool No. HMJ-250) is furnished for this purpose.




Fig. 60. The oil filter on 370-B and 452-B engines is of the revolving disc type and is self cleaning




Fig. 61. The vacuum pump acts as a booster to augment the manifold suction for operating the windshield wiper

The bushing should be removed in an arbor press and should be started by giving the handle of the press a sudden jerk instead of a steady pull. After the bushing is started it will move out quite freely.

The bushing cannot be pressed into the connecting rod in the usual manner. Instead, it is inserted loosely in the rod and expanded with an expanding bar. It is then burnished to press the bronze into very close contact with the steel rod leaving a long hard-wearing bearing surface.

To install a piston pin bushing, proceed as follows:

(1) Install the bushing in the side of the connecting rod having the large chamfer in the bearing for the crank pin. Make sure that the oil hole in the bushing is in line with the oil hole in the connecting rod and the split is at right angles to the length of the rod.

(2) Press bushing in rod using bushing replacer, tool No. HMJ-250-3. Use a No. 2 or No. 3 Greenard arbor press or its equivalent to press in the bushing.

(3) Expand the bushing with Expanding Bar (tool No. HMJ-250-1). If the bushing protrudes through the connecting rod, file it flush with the rod before burnishing.

(4) Burnish bushing by passing burnishing tool No. HMJ-250-2 through the bushing. See Fig. 62. When expanding or burnishing a bushing use a heavier press such as a No. 3½ Greenard or its equivalent.

Use kerosene as a lubricant when expanding and burnishing the bushing.

If the bushing moves during the burnishing process, it is too loose and another one should be used.

If the proper clearance between the piston pin and the bushing is not secured after the burnishing tool is

passed through the bushing, the burnishing operation should be repeated to increase the size of the piston pin hole.

The press plate (Tool No. HMJ-250-4) should be used for expanding and burnishing the bushing. This plate has two holes—one which is used for assembling, expanding and burnishing and the other for removing the bushing. The tool number of the complete set of four tools just referred to is HMJ-250.

After installing the bushing the parts should be thoroughly cleaned and the oil passages blown out with air to remove chips and dirt.




Fig. 62. The piston pin bushing is burnished to press the bronze into close contact with the steel rod leaving a long hard-wearing bearing surface

Exhaust System

Muffler—(345-B, 355-B) (370-B, 452-B)

Exhaust Pipe—(345-B, 355-B) (370-B, 452-B)

The general arrangement of the 345-B, 355-B exhaust system is similar to that of the "A" series cars. However, a new and improved type of muffler is used. See Fig. 63.

The new muffler has an asbestos lining between two shells which are welded together at the ends.




Fig. 63. Cut-away view of the new muffler

The purpose of the asbestos lining is to prevent drumming and heat from body. The exhaust pipe is also covered with a heavy asbestos lagging (Fig. 64) to prevent excessive heat under the hood and in the body and to quieten the exhaust.

In addition to the new muffler, a silencing chamber consisting of a piece of pipe about two feet long is

mounted above and connected to the tail pipe as shown in Fig. 65. The purpose of this chamber is to still further quiet the exhaust. It functions in somewhat the same manner as the tuning chamber in the intake silencer.

Rubber cushions similar to those used on the 370-A are used on the muffler support brackets to prevent exhaust noises being transmitted to the body.

The muffler supports are adjusted in the same manner as those on the 370-A, by tightening the nuts only




Fig. 64. The exhaust pipe is covered with heavy asbestos lagging

enough to flatten the lockwashers a slight amount. It is better to have these nuts a little loose than too tight.

The exhaust system on the 370-B and 452-B models is essentially the same as on the corresponding series "A" cars. The mufflers, however, are new being similar in design to those just described for the eight cylinder cars. The only differences are in the dimensions and in the location of the tuning chamber. This chamber is located inside of the muffler, as shown in Fig. 63 rather than on the tail pipe.




Fig. 65. Tuning chamber on V-8 exhaust tail pipe

Frame




Fig. 66. The front cross member extends back far enough to support the front end of the engine

The series "B" frames are entirely new; they are of the double drop type and embody some new and important features. They are of the same construction on all models, differing only in dimensions. Unusually




Fig. 67. Tubular cross-members add to the rigidity of the frame

deep side bars and new box-type cross-members have added materially to the rigidity of the frame, particularly at the front end.

The front cross-member shown in Fig. 66 is heavily reinforced to stiffen the frame against flexing and extends back far enough to support the front end of the engine. The side bars are 9 in. deep on the 345-B, 355-B and 370-B and 10 in. deep on the 452-B. Between the front outriggers and the front cross members, the side bars are reinforced with box-type sections.

The two center cross-members are also of an entirely new type with a box-shaped section. The front one (Fig. 67) of these two cross-members supports the rear end of the transmission as in the "A" series Cadillac cars. The rear end of the frame is tied together with two pressed steel cross-members.

The running board brackets are of an improved type, of heavy channel section. See Fig. 68. Only one bracket is needed for each running board as the rear ends are supported by the rear fenders.




Fig. 68. One running board bracket rigidly braced is used on each side of the frame

Gasoline System

Carburetor

Intake Silencer and Air Cleaner

Fuel Pump

Gasoline Tank—Same on all models.

(345-B, 355-B) (370-B, 452-B)

(To interchange 370-B and 452-B carburetors, the correct metering pins must be used.)

The gasoline system on all models has been improved to give satisfactory operation with any gasoline of established commercial specifications. The 345-B and 355-B carburetor is of the same type as that on the corresponding "A" models, but has been improved to give better fuel economy and more engine power. New carburetors of the expanding air-valve type are used on the 370-B and 452-B.

The gasoline line from the rear supply tank has been improved to lessen the possibility of vapor lock and interference of air bubbles. This is accomplished by the use of a larger feed pipe and by mounting it on the outside of the frame where the air sweeping by tends to cool the gasoline. Sharp bends and low spots in the fuel line have also been eliminated by running the line as nearly straight as possible from the tank to the fuel pump.

The vacuum system has been discontinued on the new cars. A fuel pump is used instead for supplying gasoline to the carburetor. The fuel pump is of extra capacity to insure an adequate supply of fuel to the carburetor at all times, regardless of the existence of vapor in the fuel line.

The capacity of the fuel supply tank has been increased to 30 gallons on all of the new models. The tank is fitted with a new type vent, which is located at the top under the valance. Its purpose is to permit

more rapid filling of the tank. The filler-pipe cap is of an improved design and is hinged to the pipe to prevent loss. It is taken off and put on in the same manner as on previous models.

Fuel Pump

The fuel pump is of the diaphragm type. It is operated by a push (driving) rod riding against a cam on the distributor shaft and is located at the front of the engine on the left, in the coolest position under the hood. See Fig. 69.

The principal moving element of the fuel pump is a diaphragm actuated through a series of lever and rods as shown in Fig. 70. The operation is as follows. When the push rod is moved in and out by the action of the driving cam, it in turn operates the rocker arm which is pivoted at the lower end. The rocker arm pulls the pull rod and diaphragm assembly down, creating a vacuum in the pump chamber which draws gasoline from the rear tank into the sediment bowl and through the strainer and inlet valve into the pump chamber.

The diaphragm is moved upward on the return stroke by pressure of the diaphragm spring. On this stroke the gasoline is forced from the pump chamber through the outlet valve, into the vapor dome and thence to the carburetor.

When the carburetor bowl is filled and the inlet needle valve closes, a back pressure is created in the fuel pump chamber. This pressure holds the diaphragm down against the pressure of the diaphragm spring, and keeps it in this position until more fuel is needed in the carburetor and the needle valve opens.

The rocker arm is in two pieces, operating as a single part when the diaphragm is working up and down. However, when fuel is not required and the link or lower part of the operating lever is held down at one end by the diaphragm pull rod, the lever or upper part operates in the usual way. This is made possible by the fact that the lever operates against the link only in the downward direction, the upward movement of both parts being accomplished by spring




Fig. 69. The fuel pump is mounted on the front left-hand side of the engine.

pressure. A second spring is provided for keeping the lever in contact with the driving rod at all times.

The service operations which can be performed on the fuel pump without special tools are the cleaning of the filter and the replacement of the filter parts, the vapor dome and the inlet and outlet valves. Under no circumstances should the pump housing be disassembled unless the necessary special tools for reassembly are available.

Service on the fuel pump can be obtained from A. C. service stations, which have special tools and spare parts. A maximum price of \$2.00 list is charged for repairing fuel pumps.

Distributors and larger Dealers are advised to keep a pump on hand for exchange to render prompt service. Distributors who wish to make all pump repairs themselves can secure the necessary tools from any A. C. service station.

Intake Silencer

A feature of the new intake silencer is the addition of a gauze air cleaner (Fig. 73). With this exception, the silencer is of the same construction as that used on the series "A" models. This type of silencer is now standard equipment on the 16-cylinder engines. The




Fig. 70. The fuel pump is operated by a cam on the distributor shaft




Fig. 71. Exploded view of an air cleaner

370-B and 452-B intake silencers are mounted on the front side of the dash.

The air cleaner is designed to catch any dust or lint in the air before it is drawn into the carburetor. It is automatic in operation and requires no attention other than periodic cleaning.

The mileage at which the air cleaner requires attention depends entirely upon the conditions under which the car is operated. For normal driving in cities and on hard surfaced roads cleaning once every 6,000 miles is sufficient. Under extreme conditions, such as continuous driving on dusty roads or in localities where there is considerable dust in the air, cleaning may be required as frequently as every 2,000 miles.

The gauze unit in the air cleaner is removed for cleaning as shown in Fig. 71. To do this, remove the two acorn nuts at the top of the silencer and lift off the cover and gauze unit. Wash the gauze unit in gasoline to remove all dirt from the gauze and dry with an air hose. Then dip the gauze unit in a light engine oil and allow to drain before reinstalling it on the silencer. When installing the gauze unit on the silencer, be sure that the louvers point down.

No attempt should be made to wash the cover containing the fabric pad or the silencer itself. This is important, because of the possibility of explosion or fire caused by igniting of gasoline in these parts by backfiring through the carburetor. Simply wipe off the top of the silencer with a cloth before the gauze unit is reinstalled.




Fig. 72. The 345-B and 355-B carburetor

345B, 355B

Carburetor

The same carburetor is used on the 345-B and 355-B. It is of the same type as those on the series "A" cars, but it has been redesigned to meet the requirements of the new engines. See Figs. 72 and 73.

The auxiliary air valve chamber is of a different shape to take care of the new intake elbow and silencer mounting. The intake pipe is smaller but less restricted than formerly. The angle of the auxiliary air valve has been changed to give a more nearly direct passage from the intake silencer into the carburetor. This, and the placing of the strangle tube higher in the air stream insures better distribution of the fuel. A new type thermostat is also provided on the throttle pump, which requires no adjustments.

The choke has been changed to facilitate starting and improve running while the choke is applied. It prevents an overrich mixture when the engine is started with the choke pulled out.

Flooding is rendered less likely by the use of a larger float.

Carburetor Adjustments

The carburetor is adjusted by means of the knurled screw on top of the auxiliary air valve housing, in identically the same manner as on the "A" series cars: it is turned clockwise to enrich the mixture and counter clockwise to lean the mixture.

The float setting is checked in exactly the same manner as in the series "A" carburetors with the bottom of the float $\frac{1}{16}$ to $\frac{1}{32}$ inches above the machined surface at the lower side of the body against which the bowl is placed.

Adjustment of Choke and Auxiliary Air Thermostat

The arrangement of the choke and auxiliary air thermostat is entirely different from any previously used and has been greatly simplified. Ordinarily, it should not be necessary to adjust the choke or to reset the air thermostat unless these parts have been tampered with.

The adjustment of the choke rod should be checked by disconnecting it from the idler choke lever on the carburetor, and noting whether the trunnion on the choke rod is in line with the hole in the idler lever with the lever midway in its free position. There is a slight amount of slack or lost motion in the travel of the idler lever before it begins to pull the spring. The idler lever should be midway in this free travel when the hole in the lever is in line with the trunnion.

The setting of the auxiliary air valve choke arm should be checked as shown in Fig. 74. With this arm in the correct position, the lower face at the end should be in line with the center of the shaft and the small hole in the outer end of the choke lever. The choke arm is adjusted by loosening the two locking screws and moving it on the shaft.

The thermostat setting should be checked at room temperature (65-85° F.) with the carburetor cold. The correct position of the thermostat is indicated in Fig. 74, and is obtained by loosening the locking screws and moving the thermostat on the shaft.




Fig. 73. Sectional view of V-8 carburetor, intake silencer and air cleaner




Fig. 74. Choke and auxiliary air thermostat adjustments

370-B, 452-B

The general arrangement of the 370-B and 452-B gasoline system is the same as on the 8-cylinder cars, except that two carburetors are used, each one having its own fuel line from the fuel pump. New expanding air valve type carburetors are used on both of these models.

Carburetor

An entirely new type of carburetor is used on the 370-B and 452-B which is specially adapted to the requirements of these engines. The carburetor adjustment controls the mixture by varying the flow of fuel rather than the air. It is simple in construction with no thermostats and requires only one adjustment. See Figs. 75, 76 and 77.

The carburetors used on the 370-B and 452-B are identical with the exception of the size of the metering pin. A No. 10 metering pin is used in the 370-B carburetors and a No. 12 in the 452-B carburetors. Otherwise the carburetors on these car models are fully interchangeable. Right and left carburetors differ in the control levers. The name plate marking identifies the type of carburetor; 370-B carburetors are Type R-13 and L-13; 452-B carburetors are Type R-14 and L-14. The carburetor consists chiefly of two units, namely, the main metering unit and the auxiliary unit.

The Main Metering Unit consists of a pair of air valves or vanes, hinged at their lower ends and opening upwards to admit air to the mixing chamber. These vanes have fingers which engage a central aspirating tube, raising it as the vanes open. This aspirating tube is attached to a spring loaded hollow stem and piston working in a dashpot, the piston carrying the

fuel metering orifice in its lower end. An adjustable tapered metering pin projects into this orifice.

The Auxiliary Unit combines an auxiliary power jet, an accelerating pump, and a priming passage for starting. The operation of the auxiliary unit is controlled by the registering of ports in the starting sleeve, which line up with passages in the throttle body. The starting sleeve rotates with the starting lever; (choke lever) the pump plunger and piston move downward as the throttle is opened.

Starting

To start a cold engine, the choke control button should be pulled out to its limit and the throttle left in the closed position. This rotates the starting sleeve in the throttle body and lines up the primer passage with a hole in the wall of the starting sleeve, allowing fuel to be drawn into the manifold directly from the float chamber through the pump cylinder and hollow stem of the pump plunger. The throttle must be closed so that a strong suction will be created above the butterfly valve to draw fuel through the priming passage.

Actually the throttle plate will be opened slightly by the kicker rod when the choke button is pulled out, but this action is automatic, and allows just enough air to pass the throttle to insure good starting. Should it ever be necessary to correct the adjustment of this kicker, the clearance between the kicker rod and kicker screw should be just perceptible or about .005 to .010 inch. First be sure that the starting lever is in normal running position and that the throttle stop screw is set to give the engine an idle speed of about 320 R. P. M.




Fig. 75. The 370-B and 452-B carburetor




Fig. 76. Cut-away views of the 370-B and 452-B carburetor

In extremely cold weather starting can be aided by giving several quick strokes of the accelerator pedal after the choke button has been pulled out. This action pumps fuel through the primer passage into the manifold and so assists starting.

After the engine has started, push the choke button part way in; the engine will then run on a richer mixture than normal, which makes the engine driveable while cold. Experience will show the correct place to set the choke button, which will depend on temperature. As the engine warms up the button should be pushed farther in, and after the engine has become warm the button should be pushed all the way.

If the engine fails to start, check the position of the starting lever and see that the starting lever stops tight against the screw in the float bowl cover when the dash control is pulled out to its limit, otherwise the primer holes will not line up.

Carburetor Adjustments

The carburetor has only one adjustment, the metering pin, which is raised or lowered by screwing it into or out of the fuel orifice. The metering pin is properly adjusted when the carburetor leaves the factory, but if for any reason it should require readjusting, be sure the motor is well warmed up, and then adjust the metering pin carefully at idle speed.

Turning the pin to the right moves the pin upward into the orifice and makes the mixture leaner; turning it to the left increases the orifice and makes the mixture richer.

The idle speed of the engine should be set by means of the throttle adjusting screws to a speed of approximately 320 R. P. M.

When the metering pin is correctly adjusted at idle speed the carburetor is set for maximum engine performance and no other adjustments are required.

The right and left carburetors should be equalized in the same manner as on the 370-A and 452-A. The same equalizing gauge (Tool No. H. M. 109626) can be used with the exception of the fitting for connecting it to the intake manifolds. Larger fittings are used on the new cars and special adapter (Tool No. H. M. 109626-6) is necessary for connecting the equalizing gauge to the manifolds.

Operation

For normal running the fuel enters the carburetor float bowl through the strainer and float needle valve, and is maintained at constant level by the float and float needle valve. This level of fuel should be $\frac{13}{16}$ to $\frac{15}{16}$ in. below top of float bowl casting.

Air enters the carburetor through the air inlet and lifts the vanes as it passes upwards into the mixing chamber. The weight of these vanes combined with the pressure exerted by the dashpot spring causes a partial vacuum to exist in the mixing chamber, which

draws fuel from the aspirating tube. The quantity of fuel flowing is controlled by the tapered metering pin; at idle speed the vanes are almost closed and the metering pin almost fills the orifice in the air valve piston. As the vanes rise to admit more air, the aspirating tube also rises and the metering orifice becomes larger due to the taper on the metering pin. This combination maintains the correct ratio of fuel and air for average running.

For *maximum power* at any speed a richer mixture is required than is necessary for part throttle running. The power jet supplies the required extra fuel while the throttle is held open beyond the point which would give a road speed of about 60 miles per hour. At this throttle position the pump plunger has travelled downward and has shut off the air vent to the power jet, therefore, the suction on the discharge nozzle draws fuel from the pump cylinder up through the hollow stem of the pump plunger and through the power jet into the mixing chamber. At part throttle positions below 60 miles per hour road speed this power jet does not supply fuel since it is vented to the outside air through the air vent hole in the upper part of the starting sleeve.

The quantity of fuel drawn from the power jet, is controlled by the air bleed hole in the pump plunger stem.

For *rapid acceleration* it is necessary to supply a momentarily rich mixture. This extra fuel is supplied by means of the accelerating pump.

A rapid opening of the throttle causes a rapid downward movement of the pump plunger and piston, forcing fuel up through the hollow stem of the pump plunger and out through the discharge nozzle into the mixing chamber. The fuel in the pump cylinder cannot escape back into the float chamber because of the check valve in the bottom of the pump cylinder.

In general—for steady driving conditions up to 60 miles per hour on level roads the fuel is all supplied from the aspirating tube. When the throttle is

opened suddenly an additional charge of fuel is supplied from the accelerating pump, and if the throttle is held open as for hard pulling or high speed, extra fuel continues to flow from the pump discharge nozzle through the power jet.

Cleaning and Disassembling

The carburetor body can be flushed out while on the car as follows: Remove the strainer housing nut and wash out the strainer housing and screen with gasoline. Replace these parts and remove the metering pin guide assembly and also the drain plug. Flush carburetor body by allowing gasoline to flow through it.

The carburetor can be disassembled for cleaning or repairs after removal from the engine in the following manner:

First remove the metering pin guide assembly so that the metering pin cannot be damaged by being jammed in the orifice when the vanes are removed.

Lift off the upper part of throttle body by removing the two cap screws.

Open the vanes and lift off the vane box casting, then the vanes can be removed from their seats.

The float mechanism can be removed by taking out the three float cover screws. One of these screws acts as a retainer for the float hinge pin, so this pin can now be moved sideways through the side of the casting which will allow the float and needle valve to be lifted out.

To remove the aspirating tube a special dowel wrench, Tool No. HMJ-253, must be used to hold the air valve piston, while the aspirating tube is turned with a wrench on the flats provided.

It should seldom be necessary to remove the air valve stem and aspirating tube; as long as these parts move freely up and down in the dashpot it is best not to remove them. But if these parts are removed make sure that they are carefully handled and that the dashpot spring is not tampered with. See that the small disc jet in the aspirating tube is in place when re-assembling.




Fig. 77. Diagrams of 370-B and 452-B carburetor showing principles of construction. For the sake of clearness some parts are not shown in their true positions

The starting sleeve can be removed by releasing the retaining screw, but it should seldom be necessary to remove these parts. If removed they should be re-assembled by first setting the pump plunger in place on the pump lever, then slide the starting sleeve into place around the pump plunger. Be very careful to line up the groove for the retaining screw so that the screw does not damage the sleeve when tightened.

Wash the disassembled parts in gasoline and dry with compressed air.

DO NOT USE ANY SORT OF ABRASIVE SUCH AS A FILE OR EMERY CLOTH FOR CLEANING THE MOVING PARTS.

Reassembling

Reassemble the float and needle valve, and put on the cover. Be sure that the float hinge pin is properly entered in the body so that the float cover screw will screw down past it and retain it in place.

Place the vanes with their hinge pins into the seats

provided in the lower body and see that the fingers on the vanes engage the groove around the aspirating tube. Press the hinge pins firmly into their seats, then open the vanes and place the vane box over the vanes with a good gasket below it so that it seats firmly on the lower body.

Drop the accelerating pump cylinder with a gasket under its top flange into place in the float cover. Place the throttle body over the vane box, but before tightening the two cap screws be sure to inspect the vane check to see that it is not caught above the vanes in a horizontal position, or its lower end pinched between the throttle body and vane box. It should hang vertically and loosely after the bodies have been tightened together.

After the carburetor is assembled check the vanes for free movement up and down, and see that the throttle and pump action works freely, also see that the starting lever moves freely and stops against the stop screw at both ends of its travel.

Lighting System

Headlamps
Lighting Switch } (345-B) (355-B, 370-B, 452-B)
(Right and left headlamps are not interchangeable on Cadillac models.)

A new headlight system called "Super-Safe" is used on all new models except the LaSalle. The LaSalle lighting system is of the conventional type used on the "A" series cars.




Fig. 78. A special 3-filament bulb is used in the Super-Safe lighting system.

Super-Safe lighting is new and used exclusively by Cadillac. This system actually comprises two independent lighting systems, one for the right-hand and one for the left-hand lamp. The lamps are purposely made so that the doors, lenses, or reflectors cannot be interchanged.

The basis of the "Super-Safe" lighting system is a bulb (Fig. 78) with three filaments, one 32 candle-power, and two 21 candle-power. These triple filament bulbs, in conjunction with the reflectors and the special lenses which are different in the two headlamps, give four lighting combinations, two for city driving and two for country driving.




Fig. 79. The lighting switch on the steering wheel has four positions besides "off" and "parking"




Fig. 80. Diagrammatic elevation of the "Super-Safe" light beams

The advantage of this system is increased and better distributed illumination for country driving.

The lens on the left-hand headlamp deflects light toward the right side of the road, whereas the right lens spreads the light uniformly over the road ahead.

The bulb in the left headlamp is installed with the 32 candle-power filament at the top, while the one in the right lamp is installed with the 32 candle-power filament at the bottom. The slots in the sockets are so arranged that it is impossible to insert the bulbs in the wrong position.

The headlamps are wired so as to give four combinations of lighting, namely: city passing, city driving, country passing and country driving. See Fig. 79. The filaments which are used and the beams they produce to give these combinations are shown in Fig. 80.

For *city passing*, both headlamps give a beam that is tilted sharply down, giving no glare, but clearly visible.

When in the *city driving* position, both headlamps give a beam of moderate tilt plainly illuminating dark streets, but complying with all city regulations.

In the *country passing* position, the left headlamp with two filaments lighted, totalling 53 candle-power, gives intense illumination of the right side of the road

close in front of the car. This illuminates clearly any ditches or obstacles, while the right headlamp gives a moderate tilted non-glaring beam straight ahead.

For *country driving*, the left headlamp gives normal illumination, moderately tilted while the right headlamp, with two filaments lighted totalling 53 candle-power, illuminates the road far ahead. This combination of light gives more and better placed illumination than is possible with conventional type headlamps, even when 32 candle-power bulbs are used.

The laws of some states prohibit the direct light above the horizontal. To comply with such laws the connections at the right headlamp must be altered to prevent use of the 32 candle-power filament. This can be done by removing the right headlamp and insulating the tip of the wire to No. 3 in the plug. This wire is black with a red tracer and has the tip with the shortest shank.

There are no focusing or other adjustments within the headlamps themselves. The only adjustment required is the aiming of the lamp, which is done in the same manner as on the "A" series Cadillac cars with this difference, that the lamps are aimed on the *city driving beam* only with the *lens in place*.

The aim should be tested periodically in accordance with the procedure given below, except where state




Fig. 81. Markings for adjustment of head lamps

Distance between lamp centers:

A—32 in. (355-B 370-B 452-B)

B—27¼ in. (345-B)

Height of lamp center above floor:

C—40⅝ in. (452-B)

D—40⅜ in. (370-B)

E—39⅜ in. (345-B 355-B)

or local regulations apply. In such cases, the procedure should be modified to satisfy the legal requirements.

A light colored vertical surface, such as a blank wall on a garage door, marked as shown in Fig. 81 according to the dimensions indicated, is required for the test. The car should be placed so that the front of the headlamps are square with and twenty-five feet from the vertical surface. The center line of the markings on the wall can then be located by sighting through the center of the rear window over the radiator cap.

The test should be made with one lamp at a time, and with the light switch on the steering column in the "City Driving" position. One lamp should be covered while the other is being tested. If the lamps are properly aimed, the light beam of the left-hand lamp will be patterned and located as shown in Fig. 82, while those of the right-hand lamp will be patterned and located as shown in Fig. 83.

If either lamp fails to project a beam patterned and located as shown, loosen the clamping nut at the

bottom of the lamp, shown in Fig. 84, and proceed as follows:

First set the lamps so that the flutes on the lens are straight up and down. Then turn the lamp sidewise or up and down until the proper aiming is secured. Hold the lamp in this position and tighten the nut securely, after which test the lamp again to make sure it is properly aimed.

LaSalle Headlamps

The 345-B Depress-Beam headlamps are of the same type as those used on the 355-A and 370-A. The two headlamps are alike, using fluted lenses, and 32-32 candle-power double filament bulbs. The only adjustment necessary is the aiming of the lamps the same as on the "A" series Cadillac cars.

The wiring connections at the headlamps are made through a male and female plug inside the headlamp supports. Three wires enter the right headlamps and two enter the left headlamp. The wire tips have different length shanks to indicate their respective positions in the plug. The plugs are also indexed into the retainers which in turn are indexed into the lamp sockets. Thus, the connections must be properly made before the various parts will fit into their respective places.

Rear Lamps

Two combination rear lamps, one located on each rear fender, are now standard equipment on the LaSalle, as well as on the Cadillac models. The lamp has two bulbs, one 3-candle power for the tail light, and one 15-candle power, which serves for both the stop and back-up lights. The larger bulb is lighted by the switch on the brake pedal bracket for the stop-light, and by a new switch on the transmission for backing. The rear lamp is fitted with a special ruby lens, the center of which is blue, the blue part being directly in line with the 15 c.p. bulb. The blending of the blue light with the ruby produces a new brilliant hue which attracts immediate attention. The lower half of the blue portion of the lens is




Fig. 82. Beam of left-hand lamp in "City Driving" position




Fig. 83. Beam of right-hand lamp in "City Driving" position




Fig. 84. The headlamps may be aimed after loosening the clamping nut at the bottom of the lamp

thinner in section than the upper half, providing ample illumination for backing.

The feed wire for the stop and reverse lights is connected to the ignition switch in all "B" cars. This prevents excessive load on the battery when the car is parked in reverse or when the brake pedal is depressed by application of the emergency brake lever. Therefore, the ignition must be turned on when these circuits are checked.

A short circuit in either the stop light or reverse light circuit will not affect the ignition as the feed wire for these lights is protected by a fuse in the circuit control box.

Map Reading Lamp

Another new feature is the map reading lamp located at the center of the instrument panel. The lamp is lighted by pulling it out against the stop.

Special attention should be given to the removal of the map lamp bulb which is accomplished in the manner illustrated in Fig. 85. The lamp is first pulled out part way to bring the end of the threaded shaft on the plunger about flush with the rear edge of the lamp cylinder. The bulb shield is then turned slowly until the hole in the plunger comes opposite the one in the cylinder. A nail or its equivalent is next inserted in the hole to keep the plunger from turning and the bulb shield removed by unscrewing it from the cylinder. The bulb shield has a right-hand thread.




Fig. 85. The map lamp bulb shield may be unscrewed after lining up the holes in the cylinder and plunger and inserting a nail to prevent the plunger from turning

Lubrication

The lubrication of the series "B" cars is similar to that of the corresponding "A" models, with the exception of a few points. There are several additional points for lubrication on the ride regulator linkage and the clutch control connections. Lubrication of these parts is covered in their respective sections.

No lubrication is necessary at the front engine support on the 345-B, as this engine has the same mounting as the 355-B.

The same kinds of lubricants should be used and the same mileage intervals should be observed in lubricating the "B" cars as given on the lubrication schedules for the "A" series cars.



LUBRICATION SCHEDULE

CADILLAC V-8 355-B

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____ DATE DELIVERED _____

		LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE													
			1	2	3	4	5	6	7	8	9	10	11	12		
LUBRICATION NOS. 6 AND 12	LUBRICATION NOS. 3 AND 9	ADD LIQUID TO RADIATOR	WATER OR ANTI-FREEZE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		ADD ENGINE OIL AS NECESSARY	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		STARTER, GENERATOR AND DISTRIBUTOR OIL CUPS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		BRAKE AND RIDE REGULATOR PINS AND CONNECTIONS	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		ACCELERATOR, ROCKER SHAFT	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		DOOR HARDWARE	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		GREASE GUN CONNECTIONS	CHASSIS GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		WATER PUMP GREASE CUP	WATER PUMP GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		CLUTCH RELEASE FORK	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		*ADD WATER TO STORAGE BATTERY	DISTILLED WATER	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	CHECK TIRE INFLATION		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	DRAIN AND REPLACE ENGINE OIL	ENGINE OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	CLUTCH RELEASE BEARING	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	TRANSMISSION—ADD LUBRICANT	GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	REAR AXLE—ADD LUBRICANT	GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	STEERING GEAR—ADD LUBRICANT	GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	FRONT BRAKE LEVERS	CHASSIS GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	SPRING COVERS	GEAR LUBRICANT	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	WHEEL BEARINGS	WHEEL BEARING GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	SPEEDOMETER DRIVE SHAFT	CHASSIS GREASE	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
**REFILL SHOCK ABSORBERS	SPECIAL OIL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
**FLUSH COOLING SYSTEM																
**REPLACE OIL FILTER CARTRIDGE, CLEAN OIL PAN AND SCREEN																

*IN SUMMER INSPECT BATTERY EVERY 500 MILES OR AT LEAST EVERY 2 WEEKS.

**RECOMMENDED BUT NOT INCLUDED IN LUBRICATIONS 6 AND 12.

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:

THIN REAR AXLE AND TRANSMISSION LUBRICANT—AS REQUIRED FOR LOW TEMPERATURES.

DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING.

RECORD ON OTHER SIDE

Fig. 86. Cadillac 355-B Lubrication Schedule and Record Card. Typical of LaSalle 345-B



LUBRICATION SCHEDULE

CADILLAC 370-B

FILE COPY
DO NOT REMOVE

OWNER'S NAME _____

ADDRESS _____

ENGINE NO. _____

DATE DELIVERED _____

DO NOT WAIT FOR SCHEDULE LUBRICATIONS BEFORE ADDING ENGINE OIL. THE OIL LEVEL SHOULD BE CHECKED EVERY 100 TO 150 MILES AND OIL ADDED IF THE INDICATOR BALL IS BELOW "FULL." THIS IS ESPECIALLY IMPORTANT ON CARS DRIVEN AT HIGH SPEEDS.

LUBRICANT	LUBRICATION NO. AND MILEAGE AT WHICH DUE											
	1	2	3	4	5	6	7	8	9	10	11	12
1000												
2000												
3000												
4000												
5000												
6000												
7000												
8000												
9000												
10000												
11000												
12000												
ADD LIQUID TO RADIATOR	WATER OR ANTI-FREEZE											
ADD ENGINE OIL AS NECESSARY	ENGINE OIL											
STARTER, GENERATOR AND DISTRIBUTOR OIL CUPS	ENGINE OIL											
BRAKE AND RIDE REGULATOR PINS AND CONNECTIONS	ENGINE OIL											
ACCELERATOR AND CHOKE ROCKER SHAFT	ENGINE OIL											
DOOR HARDWARE	ENGINE OIL											
GREASE GUN CONNECTIONS	CHASSIS GREASE											
WATER PUMP GREASE CUP	WATER PUMP GREASE											
CLUTCH RELEASE FORK AND BRAKE ASSISTER	WHEEL BEARING GREASE											
*ADD WATER TO STORAGE BATTERY	DISTILLED WATER											
CHECK TIRE INFLATION												
DRAIN AND REPLACE ENGINE OIL	ENGINE OIL											
CLUTCH RELEASE BEARING	WHEEL BEARING GREASE											
TRANSMISSION—ADD LUBRICANT	GEAR LUBRICANT											
REAR AXLE—ADD LUBRICANT	GEAR LUBRICANT											
STEERING GEAR—ADD LUBRICANT	GEAR LUBRICANT											
FRONT BRAKE LEVERS	CHASSIS GREASE											
SPRING COVERS	GEAR LUBRICANT											
WHEEL BEARINGS	WHEEL BEARING GREASE											
SPEEDOMETER DRIVE SHAFT	CHASSIS GREASE											
FAN	CHASSIS GREASE											
DRAIN OIL FILTER												
**REFILL SHOCK ABSORBERS	SPECIAL OIL											
**CLEAN OIL PAN AND SCREEN AND FLUSH COOLING SYSTEM												

*IN SUMMER INSPECT BATTERY EVERY 500 MILES OR AT LEAST EVERY 2 WEEKS.

**RECOMMENDED BUT NOT INCLUDED IN LUBRICATIONS 6 AND 12.

THE FOLLOWING OPERATIONS CANNOT BE PLACED ON A MILEAGE BASIS AND ARE NOT INCLUDED IN THE ABOVE SCHEDULE:

THIN REAR AXLE AND TRANSMISSION LUBRICANT—AS REQUIRED FOR LOW TEMPERATURES.

DRAIN AND REPLACE REAR AXLE AND TRANSMISSION LUBRICANT—AT BEGINNING OF MILD WEATHER IN SPRING.

RECORD ON OTHER SIDE

Fig. 87. Cadillac 370-B Lubrication Schedule and Record Card. Typical of 452-B

Springs and Shock Absorbers

Front Springs	{ (345-B, 355-B, 370-B) (452-B)
Rear Springs	
Rear Spring Bolts and Bushings	
Shock Absorbers	
Front Spring Bolts and Bushings	{ Same on all models.
Shackle links	

Springs

Two minor changes have been made to give easier riding and freedom from squeaks. Instead of the slightly cambered section of the leaves formerly used, the spring leaves now have a perfectly flat cross-section so as to distribute the bearing over as wide a surface




Fig. 88. The spring covers are provided with a connection for lubricating the springs

as possible. The spring covers are also provided with connections for lubricating the springs. See Fig. 88. To lubricate the springs, first remove the screw plug in each cover and substitute a grease gun connection.

The eye leaf of the front spring is turned up to form the front eye and down to form the rear eye. This is done to give more clearance at the shackles.

The rubber bumper on the frame over the front springs is placed 4 inches back of the center line of the axle on the 345-B, 355-B and 370-B and 5 inches on the 452-B instead of directly over the axle. The purpose of this is to increase the caster slightly when the front springs strike the bumper, and thus help to offset the decrease in caster angle which accompanies deflection of the spring.

An important improvement has been made in the spring shackles. The new spring shackle bolts and bushings are of a new design in which the bolt is threaded into the bushing. (Fig. 89) The threads not

only hold the spring sidewise, but also provide a much greater bearing surface to support the vertical load. They automatically compensate for normal wear and thus, no adjustment is necessary. With the threaded type construction, it is not necessary to have binding or side thrust between the spring eye and the shackle link.

Both the shackle bolt and the bushing are made of hardened steel.

This construction eliminates side slap due to excessive end play, binding due to too tight adjustment, and squeaks due to tight or rust bound shackle bolts.

Better lubrication of the spring shackles is insured as the threads act not only as a reservoir to retain the lubricant for a long time but they also distribute it to every part of the bearing surface.

Many of the shackle bolts, bushings and links, are of the same size and are interchangeable. In order to make the links interchangeable, they are made to receive the bolts in opposite directions; that is, each link receives the large end of one bolt and the small end of the other bolt.

To remove the shackle bolt it is necessary to remove the clamping screws, drive off the link and




Fig. 89. Spring shackle bolts are threaded into the bushing to provide greater bearing surface for the vertical load and to prevent side sway. The rear shackle for the front springs must be set to a specific dimension




Fig. 90. General arrangement of the ride regulator hook-up

screw the bolt out of the bushing. A slot is cut in the large end of each shackle bolt, so that it may be turned with a screw driver. An offset screw driver will prove most convenient for this work.

When assembling the shackles on the car, the shackle bolts should be screwed into place so that the spring-eye is practically centered between the links.

The rear brackets for the front springs are offset with respect to the front outrigger and the shackles at this point must be set to a specified dimension.

The upper shackle bolt should be adjusted to bring the outer face of the inside shackle link $1\frac{5}{8}$ in. from the edge of the frame bracket as shown in the insert Fig. 89. This adjustment is important because the frame tapers at this point and more shackle clearance is necessary to prevent interference between the shackle link and the frame.

Special tools No. HMJ-251 and HMJ-252 are supplied for removing and installing the shackle bushings.

Shock Absorbers

One of the outstanding features of the new cars is the new ride regulator or shock absorber control. See layout of ride control Fig. 90.

The action of the shock absorbers is regulated by a lever mounted on the steering column which, operating through a system of rods and levers, changes the spring pressure on the relief valves in the shock absorbers. See Fig. 91.

The degree of control is adjustable to five different positions and is indicated at all times by a dial gauge on the instrument panel.

The design is such that the "Free" position gives a soft "boulevard" ride with enough control to prevent

excessive rebound while the "Firm" position gives the maximum control necessary at high speeds on rolling, gravel roads.

The shock absorbers are alike on all "B" models except the relief valves which are different on the 452-B. The shock absorbers have the following identification numbers stamped on the back cover plate.

	Identification No.*	Part No.
345-B, 355-B, 370-B		
L. H. Front.....	370-1653A	047717
R. H. Front.....	370-1653B	047718
L. H. Rear.....	370-1653C	047719
R. H. Rear.....	370-1653D	047720
452-B		
L. H. Front.....	452-1653A	040617
R. H. Front.....	452-1653B	040619
L. H. Rear.....	452-1653C	040621
R. H. Rear.....	452-1653D	040623

*The letters A, B, C and D in the identification numbers indicate the location of the shock absorber on the car.




Fig. 91. View of shock absorber showing operating lever




Fig. 92. The oil level should be checked every 6000 miles and sufficient Delco shock absorber oil added to bring it to the bottom of the filler hole

The connections from the ride control lever to the shock absorbers are made by a simple system of rods, rocker arms and shafts. Proper adjustment of these connections is necessary in order that each of the four shock absorbers be in exact step or agreement with the others.

The first operation is to place the control lever in the No. 3 or central position. Then check to see that the idler levers on the cross shaft at the lower edge of the frame are in an approximate vertical position. If they are not, adjust the rods between the left-hand idler lever and the hand control lever to bring the idler levers to this position.

Then, with the control still in the No. 3 position, loosen the clamp screws on the shock absorber levers and turn the control shafts to which the levers are clamped, all the way up as far as they will go, using

a screw driver for this purpose. The shaft in the shock absorbers on the right side should be turned clockwise and those in the left shock absorbers counterclockwise, as viewed from under the car.

With the ride control lever in the No. 3 position, the levers on the front shock absorbers should be approximately $\frac{1}{2}$ in. ahead of a center line at right angles to the frame, while the levers on the rear shock absorbers should be $\frac{1}{2}$ in. toward the rear.

Next, move the hand control lever up to the No. 5 position and tighten the clamp screws on the shock absorber levers.

No other service is required on the shock absorbers, other than lubrication.

Checking the oil level in the shock absorbers is called for on the Lubrication Schedule every 6000 miles. Use only Delco shock absorber oil in the shock absorbers. See Fig. 92.

When adding oil to a shock absorber, if it takes more than a small amount, it indicates that air may be mixed with the oil due to the low level. This air must be expelled before normal action will be restored. To do this, set the regulator control at No. 5 and disconnect the link attached to the axle and move the arm up and down by hand to circulate the oil from cylinder to cylinder. Normal action is indicated by a uniform resistance being offered by the arm through the full range of movement. Then add sufficient oil to bring the oil level to the lower edge of the filler hole.

Steering Gear

Assembly—(345-B, 355-B, 370-B) (452-B)

Steering Wheel—Same on all models.

Steering Worm and Sector—(345-B, 355-B, 370-B) (452-B)

The steering gears on the new cars are of the same hour-glass, worm and sector type as the 355-A steering gears. The automatic take-up for worm and sector backlash used on the 370-A and 452-A has been discontinued as unnecessary on the new models. The steering gear is similar in construction on all "B" cars. The 452-B worm and sector are larger than on the other cars. The La Salle differs from the others in the lighting switch, the length of the column and the mounting flange.

The new steering gears are mounted with the sector shaft inclined upward at an angle with the frame the

same as on the 355-A and 370-A cars to provide sufficient clearance and proper alignment of the steering connecting rod with the steering arm.




Fig. 93. The steel core of the hub, the spokes and the rim are welded into one piece




Fig. 94. Five keyways in the hub provide for accurate alignment of the steering wheel

The steering wheel is of a new type. It has three spokes to give a better view of the instrument panel

and is stronger than the four spoke wheels formerly used. The increased strength is due to the construction of the wheel. It has a steel core (Fig. 93) with the hub, the spokes and the rim welded into one piece. The core is covered with hard rubber composition, which construction gives a sturdy yet light, easily gripped wheel.

Accurate alignment of the steering wheel to permit full vision of the instrument board is provided for by 5 keyways in the hub. With the front wheels straight ahead, one of the steering wheel spokes should be straight up. If the steering wheel is not in this position, it should be relocated on the steering shaft by using the keyway that will bring it nearest the proper position. See Fig. 94.

The adjustments of the steering gear are made in the same manner as on the "A" cars without the automatic take-up.

The steering modulator is of the same construction as on the "A" series cars.

Transmission

Assembly less cover—Same on all models.
Cover—(345-B) (355-B) (370-B, 452-B)

All models have the new Triple-Silent, Syncro-Mesh transmission. This transmission contains new features that are as fundamental as the Syncro-Mesh principle itself. The Syncro-Mesh principle made gear shifting easy and noiseless. The new transmission gives complete running silence in all forward speeds, low as well as intermediate. See Figs. 95, 96 and 97.

Helical gears are used for all forward speeds. The teeth of these gears are cut at an angle of 45° , giving maximum overlap, and are accurately ground and lapped after hardening, insuring quiet operation under all running conditions.

Gear silence has been further assured by the use of large anti-friction bearings which hold the gears rigidly in alignment. The constant-mesh gears on the main shaft run on tapered roller bearings, while the main shaft and countershaft are carried in large ball bearings. See Fig. 98.

The reverse and low sliding gear on the main shaft is carried on a splined sleeve which in turn is splined to the main shaft. This gear is shifted forward to engage with the second-speed constant mesh gear through a jaw clutch, locking the constant mesh gear to the main shaft to produce second speed. The gear

is shifted rearward into mesh with the reverse idler gear giving reverse motion in the conventional manner. High and intermediate speeds are obtained in the same manner as in the "A" cars.

On all models the transmission is supported at the rear in the same manner as on the Cadillac "A" models. The supports, however, are heavier than those formerly used. See Fig 99.

The same type of speedometer drive is used on the "B" models as on the "A" series cars. The correct speedometer drive pinion to use for each gear ratio and rolling radius is given in the table on Page 51.

Service Operations

Adjustment of the yoke travel, which is a service operation, required after considerable wear has occurred on the drums, can now be made without disassembling the transmission further than removing the top cover and the pedal bracket. To make this possible, separate yokes are now used for the high and intermediate drums. These yokes are pivoted on eccentrics which are fastened to adjusting quadrants on the outside of the transmission case. These




Fig. 95. Sectional view of the "Triple-silent, Syncro-mesh" transmission

quadrants are graduated as a guide to the amount of movement. See Figs. 100 and 101. Moving these plates up or down shortens or lengthens the yoke travel.

To adjust the yoke travel the pedal bracket must first be moved far enough from the transmission case to gain access to the yoke adjusting quadrants on the left side.




Fig. 96. Cut-away view of transmission showing helical gears

The yoke travel is measured in the same manner as that on the series "A" cars, except that a separate measurement is taken for each yoke. The front yoke is measured for forward travel, and the rear yoke for rearward travel. The travel of each yoke should be $\frac{3}{32}$ to $\frac{5}{32}$ in.

The two rear quadrants, one on each side of the case, are for adjusting the travel of the rear yoke which operates the intermediate speed drum. The front quadrants are for adjusting the travel of the front yoke which operates the high speed drum.

To change the yoke travel, if the original adjustment has not been distributed, the yoke trunnion plates should be turned up or down. It is extremely important that the two plates for each yoke be moved equal distances and located in exactly the same position as indicated by the graduated scale on each plate, in order to keep the yoke pivots in accurate alignment.

To adjust the rear yoke, turn the two rear quadrants up or down, a little at a time, to give the proper amount of yoke travel. Turning the quadrants up decreases the yoke travel and turning them down increases the travel. The two quadrants should be

moved equal distances and should be located in exactly the same position as indicated by the graduation marks.

Adjust the travel of the front yoke by moving the front quadrants in the same manner as the rear quadrants, moving them up to decrease the yoke travel and down to increase its travel.

The removal of the transmission from the engine is similar to that on the "A" series Cadillac cars. The transmission has the additional support at the rear, which must be disconnected before the transmission can be removed. The clutch control valve must also be disconnected from the power cylinder to remove the pedal assembly.

The method of disassembling the transmission is different from that previously employed in that the universal joint must first be removed and the main shaft taken out through the top of the transmission housing.

Disassemble the transmission as follows:

1. Drain the transmission and remove the cover.
2. Remove the synchronizing yokes and the yoke stop.
3. Remove ball socket and universal joint, using special wrench (Tool No. HM109217) and puller (Tool No. HM109416-12).




Fig. 97. Exploded view of transmission synchronizing mechanism

4. Remove universal joint housing and countershaft rear bearing washer.
5. Remove capscrew in rear end of countershaft.
6. Remove clutch release yoke, bearing and oil tube.
7. Remove clutch connection bearing cap (thin head capscrews).
8. Remove snap ring from clutch connection bearing.

SPEEDOMETER PINION CHART

Car Model	Gear Rates	Number of Teeth on Pinion	Part Number	Rolling Radius
452-B (7.50 x 18 in. Tires)	4.31 to 1	19	848178	15 $\frac{3}{8}$ to 15 $\frac{7}{8}$ in. (Fast) 15 $\frac{7}{8}$ in. 15 $\frac{7}{8}$ to 16 $\frac{1}{8}$ in. (Slow)
345-B, 355-B (7.00 x 17 in. Tires)	4.36 to 1	20	848122	14 $\frac{3}{4}$ to 15 $\frac{1}{4}$ in. (Fast) 15 $\frac{1}{4}$ in. 15 $\frac{1}{4}$ to 15 $\frac{1}{2}$ in. (Slow)
345-B, 355-B (7.00 x 17 in. Tires)	4.60 to 1	22	848124	14 $\frac{1}{4}$ to 14 $\frac{5}{8}$ in. (Fast) 14 $\frac{5}{8}$ in. 14 $\frac{5}{8}$ to 14 $\frac{7}{8}$ in. (Slow)
370-B (7.50 x 17 in. Tires)	4.60 to 1	21	848123	14 $\frac{7}{8}$ to 15 $\frac{3}{8}$ in. (Fast) 15 $\frac{3}{8}$ in. 15 $\frac{3}{8}$ to 15 $\frac{5}{8}$ in. (Slow)
452-B (7.50 x 18 in. Tires)	4.64 to 1	20	848122	15 $\frac{3}{4}$ to 16 $\frac{1}{4}$ in. (Fast) 16 $\frac{1}{4}$ in. 16 $\frac{1}{4}$ to 16 $\frac{1}{2}$ in. (Slow)
370-B (7.50 x 17 in. Tires)	4.80 to 1	22	848124	14 $\frac{7}{8}$ to 15 $\frac{1}{4}$ in. (Fast) 15 $\frac{1}{4}$ in. 15 $\frac{1}{4}$ to 15 $\frac{1}{2}$ in. (Slow)




Fig. 98. The second and low speed gears run on tapered roller bearings

9. Remove reverse idler gear.
10. Push clutch connection, main shaft and countershaft assemblies toward rear of housing until countershaft drops down.
11. Remove clutch connection through front of housing.
12. Remove main shaft rear bearing and take main shaft out through top of housing.
13. Remove both countershaft bearings and take countershaft out through top of housing.
14. Disassemble main shaft assembly if necessary by pulling off splined sleeve together with the low and second speed gears and bearings.

Reassemble the transmission as follows:

1. Install countershaft in running position in housing without bearings.
2. Install main shaft and clutch connection assemblies.




Fig. 99. Adjustment of the transmission supports is identical to that of the "A" models




Fig. 100. Quadrants for adjusting yoke travel

3. Install main shaft bearing and snap ring in clutch connection bearing.
4. Install bearings on countershaft from outside.
5. Install washer and cap screw on rear end of countershaft.
6. Install universal joint housing.
7. Install clutch connection bearing cap.
8. Install reverse idler gear.
9. Install clutch release bearing, yoke and oil tube.
10. Install universal joint, using pusher (Tool No. HM109422).
11. Install synchronizing yokes and yoke stop and adjust yoke travel to $\frac{3}{32}$ to $\frac{5}{32}$ in.
12. Install transmission cover.
13. Install and adjust ball socket over universal joint. (Adjust ball socket in same manner as in "A" series cars.)




Fig. 101. Cross-sectional view of transmission showing yoke eccentrics

Wheels, Rims and Tires

Hubs—Same on all models.

Wheels	} (345-B, 355-B) (370-B) (452-B)
Tires	

Wheels and Rims

The new wheels are smaller than any previously used. The rim diameter is 17 in. on the 345-B, 355-B and 370-B and 18 inches on the 452-B.

Two types of wheels—wire wheels and demountable wood wheels—are furnished. Wire wheels are stand-




Fig. 102. Detachable discs may be installed on wire wheels to give the appearance of disc wheels

ard. Disc wheels are not supplied; instead, detachable discs (Fig. 102) are supplied for installing on the wire wheels to give the appearance of disc wheels. The wood wheels are interchangeable on the same hubs and carriers as the wire wheels.

"Drop center rims" are used instead of the old style flat rims and split locking rings. See Fig. 103. These rims have many advantages over the flat type rims. They have a stronger section and give more support for the tires and are also free from the noises due to a detachable locking ring.

Tires

The tires are of unusually large cross section, especially designed for the drop center rims. The correct pressure for these tires is 40 pounds front and rear, the same as on the "A" series cars. A pressure of 45 pounds should be carried in the front tires on cars driven at high speeds.

Special attention must be given to removal and installation of tires on drop center rims, as these operations are very different from those with flat rims.

The toe of each bead has a soft rubber tip which must not be damaged in the process of applying or removing the tire. This soft rubber tip protects the tube from chafing.

To remove the tire, first deflate the tube completely and remove the rim nut on the valve stem. Loosen both beads from the bead seats, using a tire tool if necessary. Stand on the tire, opposite the valve stem, with the feet about 15 in. apart as shown in Fig. 104 to force the bead into the rim well.

Insert two tire tools, about 8 in. apart, between the bead and the rim flange near the valve. Leaving one tool in position, pry short lengths of the bead over the flange with the other until the entire bead has been removed. See Fig. 105.

Remove the inner tube before attempting to remove the second bead. Raise the wheel to an upright position, insert a tire tool between the second bead and the rim flange at the top side of the wheel as shown in Fig. 106, and pry the wheel out of the tire.




Fig. 103. Sectional view of tire and drop center rim




Fig. 104. Starting the first tire bead over the rim flange



Fig. 105. Prying short lengths of the first tire bead over the rim flange




Fig. 106. Removing the wheel from the second tire bead



Fig. 107. Installing the first tire bead over the rim flange



Fig. 108. Installing the second tire bead over the rim flange

This operation will be simplified if the soft tip of the bead is first coated with vegetable oil or soft soap.

Before mounting the tire, coat the inside and outside of the bead with vegetable oil soft soap. *Do not use oil or grease.* Soap not only facilitates changing of the tire, but it also protects the tips of the soft rubber beads. Inflate the tube until barely rounded out and insert in the tire with the stem at the tire balancing mark. Place the tire on the rim, guiding the valve through the hole, and apply the rim nut loosely. Push the bottom bead down into the well at the valve and force the remaining portion of the bead over the rim flange, using a tire tool if necessary. See Fig. 107.

Force the top bead over the rim flange and into the well at the point opposite the valve. Kneeling on this side of the tire to hold it in the well, as shown in Fig. 108, pry short lengths of the remaining portion of the bead, working around the rim until the entire bead is in place. Always keep as much of the top bead in the well as possible while prying the remainder of the bead.

Remove the rim nut and screw the locating tool No. HMJ-255 on the valve stem. Then push the valve stem back into the casing (Fig. 109) to make certain that the tube is not pinched under the bead,




Fig. 109. Testing tube for pinching

after which remove the locating tool and reapply the rim nut. With the wheel flat on the floor, inflate the tire slowly, making sure that both sides of the tire are centered on the rim.

NEW TOOLS

Few additional tools are necessary to service the new cars. The majority of the "A" series tools can be used without modification. However, special fittings or details must be used to adapt the carburetor equalizing gauge, HM-109626, and the universal joint puller, HM-109416, to the new models.

Body

Tool for removing closed body inside handles.....	Tool No. HMB-127
Complete set of tools for removing and installing hinge pin bushings.....	Tool No. HMB-99
Bushings puller.....	Tool No. HMB-128
Bushings pusher and pusher guide.....	Tool No. HMB-129
Expansion reamer.....	Tool No. HMB-130
Reamer chuck.....	Tool No. HMB-131
Ratchet wrench.....	Tool No. HMB-132

Brakes

Adapter for lubricating front brake cables.....	Tool No. HMJ-254
---	------------------

Engine

Complete set of tools for removing, installing and burnishing piston pin split bushings.....	Tool No. HMJ-250
Bar for expanding bushing.....	Tool No. HMJ-250-1
Bar for burnishing bushing in place.....	Tool No. HMJ-250-2
Plug for removing and installing bushing.....	Tool No. HMJ-250-3
Arbor press plate for removing, installing and burnishing bushing.....	Tool No. HMJ-250-4

Harmonic balancer puller HM-109614 can be adapted for use on the new models by elongating the holes in the puller bar to bring the puller bolts 1 in. closer together.

Gasoline System

Tool for holding carburetor air valve piston while removing the aspirating tube (370-B, 452-B carburetors).....	Tool No. HMJ-253
Nipples for adapting carburetor equalizing gauge HM-109626, to the new models.....	<div> <div></div> <div>Tool No. HM-109626</div> </div> <div> <div></div> <div>Detail No. 6</div> </div>

Spring Shackles

Tool for removing spring shackle threaded type bushing.....	Tool No. HMJ-251
Tool for installing spring shackle threaded type bushing.....	Tool No. HMJ-252

Universal Joint

Short fingers for use with universal joint puller HM-109416.....	<div> <div></div> <div>Tool No. HM-109416</div> </div> <div> <div></div> <div>Detail No. 12</div> </div>
--	--

Note: To use these fingers it is necessary to shorten the puller pilot $1\frac{3}{4}$ in. and to elongate the finger holes in the screw plate to bring the fingers approximately 1 in. closer together.

Tires

Tool for locating valve stem when installing tires on drop center rim.....	Tool No. HMJ-255
--	------------------

Subject and Remarks	LaSalle	Cadillac			
	345-B	355-B	370-B	452-B	
FRONT AXLE					
Type.....	Reverse Elliott	Reverse Elliott	Reverse Elliott	Reverse Elliott	Reverse Elliott
Tread.....	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "	59 $\frac{7}{8}$ "
Camber of front wheel (angle with vertical).....	1 $\frac{1}{2}$ °	1 $\frac{1}{2}$ °	1 $\frac{1}{2}$ °	1 $\frac{1}{2}$ °	1 $\frac{1}{2}$ °
Angle between steering knuckle bolt and vertical.....	7 $\frac{3}{4}$ °	7 $\frac{3}{4}$ °	7 $\frac{3}{4}$ °	7 $\frac{3}{4}$ °	7 $\frac{3}{4}$ °
Angle between steering knuckle bolt and wheel spindle.....	99 $\frac{1}{4}$ °	99 $\frac{1}{4}$ °	99 $\frac{1}{4}$ °	99 $\frac{1}{4}$ °	99 $\frac{1}{4}$ °
Caster angle.....	2 $\frac{1}{2}$ -3 $\frac{1}{2}$ °	2 $\frac{1}{2}$ -3 $\frac{1}{2}$ °	2 $\frac{1}{2}$ -3 $\frac{1}{2}$ °	2 $\frac{1}{2}$ -3 $\frac{1}{2}$ °	2-3°
Angle between spring seats and vertical plane of I-beam.....	90°	90°	90°	90°	90°
Road clearance under front axle.....	8 $\frac{1}{8}$ "	8 $\frac{1}{8}$ "	8 $\frac{5}{8}$ "	8 $\frac{5}{8}$ "	8 $\frac{3}{8}$ "
Measure with new tires inflated to 40-45 lbs. and no load in car.					
Steering cross-rod end spring—					
Free length.....	2 $\frac{3}{32}$ "	2 $\frac{3}{32}$ "	2 $\frac{3}{32}$ "	2 $\frac{3}{32}$ "	2 $\frac{3}{32}$ "
Compression in pounds when compressed to $\frac{1}{16}$ in.....	200-225	200-225	200-225	200-225	200-225
Stop screw adjustment (clearance between tire and nearest point of possible interference).....	1 $\frac{1}{2}$ -3 $\frac{1}{4}$ "	1 $\frac{1}{2}$ -3 $\frac{1}{4}$ "	1 $\frac{1}{2}$ -3 $\frac{1}{4}$ "	1 $\frac{1}{2}$ -3 $\frac{1}{4}$ "	1 $\frac{1}{2}$ -3 $\frac{1}{4}$ "
Toe-in of front wheels.....	1 $\frac{1}{8}$ -1 $\frac{1}{4}$ "	1 $\frac{1}{8}$ -1 $\frac{1}{4}$ "	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "	1 $\frac{1}{8}$ "
Unit number location.....					
All models—On top of R. H. spring pad.					
REAR AXLE					
Type of axle.....	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.	$\frac{3}{4}$ Flt.
Tread.....	61"	61"	61"	61"	61"
Axle shaft length, left side (overall).....	33 $\frac{1}{16}$ "	33 $\frac{1}{16}$ "	33 $\frac{1}{16}$ "	33 $\frac{1}{16}$ "	33 $\frac{1}{16}$ "
Axle shaft length, right side (overall).....	35 $\frac{1}{16}$ "	35 $\frac{1}{16}$ "	35 $\frac{1}{16}$ "	35 $\frac{1}{16}$ "	35 $\frac{1}{16}$ "
Gear ratios—					
High.....	4.36:1	4.36:1	4.60:1	4.60:1	4.31:1
Low.....	4.60:1	4.60:1	4.60:1	4.80:1	4.64:1
Propeller shaft length (overall)—					
130-in. wheelbase.....	55 $\frac{7}{8}$ "				
136-in. wheelbase.....	61 $\frac{3}{32}$ "				
134-in. wheelbase.....		59 $\frac{3}{32}$ "		54 $\frac{3}{16}$ "	
140-in. wheelbase.....		65 $\frac{3}{32}$ "		60 $\frac{3}{16}$ "	
143-in. wheelbase.....					54 $\frac{3}{16}$ "
149-in. wheelbase.....					60 $\frac{3}{16}$ "
Road clearance (minimum) under rear axle.....	7 $\frac{5}{8}$ "	7 $\frac{5}{8}$ "	8 $\frac{1}{8}$ "		8 $\frac{1}{16}$ "
To be measured with tires inflated to 40 lbs. and no load in car.					
Unit number location.....					
All models—Rear surface of housing at lower R. H. side.					
BRAKES					
Type.....	Mechanical	Mechanical	Mechanical with Vacuum Assister	Mechanical with Vacuum Assister	Mechanical with Vacuum Assister
Braking area (foot brakes)—total in square inches.....	238	238	238	274.6	274.6
Braking power division.....	60% front 40% rear	60% front 40% rear	60% front 40% rear	60% front 40% rear	60% front 40% rear
Clearance between pedal and under side of toe-board.....	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "
Clearance secured by turning adjusting nut on cam lever.					
Drums—					
Nominal inside diameter.....	15"	15"	15"	16"	16"
Thickness (approximately).....	$\frac{9}{32}$ "	$\frac{9}{32}$ "	$\frac{9}{32}$ "	$\frac{9}{32}$ "	$\frac{9}{32}$ "
Lining—					
Length per wheel.....	29 $\frac{3}{4}$ "	29 $\frac{3}{4}$ "	29 $\frac{3}{4}$ "	31 $\frac{5}{8}$ "	31 $\frac{5}{8}$ "
Thickness.....	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "
Width.....	2"	2"	2"	2 $\frac{1}{4}$ "	2 $\frac{1}{4}$ "
CLUTCH					
Type.....	Plate	Plate	Plate	Plate	Plate
Clearance between pedal and bottom of toe-board.....	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "	1 $\frac{1}{4}$ -3 $\frac{1}{8}$ "
Disc facings—					
Area—total in square inches.....	219.1	219.1	219.1	247.4	247.4
Diameter inside.....	5 $\frac{1}{2}$ "	5 $\frac{1}{2}$ "	5 $\frac{1}{2}$ "	6 $\frac{1}{2}$ "	6 $\frac{1}{2}$ "
Diameter outside.....	10"	10"	10"	11"	11"
Number used.....	4	4	4	4	4
Thickness.....	.135-.145"	.135-.145"	.135-.145"	.135-.145"	.135-.145"
Driven discs, number of.....	2	2	2	2	2
Driving plates, number of.....	3	3	3	3	3
Pressure springs, number of.....	12	12	12	12	12

SPECIFICATIONS

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
COOLING SYSTEM				
Fan				
Diameter.....	20 ³ / ₄ "	20 ³ / ₄ "	20 ³ / ₄ "	20 ³ / ₄ "
Belt--				
Length (center to center).....	8 ¹ / ₂ "	8 ¹ / ₂ "	14"	14"
Width.....	7 ⁷ / ₈ "	7 ⁷ / ₈ "	7 ⁷ / ₈ "	7 ⁷ / ₈ "
Blades--				
Pitch at tip of blade (spiral blades).....	31°	31°	31°	31°
Number used.....	6	6	6	6
Ratio of fan R.P.M. to engine R.P.M.....	9/10 to 1	9/10 to 1	9/10 to 1	9/10 to 1
Hose Connections				
Cylinder to radiator (top), (2 used)--				
Diameter, inside.....	1 ¹ / ₄ "	1 ¹ / ₄ "	1 ¹ / ₄ "	1 ¹ / ₄ "
Length.....	13 ¹ / ₄ "	13 ¹ / ₄ "	7 ¹ / ₄ "	7 ¹ / ₄ "
Cylinder to elbow (2 used)--				
Diameter, inside.....	2 ¹ / ₄ "	2 ¹ / ₄ "
Length.....	1 ¹ / ₄ "	1 ¹ / ₄ "
Elbow to pump--				
Diameter, inside.....	1 ⁵ / ₈ "	1 ⁵ / ₈ "
Length.....	16 ⁵ / ₈ "	16 ⁵ / ₈ "
Pump to radiator (two used on 370-B, 452-B)				
Diameter, inside.....	1 ⁷ / ₈ "	1 ⁷ / ₈ "	1 ³ / ₄ "	1 ³ / ₄ "
Length.....	10 ³ / ₈ "	10 ³ / ₈ "	4"	4"
Radiator				
Area of radiator core in square inches.....	476	476	496	550
Capacity of cooling system.....	6 ¹ / ₂ gal.	6 ¹ / ₂ gal.	6 gal.	7 gal.
Thermostatic shutter control operating temperature.....	155°-165°F	155°-165°F	155°-165°F	155°-165°F
ELECTRICAL SYSTEM				
Battery				
Delco type number.....	17 BW	17 BW	21 CW	25 AW
Capacity, rated in ampere hours.....	130	130	160	190
Charging rate on bench--				
Start in amperes.....	10	10	10	10
Finish in amperes.....	8	8	8	8
Plates, number of.....	17	17	21	25
Terminal grounded.....	Positive	Positive	Positive	Positive
Voltage--rated.....	6	6	6	6
Circuit Control Box				
Delco-Remy type number.....	480Z	480Z	480Z	480Z
<i>This box contains the circuit breakers, the generator cut-out relay and the horn relay.</i>				
Generator				
Delco-Remy type number.....	927-S	927-S	931-D	931-D
Car speed for maximum normal charging (approx.).....	22 m.p.h.	22 m.p.h.	23 m.p.h.	23 m.p.h.
Charging rate on car (in amperes)--Cold.....	22-24	22-24	22-24	22-24
Current regulation				
All models--Third brush thermostat control.				
Ratio of generator R. P. M. to engine R. P. M.....	1.35 to 1	1.35 to 1	1.40 to 1	1.40 to 1
Thermostat operating temperature.....	175°F	175°F	175°F	175°F
Voltage--rated.....	6	6	6	6
Horn				
Delco-Remy (Klaxon) type number.....	K-26 1379 1380	K-22 1160 1161	K-22 1160 1161	K-22 1160 1161
Number used.....	2	2	2	2
Ignition				
COIL				
Delco-Remy type number.....	528-G	528-G	530-K	530-K
DISTRIBUTOR				
Delco-Remy type number.....	660-Y	660-Y	004092	004093
Angle between contact arms.....	30°	30°	22 ¹ / ₂ °	22 ¹ / ₂ °
Contact point gap.....	.018-.022"	.018-.022"	.018-.024"	.014-.018"
Firing order.....				
345-B, 355-B--1-2-7-8-4-5-6-3				
370-B--1-4-9-8-5-2-11-10-3-6-7-12				
452-B--1-8-9-14-3-6-11-2-15-10-7-4-13-12-5-16				

NOTE: Cylinders are numbered from the front, alternating between the two sides. On 345-B and 355-B, No. 1 is right front; on 377-B and 452-B, No. 1 is left front.

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Ignition (Continued)				
Spark advance (degrees on flywheel)—				
Automatic.....	18°	19°	30°	32°
Timing mark (IG/A) ahead of center.....	{ 9° 12' 1 1/8"	{ 9° 12' 1 1/8"	{ 15° 1 1/8"	{ 10 1/4° 1 1/4"
SPARK PLUGS				
A. C. type number.....	D-8	D-8	D-8	D-8
Gap.....	.025-.028"	.025-.028"	.025-.028"	.025-.028"
Thread.....	Metric, 18 mm.	Metric, 18 mm.	Metric, 18 mm.	Metric, 18 mm.
IGNITION SWITCH				
Delco-Remy type number.....	426-T	426-T	426-T	426-T
Starting Motor				
Delco-Remy type number.....	728-P	728-P	000495	000495
Brushes—number used.....	4	4	4	4
Engine cranking speed.....	90-100 r.p.m.	90-100 r.p.m.	80 r.p.m.	80 r.p.m.
Gear ratio between armature pinion and flywheel.....	26 to 1	26 to 1	21 to 1	21 to 1
Number of teeth in flywheel gear.....	113	113	113	113
Number of poles.....	4	4	6	6
ENGINE				
Angle between cylinder blocks.....	90°	90°	45°	45°
Bore.....	3 3/8"	3 3/8"	3 1/8"	3"
Compression ratio—				
Standard.....	5.38 to 1	5.38 to 1	5.30 to 1	5.35 to 1
Optional.....	5.7 to 1	5.7 to 1	5.08 to 1	5.00 to 1
Horsepower—				
Rated (taxable).....	36.45	36.45	46.9	57.5
Developed at 3000 R. P. M.....	115	115	135	165
Developed at 3400 R. P. M.....			370-B	452-B
Model.....	345-B	355-B	4"	4"
Stroke.....	4 1/8"	4 1/8"	I-Overhead	I-Overhead
Valve arrangement.....	L-head	L-head	368	452
Piston displacement in cubic inches.....	353	353	6	6
Point of suspension, number of.....	6	6		
Camshaft				
Number of bearings.....	4	4	4	5
Diameter and length of bearings—				
No. 1 (front).....	1 1/8 x 1.802"	1 1/8 x 1.802"	2 x 3"	2 x 3"
No. 2.....	2.3392 x 1.00"	2.3392 x 1.00"	2 1/8 x 1 3/8"	2 1/8 x 1 3/8"
No. 3.....	2.3392 x 1 1/8"	2.3392 x 1 1/8"	2 1/8 x 1 3/8"	2 1/8 x 1 3/8"
No. 4 (rear except on 452-B).....	1 5/8 x 1 1/8"	1 5/8 x 1 1/8"	2 1/8 x 2 1/8"	2 1/8 x 1 3/8"
No. 5 (rear 452-B).....				2 1/8 x 2 1/8"
Chains				
Camshaft chain—				
Number of links.....	54	54	110	110
Pitch.....	1 1/2"	1 1/2"	.375"	.375"
Type—Morse No.....	766	766	766 Duplex	766 Duplex
Width.....	1 3/4"	1 3/4"	1 1/2"	1 1/2"
Generator and water pump drive chain.....				
Number of links.....	58	58	Only one chain used. See "Camshaft Chain" for details	
Pitch.....	1 1/2"	1 1/2"		
Type—Morse No.....	766	766		
Width.....	1 1/4"	1 1/4"		
Connecting Rods				
Center to center length.....	10 1/2"	10 1/2"	9 1/4"	9 1/4"
Clearance between connecting-rod bearing and crankpin.....	.003"	.003"	.0025"	.0025"
Diameter and length of connecting rod bearings.....	2 3/8 x 1 3/8"	2 3/8 x 1 3/8"	2 1/2 x 1 1/8"	2 1/2 x 1 1/8"
Piston pin lubrication.....				
Force feed—connecting rods rifle-bored.....				
Crankshaft and Main Bearings				
Clearance between crankshaft and main bearings.....	.0015"	.0015"	.002-.004"	.002-.004"
Diameter and length of main bearing journals—				
No. 1 (front).....	2 3/8 x 1 1/2"	2 3/8 x 1 1/2"	2 5/8 x 2 1/8"	2 5/8 x 2 1/8"
No. 2.....	2 3/8 x 1 3/8"	2 3/8 x 1 3/8"	2 5/8 x 1 3/8"	2 5/8 x 1 3/8"
No. 3 (rear on 345-B, 355-B).....	2 3/8 x 2 3/8"	2 3/8 x 2 3/8"	2 5/8 x 1 1/2"	2 5/8 x 1 1/2"
No. 4 (rear on 370-B).....			2 5/8 x 3 1/8"	2 5/8 x 1 3/8"
No. 5 (rear on 452-B).....				2 5/8 x 3 1/8"

SPECIFICATIONS

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Crankshaft and Main Bearings (Continued)				
Diameter and length of crankpin journal.....	$2\frac{3}{8} \times 2\frac{3}{4}$ "	$2\frac{3}{8} \times 2\frac{3}{4}$ "	$2\frac{1}{2} \times 2\frac{1}{4}$ "	$2\frac{1}{2} \times 2\frac{1}{4}$ "
Harmonic balancer used.....	No	No	Yes	Yes
Length of crankshaft—overall.....	$28\frac{33}{32}$ "	$28\frac{33}{32}$ "	$35\frac{13}{16}$ "	$44\frac{5}{16}$ "
Length of crankshaft—front to rear bearings inclusively.....	$23\frac{33}{32}$ "	$23\frac{33}{32}$ "	$30\frac{33}{32}$ "	$39\frac{9}{32}$ "
Number of main bearings.....	3	3	4	5
Lubrication				
OIL FILTER				
Make.....			Cuno	Cuno
Cartridge type.....				
PRESSURE REGULATOR				
Pressure, normal when oil is warm—				
30 M. P. H.....	30 lbs.	30 lbs.	30 lbs.	30 lbs.
60 M. P. H.....	11 lbs.	11 lbs.	14 lbs.	14 lbs.
Valve opens at.....				
Piston Pins				
Diameter—standard.....	$\frac{7}{8}$ "	$\frac{7}{8}$ "	$\frac{7}{8}$ "	$\frac{7}{8}$ "
Pistons and Rings				
Pistons—				
Clearance at top.....	.016"	.016"	.012"	.0125"
Clearance at bottom.....	.002-.003"	.002-.003"	.002-.003"	.003"
Rings—				
Number of compression rings.....	2	2	2	3
Number of oil rings.....	2	2	2	1
Width of rings—				
Upper compression.....	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "	$\frac{3}{16}$ "
Lower compression (Two on 452-B).....	$\frac{1}{8}$ "	$\frac{1}{8}$ "	$\frac{1}{8}$ "	$\frac{1}{8}$ "
Upper oil.....	$\frac{5}{32}$ "	$\frac{5}{32}$ "	$\frac{1}{8}$ "	
Lower oil.....	$\frac{1}{16}$ "	$\frac{1}{16}$ "	$\frac{1}{16}$ "	$\frac{1}{16}$ "
Engine unit number location.....				
All models—left rear engine support.				
Valves, Exhaust				
Clearance between stem and camslide.....	.006	.006	Automatic	Automatic
Clear diameter (port opening).....	$1\frac{1}{2}$ "	$1\frac{1}{2}$ "	$1\frac{5}{16}$ "	$1\frac{5}{16}$ "
Length—overall.....	$6\frac{1}{2}$ "	$6\frac{1}{2}$ "	$6\frac{9}{16}$ "	$6\frac{9}{16}$ "
Lift.....	$\frac{23}{64}$ "	$\frac{23}{64}$ "	$\frac{11}{32}$ "	$\frac{11}{32}$ "
Material.....	Silchrome steel	Silchrome steel	Silchrome steel	Silchrome steel
Seat angle.....	45°	45°	45°	45°
Seat width.....	$\frac{5}{16}$ "	$\frac{5}{16}$ "	$\frac{5}{16}$ "	$\frac{5}{16}$ "
Stem diameter.....	$\frac{3}{8}$ "	$\frac{3}{8}$ "	$\frac{3}{32}$ "	$\frac{3}{32}$ "
Valves, Inlet				
Clearance between stem and camslide.....	.008	.008	None	None
Clear diameter (port opening).....	$1\frac{1}{2}$ "	$1\frac{1}{2}$ "	$1\frac{5}{16}$ "	$1\frac{5}{16}$ "
Length—overall.....	$6\frac{1}{2}$ "	$6\frac{1}{2}$ "	$6\frac{9}{16}$ "	$6\frac{9}{16}$ "
Lift.....	$\frac{23}{64}$ "	$\frac{23}{64}$ "	$\frac{11}{32}$ "	$\frac{11}{32}$ "
Material.....	Tungsten steel	Tungsten steel	Tungsten steel	Tungsten steel
Seat angle.....	30°	30°	45°	45°
Seat width.....	$\frac{1}{16}$ "	$\frac{1}{16}$ "	$\frac{5}{16}$ "	$\frac{5}{16}$ "
Stem diameter.....	$\frac{3}{8}$ "	$\frac{3}{8}$ "	$\frac{11}{32}$ "	$\frac{11}{32}$ "
Valve Springs				
Free length—				
Inner valve spring.....			1.944"	1.944"
Outer valve spring.....	2.835-2.853"	2.835-2.853"	2.215-2.235"	2.347-2.378"
Pressure in pounds, inner valves—				
Compressed to 1.751 in. (valve closed).....			18-21 lbs.	18-21 lbs.
Compressed to 1.407 in. (valve open).....			49-54 lbs.	49-54 lbs.
Pressure in pounds, outer valves—				
Compressed to 2.5 in. (valve closed).....	77-81 lbs.	77-81 lbs.		
Compressed to 1.922 in. (valve closed).....			48-52 lbs.	
Compressed to 1.875 in. (valve closed).....				42-47 lbs.
Compressed to 2.148 in. (valve open).....	156-164 lbs.	156-164 lbs.		
Compressed to 1.578 in. (valve open).....			111-120 lbs.	
Compressed to 1.531 in. (valve open).....				87-92 lbs.
<i>Spring must not show any set when compressed with coils touching.</i>				

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Valve Timing				
Intake opens—before top center (.006 in. clearance on 345-B, 355-B)....	6°	6°	T. D. C.	T. D. C.
Intake closes—after bottom center (.006 in. clearance on 345-B, 355-B)....	42°	42°	44°	44°
Exhaust opens—before bottom center (.008 in. clearance on 345-B, 355-B)....	38°	38°	39°	39°
Exhaust closes—after top center (.008 in. clearance on 345-B, 355-B)....	2°	2°	5°	5°
FRAME				
Car				
Chassis model designation.....	345-B	355-B	370-B	452-B
Chassis unit number location.....
All models—rear of L. H. side of radiator cross member.				
First serial number.....	1,100,001	1,200,001	1,300,001	1,400,001
Length of car—overall (approximately).....	204 ¹ / ₄ -210 ¹ / ₄ "	207 ¹ / ₄ -213 ¹ / ₄ "	207 ¹ / ₄ -213 ¹ / ₄ "	216 ¹ / ₄ -222 ¹ / ₄ "
Wheelbase.....	130-136"	134-140"	134-140"	143-149"
Width of car—maximum overall at front.....	76 ¹ / ₈ "	76 ¹ / ₄ "	76 ¹ / ₄ "	76 ¹ / ₄ "
Frame				
Number of cross members.....	5	5	5	5
Side bar—				
Depth.....	9"	9"	9"	10"
Thickness.....	⁵ / ₁₆ "	⁵ / ₁₆ "	⁵ / ₁₆ "	⁵ / ₁₆ "
Width—top and bottom.....	21 ¹ / ₂ "	21 ¹ / ₂ "	21 ¹ / ₂ "	21 ¹ / ₂ "
Measurements taken at deepest part of frame.				
Width of frame at—				
Front.....	29 ¹ / ₂ "	29 ¹ / ₂ "	29 ¹ / ₂ "	29 ¹ / ₂ "
Rear.....	38"	38"	38"	38"
GASOLINE SYSTEM				
Air cleaner and intake silencer, make of.....	A.C.	A.C.	A.C.	A.C.
Feed.....
All models—A.C. fuel pump.				
Gasoline line location—				
All models—outside of left frame side bar.				
Gasoline gauge (electric) on instrument panel, make of.....	A.C.	A.C.	A.C.	A.C.
Tank capacity (supply).....	30 gal.	30 gal.	30 gal.	30 gal.
Carburetor				
Type.....	Air valve	Air valve	Expanding air valve	Expanding air valve
Float setting.....	⁷ / ₁₆ "	⁷ / ₁₆ "
Size.....	2"	2"	1 ¹ / ₂ "	1 ¹ / ₂ "
Size of metering pin.....	10	12
Size of nozzle (Nozzle No.).....	19	19
Thermostats—				
Throttle pump control operates.....	110-115°	110-115°
Bulb Data LIGHTING SYSTEM				
Voltage—all bulbs.....	6-8	6-8	6-8	6-8
Back-up and stop lamp—				
Candle power.....	15	15	15	15
Contact.....	Single	Single	Single	Single
Mazda No.....	85	85	85	85
Domie (closed cars)—				
Candle power.....	6	6	6	6
Contact.....	Single	Single	Single	Single
Mazda No.....	81	81	81	81
Fender lamp—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Headlamp—				
Candle power.....	32-32	21-21-32	21-21-32	21-21-32
Contact.....	Double	Triple	Triple	Triple
Mazda No.....	1000	3001	3001	3001


SPECIFICATIONS

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Bulb Data (Continued)				
Instrument (dash) lamps—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Map reading lamp—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Rear quarter lamp—				
Candle power.....	6	6	6	6
Contact.....	Single	Single	Single	Single
Mazda No.....	81	81	81	81
Tail lamp—				
Candle power.....	3	3	3	3
Contact.....	Single	Single	Single	Single
Mazda No.....	63	63	63	63
Headlamps				
Lens diameter.....	10½"	9½"	9½"	9½"
Switches				
Delco-Remy type number—				
Back-up.....	440-E	440-E	440-E	440-E
Lighting.....	486-H	486-S	486-S	486-S
Stop light.....	474-Z	474-Z	474-Z	474-Z
LUBRICATION				
Fan				
345-B, 355-B—overflow from pressure regulator.				
370-B, 452-B—gun lubricated with chassis grease.				
Rear axle—				
Capacity in pints or pounds.....	6	6	6	6
Lubricant recommended (S. A. E. viscosity).....	200 at 210°F	200 at 210°F	200 at 210°F	200 at 210°F
Fill to level of overflow opening.				
Engine—				
Capacity.....	8 qts.	8 qts.	9 qts.	10 qts.
Lubricant recommended (S. A. E. viscosity)				
Summer.....	40-50	40-50	40-50	40-50
Winter.....	20	20	20	20
Transmission—				
Capacity in pints or pounds.....	4½	4½	4½	4½
Fill to level of overflow opening.				
Lubricant recommended (S. A. E. viscosity).....	200 at 210°F	200 at 210°F	200 at 210°F	200 at 210°F
SPRINGS AND SHOCK ABSORBERS				
Springs				
Type.....	Semi-Elliptic	Semi-Elliptic	Semi-Elliptic	Semi-Elliptic
Length—				
Front.....	39"	39"	39"	42"
Rear.....	58"	58"	58"	60"
Width—				
Front.....	2¼"	2¼"	2¼"	2¼"
Rear.....	2¼"	2¼"	2¼"	2½"
STEERING GEAR				
Connecting Rod (Drag Link)				
Joint springs—				
Free length.....	31"	31"	31"	31"
Pressure in pounds when compressed to 7/8 in.....	175-225	175-225	175-225	175-225
Steering Gear				
Type.....	Hour-glass worm and sector	Hour-glass worm and sector	Hour-glass worm and sector	Hour-glass worm and sector
Ratio (steering gear only).....	17 to 1	17 to 1	17 to 1	17 to 1
Steering wheel diameter.....	18½"	18½"	18½"	18½"
Unit number location.....				
All models—on top of steering gear housing.				

SPECIFICATIONS

63

Subject and Remarks	LaSalle	Cadillac		
	345-B	355-B	370-B	452-B
Steering Modulator				
Springs—				
Free length (approximate).....	1½"	1½"	1½"	1½"
Pressure in pounds when compressed to 1⅞ in.....	95-105	95-105	95-105	95-105
TRANSMISSION				
Gear ratios—				
Low speed.....	2.40 to 1	2.40 to 1	2.40 to 1	2.40 to 1
Second speed.....	1.47 to 1	1.47 to 1	1.47 to 1	1.47 to 1
High speed (direct drive).....	1 to 1	1 to 1	1 to 1	1 to 1
Reverse speed.....	2.49 to 1	2.49 to 1	2.49 to 1	2.49 to 1
Unit number location—				
All models—on flange next to flywheel bell housing at upper L. H. side.				
Main Shaft Assembly				
Clearance between—				
Splines on mainshaft and splineways on drums.				
New limits.....	.0065-.009"	.0065-.009"	.0065-.009"	.0065-.009"
Splines on mainshaft and splineways in sliding gear coupling.				
New limits.....	.0005-.0015"	.0005-.0015"	.0005-.0015"	.0005-.0015"
Splines on mainshaft and splineways in sleeve for reverse gear.				
New limits.....	.000-.001"	.000-.001"	.000-.001"	.000-.001"
Splines on mainshaft sleeve and splineways in reverse gear.				
New limits.....	.0005-.0015"	.0005-.0015"	.0005-.0015"	.0005-.0015"
Yoke Assembly				
Plunger main spring—				
Free length (approximately).....	1⅞"	1⅞"	1⅞"	1⅞"
Pressure in pounds when compressed to ⅞ in.....	24-26	24-26	24-26	24-26
Plunger valve spring—				
Free length (approximately).....	5⅞"	5⅞"	5⅞"	5⅞"
Pressure in pounds when compressed to ⅞ in.....	2¾-3¼	2¾-3¼	2¾-3¼	2¾-3¼
Yoke return spring—				
Free length inside loops (approximately).....	2¾"	2¾"	2¾"	2¾"
Tension in pounds when stretched to 2⅞ in.....	1¼-1¾	1¼-1¾	1¼-1¾	1¼-1¾
Yoke throw from neutral to applied position—				
Limits when new.....	1⅞-2"	1⅞-2"	1⅞-2"	1⅞-2"
Speedometer Gears				
Driving gear (7 teeth) part number.....	848176	848176	848176	848176
WHEELS, RIMS AND TIRES				
Rims				
Type.....	Drop center	Drop center	Drop center	Drop center
Diameter.....	17"	17"	17"	18"
Width.....	4.19"	4.19"	4.19"	4.19"
Tires				
Balancing mark location.....				
Mark on tire should be placed in line with valve stem.				
Pressure in pounds—				
Normal.....				
Front.....	40	40	40	40
Rear.....	40	40	40	40
Size.....	7.00 x 17"	7.00 x 17"	7.50 x 17"	7.50 x 18"



Cadillac V-8, V-12, V-16 - Fisher-Fleetwood Bodies

Color Distribution Chart

Combination Number	Lower Panels	Rear Quarters, Mouldings, and Upper Panels	Fenders & Chassis	Striping	Wheel Color Application In Production
1	Classic Blue	Classic Blue	Black	Tokio Ivory	Black
2	Black	Black	Black	Tokio Ivory	Black
3	Black	Black	Black	Vincennes Red	Vincennes Red
4	Black	Black	Black	Chantilly Green	Chantilly Green
5	Thessalon Green	Thessalon Green	Thessalon Green	Chantilly Green	Chantilly Green
6	Toledo Brown	Toledo Brown	Toledo Brown	Sankety Buff	Sankety Buff
7	Viceroy Maroon Dark	Viceroy Maroon Dark	Viceroy Maroon Dark	Flamingo Carmine	Flamingo Carmine
8	Cathedral Gray	Cathedral Gray	Cathedral Gray	Vincennes Red	Vincennes Red
9	Garnet Maroon	Black	Black	Tokio Ivory	Black
10	Rouff Beige	Rouff Beige	Rouff Beige	Sealing Wax Red	Sealing Wax Red
11	Grisette Brown Dark	Grisette Brown Dark	Grisette Brown Dark	Sand Dune	Sand Dune
12	Laurel Green	Highland Green	Highland Green	Chantilly Green	Chantilly Green
13	Niagara Blue	Niagara Blue	Niagara Blue	Tokio Ivory	Deep Danube Dusk
14	Josselin Gray	Dallas Gray	Dallas Gray	Syriac Green	Syriac Green

Note: Combinations 9, 12, and 14 are not recommended for the Fleetwood closed body styles. The exterior design of the new "B" series Fleetwood bodies necessitates the finishing of the entire body in one color, allowing application of secondary color to window reveals and belt mouldings, only.

Black wire wheels are optional on order, only, on all combinations.

When demountable wood wheels are specified in color, finish will be in lower panel color.

Black wire wheels are standard on 7-Passenger Sedans, Imperials, Limousines, and Town Cars except on colored fender set combinations.

On combinations offered with colored fenders, when fenders are ordered in black, the wire wheels will be in colors designated, unless otherwise specified.

CADILLAC V-16—SERIES 452B

Group Number 7 - Five Wheel Group

Part Number		Distrib- utor Cost	Dealer Cost	List Price
A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
A-914	Radio	54.50	64.50	89.50
A-810	Burbank Tire Cover	4.50	6.00	10.00
891697	Protection Bar	2.90	3.90	6.00
891623	Hinge Mirror	3.60	4.80	8.00
891307	Handy Kit	2.95	3.75	6.75
A-865	License Frames	2.50	3.25	7.00
892404	Cowl Ventilator Screen	.55	.70	1.25
GROUP 7 TOTAL		\$81.00	\$98.90	\$147.50

Group Number 8 - Six Wheel Group

A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
896473-4	Metal Tire Covers	19.00	25.00	45.00
A-807	Metal Cover Mirrors	9.90	13.20	22.00
A-914	Radio	54.50	64.50	89.50
891307	Handy Kit	2.95	3.75	6.75
A-865	License Frames	2.50	3.25	7.00
892404	Cowl Ventilator Screen	.55	.70	1.25
GROUP 8 TOTAL		\$98.90	\$122.40	\$190.00

On colored Fender Sets with Metal Covers ducoed to match specify Group 8A. Extra charge \$5.00 net and list.

GROUP 8A TOTAL \$103.90 \$127.40 \$195.00

DE LUXE GROUPS

Cadillac V-16—Series 452B

Part Number		Distrib- utor Cost	Dealer Cost	List Price
GROUP 7		\$ 81.00	\$ 98.90	\$147.50
47276	Fleetwood Robe	27.00	31.50	45.00
891550	Duplex Pilot Ray Driving Light	31.25	36.50	57.50
896499	Dual Hot Air Heater	26.25	30.50	47.50
GROUP 7 DE LUXE		\$165.50	\$197.40	\$295.00
GROUP 8		\$ 98.90	\$122.40	\$190.00
47276	Fleetwood Robe	27.00	31.50	45.00
891550	Duplex Pilot Ray Driving Light	31.25	36.50	57.50
896499	Dual Hot Air Heater	26.25	30.50	47.50
GROUP 8 DE LUXE		\$183.40	\$220.90	\$340.00
GROUP 8A DE LUXE		\$188.40	\$225.90	\$345.00

Cadillac V-12—Series 370B

GROUP 5		\$ 30.60	\$ 39.70	\$ 69.50
A-915	Radio	54.50	64.50	89.50
47276	Fleetwood Robe	27.00	31.50	45.00
894390	Dual Hot Air Heater	26.25	30.50	47.50
GROUP 5 DE LUXE		\$138.35	\$166.20	\$250.00
GROUP 5A DE LUXE		\$140.85	\$168.70	\$252.50
GROUP 6		\$ 42.60	\$ 55.50	\$ 98.00
A-915	Radio	54.50	64.50	89.50
47276	Fleetwood Robe	27.00	31.50	45.00
894390	Dual Hot Air Heater	26.25	30.50	47.50
GROUP 6 DE LUXE		\$150.35	\$182.00	\$280.00
GROUP 6A DE LUXE		\$155.35	\$187.00	\$285.00


DISTRIBUTORS ACCESSORY GROUP EQUIPMENT LIST

La Salle V-8 —Series 345B

Cadillac V-8 —Series 355B

Cadillac V-12—Series 370B

Cadillac V-16—Series 452B



June 20, 1932

Prices subject to Change Without Notice

CADILLAC MOTOR CAR COMPANY

Detroit, Michigan, U.S.A.

LaSALLE V-8—SERIES 345B

Group Number 1 - Five Wheel Group

Part Number		Distrib- utor Cost	Dealer Cost	List Price
A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
891695	Metal Tire Cover	7.70	10.10	18.50
891697	Protection Bar	2.90	3.90	6.00
891697	Hinge Mirror	3.60	4.80	8.00
A-864	Handy Kit	2.65	3.45	6.25
A-864	License Frames	2.50	3.25	7.00
892404	Cowl Ventilator Screen	.55	.70	1.25
GROUP 1 TOTAL		\$29.40	\$38.20	\$ 67.00

On colored fender sets with Metal
Tire Cover to match specify Group
1A. Extra charge \$2.50 net and list.

GROUP 1A TOTAL \$31.90 \$40.70 \$ 69.50

CADILLAC V-8—SERIES 355B

Group Number 3 - Five Wheel Group

Part Number		Distrib- utor Cost	Dealer Cost	List Price
A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
891695	Metal Tire Cover F & US	7.70	10.10	18.50
891696	Metal Tire Cover Goodyear	2.90	3.90	6.00
891697	Protection Bar	3.60	4.80	8.00
891623	Hinge Mirror	2.95	3.75	6.75
891307	Handy Kit	2.50	3.25	7.00
A-865	License Frames	.55	.70	1.25
892404	Cowl Ventilator Screen			
GROUP 3 TOTAL		\$29.70	\$38.50	\$ 67.50

On colored fender sets with Metal
Tire Cover to match specify Group
3A. Extra charge \$2.50 net and list.

GROUP 3A TOTAL \$32.20 \$41.00 \$ 70.00

CADILLAC V-12—SERIES 370B

Group Number 5 - Five Wheel Group

Part Number		Distrib- utor Cost	Dealer Cost	List Price
A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
894363	Metal Tire Cover F & US	8.60	11.30	20.50
894364	Metal Tire Cover Goodyear	2.90	3.90	6.00
891697	Protection Bar	3.60	4.80	8.00
891623	Hinge Mirror	2.95	3.75	6.75
891307	Handy Kit	2.50	3.25	7.00
A-865	License Frames	.55	.70	1.25
892404	Cowl Ventilator Screen			
GROUP 5 TOTAL		\$30.60	\$39.70	\$ 69.50

On colored fender sets with Metal
Tire Covers to match specify Group
5A. Extra charge \$2.50 net and list.

GROUP 5A TOTAL \$33.10 \$42.20 \$ 72.00

Group Number 2 - Six Wheel Group

A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
891691-2	Metal Tire Covers	15.40	20.20	37.00
A-807	Metal Cover Mirrors	9.90	13.20	22.00
A-592	Handy Kit	2.65	3.45	6.25
A-864	License Frames	2.50	3.00	7.00
892404	Cowl Ventilator Screen	.55	.70	1.25
GROUP 2 TOTAL		\$40.50	\$52.55	\$ 93.50

On colored Fender Sets with Metal
Covers ducoed to match specify
Group 2A. Extra charge \$5.00 net
and list.

GROUP 2A TOTAL \$45.50 \$57.55 \$ 98.50

Group Number 4 - Six Wheel Group

A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
891691-2	Metal Tire Covers	15.40	20.20	37.00
A-807	Metal Cover Mirrors	9.90	13.20	22.00
891307	Handy Kit	2.95	3.75	6.75
A-865	License Frames	2.50	3.00	7.00
892404	Cowl Ventilator Screen	.55	.70	1.25
GROUP 4 TOTAL		\$40.80	\$52.85	\$ 94.00

On colored Fender Sets with Metal
Covers ducoed to match specify
Group 4A. Extra charge \$5.00 net
and list.

GROUP 4A TOTAL \$45.80 \$57.85 \$ 99.00

Group Number 6 - Six Wheel Group

A-586	Heron Ornament	\$ 9.50	\$12.00	\$ 20.00
1098123	Goddess Ornament			
894360-1	Metal Tire Covers	17.20	22.60	41.00
A-807	Metal Cover Mirrors	9.90	13.20	22.00
891307	Handy Kit	2.95	3.75	6.75
A-865	License Frames	2.50	3.25	7.00
892404	Cowl Ventilator Screen	.55	.70	1.25
GROUP 6 TOTAL		\$42.60	\$55.50	\$ 98.00

On colored Fender Sets with Metal
Covers ducoed to match specify
Group 6A. Extra charge \$5.00 net
and list.

GROUP 6A TOTAL \$47.60 \$60.50 \$103.00

Cadillac V-16, Series 452-B

(143-inch Wheelbase)
(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$4495.00	_____
5-Passenger Standard Sedan.....	4595.00	_____
2-Passenger Roadster.....	4595.00	_____
2-Passenger Convertible Coupe....	4645.00	_____

(149-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Standard Phaeton.....	\$4695.00	_____
5-Passenger Special Phaeton.....	4795.00	_____
5-Passenger Sport Phaeton.....	4945.00	_____
5-Passenger All-Weather Phaeton..	5195.00	_____

(149-inch Wheelbase)

(BODY BY FLEETWOOD)

5-Passenger Sedan.....	\$5095.00	_____
5-Passenger Town Coupe.....	5095.00	_____
7-Passenger Sedan.....	5245.00	_____
7-Passenger Limousine.....	5445.00	_____
5-Passenger Town Cabriolet.....	5795.00	_____
7-Passenger Town Cabriolet.....	5945.00	_____
7-Passenger Limousine Brougham..	5945.00	_____

Standard wheel equipment—5 wire; tire size 7.50 x 18.

White sidewall tires, standard equipment; black sidewall tires, optional equipment.

Extras

Accessory Group No. 7—5 wheels.....	\$ 72.50
Accessory Group No. 8—6 wheels, black fenders.	110.00
Accessory Group No. 8A—6 wheels, colored fenders.....	115.00
6 Wire wheels, fender wells, 2 spare tires and trunk rack.....	170.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	206.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Colored fender set and chassis.....	50.00

La Salle V-8, Series 345-B

Accessory Group No. 1—5 wheels, black fenders.	\$ 72.00
(Ornament, metal cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 1A—5 wheels, colored fenders.....	74.50
(Ornament, colored metal cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 2—6 wheels, black fenders.	96.00
(Ornament, metal covers, mirrors, license frames, chains, handykit)	
Accessory Group No. 2A—6 wheels, colored fenders.....	101.00
(Ornament, colored metal covers, mirrors, license frames, chains, handykit)	

Cadillac V-8, Series 355-B

Accessory Group No. 3—5 wheels, black fenders.	\$ 72.50
(Ornament, metal cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 3A—5 wheels, colored fenders.....	75.00
(Ornament, colored metal cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 4—6 wheels, black fenders.	96.00
(Ornament, metal covers, mirrors, license frames, chains, handykit)	
Accessory Group No. 4A—6 wheels, colored fenders.....	101.00
(Ornament, colored metal covers, mirrors, license frames, chains, handykit)	

Cadillac V-12, Series 370-B

Accessory Group No. 5—5 wheels, black fenders.	\$ 74.50
(Ornament, metal cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 5A—5 wheels, colored fenders.....	77.00
(Ornament, colored metal cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 6—6 wheels, black fenders.	100.00
(Ornament, metal covers, mirrors, license frames, chains, handykit)	
Accessory Group No. 6A—6 wheels, colored fenders.....	105.00
(Ornament, colored metal covers, mirrors, license frames, chains, handykit)	

Cadillac V-16, Series 452-B

Accessory Group No. 7—5 wheels.....	\$ 72.50
(Ornament, tire cover, bar, hinge mirror, license frames, chains, handykit)	
Accessory Group No. 8—6 wheels, black fenders.	110.00
(Ornament, metal covers, mirrors, license frames, chains, handykit)	
Accessory Group No. 8A—6 wheels, colored fenders.....	115.00
(Ornament, colored metal covers, mirrors, license frames, chains, handykit)	

1932 PRICE LIST

La Salle V-8
Cadillac V-8
Cadillac V-12
Cadillac V-16



January 2, 1932

All prices f.o.b. Detroit

Subject to change without notice

CADILLAC MOTOR CAR COMPANY

Detroit, Michigan, U.S.A.

La Salle V-8, Series 345-B

(130-inch Wheelbase)

(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$2395.00	_____
5-Passenger Sedan.....	2495.00	_____
5-Passenger Town Coupe.....	2545.00	_____
2-Passenger Convertible Coupe....	2545.00	_____

(136-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Town Sedan.....	\$2645.00	_____
7-Passenger Sedan.....	2645.00	_____
7-Passenger Imperial.....	2795.00	_____
Standard wheel equipment—5 wire; tire size 7.00 x 17.		
U.S. Royal black sidewall tires standard equipment.		

Extras

Accessory Group No. 1—5 wheels, black fenders.	\$ 72.00
Accessory Group No. 1A—5 wheels, colored fenders.....	74.50
Accessory Group No. 2—6 wheels, black fenders.	96.00
Accessory Group No. 2A—6 wheels, colored fenders.....	101.00
6 Wire wheels, fender wells, 2 spare tires and trunk rack.....	130.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	166.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Chromium trim or appearance rings for wire wheels—Per set of 5.....	
Per set of 6.....	7.50
U.S. Royal white side wall tires—	
Per set of 5 (Extra).....	15.00
Per set of 6 (Extra).....	18.00
Colored fender set and chassis.....	50.00

Cadillac V-8, Series 355-B

(134-inch Wheelbase)

(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$2795.00	_____
5-Passenger Standard Sedan.....	2895.00	_____
2-Passenger Roadster.....	2895.00	_____
2-Passenger Convertible Coupe....	2945.00	_____

(140-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Coupe.....	\$2995.00	_____
5-Passenger Special Sedan.....	3045.00	_____
5-Passenger Town Sedan.....	3095.00	_____
7-Passenger Sedan.....	3145.00	_____
7-Passenger Imperial.....	3295.00	_____
5-Passenger Standard Phaeton.....	2995.00	_____
5-Passenger Special Phaeton.....	3095.00	_____
5-Passenger Sport Phaeton.....	3245.00	_____
5-Passenger All-Weather Phaeton..	3495.00	_____

(140-inch Wheelbase)

(BODY BY FLEETWOOD)

5-Passenger Sedan.....	\$3395.00	_____
5-Passenger Town Coupe.....	3395.00	_____
7-Passenger Sedan.....	3545.00	_____
7-Passenger Limousine.....	3745.00	_____
5-Passenger Town Cabriolet.....	4095.00	_____
7-Passenger Town Cabriolet.....	4245.00	_____
7-Passenger Limousine Brougham..	4245.00	_____
Standard wheel equipment—5 wire; tire size 7.00 x 17.		
White sidewall tires, standard equipment; black sidewall tires, optional equipment.		

Extras

Accessory Group No. 3—5 wheels, black fenders.	\$ 72.50
Accessory Group No. 3A—5 wheels, colored fenders.....	75.00
Accessory Group No. 4—6 wheels, black fenders.	96.00
Accessory Group No. 4A—6 wheels, colored fenders.....	101.00
6 Wire wheels, fenders wells, 2 spare tires and trunk rack.....	130.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	166.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Colored fender set and chassis.....	50.00

Cadillac V-12, Series 370-B

(134-inch Wheelbase)

(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$3495.00	_____
5-Passenger Standard Sedan.....	3595.00	_____
2-Passenger Roadster.....	3595.00	_____
2-Passenger Convertible Coupe....	3645.00	_____

(140-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Coupe.....	\$3695.00	_____
5-Passenger Special Sedan.....	3745.00	_____
5-Passenger Town Sedan.....	3795.00	_____
7-Passenger Sedan.....	3845.00	_____
7-Passenger Imperial.....	3995.00	_____
5-Passenger Standard Phaeton.....	3695.00	_____
5-Passenger Special Phaeton.....	3795.00	_____
5-Passenger Sport Phaeton.....	3945.00	_____
5-Passenger All-Weather Phaeton..	4195.00	_____

(140-inch Wheelbase)

(BODY BY FLEETWOOD)

5-Passenger Sedan.....	\$4095.00	_____
5-Passenger Town Coupe.....	4095.00	_____
7-Passenger Sedan.....	4245.00	_____
7-Passenger Limousine.....	4445.00	_____
5-Passenger Town Cabriolet.....	4795.00	_____
7-Passenger Town Cabriolet.....	4945.00	_____
7-Passenger Limousine Brougham..	4945.00	_____
Standard wheel equipment—5 wire; tire size 7.50 x 17.		
White sidewall tires, standard equipment; black sidewall tires, optional equipment.		

Extras

Accessory Group No. 5—5 wheels, black fenders.	\$ 74.50
Accessory Group No. 5A—5 wheels, colored fenders.....	77.00
Accessory Group No. 6—6 wheels, black fenders.	100.00
Accessory Group No. 6A—6 wheels, colored fenders.....	105.00
6 Wire wheels, fender wells, 2 spare tires and trunk rack.....	150.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	186.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Colored fender set and chassis.....	50.00

La Salle V-8, Series 345-B

(130-inch Wheelbase)

(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$2395.00	_____
5-Passenger Sedan.....	2495.00	_____
5-Passenger Town Coupe.....	2545.00	_____
2-Passenger Convertible Coupe....	2545.00	_____

(136-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Town Sedan.....	\$2645.00	_____
7-Passenger Sedan.....	2645.00	_____
7-Passenger Imperial.....	2795.00	_____

Standard wheel equipment—5 wire; tire size 7.00 x 17.
U.S. Royal black sidewall tires standard equipment.

Extras

Accessory Group No. 1—5 wheels, black fenders.	\$ 72.00
Accessory Group No. 1A—5 wheels, colored fenders.....	74.50
Accessory Group No. 2—6 wheels, black fenders.	96.00
Accessory Group No. 2A—6 wheels, colored fenders.....	101.00
6 Wire wheels, fender wells, 2 spare tires and trunk rack.....	130.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	166.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Chromium trim or appearance rings for wire wheels—Per set of 5.....	7.50
Per set of 6.....	9.00
U.S. Royal white side wall tires—	
Per set of 5 (Extra).....	15.00
Per set of 6 (Extra).....	18.00
Colored fender set and chassis.....	50.00

Cadillac V-8, Series 355-B

(134-inch Wheelbase)

(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$2795.00	_____
5-Passenger Standard Sedan.....	2895.00	_____
2-Passenger Roadster.....	2895.00	_____
2-Passenger Convertible Coupe....	2945.00	_____

(140-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Coupe.....	\$2995.00	_____
5-Passenger Special Sedan.....	3045.00	_____
5-Passenger Town Sedan.....	3095.00	_____
7-Passenger Sedan.....	3145.00	_____
7-Passenger Imperial.....	3295.00	_____
5-Passenger Standard Phaeton.....	2995.00	_____
5-Passenger Special Phaeton.....	3095.00	_____
5-Passenger Sport Phaeton.....	3245.00	_____
5-Passenger All-Weather Phaeton..	3495.00	_____

(140-inch Wheelbase)

(BODY BY FLEETWOOD)

5-Passenger Sedan.....	\$3395.00	_____
5-Passenger Town Coupe.....	3395.00	_____
7-Passenger Sedan.....	3545.00	_____
7-Passenger Limousine.....	3745.00	_____
5-Passenger Town Cabriolet.....	4095.00	_____
7-Passenger Town Cabriolet.....	4245.00	_____
7-Passenger Limousine Brougham..	4245.00	_____
Standard wheel equipment—5 wire; tire size 7.00 x 17.		
White sidewall tires, standard equipment; black sidewall tires, optional equipment.		

Extras

Accessory Group No. 3—5 wheels, black fenders.	\$ 72.50
Accessory Group No. 3A—5 wheels, colored fenders.....	75.00
Accessory Group No. 4—6 wheels, black fenders.	96.00
Accessory Group No. 4A—6 wheels, colored fenders.....	101.00
6 Wire wheels, fenders wells, 2 spare tires and trunk rack.....	130.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	166.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Colored fender set and chassis.....	50.00

Cadillac V-12, Series 370-B

(134-inch Wheelbase)

(BODY BY FISHER)

Style	List	Delivered
2-Passenger Coupe.....	\$3495.00	_____
5-Passenger Standard Sedan.....	3595.00	_____
2-Passenger Roadster.....	3595.00	_____
2-Passenger Convertible Coupe....	3645.00	_____

(140-inch Wheelbase)

(BODY BY FISHER)

5-Passenger Coupe.....	\$3695.00	_____
5-Passenger Special Sedan.....	3745.00	_____
5-Passenger Town Sedan.....	3795.00	_____
7-Passenger Sedan.....	3845.00	_____
7-Passenger Imperial.....	3995.00	_____
5-Passenger Standard Phaeton.....	3695.00	_____
5-Passenger Special Phaeton.....	3795.00	_____
5-Passenger Sport Phaeton.....	3945.00	_____
5-Passenger All-Weather Phaeton..	4195.00	_____

(140-inch Wheelbase)


(BODY BY FLEETWOOD)

5-Passenger Sedan.....	\$4095.00	_____
5-Passenger Town Coupe.....	4095.00	_____
7-Passenger Sedan.....	4245.00	_____
7-Passenger Limousine.....	4445.00	_____
5-Passenger Town Cabriolet.....	4795.00	_____
7-Passenger Town Cabriolet.....	4945.00	_____
7-Passenger Limousine Brougham..	4945.00	_____
Standard wheel equipment—5 wire; tire size 7.50 x 17.		
White sidewall tires, standard equipment; black sidewall tires, optional equipment.		

Extras

Accessory Group No. 5—5 wheels, black fenders.	\$ 74.50
Accessory Group No. 5A—5 wheels, colored fenders.....	77.00
Accessory Group No. 6—6 wheels, black fenders.	100.00
Accessory Group No. 6A—6 wheels, colored fenders.....	105.00
6 Wire wheels, fender wells, 2 spare tires and trunk rack.....	150.00
5 Demountable wood wheels.....	30.00
6 Demountable wood wheels, fender wells, 2 spare tires and trunk rack.....	186.00
Chromium disc covers for wire wheels—	
Per set of 5.....	75.00
Per set of 6.....	90.00
Colored fender set and chassis.....	50.00

EXCLUSIVE CADILLAC ACCESSORY PRICE LIST



**CADILLAC MOTOR CAR CO.
DETROIT, MICH.**

Effective June 15, 1932

Prices subject to Change without Notice

All Prices F. O. B. Detroit

Part No.	DESCRIPTION	List Price	Installed Price
BREEZE FILTERS			
892442	Cadillac Breeze Filter—Series 345B-355B-370B-452B.....	\$4.25	\$5.00
47218	Cadillac Breeze Filter—Series 353-452A.....	4.25	5.00
A-616	Cadillac Breeze Filter—Series 355A-370A.....	4.25	5.00
47219	LaSalle Breeze Filter—Series 340-345A.....	4.25	5.00
892404	Cadillac Cowl Ventilator Screen—Series 345B-355B-370B-452B.....	1.25	1.25
HEATERS — HOT AIR			
896499	Cadillac Hot Air Heater Series 452B—Dual Register.....	42.50	47.50
	Factory Installed.....		
A-510	Cadillac Hot Air Heater Series 452A Dual Register.....	42.50	47.50
896527	Cadillac Hot Air Heater Series 452B—Single Register.....	38.50	42.50
	Factory Installed.....		
A-564	Cadillac Hot Air Heater Series 452A—Single Register.....	38.50	42.50
894390	Cadillac Hot Air Heater Series 370B—Dual Register.....	42.50	47.50
	Factory Installed.....		
A-621	Cadillac Hot Air Heater Series 370A—Dual Register.....	42.50	47.50
894428	Cadillac Hot Air Heater Series 370B—Single Register.....	38.50	42.50
	Factory Installed.....		
A-622	Cadillac Hot Air Heater Series 370A—Single Register.....	38.50	42.50
891807	Cadillac Hot Air Heater Series 345B—355B—Dual Register.....	42.50	47.50
	Factory Installed.....		
A-618	Cadillac Hot Air Heater Series 328-340-341-345A-353-355A—Dual Register.....	40.00	45.00
891878	Cadillac Hot Air Heater Series 345B—355B—Single Register.....	38.50	42.50
	Factory Installed.....		
A-617	Cadillac Hot Air Heater Series 328-340-341-345A-353-355A—Single Register.....	37.00	41.00
A-681	Cadillac Hot Air Heater Mounted on Display Stand.....		
HEATERS — HOT WATER			
A-793	Cadillac Hot Water Heater—All Series.....	34.00	37.50
	Factory Installed.....		
A-795	Cadillac Hot Water Heater Mounted on Display Stand.....		
883591	V-16 Choke Control—For Hot Water Heater Installation— Series 452A.....		
SPECIAL HOT AIR HEATER INSTALLATION TOOLS			
A-651	Circular Saw—4".....		
A-652	Mandrel—for holding saw in drill.....		
A-794	Special Socket Wrench.....		
LICENSE FRAMES			
A-865	Cadillac License Frames—Series 355B-370B-452B.....	7.00	7.00
A-864	LaSalle License Frames—Series 345B.....	7.00	7.00
LIGHTS			
891550	Cadillac Duplex Pilot Ray—Series 345B-355B-370B-452B..	52.50	57.50
	Factory Installed.....		
A-853	Cadillac Duplex Pilot Ray— Mounted on Display Stand.....		
A-675	Cadillac Duplex Pilot Ray— Series 340-345A-353-355A-370A-452A.....	52.50	57.50
47255	Cadillac Pilot Ray— Standard—Series 328-340-341-345A-353-355A-370A-452A....	36.50	40.00

*On orders for eight or more transportation prepaid.

Part No.	DESCRIPTION	List Price	Installed Price
TIRE CHAINS			
A-792	7.50x18—Series 452B.....	\$15.00	
A-626	7.50x19—Series 452A.....	15.00	
A-830	7.50x17—Series 370B.....	9.00	
A-641	7.00x18—Series 345A-355A.....	9.00	
	7.00x17—Series 345B-355B.....		
A-640	7.50x18—Series 370A.....	9.50	
	7.00x19—Series 353.....		
	6.75x32—Series 341B.....		
A-639	6.50x19—Series 340-345A-355A.....	9.00	
	6.00x32—Series 303.....		
	6.20x31—Series 328.....		
A-643	6.20x32—Series 303.....	9.50	
A-644	6.75x33—Series 314.....	10.50	
A-799	Cross Links—7.50 for A-792.....	.32 each	
A-800	Cross Links—6.50-6.20-6.00 for A-639—A-643.....	.15 each	
A-801	Cross Links—7.00-7.30-7.50 for A-640—A-641—A-644.....	.16 each	
A-802	Cross Links—7.50 for A-626.....	.27 each	
A-798	Chain Pliers.....	3.00	

(All chain orders must be in multiples of five to facilitate shipment. On orders of 30 chains or more freight will be prepaid.)

TIRE COVERS — METAL

896473	Cadillac Metal Tire Cover—Series 452B—Black Duco—R. H.	22.50	\$22.50
896474	Cadillac Metal Tire Cover—Series 452B—Black Duco—L. H.	22.50	22.50
	Ducoed in color to match fender sets.....each	25.00	25.00
	Full Chromium Plated.....each	27.50	27.50
	Bare Metal.....each		
894360	Cadillac Metal Tire Cover—Black Duco—Series 370B—R. H.	20.50	20.50
894361	Cadillac Metal Tire Cover—Black Duco—Series 370B—L. H.	20.50	20.50
	Ducoed in color to match fender sets.....each	23.00	23.00
	Full Chromium Plated.....each	25.50	25.50
	Bare Metal.....each		
891691	Cadillac Metal Tire Cover—Black Duco—Series 345B-355B—R. H.	18.50	18.50
891692	Cadillac Metal Tire Cover—Black Duco—Series 345B-355B—L. H.	18.50	18.50
	Ducoed in color to match fender sets.....each	21.00	21.00
	Full Chromium Plated.....each	23.50	23.50
	Bare Metal.....each		
894363	Cadillac Rear Metal Tire Cover—Series 370B—Black Duco (F. & U. S. Tires).....	20.50	20.50
894364	Cadillac Rear Metal Tire Cover—Series 370B—Black Duco (Goodyear Tires).....	20.50	20.50
	Ducoed in color to match fender sets.....each	23.00	23.00
	Bare Metal.....each		
891695	Cadillac Rear Metal Tire Cover—Series 345B-355B—Black Duco (F. & U. S. Tires).....	18.50	18.50
891696	Cadillac Rear Metal Tire Cover—Series 355B—Black Duco (Goodyear Tires).....	18.50	18.50
	Ducoed in color to match fender sets.....each	21.00	21.00
	Bare Metal.....each		
883562	Cadillac Metal Tire Cover—Series 452A—Black Duco—R. H.	22.50	22.50
883563	Cadillac Metal Tire Cover—Series 452A—Black Duco—L. H.	22.50	22.50
	Ducoed in color to match fender sets.....each	25.00	25.00
	Full Chromium Plated.....each	27.50	27.50
	Bare Metal.....each		

Part No.	DESCRIPTION	List Price	Installed Price
TIRE COVERS — METAL — Continued			
889330	Cadillac Metal Tire Cover—Series 370A—Black, R. H.	\$20.50	\$20.50
889331	Cadillac Metal Tire Cover—Series 370A—Black, L. H.	20.50	20.50
	Ducoed in color to match fender sets. each	23.00	23.00
	Full Chromium Plated. each	25.50	25.50
	Bare Metal. each		
887330	Cadillac Metal Tire Cover—Series 355A—Black, R. H.	18.50	18.50
887331	Cadillac Metal Tire Cover—Series 355A—Black, L. H.	18.50	18.50
	Ducoed in color to match fender sets. each	21.00	21.00
	Full Chromium Plated. each	23.50	23.50
	Bare Metal. each		
885776	LaSalle Metal Tire Cover—Series 340-345A—Black, R. H.	16.50	16.50
885777	LaSalle Metal Tire Cover—Series 340-345A—Black, L. H.	16.50	16.50
	Ducoed in color to match fender sets. each	19.00	19.00
	Full Chromium Plated. each	21.50	21.50
	Bare Metal. each		

Note: When Metal Covers are desired finished other than in black the part number should be designated as:

896473-D—When special color is desired
896473-C—When full chromium is desired
896473-B—When bare metal is desired

TIRE COVERS — FABRIC

Series 452B			
A-810	7.50x18 Burbank 1-T-1532 with Emblem.	10.00	
A-814	7.50x18 Long Grain with Emblem.	5.50	
Series 370B			
A-811	7.50x17 Burbank 1-T-1532 with Emblem.	9.00	
A-815	7.50x17 Long Grain with Emblem.	5.50	
Series 355B			
A-812	7.00x17 Burbank 1-T-1532 with Emblem.	9.00	
A-816	7.00x17 Long Grain with Emblem.	5.50	
Series 345B			
A-813	7.00x17 Burbank 1-T-1532 with Emblem.	9.00	
A-817	7.00x17 Long Grain with Emblem.	5.50	
Series 452A			
A-562	7.50x19 Patent Leather with Emblem.	7.00	
A-568	7.50x19 Burbank 2-T-1531 with Emblem.	10.00	
Series 370A			
A-628	7.50x18 Long Grain with Emblem.	5.50	
A-631	7.50x18 Burbank 2-T-1530 with Emblem.	9.00	
Series 355A			
A-598	7.00x18—6.50x19 Long Grain with Emblem.	5.50	
A-605	7.00x18—6.50x19 Burbank 2-T-1530 with Emblem.	9.00	
Series 328-340-345A			
47177	7.00x18—6.50x19 Long Grain with Emblem.	5.50	
A-606	7.00x18—6.50x19 Burbank 2-T-1530 with Emblem.	9.00	
Series 353			
47176	7.00x19 Long Grain with Emblem.	5.50	
47222	7.00x19 Burbank 2-T-1531 with Emblem.	9.00	

TONNEAU SHIELDS

A-634	Cadillac Tonneau Shields—Phaeton—Series 355-370.	170.00	185.00
47152	Cadillac Rumble Seat Shield—All Series.	170.00	185.00

TRUNKS

A-851	Cadillac DeLuxe Metal Covered Trunk equipped with 2 Genuine Cowhide Cases and Hat Box—Series 340-345-353- 355-370-452 (except open and convertible body styles)	180.00	180.00
-------	---	--------	--------

Part No.	DESCRIPTION	List Price	Installed Price
LIGHTS—Continued			
891531	Cadillac Lorraine Light—Closed Car—All Series.....	\$35.00	\$37.50
	Factory Installed.....		
891577	Cadillac Lorraine Light—Open Car—All Series.....	35.00	37.50
	Factory Installed.....		
A-836	Cadillac Lorraine Light— Mounted on Display Stand.....		
47167	Cadillac Lorraine Tool Set.....		
MIRRORS			
A-807	Cadillac Metal Cover Mirrors—Series 345B-355B-370B- 452B.....	22.00 pair	22.00 pair
885767	Cadillac Metal Cover Mirrors—Series 345A-355A-370A- 452A.....	22.00 pair	22.00 pair
A-541	Cadillac Tire Mirrors—All Series.....	16.00 each	16.00 each
891623	Cadillac Hinge Mirror—Series 345B-355B-370B-452B— Closed Cars.....	8.00 each	8.00 each
ORNAMENTS			
A-586	Cadillac Heron Ornament—Complete with Lock—All Series.....	20.00	20.00
1098123	Cadillac Goddess Ornament—Complete with Lock—All Series.....	20.00	20.00
POLISH—CLEANER—HANDY KIT—HANDY KIT ITEMS			
891307	Cadillac Handy Kit—Series 355B-370B-452B.....	6.75	
	Includes Cadillac Body Polish (pt.) Cadillac Dust Mit Cadillac Metal Polish (pt.) Cadillac Bulb Kit (891303) Cadillac Fabric Cleaner (pt.) Cadillac Tire Gauge		
A-592	Cadillac Handy Kit—Series 345A&B-355A-370A-452A.....	6.25	
	Includes Cadillac Body Polish (pt.) Cadillac Dust Mit Cadillac Metal Polish (pt.) Cadillac Bulb Kit (42677) Cadillac Fabric Cleaner (qt.) Cadillac Tire Gauge		
47000	Cadillac Body Polish—Pints.....	1.00	{ Dozen lots Gross lots
47059	Cadillac Body Polish—Gallons.....	\$6.00	
885709	Cadillac Metal Polish—Pints.....	.75	{ Dozen lots Gross lots
891620	Cadillac Fabric Cleaner—Pints.....	.75	
47042	Cadillac Fabric Cleaner—Quarts.....	1.25	{ Dozen lots Gross lots
47080	Cadillac Fabric Cleaner—Gallons.....	3.50	
47034	Cadillac Dust Mits.....	.50	{ Dozen lots Gross lots
891303	Cadillac Bulb Kit—Series 355B-370B-452B.....	1.75	
42677	Cadillac Bulb Kit—Series 345A&B-355A-370A-452A.....	1.25	
47058	Cadillac Tire Gauge.....	1.50	
PROTECTION BAR			
891697	Cadillac Protection Bar—Series 345B-355B-370B-452B...	6.00	6.00
RADIO			
A-914	Cadillac Radio Assembly—Series 452A-452B.....		89.50
	Factory Installed.....		
A-915	Cadillac Radio Assembly—Series 370A-370B.....		89.50
	Factory Installed.....		
A-916	Cadillac Radio Assembly—Series 345A-345B-355A-355B..		89.50
	Factory Installed.....		
A-910	Cadillac B Eliminator.....		20.00
A-917	Cadillac Elkonode.....		4.50
A-918	Cadillac B Eliminator Tube.....		2.50
All assemblies as listed above include Receiver, Speaker, Tubes, Eliminator and all attaching parts.			
Factory Installed Prices include complete installation.			

Part No.	DESCRIPTION	List Price	Installed Price
ROBES			
47276	Fleetwood Cloth and Crushed Plush or Alpaca Robe...	\$45.00	
	Pillow to Match.....	8.00	
	Foot Muff to Match.....	20.00	
(All Fleetwood Cloth Robes are tailored from the identical trim fabrics with which the body is upholstered. All orders must bear Cadillac-LaSalle upholstery identification numbers.)			
47211	Cadillac Double Alpaca Robe.....	30.00	
47037	Cadillac Double Plush Robe.....	27.50	
	Monograms.....	5.50	

SLIP-ON SEAT COVERS

Sea Breeze Slip-ons

A-924	Front Seat Undivided—Series 340-353-345A.....	9.75
A-925	Rear Seat Undivided—Series 340-353-345A.....	9.75
A-926	Front Seat Undivided—Series 355A-370A-452A.....	9.75
A-927	Front Seat Divided—Series 345B-355B-370B-452B.....	10.75
A-928	Rear Seat Undivided — Series 345B- 355A&B- 370A&B- 452A&B.....	9.75
A-929	Rear Seat Divided — Series 345B- 355A&B- 370A&B- 452A&B.....	10.75

Jacquard Rayon Slip-ons

A-930	Front Seat Undivided—Series 340-353-345A.....	12.25
A-931	Rear Seat Undivided—Series 340-353-345A.....	12.25
A-932	Front Seat Undivided—Series 355A-370A-452A.....	12.25
A-933	Front Seat Divided—Series 345B-355B-370B-452B.....	14.75
A-934	Rear Seat Undivided — Series 345B- 355A&B- 370A&B- 452A&B.....	12.25
A-935	Rear Seat Divided — Series 345B- 355A&B- 370A&B- 452A&B.....	14.75

Above Cadillac Seat Covers carried in stock. Immediate shipment will be made upon receipt of order specifying Part Number.

SEAT COVERINGS—CUSTOM

JACQUARD RAYON CUSTOM SEAT COVERS*

*The following Seat Coverings are custom tailored on order only. Because of the custom workmanship required Custom Seat Covers must be tailored on the car at the Factory.

Seats and Backs only

Two-Pass. Body Styles.....	30.00
Five-Pass. Body Styles except Five-Pass. Coupe.....	45.00
Five-Pass. Coupe.....	50.00
Seven-Pass. Body Styles.....	55.00

Seats, Backs, Sides, Doors

Two-Pass. Body Styles.....	65.00
Five-Pass. Body Styles.....	95.00
Five-Pass. Coupe.....	105.00
Seven-Pass. Body Styles.....	125.00

SPLASH GUARDS

1080656	Cadillac Splash Guards—Series 355A-370A.....per pair	4.00	\$4.00
---------	--	------	--------

SUMMER CUSHIONS

A-579	Cadillac Summer Cushions—Sea Breeze material front with Laidlaw cloth back.....set of two	6.00	6.00
-------	---	------	------

SUN VISORS

A-731	LaSalle Sun Visor with trim—Series 345A—Second Style...	14.00 pair	14.00 pair
A-645	LaSalle Sun Visor with trim—Series 345A—First Style....	14.00 pair	14.00 pair

(Sun Visors covered with headlining fabric other than used on standard LaSalle Series 345 production will carry an additional charge of \$3.50 per pair to Distributors and Dealers.)

Part No.	DESCRIPTION	List Price	Installed Price
TRUNK CASES—TOWN SEDAN AND TOWN COUPE—Continued			
Town Coupes—Series 345B-355B-370B-452B—can also be equipped with any of the other four case combinations used in Trunk Assemblies A-851, A-852, 1098279 or 1098280 as listed below.			
891793	Town Coupe DeLuxe Case Assembly—(2 Cowhide Cases—1 Cowhide Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	\$110.00	
891800	Town Coupe DeLuxe Case Assembly—(2 Aero Cases—1 Aero Hat Box, Auxiliary Floor) Series 345B-355B-370B-452B.....	90.00	
891546	Town Coupe Case Assembly—(3 Suitcases—1 Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	49.00	
891547	Town Coupe Case Assembly—(3 long Suitcases, Auxiliary Floor)—Series 345B-355B-370B-452B.....	45.00	
A-857	Town Sedan Case Assembly—(2 Suitcases—1 Hat Box, Auxiliary Floor)—Series 355A-370A-452A.....	37.00	
	A-646 Suitcase—Black Fabrikoid—Town Sedan—Series 355A-370A-452A (6 $\frac{3}{8}$ "x14 $\frac{3}{4}$ "x27 $\frac{3}{8}$ ").....	13.00	
	A-647 Hat Box—Black Fabrikoid—Town Sedan—Series 355A-370A-452A (11 $\frac{1}{2}$ "x12 $\frac{5}{8}$ "x12 $\frac{7}{16}$ ").....	11.00	
	A-650 Auxiliary Floor—Town Sedan—Series 355A-370A-452A.....		
A-858	Town Sedan Case Assembly—(2 Suitcases—1 Hat Box, Auxiliary Floor)—Series 340-353-345A.....	37.00	
	873370 Suitcase—Black Fabrikoid—Town Sedan—Series 340-353-345A (7 $\frac{3}{8}$ "x14 $\frac{1}{4}$ "x30").....	13.00	
	873371 Hat Box—Black Fabrikoid—Town Sedan—Series 340-353-345A (8"x14 $\frac{1}{4}$ "x14").....	11.00	
	873379 Auxiliary Floor—Town Sedan—Series 340-353-345A		

WHEEL DISCS — CHROMIUM

896476	Cadillac Wheel Discs—18" Wheel—Series 452B.....	10.00	10.00
891728	Cadillac Wheel Discs—17" Wheel—Series 345B-355B-370B.....	10.00	10.00

WIND DEFLECTORS


A-885	Cadillac Draft Deflectors—Closed Car—Fisher Bodies—Series 345B-355B-370B-452B.....	25.00	25.00
A-886	Cadillac Draft Deflectors—Closed Car—Fleetwood Bodies—Series 345B-355B-370B-452B.....	25.00	25.00
A-503	Cadillac Draft Deflectors—Closed Car—Series 452A.....	25.00	25.00
A-615	Cadillac Draft Deflectors—Closed Car—Series 355A-370A—except 2 Pass. Coupes.....	25.00	25.00
A-705	Cadillac Draft Deflectors—Closed Car—Series 355A-370A—2 Pass. Coupe only.....	25.00	25.00
A-502	LaSalle Draft Deflectors—Closed Car—Series 340-345A.....	25.00	25.00
A-501	Cadillac Draft Deflectors—Closed Car—Series 353.....	25.00	25.00
A-908	Cadillac DeLuxe Side Wings—Open Car—Series 340-353-345A—Folding Windshields.....	47.50	47.50
A-905	Cadillac DeLuxe Side Wings—Open Car—Series A and B—Stationary Windshields.....	47.50	47.50

Part No.	DESCRIPTION	List Price	Installed Price
TRUNKS—Continued			
	892356 Cadillac Metal Covered Trunk only.....	\$70.00	\$70.00
	891794 Suitcase Genuine Cowhide (7 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	40.00	
	891795 Hat Box Genuine Cowhide (7 $\frac{1}{2}$ "x16"x15 $\frac{3}{8}$ ").....	30.00	
A-852	Cadillac DeLuxe Metal Covered Trunk equipped with Aero type (Linen finish) Wardrobe Case, Suitcase, and Hat Box—Series 340-345-353-355-370-452 (except open and convertible body styles).....	160.00	160.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	891801 Wardrobe Case—Aero type (Linen finish) (7 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	32.50	
	891802 Suitcase—Aero type (Linen finish) (7 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	32.50	
	891803 Hat Box—Aero type (Linen finish) (7 $\frac{1}{2}$ "x16"x15 $\frac{3}{8}$ ").....	25.00	
1098279	Cadillac Metal Covered Trunk equipped with 3 Suitcases and Hat Box—Series 340-345-353-355-370-452 (except open and convertible body styles).....	119.00	119.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	885778 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x26 $\frac{1}{4}$ ").....	12.00	
	885779 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x37 $\frac{3}{8}$ ").....	15.00	
	885780 Hat Box—Black Fabrikoid (10 $\frac{5}{8}$ "x16 $\frac{1}{2}$ "x11 $\frac{3}{8}$ ").....	10.00	
1098280	Cadillac Metal Covered Trunk equipped with 3 long Suitcases—Series 340-345-353-355-370-452 (except open and convertible body styles).....	115.00	115.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	885779 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x37 $\frac{3}{8}$ ").....	15.00	
A-912	Cadillac Metal Covered Trunk equipped with 2 Suitcases and Hat Box—Series 340-345-353-355-370-452 (except open and convertible body styles).....	107.00	107.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	892457 Suitcase—Black Fabrikoid (7 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	13.00	
	892456 Hat Box—Black Fabrikoid (7 $\frac{1}{2}$ "x16"x15 $\frac{3}{8}$ ").....	11.00	
85059	Cadillac Fleetwood Metal Covered Trunk equipped with 2 Suitcases and Hat Box—Series 340-345-353-355-370-452 (open, convertible and coupe body styles).....	104.00	104.00
	892452 Cadillac Fleetwood Metal Covered Trunk only.....	70.00	70.00
	885778 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x26 $\frac{1}{4}$ ").....	12.00	
	885780 Hat Box—Black Fabrikoid (10 $\frac{5}{8}$ "x16 $\frac{1}{2}$ "x11 $\frac{3}{8}$ ").....	10.00	
1098281	Cadillac Fleetwood Metal Covered Trunk equipped with 2 long Suitcases—Series 340-345-353-355-370-452 (open, convertible and coupe body styles).....	100.00	100.00
	892452 Cadillac Fleetwood Metal Covered Trunk only.....	70.00	70.00
	885779 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x37 $\frac{3}{8}$ ").....	15.00	
Cadillac Metal Trunks furnished in Color to Match Car—Special Order \$10.00 Extra List and Net.			
Cadillac Metal Covered Trunk 892356—Total Case capacity 15 $\frac{3}{4}$ " height x 16 $\frac{1}{2}$ " depth x 37 $\frac{3}{8}$ " length			
Cadillac Fleetwood Trunk 892452—Total Case capacity 10 $\frac{1}{2}$ " height x 16 $\frac{1}{2}$ " depth x 37 $\frac{3}{8}$ " length.			

TRUNK CASES — TOWN SEDAN AND TOWN COUPE

A-854	Town Sedan Case Assembly—(2 Suitcases, 1 Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	37.00
	891753 Suitcase—Black Fabrikoid—Town Sedan—Series 345B-355B-370B-452B (.....)	13.00
	891752 Hat Box—Black Fabrikoid—Town Sedan—Series 345B-355B-370B-452B (.....)	11.00
	A-855 Auxiliary Floor—Town Sedan—Series 345B-355B-370B-452B.....	
A-913	Town Coupe Case Assembly (2 Suitcases—1 Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	37.00
	892457 Suitcase—Black Fabrikoid (7 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	13.00
	892456 Hat Box—Black Fabrikoid (7 $\frac{1}{2}$ "x16"x15 $\frac{3}{8}$ ").....	11.00
	A-856 Auxiliary Floor—Town Coupe—Series 345B-355B-370B-452B.....	

EXCLUSIVE CADILLAC ACCESSORY PRICE LIST



**CADILLAC MOTOR CAR CO.
DETROIT, MICH.**

Effective June 15, 1932

Prices subject to Change without Notice

All Prices F. O. B. Detroit

Part No.	DESCRIPTION	List Price	Installed Price
BREEZE FILTERS			
892442	Cadillac Breeze Filter—Series 345B-355B-370B-452B.....	\$4.25	\$5.00
47218	Cadillac Breeze Filter—Series 353-452A.....	4.25	5.00
A-616	Cadillac Breeze Filter—Series 355A-370A.....	4.25	5.00
47219	LaSalle Breeze Filter—Series 340-345A.....	4.25	5.00
892404	Cadillac Cowl Ventilator Screen—Series 345B-355B-370B-452B.....	1.25	1.25
HEATERS — HOT AIR			
896499	Cadillac Hot Air Heater Series 452B—Dual Register.....	42.50	47.50
	Factory Installed.....		
A-510	Cadillac Hot Air Heater Series 452A Dual Register.....	42.50	47.50
896527	Cadillac Hot Air Heater Series 452B—Single Register.....	38.50	42.50
	Factory Installed.....		
A-564	Cadillac Hot Air Heater Series 452A—Single Register.....	38.50	42.50
894390	Cadillac Hot Air Heater Series 370B—Dual Register.....	42.50	47.50
	Factory Installed.....		
A-621	Cadillac Hot Air Heater Series 370A—Dual Register.....	42.50	47.50
894428	Cadillac Hot Air Heater Series 370B—Single Register.....	38.50	42.50
	Factory Installed.....		
A-622	Cadillac Hot Air Heater Series 370A—Single Register.....	38.50	42.50
891807	Cadillac Hot Air Heater Series 345B—355B—Dual Register.....	42.50	47.50
	Factory Installed.....		
A-618	Cadillac Hot Air Heater Series 328-340-341-345A-353-355A—Dual Register.....	40.00	45.00
891878	Cadillac Hot Air Heater Series 345B—355B—Single Register.....	38.50	42.50
	Factory Installed.....		
A-617	Cadillac Hot Air Heater Series 328-340-341-345A-353-355A—Single Register.....	37.00	41.00
A-681	Cadillac Hot Air Heater Mounted on Display Stand.....		
HEATERS — HOT WATER			
A-793	Cadillac Hot Water Heater—All Series.....	34.00	37.50
	Factory Installed.....		
A-795	Cadillac Hot Water Heater Mounted on Display Stand.....		
883591	V-16 Choke Control—For Hot Water Heater Installation— Series 452A.....		
SPECIAL HOT AIR HEATER INSTALLATION TOOLS			
A-651	Circular Saw—4".....		
A-652	Mandrel—for holding saw in drill.....		
A-794	Special Socket Wrench.....		
LICENSE FRAMES			
A-865	Cadillac License Frames—Series 355B-370B-452B.....	7.00	7.00
A-864	LaSalle License Frames—Series 345B.....	7.00	7.00
LIGHTS			
891550	Cadillac Duplex Pilot Ray—Series 345B-355B-370B-452B..	52.50	57.50
	Factory Installed.....		
A-853	Cadillac Duplex Pilot Ray— Mounted on Display Stand.....		
A-675	Cadillac Duplex Pilot Ray— Series 340-345A-353-355A-370A-452A.....	52.50	57.50
47255	Cadillac Pilot Ray— Standard—Series 328-340-341-345A-353-355A-370A-452A....	36.50	40.00

*On orders for eight or more transportation prepaid.

Part No.	DESCRIPTION	List Price	Installed Price
TIRE CHAINS			
A-792	7.50x18—Series 452B.....	\$15.00	
A-626	7.50x19—Series 452A.....	15.00	
A-830	7.50x17—Series 370B.....	9.00	
A-641	7.00x18—Series 345A-355A.....	9.00	
	7.00x17—Series 345B-355B.....		
A-640	{ 7.50x18—Series 370A } 7.00x19—Series 353.....	9.50	
	{ 6.75x32—Series 341B } 6.50x19—Series 340-345A-355A.....		
A-639	{ 6.00x32—Series 303 } 6.20x31—Series 328.....	9.00	
A-643	6.20x32—Series 303.....	9.50	
A-644	6.75x33—Series 314.....	10.50	
A-799	Cross Links—7.50 for A-792.....	.32 each	
A-800	Cross Links—6.50-6.20-6.00 for A-639—A-643.....	.15 each	
A-801	Cross Links—7.00-7.30-7.50 for A-640—A-641—A-644.....	.16 each	
A-802	Cross Links—7.50 for A-626.....	.27 each	
A-798	Chain Pliers.....	3.00	

(All chain orders must be in multiples of five to facilitate shipment. On orders of 30 chains or more freight will be prepaid.)

TIRE COVERS — METAL

896473	Cadillac Metal Tire Cover—Series 452B—Black Duco—R.H.	22.50	\$22.50
896474	Cadillac Metal Tire Cover—Series 452B—Black Duco—L.H.	22.50	22.50
	Ducoed in color to match fender sets.....each	25.00	25.00
	Full Chromium Plated.....each	27.50	27.50
	Bare Metal.....each		
894360	Cadillac Metal Tire Cover—Black Duco—Series 370B—R.H.	20.50	20.50
894361	Cadillac Metal Tire Cover—Black Duco—Series 370B—L.H.	20.50	20.50
	Ducoed in color to match fender sets.....each	23.00	23.00
	Full Chromium Plated.....each	25.50	25.50
	Bare Metal.....each		
891691	Cadillac Metal Tire Cover—Black Duco—Series 345B-355B—R.H.	18.50	18.50
891692	Cadillac Metal Tire Cover—Black Duco—Series 345B-355B—L.H.	18.50	18.50
	Ducoed in color to match fender sets.....each	21.00	21.00
	Full Chromium Plated.....each	23.50	23.50
	Bare Metal.....each		
894363	Cadillac Rear Metal Tire Cover—Series 370B—Black Duco (F. & U. S. Tires).....	20.50	20.50
894364	Cadillac Rear Metal Tire Cover—Series 370B—Black Duco (Goodyear Tires).....	20.50	20.50
	Ducoed in color to match fender sets.....each	23.00	23.00
	Bare Metal.....each		
891695	Cadillac Rear Metal Tire Cover—Series 345B-355B—Black Duco (F. & U. S. Tires).....	18.50	18.50
891696	Cadillac Rear Metal Tire Cover—Series 355B—Black Duco (Goodyear Tires).....	18.50	18.50
	Ducoed in color to match fender sets.....each	21.00	21.00
	Bare Metal.....each		
883562	Cadillac Metal Tire Cover—Series 452A—Black Duco—R. H.	22.50	22.50
883563	Cadillac Metal Tire Cover—Series 452A—Black Duco—L. H.	22.50	22.50
	Ducoed in color to match fender sets.....each	25.00	25.00
	Full Chromium Plated.....each	27.50	27.50
	Bare Metal.....each		

Part No.	DESCRIPTION	List Price	Installed Price
TIRE COVERS — METAL — Continued			
889330	Cadillac Metal Tire Cover—Series 370A—Black, R. H.	\$20.50	\$20.50
889331	Cadillac Metal Tire Cover—Series 370A—Black, L. H.	20.50	20.50
	Duocoed in color to match fender sets. each	23.00	23.00
	Full Chromium Plated. each	25.50	25.50
	Bare Metal. each		
887330	Cadillac Metal Tire Cover—Series 355A—Black, R. H.	18.50	18.50
887331	Cadillac Metal Tire Cover—Series 355A—Black, L. H.	18.50	18.50
	Duocoed in color to match fender sets. each	21.00	21.00
	Full Chromium Plated. each	23.50	23.50
	Bare Metal. each		
885776	LaSalle Metal Tire Cover—Series 340-345A—Black, R. H. ..	16.50	16.50
885777	LaSalle Metal Tire Cover—Series 340-345A—Black, L. H. ..	16.50	16.50
	Duocoed in color to match fender sets. each	19.00	19.00
	Full Chromium Plated. each	21.50	21.50
	Bare Metal. each		

Note: When Metal Covers are desired finished other than in black the part number should be designated as:

896473-D—When special color is desired
896473-C—When full chromium is desired
896473-B—When bare metal is desired

TIRE COVERS — FABRIC

Series 452B

A-810	7.50x18 Burbank 1-T-1532 with Emblem.	10.00
A-814	7.50x18 Long Grain with Emblem.	5.50

Series 370B

A-811	7.50x17 Burbank 1-T-1532 with Emblem.	9.00
A-815	7.50x17 Long Grain with Emblem.	5.50

Series 355B

A-812	7.00x17 Burbank 1-T-1532 with Emblem.	9.00
A-816	7.00x17 Long Grain with Emblem.	5.50

Series 345B

A-813	7.00x17 Burbank 1-T-1532 with Emblem.	9.00
A-817	7.00x17 Long Grain with Emblem.	5.50

Series 452A

A-562	7.50x19 Patent Leather with Emblem.	7.00
A-568	7.50x19 Burbank 2-T-1531 with Emblem.	10.00

Series 370A

A-628	7.50x18 Long Grain with Emblem.	5.50
A-631	7.50x18 Burbank 2-T-1530 with Emblem.	9.00

Series 355A

A-598	7.00x18—6.50x19 Long Grain with Emblem.	5.50
A-605	7.00x18—6.50x19 Burbank 2-T-1530 with Emblem.	9.00

Series 328-340-345A

47177	7.00x18—6.50x19 Long Grain with Emblem.	5.50
A-606	7.00x18—6.50x19 Burbank 2-T-1530 with Emblem.	9.00

Series 353

47176	7.00x19 Long Grain with Emblem.	5.50
47222	7.00x19 Burbank 2-T-1531 with Emblem.	9.00

TONNEAU SHIELDS

A-634	Cadillac Tonneau Shields—Phaeton—Series 355-370.	170.00	185.00
47152	Cadillac Rumble Seat Shield—All Series.	170.00	185.00

TRUNKS

A-851	Cadillac DeLuxe Metal Covered Trunk equipped with 2 Genuine Cowhide Cases and Hat Box—Series 340-345-353- 355-370-452 (except open and convertible body styles)	180.00	180.00
-------	---	--------	--------

Part No.	DESCRIPTION	List Price	Installed Price
LIGHTS—Continued			
891531	Cadillac Lorraine Light—Closed Car—All Series.....	\$35.00	\$37.50
	Factory Installed.....		
891577	Cadillac Lorraine Light—Open Car—All Series.....	35.00	37.50
	Factory Installed.....		
A-836	Cadillac Lorraine Light— Mounted on Display Stand.....		
47167	Cadillac Lorraine Tool Set.....		
MIRRORS			
A-807	Cadillac Metal Cover Mirrors—Series 345B-355B-370B-452B.....	22.00 pair	22.00 pair
885767	Cadillac Metal Cover Mirrors—Series 345A-355A-370A-452A.....	22.00 pair	22.00 pair
A-541	Cadillac Tire Mirrors—All Series.....	16.00 each	16.00 each
891623	Cadillac Hinge Mirror—Series 345B-355B-370B-452B— Closed Cars.....	8.00 each	8.00 each
ORNAMENTS			
A-586	Cadillac Heron Ornament—Complete with Lock—All Series.....	20.00	20.00
1098123	Cadillac Goddess Ornament—Complete with Lock—All Series.....	20.00	20.00
POLISH—CLEANER—HANDY KIT—HANDY KIT ITEMS			
891307	Cadillac Handy Kit—Series 355B-370B-452B.....	6.75	
	Includes Cadillac Body Polish (pt.) Cadillac Dust Mit Cadillac Metal Polish (pt.) Cadillac Bulb Kit (891303) Cadillac Fabric Cleaner (pt.) Cadillac Tire Gauge		
A-592	Cadillac Handy Kit—Series 345A&B-355A-370A-452A.....	6.25	
	Includes Cadillac Body Polish (pt.) Cadillac Dust Mit Cadillac Metal Polish (pt.) Cadillac Bulb Kit (42677) Cadillac Fabric Cleaner (qt.) Cadillac Tire Gauge		
47000	Cadillac Body Polish—Pints.....	1.00	{ Dozen lots Gross lots
47059	Cadillac Body Polish—Gallons.....	\$6.00	
885709	Cadillac Metal Polish—Pints.....	.75	{ Dozen lots Gross lots
891620	Cadillac Fabric Cleaner—Pints.....	.75	
47042	Cadillac Fabric Cleaner—Quarts.....	1.25	{ Dozen lots Gross lots
47080	Cadillac Fabric Cleaner—Gallons.....	3.50	
47034	Cadillac Dust Mits.....	.50	{ Dozen lots Gross lots
891303	Cadillac Bulb Kit—Series 355B-370B-452B.....	1.75	
42677	Cadillac Bulb Kit—Series 345A&B-355A-370A-452A.....	1.25	
47058	Cadillac Tire Gauge.....	1.50	
PROTECTION BAR			
891697	Cadillac Protection Bar—Series 345B-355B-370B-452B...	6.00	6.00
RADIO			
A-914	Cadillac Radio Assembly—Series 452A-452B.....		89.50
	Factory Installed.....		
A-915	Cadillac Radio Assembly—Series 370A-370B.....		89.50
	Factory Installed.....		
A-916	Cadillac Radio Assembly—Series 345A-345B-355A-355B.. Factory Installed.....		89.50
A-910	Cadillac B Eliminator.....		20.00
A-917	Cadillac Elkonode.....		4.50
A-918	Cadillac B Eliminator Tube.....		2.50
	All assemblies as listed above include Receiver, Speaker, Tubes, Eliminator and all attaching parts.		
	Factory Installed Prices include complete installation.		

Part No.	DESCRIPTION	List Price	Installed Price
ROBES			
47276	Fleetwood Cloth and Crushed Plush or Alpaca Robe . . .	\$45.00	
	Pillow to Match	8.00	
	Foot Muff to Match	20.00	
(All Fleetwood Cloth Robes are tailored from the identical trim fabrics with which the body is upholstered. All orders must bear Cadillac-LaSalle upholstery identification numbers.)			
47211	Cadillac Double Alpaca Robe	30.00	
47037	Cadillac Double Plush Robe	27.50	
	Monograms	5.50	

SLIP-ON SEAT COVERS

Sea Breeze Slip-ons

A-924	Front Seat Undivided—Series 340-353-345A	9.75
A-925	Rear Seat Undivided—Series 340-353-345A	9.75
A-926	Front Seat Undivided—Series 355A-370A-452A	9.75
A-927	Front Seat Divided—Series 345B-355B-370B-452B	10.75
A-928	Rear Seat Undivided — Series 345B-355A&B-370A&B-452A&B	9.75
A-929	Rear Seat Divided — Series 345B-355A&B-370A&B-452A&B	10.75

Jacquard Rayon Slip-ons

A-930	Front Seat Undivided—Series 340-353-345A	12.25
A-931	Rear Seat Undivided—Series 340-353-345A	12.25
A-932	Front Seat Undivided—Series 355A-370A-452A	12.25
A-933	Front Seat Divided—Series 345B-355B-370B-452B	14.75
A-934	Rear Seat Undivided — Series 345B-355A&B-370A&B-452A&B	12.25
A-935	Rear Seat Divided — Series 345B-355A&B-370A&B-452A&B	14.75

Above Cadillac Seat Covers carried in stock. Immediate shipment will be made upon receipt of order specifying Part Number.

SEAT COVERINGS—CUSTOM

JACQUARD RAYON CUSTOM SEAT COVERS*

*The following Seat Coverings are custom tailored on order only. Because of the custom workmanship required Custom Seat Covers must be tailored on the car at the Factory.

Seats and Backs only

Two-Pass. Body Styles	30.00
Five-Pass. Body Styles except Five-Pass. Coupe	45.00
Five-Pass. Coupe	50.00
Seven-Pass. Body Styles	55.00

Seats, Backs, Sides, Doors

Two-Pass. Body Styles	65.00
Five-Pass. Body Styles	95.00
Five-Pass. Coupe	105.00
Seven-Pass. Body Styles	125.00

SPLASH GUARDS

1080656	Cadillac Splash Guards—Series 355A-370Aper pair	4.00	\$4.00
---------	---	------	--------

SUMMER CUSHIONS

A-579	Cadillac Summer Cushions—Sea Breeze material front with Laidlaw cloth backset of two	6.00	6.00
-------	--	------	------

SUN VISORS

A-731	LaSalle Sun Visor with trim—Series 345A—Second Style . . .	14.00 pair	14.00 pair
A-645	LaSalle Sun Visor with trim—Series 345A—First Style . . .	14.00 pair	14.00 pair

(Sun Visors covered with headlining fabric other than used on standard LaSalle Series 345 production will carry an additional charge of \$3.50 per pair to Distributors and Dealers.)

Part No.	DESCRIPTION	List Price	Installed Price
TRUNKS—Continued			
	892356 Cadillac Metal Covered Trunk only.....	\$70.00	\$70.00
	891794 Suitcase Genuine Cowhide (7 $\frac{1}{8}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	40.00	
	891795 Hat Box Genuine Cowhide (7 $\frac{1}{2}$ "x16"x15 $\frac{7}{8}$ ").....	30.00	
A-852	Cadillac DeLuxe Metal Covered Trunk equipped with Aero type (Linen finish) Wardrobe Case, Suitcase, and Hat Box—Series 340-345-353-355-370-452 (except open and convertible body styles).....	160.00	160.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	891801 Wardrobe Case—Aero type (Linen finish) (7 $\frac{1}{8}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	32.50	
	891802 Suitcase—Aero type (Linen finish) (7 $\frac{1}{8}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	32.50	
	891803 Hat Box—Aero type (Linen finish) (7 $\frac{1}{2}$ "x16"x15 $\frac{7}{8}$ ").....	25.00	
1098279	Cadillac Metal Covered Trunk equipped with 3 Suitcases and Hat Box—Series 340-345-353-355-370-452 (except open and convertible body styles).....	119.00	119.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	885778 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x26 $\frac{1}{4}$ ").....	12.00	
	885779 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x37 $\frac{3}{8}$ ").....	15.00	
	885780 Hat Box—Black Fabrikoid (10 $\frac{5}{8}$ "x16 $\frac{1}{2}$ "x11 $\frac{1}{8}$ ").....	10.00	
1098280	Cadillac Metal Covered Trunk equipped with 3 long Suitcases—Series 340-345-353-355-370-452 (except open and convertible body styles).....	115.00	115.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	885779 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x37 $\frac{3}{8}$ ").....	15.00	
A-912	Cadillac Metal Covered Trunk equipped with 2 Suitcases and Hat Box—Series 340-345-353-355-370-452 (except open and convertible body styles).....	107.00	107.00
	892356 Cadillac Metal Covered Trunk only.....	70.00	70.00
	892457 Suitcase—Black Fabrikoid (7 $\frac{1}{8}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	13.00	
	892456 Hat Box—Black Fabrikoid (7 $\frac{1}{2}$ "x16"x15 $\frac{7}{8}$ ").....	11.00	
85059	Cadillac Fleetwood Metal Covered Trunk equipped with 2 Suitcases and Hat Box—Series 340-345-353-355-370-452 (open, convertible and coupe body styles).....	104.00	104.00
	892452 Cadillac Fleetwood Metal Covered Trunk only.....	70.00	70.00
	885778 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x26 $\frac{1}{4}$ ").....	12.00	
	885780 Hat Box—Black Fabrikoid (10 $\frac{5}{8}$ "x16 $\frac{1}{2}$ "x11 $\frac{1}{8}$ ").....	10.00	
1098281	Cadillac Fleetwood Metal Covered Trunk equipped with 2 long Suitcases—Series 340-345-353-355-370-452 (open, convertible and coupe body styles).....	100.00	100.00
	892452 Cadillac Fleetwood Metal Covered Trunk only.....	70.00	70.00
	885779 Suitcase—Black Fabrikoid (5 $\frac{1}{4}$ "x16 $\frac{1}{2}$ "x37 $\frac{3}{8}$ ").....	15.00	
Cadillac Metal Trunks furnished in Color to Match Car—Special Order \$10.00 Extra List and Net.			
Cadillac Metal Covered Trunk 892356—Total Case capacity 15 $\frac{3}{4}$ " height x 16 $\frac{1}{2}$ " depth x 37 $\frac{3}{8}$ " length			
Cadillac Fleetwood Trunk 892452—Total Case capacity 10 $\frac{1}{2}$ " height x 16 $\frac{1}{2}$ " depth x 37 $\frac{3}{8}$ " length.			

TRUNK CASES — TOWN SEDAN AND TOWN COUPE

A-854	Town Sedan Case Assembly—(2 Suitcases, 1 Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	37.00
	891753 Suitcase—Black Fabrikoid—Town Sedan—Series 345B-355B-370B-452B (.....)	13.00
	891752 Hat Box—Black Fabrikoid—Town Sedan—Series 345B-355B-370B-452B (.....)	11.00
	A-855 Auxiliary Floor—Town Sedan—Series 345B-355B-370B-452B.....	
A-913	Town Coupe Case Assembly (2 Suitcases—1 Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	37.00
	892457 Suitcase—Black Fabrikoid (7 $\frac{1}{8}$ "x16 $\frac{1}{2}$ "x29 $\frac{3}{4}$ ").....	13.00
	892456 Hat Box—Black Fabrikoid (7 $\frac{1}{2}$ "x16"x15 $\frac{7}{8}$ ").....	11.00
	A-856 Auxiliary Floor—Town Coupe—Series 345B-355B-370B-452B.....	

Part No.	DESCRIPTION	List Price	Installed Price
TRUNK CASES—TOWN SEDAN AND TOWN COUPE—Continued			
Town Coupes—Series 345B-355B-370B-452B—can also be equipped with any of the other four case combinations used in Trunk Assemblies A-851, A-852, 1098279 or 1098280 as listed below.			
891793	Town Coupe DeLuxe Case Assembly—(2 Cowhide Cases—1 Cowhide Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	\$110.00	
891800	Town Coupe DeLuxe Case Assembly—(2 Aero Cases—1 Aero Hat Box, Auxiliary Floor) Series 345B-355B-370B-452B.....	90.00	
891546	Town Coupe Case Assembly—(3 Suitcases—1 Hat Box, Auxiliary Floor)—Series 345B-355B-370B-452B.....	49.00	
891547	Town Coupe Case Assembly—(3 long Suitcases, Auxiliary Floor)—Series 345B-355B-370B-452B.....	45.00	
A-857	Town Sedan Case Assembly—(2 Suitcases—1 Hat Box, Auxiliary Floor)—Series 355A-370A-452A.....	37.00	
	A-646 Suitcase—Black Fabrikoid—Town Sedan—Series 355A-370A-452A (6 $\frac{7}{8}$ "x14 $\frac{3}{4}$ "x27 $\frac{3}{8}$ ").....	13.00	
	A-647 Hat Box—Black Fabrikoid—Town Sedan—Series 355A-370A-452A (11 $\frac{1}{2}$ "x12 $\frac{5}{8}$ "x12 $\frac{1}{8}$ ").....	11.00	
	A-650 Auxiliary Floor—Town Sedan—Series 355A-370A-452A.....		
A-858	Town Sedan Case Assembly—(2 Suitcases—1 Hat Box, Auxiliary Floor)—Series 340-353-345A.....	37.00	
	873370 Suitcase—Black Fabrikoid—Town Sedan—Series 340-353-345A (7 $\frac{3}{8}$ "x14 $\frac{1}{4}$ "x30").....	13.00	
	873371 Hat Box—Black Fabrikoid—Town Sedan—Series 340-353-345A (8"x14 $\frac{1}{4}$ "x14").....	11.00	
	873379 Auxiliary Floor—Town Sedan—Series 340-353-345A		

WHEEL DISCS — CHROMIUM

896476	Cadillac Wheel Discs—18" Wheel—Series 452B.....	10.00	10.00
891728	Cadillac Wheel Discs—17" Wheel—Series 345B-355B-370B.....	10.00	10.00

WIND DEFLECTORS

A-885	Cadillac Draft Deflectors—Closed Car—Fisher Bodies—Series 345B-355B-370B-452B.....	25.00	25.00
A-886	Cadillac Draft Deflectors—Closed Car—Fleetwood Bodies—Series 345B-355B-370B-452B.....	25.00	25.00
A-503	Cadillac Draft Deflectors—Closed Car—Series 452A.....	25.00	25.00
A-615	Cadillac Draft Deflectors—Closed Car—Series 355A-370A—except 2 Pass. Coupes.....	25.00	25.00
A-705	Cadillac Draft Deflectors—Closed Car—Series 355A-370A—2 Pass. Coupe only.....	25.00	25.00
A-502	LaSalle Draft Deflectors—Closed Car—Series 340-345A....	25.00	25.00
A-501	Cadillac Draft Deflectors—Closed Car—Series 353.....	25.00	25.00
A-908	Cadillac DeLuxe Side Wings—Open Car—Series 340-353-345A—Folding Windshields.....	47.50	47.50
A-905	Cadillac DeLuxe Side Wings—Open Car—Series A and B—Stationary Windshields.....	47.50	47.50

Cadillac V-12

Upholstery

Fisher Bodies

39 T 132	-	Tan Shadow Pattern Broadcloth
40 T 132	-	Brown Diagonal Pattern Broadcloth
41 T 132	-	Brown Plain Broadcloth
42 T 132	-	Gray Diagonal Pattern Broadcloth
43 T 132	-	Gray Plain Broadcloth
44 T 132	-	Brown Whipcord
45 T 132	-	Green Gray Whipcord

Fleetwood Bodies

Wiese 4305	-	Brown Vogue Weave Broadcloth
Wiese 4306	-	Taupe Vogue Weave Broadcloth
Wiese 4307	-	Gray Vogue Weave Broadcloth
Wiese 4308	-	Brown Plain Broadcloth
Wiese 4309	-	Taupe Plain Broadcloth
Wiese 4310	-	Gray Plain Broadcloth
Wiese 4311	-	Tan Arabesque Weave Broadcloth (used with plain headlining to match)

Fisher - Fleetwood Bodies

9 T 1331	-	Brown Leather
10 T 1331	-	Green Leather
11 T 1331	-	Black Leather
12 T 1331	-	Blue Gray Leather

Cadillac V-8

UpholsteryFisher Bodies

28 T 132	-	Taupe Plain Mohair
29 T 132	-	Gray Whipcord
31 T 132	-	Taupe Whipcord
33 T 132	-	Taupe Striped Broadcloth
35 T 132	-	Taupe Plain Broadcloth

Fleetwood Bodies

Wiese 4305	-	Brown Vogue Weave Broadcloth
Wiese 4306	-	Taupe Vogue Weave Broadcloth
Wiese 4307	-	Gray Vogue Weave Broadcloth
Wiese 4308	-	Brown Plain Broadcloth
Wiese 4309	-	Taupe Plain Broadcloth
Wiese 4310	-	Gray Plain Broadcloth
Wiese 4311	-	Tan Arabesque Weave Broadcloth (used with plain headlining to match)

Leather Options for Open Cars and Convertible CoupesFisher - Fleetwood Bodies

9 T 1331	-	Brown Leather
10 T 1331	-	Green Leather
11 T 1331	-	Black Leather
12 T 1331	-	Blue Gray Leather