



## MINIVAN RADIO

AM/FM STEREO WITH SIX-DISC CD CHANGER



DIVISION	VEHICLE	OPTION CODE
Chevrolet	Uplander ('05-'07)	UC6
Saturn	RELAY ('06-'07)	UC6

### RADIO FUNCTIONS:

- **How to get to the XM band**
  - Select XM1 or XM2 with the BAND button
- **Tuning in XM channels**
  - Scroll through XM channels with the TUNE knob, labeled 
  - When you change channels, the radio will display the Channel Number/Name, then revert to the default display
  - Press SEEK/SCAN once to select the next channel, or press and hold for 2 seconds to scan through all channels; SCAN will be displayed. Press and hold for 4 seconds to scan through all preset channels; SCAN and the preset number will be displayed
- **How to preset your favorite channels**
  - Select preset channels 1 through 6 for bands XM1 and XM2; a total of 12 presets
  - Set a preset channel by pressing and holding the button until it beeps
- **How to display Song Title and Artist Name**
  - Press the  button to show Song Title/Artist Name/Category/Channel Name information
  - Multiple presses will advance through this information
  - Press and hold this button to set desired information as the default display, e.g., Artist Name
- **Channel Category search)**
  - Press the CAT button and the last selected category will appear on the display
  - Scroll through categories with the TUNE knob to locate the desired category
  - Press either SEEK/SCAN arrow to take you to a category's channel; SEEKING CATEGORY will be displayed
  - To go to another channel within that category, press the CAT button to display the category, then press either SEEK/SCAN arrow to go to another channel
  - Once the desired category is displayed, press and hold either SCAN arrow until you hear a beep and SCAN CATEGORY appears on the display; the radio will begin scanning the channels in the category
  - Press either SEEK/SCAN arrow to stop scanning

# SATURN RADIO

US9: AM/FM STEREO WITH SIX-DISC CD CHANGER AND MP3 (SHOWN)

US8: AM/FM STEREO WITH CD AND MP3



DIVISION	VEHICLE	OPTION CODE
Saturn	ION ('05)	US9/US8
	VUE ('05)	US9/US8

## RADIO FUNCTIONS:

- **How to get to the XM band**
  - Select XM1 or XM2 with the AUX button
- **Tuning in XM channels**
  - Scroll through XM channels by turning the TUNE knob, labeled
  - When you change channels, the radio will display the Channel Number/Name, then revert to the default display
  - Press SEEK/SCAN once to select the next channel, or press and hold for 2 seconds (one beep) to scan through all channels; SCAN will be displayed
- **How to preset your favorite channels**
  - Select preset channels 1 through 6 for bands XM1 and XM2; a total of 12 presets
  - Set a preset channel by pressing and holding the button until it beeps
- **How to display Song Title and Artist Name**
  - Press the **i** button to show Song Title/Artist Name/Category/Channel Name information
  - Multiple presses will advance through this information
- **Channel Category search**
  - Press the PTY button and CAT will appear on the display
  - Scroll through categories with the TUNE knob
  - Press the SEEK/SCAN button to select the first channel of the displayed category
  - Press SEEK/SCAN again to select the next channel of the displayed category
  - Once the desired category is displayed, press and hold the SEEK/SCAN button, and the radio will begin scanning within your chosen category

# MIXED BAND RADIO

AM/FM STEREO WITH CD AND MP3



## RADIO FUNCTIONS:

- **How to get to the XM band**
  - Select XM with the BAND button; the last selected XM channel will be displayed above the preset tabs; preset channels in the XM band can be mixed with stations from the AM and FM radio bands
- **Tuning in XM channels**
  - Scroll through XM channels by turning the TUNE knob, labeled
  - When you change channels, the radio will display the Channel Number/Name
  - Press SEEK once to select the next channel, or press and hold for 2 seconds (one beep) to scan through all channels; SCAN will be displayed. Press and hold for 4 seconds (double beep) to scan through all preset channels; PSCAN will be displayed
- **How to preset your favorite channels**
  - Preset buttons are labeled with and have display tabs above them
  - Select your favorite channels by pressing the button below the display tab
  - You can have up to 6 pages of favorite channels and cycle through pages by pressing the FAV button; a total of 36 favorite channels as presets
  - Favorite pages are displayed as 1 through 6 to the left of tab displays; you can select a FAV page number using the MENU button
  - Set a preset channel by pressing and holding the button until it beeps
  - Press the button to see the Song Title/Artist Name/Category/Channel Name; multiple presses will advance through this information
  - Pressing the button below a tab will display Song Title; the display will then default to the information last selected
- **Channel Category search**
  - Press the CAT button and the last selected category will be displayed
  - Multiple presses of the CAT button will advance through categories; or scroll through categories with the TUNE knob
  - Categories will appear on the display tabs
  - Press the button below the display tab to select the desired category
  - Press the SEEK arrows to move through the channels of the desired category
  - Once the desired category is displayed, press and hold the SEEK button, and the radio will begin scanning within your chosen category
  - Press the FAV button to exit the Channel Category search mode

DIVISION	VEHICLE	OPTION CODE
Buick	Lucerne ('06-'07)	US8
Chevrolet	Avalanche ('07)	US8
	Cobalt ('07)	US8
	Equinox ('07)	US8
	HHR ('06-'07)	US8
	Impala ('06-'07)	US8
	Monte Carlo ('06-'07)	US8
	Silverado ('07)	US8
	Suburban ('07)	US8
GMC	Tahoe ('07)	US8
	Acadia ('07)	US8
	Sierra ('07)	US8
	Yukon ('07)	US8
Pontiac	Yukon Denali ('07)	US8
	G5 ('07)	US8
	Solstice ('06-'07)	US8
Saturn	Torrent ('07)	US8
	AURA ('07)	US8
	ION ('06-'07)	US8
	OUTLOOK ('07)	US8
	SKY ('07)	US8
	VUE ('06-'07)	US8

# TRUCK NAVIGATION RADIO

AM/FM/CD/CDX/DVD/DV DX/NAVIGATION SYSTEM



DIVISION	VEHICLE	OPTION CODE
Cadillac	Escalade ('07)	UBO
Chevrolet	Avalanche ('07)	UBO
	Tahoe ('07)	UBO
	Suburban ('07)	UBO
	Silverado ('07)	UBO
GMC	Acadia ('07)	UBO
	Sierra ('07)	UBO
	Yukon ('07)	UBO
	Yukon Denali ('04-'07)	UBO
Saturn	OUTLOOK ('07)	UBO

## RADIO FUNCTIONS:

- **How to get to the XM band**
  - Touch the XM screen button, after pressing the AUDIO button
- **Tuning in XM channels**
  - Scroll through XM channels by turning the TUNE knob labeled with musical notes
  - Touch the Single ARROW button once to seek the next channel
  - Press the Double ARROW button to scan through all channels; SCAN will be displayed. Press and hold for 2 seconds to scan through all the preset channels; PSCAN will be displayed
- **How to preset your favorite channels**
  - Touch the FAV screen button to scroll through 6 preset pages; from 1-6. Each FAV page can store 6 preset channels. The presets can be mixed, AM, FM, or XM. Press the left/right arrow buttons to scroll through the list. The name of the FAV page is displayed above the presets for each page.
  - If available on your vehicle, you can also use the 1-6 (preset seek) steering-wheel control to scan through your preset channels
  - Set a preset channel by pressing and holding the button until it beeps
- **How to display Song Title and Artist Name**
  - The XM information will be displayed with each channel, or touch INFO to display information broadcast by XM
- **Channel Category search (CATEGORY)**
  - Touch the CATEGORY button and categories are displayed on the screen
  - Use the arrows on both sides of the category display; the current category is displayed in the middle of the arrows. The category display will time out after 6 seconds if you do not select anything
  - While in category mode, you can scroll through the category list, select a category type, and scroll through the channels available in each list
  - To exit the category mode, touch the CATEGORY button again