
Chevrolet





2003

Table of Contents

Product Information	1
2003 Chevy S-10 Pickup Offers An Array Of Versatile, Affordable Compact Pickups	1
Versatility and Choice	
Powertrain Choices	
Well-Equipped	
New For 2003	2
Model Lineup	
Specifications	3
Overview	3
Engines	3
Transmissions	
Chassis/Suspension	
Brakes	4
Wheels/Tires	
Dimensions	5
Exterior	
Cargo Box	
Interior	
Capacities	
Vehicle Identification	6
Vehicle Identification Number (VIN)	6
VIN Derivative	
Label Certification w/o RPO Z49	8
Label Certification w/o RPO Z49 – Incomplete Vehicle	<u>C</u>
Label Certification with RPO Z49	10
Label Certification with RPO Z49 – Incomplete Vehicle	11
Service Parts Identification Label (SPID)	
Tire Placard	14
Engine ID and VIN Derivative Location 4.3L	15
Engine ID and VIN Derivative Location 2.2L	18
Transmission ID and VIN Derivative Location	19
Manual Transmission	19
4L60-E Transmission ID Location	20
Engine and Transmission Usage	21
Transfer Case Identification	22
Axle Identification – Front	23
Axle Identification – Rear	24
Labeling - Anti-Theft	25
Notice	25
RPO Code List	26
Technical Information	30
Maintenance and Lubrication	30
Capacities - Approximate Fluid	30
Axles	30
Engine Cooling System	30
Engine Crankcase	
Fuel Tank	
Transmission	30
Power Steering Capacity	
Transfer Case	30
Maintenance Items	31
Automatic Transmission Filter Kit	31
Air Cleaner	
Engine Oil Filter	31

PCV Valve	3.
Spark Plugs	٠ع٠
Fuel Filter	9.
Windshield Wiper Blades	ر ب
Dackglass wider Blage	2.
Fluid and Lubricant Recommendations	ن
Descriptions and Operations	د
Power Steering System	
Steering Linkage Description and Operation	
Steering Wheel and Column - Standard Description and Operation	
Vehicle Steering	
Vehicle Security	34
Driver Convenience	34
Driver Safety	32
Suspension Description and Operation	34
Front Suspension	
Coil Spring	
Torsion Bar	5t
Rear Suspension	55
Automatic Level Control General Description	36
Loading The Vehicle	36
Unloading The Vehicle	36
Head Relief Function	3/
Air Replenishment Cycle (ARC)	37
Air Replenishment Cycle (ARC)	37
Inflator	37
Wheels and Tires	38
Fastener Tightening Specifications	38
General Description	38
Tread Wear Indicators Description	38
Metric Wheel Nuts and Bolts Description	38
Tire Inflation Description	39
P-Metric Sized Tires Description	40
Driveline System Description and Operation	41
Driveline/Axle – Propeller Shaft	41
Front Propeller Shaft Description	41
One Piece Propeller Shaft Description	41
Two Piece Propeller Shaft Description.	41
Propeller Shaft Phasing Description	41
Universal Joint Description	41
Center bearing Description	/11
Wheel Drive Shafts Description and Operation	41
Front Drive Axle Description and Operation	42
Real Drive Axie Description and Operation	42
Locking Differential Description and Operation	43
Transfer Case Description – NVG233 (NP1)	43
rioni Axie indicator Switch	11
Transfer Case Encoder	44
Transfer Case Encoder Motor	44
Transfer Case Shift Control Module	4.4
Transfer Case Description – NVG236/246 (NP8)	15
Transfer Case Still Control Module	45
Transfer Case Encoder Motor	46
Transfer Case Encoder	46
ransfer Case Motor Lock	46
Transfer Case Speed Sensors	46
SERVICE 4WD Indicator	47

Braking System Description and Operation	47
Hydraulic Brake System Description and Operation	47
System Component Description	47
Hydraulic Brake Master Cylinder Fluid Reservoir	47
Hydraulic Brake Master Cylinder	
Hydraulic Brake Pressure Balance Control System	47
Hydraulic Brake Pipes and Flexible Brake Hoses	47
Hydraulic Brake Wheel Apply Components	47
System Operation	
Brake Assist System Description and Operation	
System Component Description	
Brake Pedal	
Brake Pedal Pushrod	47 17
Vacuum Brake Booster	47 17
Vacuum Source	<i>۲</i> ۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰
Vacuum Source Delivery System	4C
System Operation	4C
Disc Brake System Description and Operation	48
System Component Description	48
Disc Brake Pads	48
Disc Brake Rotors	40
Disc Brake Pad Hardware	40
Disc Brake Caliper Hardware	40
System Operation	48
Drum Brake System Description and Operation	48
System Component Description	40
Drum Brake Shoes	48
Brake Drums	40
Drum Brake Hardware	
Drum Brake Adjusting Hardware	49
System Operation	49
Park Brake System Description and Operation	49
System Component Description	49
Park Brake Lever Assembly	49
Park Brake Cables	49
Park Brake Cable Equalizer	49
Park Brake Cable Equalizer	49
Park Brake Actuator/Adjuster	49
Park Brake Actuator/Adjuster	49
Park Brake Shoe (Rear Disc, Drum-In-Hat System)	49
System Operation	50
ABS Description and Operation	50
Antilock Brake System	50
Engine Description and Operation	51
Engine Mechanical 2.2L	51
Mechanical Specifications	51
General Data	
Cylinder Bore	51
Piston Ping Compression	51
Piston Ring Compression	51
Piston Ring Oil	51
Piston Pin	
Oil Pump	51
Crankshaft	52
Camshaft	52
Valve SystemFastener Tightening Specifications	52
rasienei rightening Specifications	53

Engine Component Description	54
Engine Block	54
Cylinder Head	54
Crankshaft	54
Piston and Connecting Rod Assemblies	54
Camshaft	54
Valve Train	55
Intake Manifold and Fuel Rail	55
Exhauet Manifold	55
Exhaust Manifold	55
Drive Belt System Description	55
Lubrication	56
Engine Mechanical – 4.3L	57
General Specifications	57
General	57
Balance Shaft	57
BIOCK	57
Camsnatt	57
Connecting Rod	57
Cranksnaft	57
Exhaust Manifold	58
Intake Manifold	58
Lubrication System	58
Piston Rings	58
Pistons and Pins	50 58
Valve System	50 50
Fastener Tightening Specifications	59 50
Engine Component Description 4.3L	o o
Balance Shaft	02
Camshaft	02
Camshaft	62
Cylinder Heads	62
Engine Block	62
Exhaust Manifolds	62
Exhaust Manifolds	62
Intake Manifold	62
Piston and Connecting Rod Assemblies	63
Valve Train	63
Engine Cooling	64
Fastener Tightening Specifications	64
Cooling System Description and Operation.	64
Coolant Heater	64
Cooling System	64
Cooling Cycle	64
Coolant	65
Radiator	65
Pressure Cap	65
Coolant Recovery System	65
All ballies and Seals	66
vvater Pump	66
i nermostat	66
Engine Oil Cooler	66
Harismission Oil Cooler	67
Engine Electrical	67
Fastener Tightening Specifications	67
Battery Usage	60
Battery Temperature vs Minimum Voltage	00
Starter Motor Usage	oo 88

Generator Usage	68
Battery Description and Operation	69
Reserve Capacity	70
Cold Cranking Amperage	70
Circuit Description	70
Starting System Description and Operation	70
Charging System Description and Operation	71
Generator	71
Regulator	71
Circuit Description	71
Engine Controls	79
Engine Controls – 4.3L	72
ignition System Specifications	72
Fastener Lightening Specifications	72
Fuel System Specifications	73
Exhaust System	74
Fastener Tightening Specifications	· · 74
Exhaust System Description	74
Resonator	74
Catalytic Converter	7.7
Muffler	75
ransmission/Transaxle Description and Operation	75
Manual Transmission – NV 1500	75
Fastener Lightening Specifications	75
Lubrication Specifications	75
Description and Operation	75
Manual Transmission – NV 3500	
rastener Lightening Specifications	77
Lubrication Specifications	77
Description	77
Hydraulic Clutch	78
Fastener Tightening Specifications	78
Hydraulic Clutch Description	78
4.3L Clutch	78
2.2L Clutch	78
Clutch Driving Members	78
Clutch Driven Members	
Hydraulic Clutch Fluid	78
Hydraulic Clutch Operating Members	70
Automatic Transmission - 4L60-E	80
Fastener Lightening Specifications	80
ransmission General Specifications	81
Fluid Capacity Specifications	91
ransmission Component and System Description	82
Adapt Function	82
ransmission Adapt Function	82
Automatic Transmission Shift Lock Control Description	82
Abbreviations and Meanings	ii
Sonversion - English/Metric	i
=quivalents - Decimal and Metric	ii
-asteners	i
Metric Fasteners	i
Fastener Strength Identification	ii
rievailing Torque Fasteners	ii
All Metal Prevailing Torque Fasteners	. ii
Nylon Interface Prevailing Torque Fasteners	ii

Adhesive Coated Fasteners	i
Metric Prevailing Torque Fastener Minimum Torque Development	ii
All Metal Prevailing Torque Fasteners	ii
Nylon Interface Prevailing Torque Fasteners	ii
English Prevailing Torque Fastener Minimum Torque Development	iν
All Metal Prevailing Torque Fasteners	iv.
Nylon Interface Prevailing Torque Fasteners	iv.

Product Information

2003 Chevy S-10 Pickup Offers An Array Of Versatile, Affordable Compact Pickups

New cloth interior seating surfaces and new door trim panels for LS trim for 2003 - added to a host of changes introduced mid-year 2002 - give the popular Chevy S-10 Pickup even more comfort and flexibility.

"S-10 Pickup has always been an affordable, reliable and versatile truck that delivers the dependability consumers demand," said Russ Clark, S-10 Pickup marketing director. "It can be tailored to fit the variety of 'on-the-go' lifestyles that so many people have."

Versatility and Choice

The S-10 Pickup offers tremendous versatility with an array of body styles and bed lengths. Available in Regular, Extended and Crew Cab - with seating for five, and four real doors - S-10 has a lineup that will satisfy virtually any compact truck buyer.

In addition to the three body configurations, S-10 Pickup offers the four-wheel-drive ZR2 Wide Stance Sport Performance Package and the Xtreme ZQ8 Sport Suspension Package for those who want extra variety.

The ZR2 package for off-roaders adds available fog lamps to a list of features that includes special ZR2 decals on all equipped 4x4 Extended Cab models, plus extra-wide argent wheel flares, 46mm Bilstein high-pressure gas shocks and 31-inch x 10.5-inch R15 on/off road tires.

The S-10 Xtreme - for those who want to turn heads as they zip down the road - features 270-degree ground effects, a front air dam with foglamps and optional exterior stripes available with all exterior colors. A Flame/Heat decal is also available.

Powertrain Choices

The Vortec 4300 4.3L V6 engine, standard on all 4x4 models and available on 2WD models, delivers 190 horsepower and 250 lb-ft of torque (on 4WD only). A new multi-port fuel-injection system features a central fuel injector that delivers a separate flow of fuel to six individual hybrid injectors for better performance and improved emissions.

The efficient Vortec 2200 2.2L inline four SFI engine is standard on all 2WD models.

The Insta-trac four-wheel-drive system, allowing push-button, on-the-fly four-wheel drive, is standard on all 4x4 models.

With a maximum wheelbase of 122.9 inches and a maximum payload of at least 1,111 pounds (Crew Cab model), the S-10 Pickup also is extremely nimble and maneuverable for city driving or hauling.

Well-Equipped

All S-10 Pickup two-wheel-drive retail models have a comprehensive list of standard equipment that includes a 60/40 bench seat, air conditioning, driver and passenger air bags, antilock brakes, PASSLock theft-deterrent system and daytime running lamps. Extended Cab models offer a standard third door for easier loading and access to the cargo area on the driver's side. The Crew Cab is now available with a ZR5 option that includes black aluminum bed rails, side steps, roof rack, wheel flares and unique aluminum wheels.

Several interior amenities come standard in the S-10 Pickup. Delayed interior lighting keeps the dome lamp lit for 15 seconds or until the ignition is turned on after closing the front doors. The stereo, power windows and other power options remain active for as long as 20 minutes after the ignition is turned off or a door is open, thanks to the retained accessory power feature.

New For 2003

- New interior cloth trim for seats and door trim panels
- New fuel-injection system for Vortec 4300 4.3L V6
- New Flame/Heat decal for Xtreme (introduced mid-year 2002)
- New Yellow exterior color (introduced mid-year 2002)
- ZR5 Sport Appearance Package on Crew Cab models (introduced mid-year 2002)

Model Lineup

	Engines		Transmissions		
•	Vortec 2200 2.2L L4	Vortec 4300 4.3L V6	5-spd man (MW2)	5-spd man (M50)	4-spd auto (Hydra-Matic 4L60-E)
2WD Regular Cab	S	0	S	· -	0
2WD Regular Cab long box	S	0	-	-	S
2WD Extended Cab	S	0	S	_	0
4WD Extended Cab	-	S	-	S	0
4WD Crew Cab	-	S	-	-	S

Standard:

S

Optional: Not available: Ō

Specifications

Overview					
Models:	 2003 Chevrolet S-10 Pickup 2WD Regular Cab Short Box 2WD Regular Cab Long Box 2WD Extended Cab Short Box 4x4 Extended Cab Short Box 4x4 Crew Cab 				
Body style / driveline:	 Regular Cab (2-3 passengers), Extended Cab (3-4 passengers), Crew Cab (5 passengers), front-engine rear-wheel-drive and four-wheel-drive pickup 				
Construction:	welded steel frame, hot-dipped steel, two panels	-sided galvanized steel on strategic			
EPA vehicle class:	compact pickup				
Manufacturing location:	Linden, New Jersey and Shreveport, Lou	isiana			
Key competitors:	S-10 Pickup: Ford Ranger, Dodge Dakota, Toyota Tacoma, Nissan Frontier, Mazda B-Series S-10 Crew Cab 4x4 Pickup: Dodge Dakota Quad Cab, Nissan Frontier Crew Cab, Toyota Tacoma Double Cab, Ford Explorer Sport Trac				
Engines	Vortec 2200 2.2L L4 (L43)	Vortec 4300 4.3L V6 (L35)			
Application:	standard with 2WD models	standard with 4WD models; optional with 2WD models			
Туре:	2.2-liter inline four cylinder	4.3-liter V6			
Displacement (cu in / liters):	134 / 2189	262 / 4293			
Bore & stroke (in / mm):	3.5 x 3.46 / 89 x 88	4 x 3.48 / 101.6 x 88.39			
Block material:	cast iron	cast iron			
Cylinder head material:	cast aluminum	cast iron			
Valvetrain:	pushrod, OHV, two valves per cylinder	pushrod, OHV, two valves per cylinder			
Ignition system:	distributorless, platinum-tipped spark plugs composite	distributor, platinum-tipped spark plugs, low-resistance spark plug wires			
Fuel delivery:	sequential fuel injection	sequential fuel injection			
Compression ratio:	9.0:1	9.2:1			
Horsepower (hp / kw @ rpm):	120 / 89 @ 5000	180 / 134 @ 4400 (2WD) 190 / 142 @ 4400 (4x4)			
Torque (lb-ft / Nm @ rpm):	140 / 190 @ 3600	245 / 332 @ 2800 (2WD) 250 / 339 @ 2800 (4x4)			
Recommended fuel:	87 octane (85-percent-ethanol capable)	87 octane			
Max engine speed (rpm):	6000	5600			
Emissions controls:	three-way catalytic converter, exhaust gas recirculation, positive crankcase ventilation, evaporative collection system	three-way catalytic converter, exhaust gas recirculation, positive crankcase ventilation, evaporative collection system			
Estimated fuel economy mpg city / hwy / combined):	5-speed manual: 22 / 28 / 24 4-speed automatic: 19 / 25 / 21	5-speed manual: 17 / 22 / 19 4-speed automatic: 16 / 22 / 18			


Transmissions					
	MW2	M50	Hydra-Matic 4L60-E		
Type:	5-speed manual	5-speed manual	4-speed automatic		
	Gear	ratios (:1):	opeca datomatic		
First:	3.96	3.49	3.06		
Second:	2.37	2.16	1.63		
Third:	1.49	1.40	1.00		
Fourth:	1.00	1.00	0.70		
Fifth:	0.83	0.73	-		
Reverse:	3.54	3.55	2.29		
Final drive ratio:	3.08	-	4.10:1 (3.73:1 standard with ZR2 wide-stance package)		
Chassis/Suspension	n i i i i i i i i i i i i i i i i i i i		- Paskage/		
Front:	independent with upper	er and lower control arms: coi	l spring 2WD, torsion bar 4WD		
Rear:	two-stage, variable-ra	te, multileaf rear springs	i spring 2000, torsion par 4000		
Steering type:	variable-ratio, integral	power, recirculating ball-type			
Steering ratio:	, ,	13:1 (2WD or 4WD at st	ton)		
Steering wheel turns, lock-t	o look:				
	4WD: 3.2				
Turning circle, curb-to-curb	urning circle, curb-to-curb (ft / m): Reg. Cab Short Box: 37 / 10.6 Ext. Cab: 41.6 / 12.7				
Brakes		Ext. 000. 41.07 12.7			
ype: 2WD: vacuum power, front disc / rear drum, antilock brakes					
71	4WD: vacuum power,	4WD: vacuum power, 4-wheel disc, antilock brakes			
Rotor diameter x thickness		front: 2WD, 10.05 x 1.03 / 267 x 26			
(in / mm):		4WD, 10.82 x 1.14 / 275			
-		rear: 4WD, 11.6 x .787 / 29			
Drum diameter x width (in /	mm):	rear: 2WD, 9.5 x 2 / 255	x 26		
Total swept area (sq in / sq	cm):	190.1 / 3115.1			
Drum swept area (sq in / sq	cm):	118.5 / 1941.9			
Wheels/Tires					
Wheel size & type:	2WD / 4WD: 15-inch x	7-inch steel; 4WD			
Crew Cab:	15-inch x 7-inch alumii	15-inch x 7-inch aluminum			
Tires:					
•	 P205/75R15 star 				
	(optional on 2WI	(optional on 2WD models)			
	 P235/70R15 all-s models) 	P235/70R15 all-season steel-belted radial blackwall tires (standard on 4x4)			
	(optional on 4v4)	- 2007 Of 701-10ad Steel-belted radial Write Outline-lettered fires			
	• 31-inch x 10.5-in	 (optional on 4x4 models with Z85 suspension) 31-inch x 10.5-inch R-15 LTC on-/off-road steel-belted radial blackwall tires 			
•		(ZR2 models only)			
	Y235/55K16 all-s Xtreme Sport Apple	 P235/55R16 all-season steel-belted radial blackwall tires (included with Xtreme Sport Appearance Package and ZQ8 suspension) 			
	 Full-size spare st 	andard on ZR2-equipped mod	dels and available on all		
	others except Xtreme or ZQ8-equipped models				

Dimensions

Wheelbase (in / mm): 117 Overall length (in / mm): 206 Overall width (in / mm): 67 Overall height (in / mm): 62 Track (in / mm): front: rear: Minimum ground clearance (in / mm): rear Ground to top of load floor (in / mm): 28 Step-in height (in / mm): 18	Long Box 7.9 / 2995 6.1 / 5235 .9 / 1725 .9 / 1598 54.9 / 1394 54.6 / 1387 :: 8.7 / 221 :: 6.7 / 170 6.1 / 714 6.2 / 462 35 / 1446	108.3 / 2751 190.1 / 4829 67.9 / 1725 62 / 1575 front: 54.4 / 1381 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183	Cab 4WD 122.9 / 3122 204.8 / 5201 67.9 / 1725 63.4 / 1610 front: 57.2 / 145; rear: 55.1 / 1400 front: 8.5 / 216 rear: 7.5 / 191	Crew Cab 4WD 122.9 / 3122 204.8 / 5201 67.8 / 1723 63.4 / 1610 3front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216 rear: 7.5 / 191
Overall length (in / mm): Overall width (in / mm): Overall width (in / mm): Overall height (in / mm): Front: rear: Minimum ground clearance (in / mm): Ground to top of load floor (in / mm): Step-in height (in / mm): Curb weight (lbs / kg): 318	3.1 / 5235 .9 / 1725 .9 / 1598 54.9 / 1394 54.6 / 1387 :: 8.7 / 221 :: 6.7 / 170 3.1 / 714 3.2 / 462	190.1 / 4829 67.9 / 1725 62 / 1575 front: 54.4 / 1381 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	204.8 / 5201 67.9 / 1725 62.7 / 1593 front: 54.5 / 1384 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183	204.8 / 5201 67.9 / 1725 63.4 / 1610 front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216	204.8 / 5201 67.8 / 1723 63.4 / 1610 3 front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216
Overall width (in / mm): 67 Overall height (in / mm): 62 Track (in / mm): front: rear: Minimum ground clearance (in / mm): rear Ground to top of load floor (in / mm): 28 Step-in height (in / mm): 18 Curb weight (lbs / kg): 318	.9 / 1725 .9 / 1598 54.9 / 1394 54.6 / 1387 :: 8.7 / 221 : 6.7 / 170 3.1 / 714 3.2 / 462	67.9 / 1725 62 / 1575 front: 54.4 / 1381 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	67.9 / 1725 62.7 / 1593 front: 54.5 / 1384 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183	67.9 / 1725 63.4 / 1610 front: 57.2 / 145; rear: 55.1 / 1400 front: 8.5 / 216	67.8 / 1723 63.4 / 1610 Bfront: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216
Overall height (in / mm): Track (in / mm): Minimum ground clearance (in / mm): Ground to top of load floor (in / mm): Step-in height (in / mm): Curb weight (lbs / kg): 62 front: rear: front: rear 18 28	.9 / 1598 54.9 / 1394 54.6 / 1387 :: 8.7 / 221 : 6.7 / 170 3.1 / 714	62 / 1575 front: 54.4 / 1381 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	62.7 / 1593 front: 54.5 / 1384 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183	63.4 / 1610 front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216	63.4 / 1610 3 front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216
Track (in / mm): Minimum ground clearance (in / mm): Ground to top of load floor (in / mm): Step-in height (in / mm): Curb weight (lbs / kg): front: rear: front: rear: front: rear: front: rear: 18 28 318	54.9 / 1394 54.6 / 1387 :: 8.7 / 221 :: 6.7 / 170 3.1 / 714	front: 54.4 / 1381 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	front: 54.5 / 1384 rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183	front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216	front: 57.2 / 1453 rear: 55.1 / 1400 front: 8.5 / 216
Minimum ground clearance (in / mm): front rear: Ground to top of load floor (in / mm): 28 Step-in height (in / mm): 18 Curb weight (lbs / kg): 318	54.6 / 1387 :: 8.7 / 221 :: 6.7 / 170 3.1 / 714 3.2 / 462	rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	rear: 54.6 / 1387 front: 9.1 / 234 rear: 7.2 / 183	rear: 55.1 / 1400 front: 8.5 / 216	rear: 55.1 / 1400 front: 8.5 / 216
(in / mm): rear Ground to top of load floor (in / mm): 28 Step-in height (in / mm): 18 Curb weight (lbs / kg): 318	:: 8.7 / 221 :: 6.7 / 170 3.1 / 714 3.2 / 462	front: 9.1 / 234 rear: 7.2 / 183 25.9 / 656	front: 9.1 / 234 rear: 7.2 / 183	front: 8.5 / 216	front: 8.5 / 216
Ground to top of load floor (in / mm): Step-in height (in / mm): Curb weight (lbs / kg): 318	3.1 / 714 3.2 / 462	rear: 7.2 / 183 25.9 / 656	rear: 7.2 / 183		
Step-in height (in / mm): 28	3.2 / 462	25.9 / 656		1041. 1.07 101	1 144r / 5 / 707
Curb weight (lbs / kg): 318			27.7 / 704	27.2 / 691	27.2 / 691
Curb weight (lbs / kg): 318 Weight distribution	35 / 1446	17.3 / 439	17.9 / 455	18.7 / 475	NA
Weight distribution		3042 / 1380	3212 / 1457	3788 / 1718	4039 / 1832
(% front / rear):	57 / 43	57 / 43	57 / 43	61 / 39	59 / 41
	ng Box		Short Box		Crew Cab Box
Cargo volume (cu ft / liters):	NA		39.4 / 1101		30.2 / 855
Length at floor (in / mm):	NA		72.8 / 1849		55.2 / 1402
	9 / 1394		54.9 / 1394		56.6 / 1438
Width at top (in / mm): 54. Width between	9 / 1394		54.9 / 1394		56.6 / 1438
wheelhousings (in / mm): 40.	3 / 1024	40.3 / 1024			40.4 / 1026
	9 / 1394	54.9 / 1394		56.6 / 1438	
Inside height (in / mm): 17	.1 / 434	17.1 / 434		17.1 / 434	
Interior	Regula			Crew Cab	
Seating capacity:	2/	2/3 3/4 5		5 front: 39.4 / 1002	
Head room (in / mm):	39.5 / 1003		39.6 /	39.6 / 1006	
Leg room (in / mm):	42.4 / 1076		42.4 /	1076	front: 42.7 / 1084 rear: 34.6 / 878
Shoulder room (in / mm):	56.9 /	9 / 1443 56.9 / 1443		front: 57.1 / 1450 rear: 57.2 / 1452	
Hip room (in / mm):	53.6 /	1361 51.6 / 1311		1311	front: 53.6 / 1361 rear: 53.7 / 1363
Capacities		100 EP	carding a		1.001.00.17 1000
	Short Regula		Extende	Extended Cab	
GVWR, standard (lbs / kg):	2WD: 4200 / 1905			2WD: 4400 / 1996 4WD: 5150 / 2336	
Payload, base (lbs / kg):	2WD: 1157 / 525		2WD: 118	2WD: 1188 / 539	
Fuel tank (gals / liters):	18 / 68.1			4WD: 1362/ 618 18.3 / 69.3	
	18 / 68.1 18.3 / 69.3 17.5 / 66.3 Vortec 2200 Vortec 4300			17.3700.3	
Engine oil (qts / liters):	4.5 / 4.3				
Cooling system (qts / liters):	manual: 11.5 / 10.8			manual: 11.9 / 11.3	
	automatic: 11.5 / 10.8 automatic: 11.7 / 11.1 Maximum trailer weight (lbs / kg):			11.1	
Regular Cab 2WD:			(ins / kg):	F000 / 00=0	
Extended Cab 2WD:	3100 / 1406 3000 / 1360		5900 / 2676 5600 / 2540		
Extended Cab 4WD:			5600 / 2540		
Crew Cab 4WD:	- 5500 / 2494 - 5200 / 2358				
Maximum tongue weight:	10-15 percent of total trailer weight up to 750 lbs (340 kg)			(a)	

Vehicle Identification

Vehicle Identification Number (VIN)



The vehicle identification number (VIN) plate is the legal identifier of the vehicle. The VIN plate is located on the upper LH corner of the Instrument Panel and can be seen through the windshield from the outside of the vehicle:

Position	Definition	Character	Description
1	Country of Origin	1,4	U.S. Built
2	Manufacturer	G	General Motors
		С	Chevrolet Truck
ļ		Н	Oldsmobile MPV
3	Make	K	GMC MPV
	·	N	Chevrolet MPV
		T	GMC Truck
4	GVWR/Brake System	С	4,001-5,000 HYD Brakes
	OTTTO Brake bystem	D	5,001-6,000 HYD Brakes
5	Truck Line/Chassis Type	S	Sm Conventional Cab4x2
	Track Emerchadolo Type	T	Sm Conventional Cab4x4
6	Series	1	½ Ton Nominal
	00.100	6	½ Ton Luxury
		4	Two Door Cab
7	Body Type	9	Two Door Extended Cab
		8	Two Door Utility
		3	Four Door Utility or Crew Cab
8	Engine Type	4	2.2L L4 MFI (LN2)
		W	4.3L V6 CPI (L35)
9	Check Digit		Check Digit
10	Model Year	3	2003
11	Plant Location	8	Shreveport,LA
		K	Linden, NJ
12-17	Plant Sequence Number		Plant Sequence Number

VIN Derivative


All engines and transmissions are stamped or laser etched with a partial vehicle identification number (VIN), which was derived from the complete VIN. A VIN derivative contains the following nine positions:

Position	Definition	Character	Description
		С	Chevrolet Truck
1	200	Н	Oldsmobile MPV
	GM Division Identifier	K	GMC MPV
		N	Chevrolet MPV
		T	GMC Truck
2	Model Year	3	2003
3	Assembly Plant	K	Linden, NJ
		8	Shreveport, LA
4-9	Plant Sequence Number		Plant Sequence Number

A VIN derivative can be used to determine if a vehicle contains the original engine or transmission, by matching the VIN derivative positions to their accompanying positions in the complete VIN:

VIN Derivative Position	Equivalent VIN Position
1	3
2	10
3	11
4-9	12-17

Label Certification w/o RPO Z49



- (1) GM Logo
- (2) Gross Vehicle Weight Rating
- (3) Gross Axle Weight Rating Front
- (4) Gross Axle Weight Rating Rear
- (5) Name Of Manufacturer
- (6) Final Manufacturer's Date
- (7) Manufacturer's Statement
- (8) Model Designation
- (9) Payload
- (10) DUAL When Equipped
- (11) Front Axle Reserve When Equipped
- (12) Total Capacity When Required
- (13) Tire Pressure
- (14) Rim Size
- (15) Speed Rating When Required
- (16) Tire Size
- (17) GVW Rating Code
- (18) Engineering Model
- (19) Vehicle Identification Number

The vehicle certification label displays the following assessments:

- The Gross Vehicle Weight Rating (GVWR)
- The Gross Axle Weight Rating (GAWR) -- Front and Rear
- The vehicle's payload rating
- The original equipment tire sizes and the recommended tire pressures

Gross vehicle weight (GVW) is the weight of the vehicle and everything it carries. Include the following items when figuring the GVW:

- The base vehicle weight (factory weight)
- The weight of all vehicle accessories, like the winches or the plows
- The weight of the driver and the passengers
- The weight of the cargo

The gross vehicle weight must not exceed the Gross Vehicle Weight Rating.


The front gross axle weight rating (GAWR FRT) is the weight exerted on the front axle. The rear gross axle weight rating (GAW RR) is the weight exerted on the rear axle. The front and rear gross axle weights must not exceed the front and rear gross axle weight ratings.

The payload rating defines the vehicle's maximum allowable cargo load. The cargo load includes the driver and the passengers. The payload rating is based on the vehicle's factory installed equipment. Deduct from the payload rating the weight of accessories added to the vehicle after the final date of manufacture .

The vehicle may have a Gross Combination Weight Rating (GCWR). The Gross Combination Weight Rating refers to the total maximum weight of the loaded tow vehicle (including driver and passengers) and a loaded trailer.

The vehicle's tires must be the proper size and properly inflated for the load the vehicle is carrying.

Label Certification w/o RPO Z49 - Incomplete Vehicle



- (1) Logo
- (2) Gross Vehicle Weight Rating
- (3) Gross Axle Weight Rating Front
- (4) Gross Vehicle Weight Rating Rear
- (5) Name of Manufacturer
- (6) Manufacturer's Date
- (7) Manufacturer's Statement
- (8) DUAL When Equipped
- (9) Front Axle Reserve When Required
- (10) Total Capacity When Required
- (11) Tire Pressure Spare Optional
- (12) Rim Size Spare Optional
- (13) Speed Rating When required Spare Optional
- (14) Tire Size Spare Optional
- (15) GVW Rating Code
- (16) Engineering Model
- (17) Vehicle Identification Number

The vehicle certification label displays the following assessments:

- The Gross Vehicle Weight Rating (GVWR)
- The Gross Axle Weight Rating (GAWR) -- Front and Rear

- The vehicle's payload rating
- The original equipment tire sizes and the recommended tire pressures


Gross vehicle weight (GVW) is the weight of the vehicle and everything it carries. Include the following items when figuring the GVW:

- The base vehicle weight factory weight
- The weight of all vehicle accessories, like the winches or the plows
- The weight of the driver and the passengers
- The weight of the cargo

The gross vehicle weight must not exceed the Gross Vehicle Weight Rating.

The front gross axle weight rating (GAWR FRT) is the weight exerted on the front axle. The rear gross axle weight rating (GAW RR) is the weight exerted on the rear axle. The front and rear gross axle weights must not exceed the front and rear gross axle weight ratings.

Label Certification with RPO Z49



- (1) Logo
- (2) Gross Vehicle Weight Rating
- (3) Gross Axle Weight Rating Front
- (4) Gross Axle Weight Rating Rear
- (5) Name of Manufacturer
- (6) Final Manufacturer's Date
- (7) RFI Statement Canada Only
- (8) DUAL When Equipped
- (9) Front Axle Reserve When Equipped
- (10) Total Capacity When Required
- (11) Tire Pressure
- (12) Rim Size
- (13) Speed Rating When Required
- (14) Tire Size
- (15) GVW Rating Code
- (16) Engineering Model
- (17) Vehicle Identification Number
- (18) Payload
- (19) Model Designation

The vehicle certification label displays the following assessments:

- The Gross Vehicle Weight Rating (GVWR)
- The Gross Axle Weight Rating (GAWR) -- Front and Rear
- The vehicle's payload rating
- The original equipment tire sizes and the recommended tire pressures

Gross vehicle weight (GVW) is the weight of the vehicle and everything it carries. Include the following items when figuring the GVW:

- The base vehicle weight factory weight
- The weight of all vehicle accessories, like the winches or the plows
- The weight of the driver and the passengers
- The weight of the cargo

The gross vehicle weight must not exceed the Gross Vehicle Weight Rating.


The front gross axle weight rating (GAWR FRT) is the weight exerted on the front axle. The rear gross axle weight rating (GAW RR) is the weight exerted on the rear axle. The front and rear gross axle weights must not exceed the front and rear gross axle weight ratings.

The payload rating defines the vehicle's maximum allowable cargo load. The cargo load includes the driver and the passengers. The payload rating is based on the vehicle's factory installed equipment. Deduct from the payload rating the weight of accessories added to the vehicle after the final date of manufacture .

The vehicle may have a Gross Combination Weight Rating (GCWR). The Gross Combination Weight Rating refers to the total maximum weight of the loaded tow vehicle including driver and passengers and a loaded trailer.

The vehicle tires must be the proper size and properly inflated for the load the vehicle is carrying.

Label Certification with RPO Z49 – Incomplete Vehicle



- (1) Logo
- (2) Gross Vehicle Weight Rating
- (3) Gross Axle Weight Rating Front
- (4) Gross Axle Weight Rating Rear
- (5) Name Of Manufacturer
- (6) Manufacturer's Date

2003 Chevrolet S-10 Restoration Kit

- (7) RFI Statement Canada Only
- (8) DUAL When Equipped
- (9) Front Axle Reserve When Required
- (10) Total Capacity When Required
- (11) Tire Pressure Spare Optional
- (12) Rim Size Spare Optional
- (13) Speed Rating When Required Spare Optional
- (14) Tire Size Spare Optional
- (15) GVW Rating Code
- (16) Engineering Model
- (17) Vehicle Identification Number
- (18) Model Designation

The vehicle certification label displays the following assessments:

- The Gross Vehicle Weight Rating (GVWR)
- The Gross Axle Weight Rating (GAWR) -- Front and Rear
- The vehicle's payload rating
- The original equipment tire sizes and the recommended tire pressures


Gross vehicle weight (GVW) is the weight of the vehicle and everything it carries. Include the following items when figuring the GVW:

- The base vehicle weight factory weight
- The weight of all vehicle accessories, like the winches or the plows
- The weight of the driver and the passengers
- The weight of the cargo

The gross vehicle weight must not exceed the Gross Vehicle Weight Rating.

The front gross axle weight rating (GAWR FRT) is the weight exerted on the front axle. The rear gross axle weight rating (GAW RR) is the weight exerted on the rear axle. The front and rear gross axle weights must not exceed the front and rear gross axle weight ratings.


Service Parts Identification Label (SPID)



- (1) Vehicle Identification Number
- (2) Wheel Base
- (3) Part Number Location
- (4) Model Designation
- (5) Order Number
- (6) Exterior Color
- (7) Paint Technology

The service parts identification label is located on the instrument panel storage compartment door in order to help service and parts personnel identify the vehicle's original parts and the vehicle's original options.

Tire Placard




- (1) Specified Occupant Seating Positions
- (2) Total Occupant Seating
- (3) Maximum Vehicle Capacity Weight
- (4) Tire Pressures, Front, Rear, and Spare
- (5) Tire Speed Rating, Front, Rear, and Spare
- (6) Tire Label Code
- (7) Engineering Model Minus First Character
- (8) Tire Sizes, Front, Rear, and Spare
- (9) Vehicle Identification Number

The Tire Placard is permanently located on the edge of the driver's door. Refer to the placard in order to obtain the following information:


- The maximum vehicle capacity weight
- The cold tire inflation pressures
- The tire sizes (original equipment tires)
- The tire speed ratings (original equipment tires)

Engine ID and VIN Derivative Location 4.3L




The Vehicle Identification Number (VIN) Derivative is located on the left side rear of the engine block (1) or on the right side rear (2) and typically is a nine digit number stamped or laser etched onto the engine at the vehicle assembly plant.

- The first digit identifies the division.
- The second digit identifies the model year.
- The third digit identifies the assembly plant.
- The fourth through ninth digits are the last six digits of the Vehicle Identification Number (VIN).



Engines built at the Tonawanda engine plant have the engine identification number located at the right front top of the engine block.


- The first digit (1) is the source code.
- The second and third digits (2) are the month of build.
- The fourth and fifth digits (3) are the date of build.
- The sixth, seventh, and eighth digits (4) are the broadcast code.



Engines built at the Romulus engine plant have the engine identification number located at the right front top of the engine block.

- The first digit (1) is the source code.
- The second and third digits (2) are the month of build.
- The fourth digit (3) is the hour of the build.
- The fifth and sixth digits (4) are the date of build.
- The seventh, eighth, and ninth digits (5) are the broadcast code.

Engine ID and VIN Derivative Location 2.2L




Identification can be made through the use of the Broadcast Code label on the valve rocker arm cover (1) and the use of the partial VIN etched on the left side of the engine block above the starter (2).

The broadcast code identifies the engine, transmission, and vehicle relationship. The partial VIN identifies the specific vehicle by sequence number.


Transmission ID and VIN Derivative Location


Manual Transmission



The transmission model identification is located on a label or tag on the transmission case. If this label is missing or unreadable, use the service parts identification label in order to identify the vehicle's transmission.

4L60-E Transmission ID Location






- (1) Model Year
- (2)Hydra-Matic 4L60-E
- (4)
- Julian Date (or Day of the Year) Shift Built (A, B, J = First Shift; C, H, W = Second Shift) (5)
- (6)Model
- Transmission ID Location (7)
- Hydra-Matic 4L60-E (8)
- (9) Julian Date (or Day of the Year)
- (10) Serial No.
- Shift Built (A, B, J = First Shift; C, H, W = Second Shift) (11)
- (12) Model
- (13) Model Year
- (14) Transmission ID Location

Engine and Transmission Usage

Model	Engine		Transmission	
Model	Base	Option	Base	Option
S105 (06)	4.3L V6 (L35)		4 Spd. Auto. (M30)	
S105 (16)	4.3L V6 (L35)		5 Spd. Manual (M50)	4 Spd. Auto. (M30)
S106 (03)	2.2L L4 (L43)	2.2L L4 (L43) 4.3L V6 (L35)	5 Spd. Manual (M50) 5 Spd. Manual (MW2)	4 Spd Auto (M20)
S106 (53)	2.2L L4 (L43)	2.2L L4 (L43) 4.3L V6 (L35)	5 Spd. Manual (MW2) 5 Spd. Manual (M50)	
S108 (03)	2.2L L4 (L43)	2.2L L4 (L43) 4.3L V6 (L35)	5 Spd. Manual (MW2) 5 Spd. Manual (M50)	4 Spd. Auto. (M30)
T105 (06)	4.3L V6 (L35)		5 Spd. Manual (M50) 4 Spd. Auto. (M30)	5 Spd. Manual (M50)
T105 (16)	4.3L V6 (L35)		5 Spd. Manual (M50)	4 Spd. Auto. (M30)
T106 (03)	4.3L V6 (L35)	4.3L V6 (L35)	5 Spd. Manual (M50)	4 Spd. Auto. (M30)
T106 (43)	4.3L V6 (L35)		4 Spd. Auto. (M30)	
T106 (53)	4.3L V6 (L35)	4.3L V6 (L35)	5 Spd. Manual (M50)	4 Spd. Auto. (M30)

Model Codes: S-Two-Wheel Drive and T-Four-Wheel Drive 03—Two-Door Cab 06—Four-Door Utility 16—Two-Door Utility 43—Four-Door Pickup 53—Two-Door Extended Cab 08—Long Box Pickup

Transfer Case Identification




An identification tag is attached to the rear half of the transfer case. The tag provides the following information:

- 1 Model number (1)
 - A First Digit-1 =Single Speed, 2=Two-Speed
 - B Second Digit-2 = T Utility, 3 =T-Truck, L-Van, 4 or 6 = K Truck and Utility
 - C Third Digit-1 = Manual, 3 = Electric Shift, 6 = Automatic, 9 = All Wheel Drive
- 2 Assembly number (2)
- 3 Serial number (Date and Shift Code) (3)
- 4 Low range reduction ratio (4)

The information on this tag is necessary for servicing the transfer case. If the tag is removed or becomes dislodged during service operations, keep the identification tag with the unit.

Axle Identification - Front



- (1) (2) **Broadcast Code**
- Supplier Code (G = American Axle)
- (3) Julian Date (Day of Year)
- Shift Built (1 = First Shift; 2 = Second Shift) (Optional for 8.25" and 9.25" axles) (4)
- (5) Hour Built


Front axle identification information is stamped on the top of the differential carrier assembly.

The following broadcast codes identifies the axle ratio:

Broadcast Code	Ratio
ZTM	3.08
ZTN, ZTU, ZTW, ZSY, ZA2, ZC2	3.42
ZTP, ZTR, ZTS, ZTX, ZSZ, ZB2,ZD2	3.73
ZTT,ZF2	4.10
ZH2	4.56

The information on the differential carrier assembly is necessary for servicing.


Axle Identification - Rear



- (1) Rear Axle Ratio
- (2) Build Source (C = Buffalo; K = Canada)
- (3) Julian Date
- (4) Shift Built (1 = First; 2 = Second)

All rear axles are identified by a broadcast code on the right axle tube near the carrier. The rear axle identification and manufacturer's codes must be known before attempting to adjust or to repair axle shafts or the rear axle case assembly. Rear axle ratio, differential type, manufacturer, and build date information is stamped on the right axle tube on the forward side.

Labeling - Anti-Theft



Notice

The anti-theft label found on some major body panels MUST be covered before performing any painting, rustproofing or undercoating procedures. The mask must also be removed following those procedures. Failure to follow these precautionary steps may result in liability for violation of the Federal Vehicle Theft Prevention Standard, and subject the vehicle owner to possible suspicion that the part was stolen.

Federal law requires General Motors (GM) to affix a label to certain parts on selected vehicles with the Vehicle Identification Number (VIN). The purpose of this law is to reduce the number of motor vehicle thefts by helping in the tracing and recovery of parts from stolen vehicles. The certification label on the driver's door qualifies as a theft deterrent label.

The theft deterrent label will be permanently affixed to an interior surface of the part and will contain the complete VIN. The label on replacement parts will contain the letter R, the manufacturer's logo, and the acronym for the Department of Transportation (DOT). DO NOT deface, or remove these labels.

RPO Code List

The production/process codes provide the description of the Regular Production Options (RPOs) used on the vehicle. The RPO list is printed on the Service Parts Identification Label. The following is a list of the RPO abbreviations and the description of each:

RPO	Description Description
AA3	Window Tinted, Deep Tint
AG0	Adjuster, Front Seat, Power
AG1	Adjuster, Driver Seat, Power 6-Way
AG2	Adjuster, Passenger Seat, Power 6-Way
AH8	Adjuster, Passenger Seat, Power 8-Way
AJ1	Window Tinted, Deep Tint
AM6	Seat, Front Split, 3 Passenger, Center Arm Rest
AM7	Seat, Rear Folding
ANL	Sale Package Air Deflector and Fog Lamp
AN3	Seat, Front Bucket
AU0	Remote Keyless Entry
AU3	Power Door Locks
AV5	Seat, Front Bucket, High Back
A28	Window, Rear Full Width, Sliding
A31	Window Power Operated, Side
BAG	Parts Package Export
BG9	Covering Floor Rubber
BNB	Ornamentation Exterior, Unpainted
BZY	Liner PUBX
B30	Covering, Floor Carpet
B32	Covering Floor Mats, Front Auxiliary
B84	Molding B/S Exterior
B94	Ornamentation Extgerior, Emblem, Body
CF5	Sun Roof, Glass, Sliding, Electric
CKD	Vehicle Completely Knocked Down
C25	Wiper System Rear Window, Intermittent
C3A	GVW RATING 4400 LBS
C3G	GVW RATING 4450 LBS
C3T	GVW RATING 5350 LBS
C42	HVAC System Heater Deluxe, Outside Air
C49	Defogger Rear Window, Electric
C5A	GVW Rating 4900 lbs
C5C	GVW Rating 5000 lbs
C5D	GVW Rating 4600 lbs
C5T	GVW Rating 4200 lbs
C6F	GVW Rating 5150 lbs
C6I	GVW Rating 4850 lbs
C60	HVAC System Air Conditioner, Front Manual Controls
DD0	Mirrors, Outside, Remote Control, Electric, Heated, Light Sensitive
DD8	Mirrors, Inside, RV, Light Sensitive
DH6 DK2	Mirrors, Inside Front Van, Sunshade
DK2 DK7	Mirror, Outside Remote Control, Electric, Heated, Color
DK7	Console Roof Interior, Custom
D07	Console Front Comportment Floor Contains
D34	Console Front Compartment Floor, Custom
D34 D44	Mirror I/S Front VAN Left Hand and Right Hand, Sunshade, No Illumination Mirror, Outside, Color
	iviii Tor, Outside, Coloi

D55	Canada Front Compositional Eliza
D98	Console Front Compartment, Floor
EVA	Stripe, Accent
E55	Test DVT, Evaporator Emission Requirement
	Body Equipment End Gate
E62	Body Equipment Stepside
E63	Body Equipment Fleetside PUBX
FF4	Arm Torsion Bar Spring Adjustment (C)
FF5	Arm Torsion Bar Spring Adjustment (D)
FF6	Arm Torsion Bar Spring Adjustment (E)
FF7	Arm Torsion Bar Spring Adjustment (F)
FK2	Arm Torsion Bar Spring Adjustment (A)
FK3	Arm Torsion Bar Spring Adjustment (B)
GT4	Axle Rear 3.73 Ratio (Dup with 5X1)
GT5	Axle Rear 4.10 Ratio (Dup with GT8)
GU4	Axle Rear 3.08 Ratio
GU6	Axle Rear 3.42 Ratio
G80	Axle Positraction Limited, Slip
JC1	Brake Vacuum Power, 4-Wheel DISC, 5500 lbs
JM3	Booster Brake, 240 mm Tandem, High Flow
KA1	Heater Seat
K05	Engine Block Heater
K18	Reactor System, Air Injection, Electric
K34	Cruise Control Automatic, Electronic
K53	Fuel Sender Assembly, Robust Fuel System
K60	Generator, 100 Amp
LIN	Plant Code, LInden, NJ
LN2	Engine, Gas, 4 Cylinder, 2.2 L, MFI
LU3	Engine, Gas, 6 Cylinder, 4.3 L, MFI, V6, 90 Deg
MW2	Transmission, Manual 5-Speed, 76 mm, 3.96 1st, .83 5th, O/D
M30	Transmission, Automatic 4-Speed, 4L60E, Electronic
M50	Transmission, Manual 5-Speed, 85 mm, 3.49 1st, O/D
NC1	Emission System California LEV
NF4	Emission System Clean Fuel, Fleet
NF7	Emission System Federal NLEV
NF9	Emission System General Unleaded
NP1	Transfer Case Electric Shift Control, Two-Speed
NP5	Steering Wheel Leather Wrapped
NP6	Provisions Transfer Case, Export
NP8	Transfer Case Active, Two-Speed, Push Button Control
NT9	Emission System, Federal, Tier 2 Phase-Out
NU4 N12	Emission System, California, Level 2 Plus
	Exhaust System Rear Exit
N33	Steering Column Tilt Type
N40 N60	Steering Power, Non-Variable Ration
N90	Wheel, Aluminum, Painted
	Wheel 15 x 7, Aluminum Cast, 4.75 inch Bolt
N96 PA3	Wheel 16 x 8, Cast Aluminum
PH1	Wheel 15 x 7, Aluminum Styled
PNV	Wheel 15 x 7, Steel
PNV P16	Carrier Outside Spare Tire Mount Not Desired
QBF	Carrier Rear Mounted, Spare Tire
QBG	Tire, P235/70R15 Black Wall, All Season
טטט	Tire, P235/70R15 White Wall, All Season

000	Tiro DODE/ZED45 Milita Mall All O
QCA	Tire, P205/75R15, White Wall, All Season
QCB	Tire P235/55R16, Black Wall, AL2
QCE	Tire, P205/75R15/N Black Wall, All Season
QEB	Tire P235/75R15/N White Wall, All Season
QJJ	Tire 31X10.50R15LT/C Black Wall, OOR
QLN	Tire 235/70R15-103H Black Wall, All Season
RAE	Equipment Cargo Management System
RYJ	Covering Cargo Area, Retractable
SLA	Plant Code Shreveport, LA, GM T&B
TB4	Body Equipment Lift Gate
T61	Lighting, Daytime Running
T62	Lighting, Daytime Running - Delete
UA1	Battery, High Capacity, Wet
UC2	Speedometer, Kilometer and Miles, Kilometer Odometer
UC6	Radio AM/FM Stereo, Seek/Scan, RDS, Multiple Compact Disc, Auto Tone Control, Clock, ETR
UD4	Alarm Vehicle Speed, 120 K/H
UK3	Electronic System Steering Wheel Accessory Controls
UL2	European Frequencies
UL5	Radio - Delete
UM7	Radio, AM/FM Stereo, Seek/Scan, Clock
UN0	Radio, AM/FM, Stereo, Seek/Scan, Compact Disc, Auto Tone, Clock
LIDO	Radio, AM/FM, Stereo, Seek/Scan, Auto Reverse Music Search Cassette, CD, Auto Tone,
UP0	Clock
UW3	Radio, AM/FM, Stereo, Seek/Scan, Auto Reverse Music Search Cassette, Data System, Clock
UY7	Wiring Harness Truck Trailer, HD
U16	Tachometer Engine
U73	Antenna, Fixed, Radio
U89	Wiring Harness Car Trailer
VC5	Label Shipping, except US, US Possessions, or Japan
VC7	Label Price/Fuel Economy, Guam
VF6	Bumper Rear Step
VGC	Protector Film, Paint Etch Preventive
VG8	Vehicle Buyer Notice Label
VJ4	Label, Export Child Seat Location
\ // /D	Handling Charge Shreveport Assembly to Tecstar, Inc. Shreveport, with final shipment
VKB	through Shreveport
VKC	Handling Charge Shreveport Assembly to Centurion Vehicles, White PIgeon, MI, return to Fort
	Wayne for reshipment
VKE	Handling Charge Linden Assembly to Centurion Vehicles, White Pigeon, MI, return to Fort
	Wayne for reshipment
VPH	Vehicle Preparation, Overseas Delivery
VR4	Trailer Hitch Weight Distributing Platform
VR6	Hook Tie Down
VXS	Vehicle Complete
V10	Provision Options, Cold Climate
V37	Bumper Front and Rear, Chrome
V4A	Performance Package Chevy Xtreme
V73	Vehicle Statement, US and Canada
V78	Vehicle Statement - Delete
V87	Vehicle Statement, Gulf States Organization
V98	Factory Delivery Processing
W84	Miscellaneous Equipment for Egypt (Egypt Controlled)
W86	Miscellaneous Equipment for Venezuela (GMV Controlled)

W87	North American Ports, Sourced in Vancousty (OND) (O. 1. II.)
W99	North American Parts, Sourced in Venezuela (GMV Controlled)
XBF	Miscellaneous Equipment for Venezuela (GM Platform Controlled)
	Tire Front P235/70R15 Black Wall
XBG	Tire Front P235/70R15 White Wall
XCA	Tire Front P205/75R15 White Wall
XCB	Tire Front P235/55R16 Black Wall
XCE	Tire Front P205/75R15/N Black Wall
XEB	Tire Front P235/75R15/N White Wall
XJJ	Tire Front 31X10.50R15LT/C Black Wall
XLN	Tire Front 235/70R15-103H Black Wall
X44	North American Parts Sourced & Shipped to Outside Supplier & Checked (GMCL Controlled)
X52	Miscellaneous Equipment for Guam, Puerto Rico, US Virgin Islands
X88	Conversion Name PLate, Chevrolet
YBF	Tire Rear P235/70R15 Black
YBG	Tire Rear P235/70R15 White
YCA	Tire Rear P205/75R15 White
YCB	Tire Rear P235/55R16 Black
YCE	Tire Rear P205/75R15/N Black
YC3	Convenience Package Decor Level #3
YC5	Connvenience Package Decor Level #5
YEB	Tire Rear P235/75R15/N White Wall
YJJ	Tire Rear 31X10.50R15LT/C Black Wall
YLN	Tire Rear 235/70R15-103H Black Wall
ZAA	Tire, Spare Compact
ZBF	Tire, Spare P235/70R15 Black Wall
ZBG	Tire, Spare P235/70R15 White Wall
ZCA	Tire, Spare P205/75R15 White Wall
ZCE	Tire, Spare P205/75R15/N Black Wall
ZEB	Tire, Spare P235/75R15/N White Wall
ZJJ	Tire, Spare 31X10.50R15LT/C Black Wall
ZLN	Tire, Spare 235/70R15-103H Black Wall
ZM5	Sales Package Underbody Shield
ZM6	Chassis Package Off-Road Suspension
ZM8	Sales Package Combination Electric Tailgate Release/Rear Window Defogger
ZQ8	Chassis Package Sport
ZR2	Chassis Package High Wider Performance, 4x4 Sport
ZR5	Appearance Package, Sport Crew
ZW7	Chassis Package Premium Smooth Ride
ZY1	Color Combination Solid
Z49	Export Canadian Modified, Mandatory Base Equipment
Z82	Trailer Provisions Special Equipment, H.D.
Z85	Chassis Package Increased Capacity
Z88	Conversion Name Plate "GMC"
1Q6	Vehicle Inspection Pre-delivery Form

Technical Information

Maintenance and Lubrication

Capacities - Approximate Fluid

Application Specification		ification
909NP209NP209NP209NP209NP209NP209NP20	Metric	English
Axles		
Front Axle	1.2 liters	1.27 quarts
Rear Axle-7.625	1.7 liters	1.8 quarts
Rear Axle-8.6	1.9 liters	2.0 quarts
Engine Cooling System		
 2.2L (VIN 4) Automatic 	9.2 liters	9.7 quarts
 2.2 L (VIN 4) Manual 	9.4 liters	9.9 quarts
 4.3 L (VIN W) Automatic (Pickup) 	13.1 liters	13.8 quarts
 4.3 L (VIN W) Manual (Pickup) 	13.3 liters	14.0 quarts
 4.3 L (VIN W) Automatic (Utility) 	11.1 liters	11.7 quarts
 4.3 L (VIN W) Manual (Utility) 	11.3 liters	11.9 quarts
Engine Crankcase		
• 2.2L (VIN 4)	4.3 liters	4.5 quarts
• 4.3 L (VIN W)	4.3 liters	4.5 quarts
Fuel Tank		
• (2-Door Models)	72.0 liters	19.0 gallons
(Crew Cab Models)	72.0 liters	19.0 gallons
(4-Door Models)	68.0 liters	18.0 gallons
(Regular Extended Cab Models)	70.0 liters	18.5 gallons
Transmission		, 3
 4L60-E After Filter/Pan Removal 	4.7 liters	5.0 quarts
 After Complete Overhaul-4L60-E 	10.6 liters	11 quarts
 New Venture Gear 1500 Manual Transmission 	2.7 liters	2.9 quarts
 New Venture Gear 3500 Manual Transmission 	2.0 liters	2.2 quarts
Power Steering Capacity	0.64 liters-0.99 liters	0.68 quarts-1.05 quarts
Transfer Case		
New Venture Gear 233 (NP1)	1.0 Liters	1.1 Quarts
New Venture Gear 236 (NP8)	1.9 Liters	2.0 Quarts

Maintenance Items

Application	Part Number
Automatic Transmission Filter Kit	GM P/N 24200796
Air Cleaner	A STATE OF THE
• 2.2 L (VIN 4)	AC Type A1163C
• 4.3 L (VIN X)	AC Type A1163C
• 4.3 L (VIN W)	AC Type A1163C
Engine Oil Filter	
2-Wheel Drive	AC Type PF-47 (PF-52 Optional)
4-Wheel Drive	AC Type PF-52
PCV Valve	
• 4.3 L (VIN X)	AC Type CV789C
• 4.3 L (VIN W)	AC Type CV769C
Spark Plugs	
• 2.2 L (VIN 4)	AC Type 41-948
	(GAP 1.27 mm, 0.040 in)
• 4.3 L (VIN X)	AC Type 41-932
4.0.1.0/(0.10.40)	(GAP 1.14 mm, 0.060 in)
• 4.3 L (VIN W)	AC Type 41-932
Thormostat (Planer, Linear)	(GAP 1.52 mm, 0.060 in)
Thermostat (Blazer, Jimmy)	GM P/N 12559051
Fuel Filter	
• 2.2 L (VIN 4)	AC Type GF-481
• 4.3 L (VIN X) AC Type GF-481	
• 4.3 L (VIN W)	AC Type GF-481
Windshield Wiper Blades	Trico 51 cm (20 in)
Backglass Wiper Blade	Trico 36 cm (14 in)

Fluid and Lubricant Recommendations

Usage	Fluid/Lubricant
Engine Oil	Engine Oil with the American Petroleum Institute Certified For Gasoline Engines Starburst symbol of the proper viscosity.
Engine Coolant	A 50/50 mixture of clean, drinkable water and use only GM Goodwrench DEX-COOL® or Havoline® DEX-COOL® (orange-colored, silicate-free) coolant conforming to GM specification 6277M.
Engine Coolant Supplemental Sealer	DO NOT use cooling system seal tabs, or similar compounds, unless otherwise instructed. The use of cooling system seal tabs, or similar compounds, may restrict coolant flow through the passages of the cooling system or the engine components. Restricted coolant flow may cause engine overheating and/or damage to the cooling system or the engine components/assembly.
Hydraulic Brake System	Delco Supreme 11® Brake Fluid (GM P/N 12377967 or equivalent DOT-3 Brake Fluid).
Windshield Washer Solvent	GM Optikleen® Washer Solvent (GM P/N 1051515 or equivalent).
Hydraulic Clutch System	Hydraulic Clutch Fluid (GM P/N 12345347 or equivalent DOT-3 Brake Fluid).
Park Brake Cable Guides	Chassis Lubricant (GM P/N 12377985 or equivalent) or lubricant meeting requirements of NLGI Grade 2, Category LB or GC-LB.

Power Steering System	GM Power Steering Fluid (GM P/N 1052884-1 pint, 1050017-1 quart, or equivalent).
Manual Transmission	 L4 engine: Manual Transmission Fluid with 5% Friction modifier (GM P/N 12377916).
Automatic Transmission	V6 engine: Synchromesh Transmission Fluid (GM P/N 12345349). DEXRON®-III Automatic Transmission Fluid with a G-License Number (G-xxxx). The G-License Number will be found on the back label.
Key Lock Cylinders	Multi-Purpose Lubricant, Superlube® (GM P/N 12346241 or equivalent).
Chassis Lubrication	Chassis Lubricant (GM P/N 12377985 or equivalent) or lubricant meeting requirements of NLGI Grade 2, Category LB or GC-LB.
Front Wheel Bearings-RWD	Wheel Bearing Lubricant meeting requirements of NLGI Grade 2, Category GC or GC-LB (GM P/N 1051344 or equivalent).
Rear Axle (Standard)	Axle Lubricant (GM P/N 1052271) or SAE 80W-90 GL-5 Gear Lubricant.
Rear Axle (Locking Differential)	Axle Lubricant, use only GM Part No. 1052271 (in Canada use Part No. 10950849). Do not add friction modifier.
Transfer Case	DEXRON®-III Automatic Transmission Fluid.
Automatic Transfer Case	Automatic Transfer Case Fluid (GM P/N 12378396 or equivalent).
Column Shift Linkage	Chassis Lubricant (GM P/N 12377985 or equivalent) meeting requirements of NLGI Grade 2, Category LB or GC-LB.
Floor Shift Linkage	Chassis Lubricant (GM P/N 12377985 or equivalent) meeting requirements of NLGI Grade 2, Category LB or GC-LB.
Propeller Shaft Slip Splines and Universal Joints	Chassis Lubricant (GM P/N 12377985 or equivalent) or lubricant meeting requirements of NLGI Grade 2. Category LB or GC-LB
	Chassis Lubricant (GM P/N 12377985 or equivalent) or lubricant meeting requirements of NLGI Grade 2. Category I B or GC-I B
Joint	Chassis Lubricant (GM P/N 12377895 or equivalent) or lubricant meeting requirements of NLGI Grade 2. Category I B or GC-I B
Pawl	Lubriplate® Lubricant Aerosol (GM P/N 12346293 or equivalent) or lubricant meeting requirements of NLGI Grade 2, Category LB or GC-LB.
Hood and Door Hinges	Multi-Purpose Lubricant, Superlube® (GM P/N 12346241 or equivalent).
Carrier (if equipped), Outer Endgate Handle Pivot Points and Hinges	Multi-Purpose Lubricant, Superlube® (GM P/N 12346241 or equivalent).
Weatherstrip conditioning	Dielectric Silicone Grease (GM P/N 12345579 or equivalent).
Weatherstrip squeaks	Synthetic Grease with Teflon, Loctite Superlube® (GM P/N 12371287 or equivalent).

Descriptions and Operations

Power Steering System

The hydraulic power steering pump is a constant displacement vane-type pump that provides hydraulic pressure and flow for the power steering gear. The hydraulic power steering pumps are either belt-driven or direct-drive, cam-driven.

The power steering fluid reservoir holds the power steering fluid and may be integral with the power steering pump or remotely located. The following locations are typical locations for the remote reservoir:

- Mounted to the front of the dash panel
- Mounted to the inner fender
- Mounted to a bracket on the engine

The 2 basic types of power steering gears are listed below:

- A recirculating ball system
- A rack and pinion system

In the recirculating ball system, a worm gear converts steering wheel movement to movement of a sector shaft. A pitman arm attached to the bottom of the sector shaft actually moves one tie rod and an intermediate rod move the other tie rod.

In the rack and pinion system, the rack and the pinion are the 2 components that convert steering wheel rotation to lateral movement. The steering shaft is attached to the pinion in the steering gear. The pinion rotates with the steering wheel. Gear teeth on the pinion mesh with the gear teeth on the rack. The rotating pinion moves the rack from side to side. The lateral action of the rack pushes and pulls the tie rods in order to change the direction of the vehicle's front wheels.

The power steering pressure hose connects the power steering pump union fitting to the power steering gear and allows pressurized power steering fluid to flow from the pump to the gear.

The power steering return hose returns fluid from the power steering gear back to the power steering fluid reservoir. The power steering return line may contain an integral fin-type or line-type power steering fluid cooler.

In a typical power steering system, a pump generates hydraulic pressure, causing fluid to flow, via the pressure hose, to the steering gear valve assembly. The steering gear valve assembly regulates the incoming fluid to the right and left chambers in order to assist in right and left turns.

Turning the steering wheel activates the valve assembly, which applies greater fluid pressure and flow to 1 side of the steering gear piston, and lower pressure and flow to the other side of the piston. The pressure assists the movement of the gear piston. Tie rods transfer this force to the front wheels, which turn the vehicle right or left.

Steering Linkage Description and Operation

The steering linkage consists of the following components:

- A pitman arm
- An idler arm
- A relay rod
- 2 adjustable tie rods

When you turn the steering wheel, the steering gear rotates the pitman arm which forces the relay rod to one side. The tie rods connect to the relay rod with the ball studs. The tie rods transfer the steering force to the wheels. Use the tie rods in toe adjustments. The tie rods are adjustable. The pitman arm support the relay rod. The idler arm pivots on a support attached to the frame rail and the ball stud attaches to the relay rod.

The 2 tie rod are threaded into the tube and secured with jam nuts. Right and left hand threads are used in order to permit the adjustment of toe.

Steering Wheel and Column - Standard Description and Operation

The steering wheel and column has 4 primary functions:

- Vehicle steering
- Vehicle security
- Driver convenience
- Driver safety

Vehicle Steering

The steering wheel is the first link between the driver and the vehicle. The steering wheel is fastened to a steering shaft within the column. At the lower end of the column, the intermediate shaft connects the column to the steering gear.

Vehicle Security

Theft deterrent components are mounted and designed into the steering column. The following components allow the column to be locked in order to minimize theft:

- The ignition switch
- The steering column lock
- The ignition cylinder

Driver Convenience

The steering wheel and column may also have driver controls attached for convenience and comfort. The following controls may be mounted on or near the steering wheel or column.

- The turn signal switch
- The hazard switch
- The headlamp dimmer switch
- The wiper/washer switch
- The horn pad/cruise control switch
- The redundant radio/entertainment system controls
- The tilt or tilt/telescoping functions
- The HVAC controls

Driver Safety

The energy-absorbing steering column compresses in the event of a front-end collision, which reduces the chance of injury to the driver. The mounting capsules break away from the mounting bracket in the event of an accident.

Suspension Description and Operation

Front Suspension

Coil Spring

The front suspension has 2 primary purposes:

- Isolate the driver from irregularities in the road surface.
- Define the ride and handling characteristics of the vehicle.

The front suspension absorbs the impact of the tires travelling over irregular road surfaces and dissipates this energy throughout the suspension system. This process isolates the vehicle occupants from the road surface. The rate at which the suspension dissipates the energy and the amount of energy that is absorbed is how the suspension defines the vehicle's ride characteristics. Ride characteristics are designed into the suspension system and are not adjustable. The ride characteristics are mentioned in this description in order to aid in the understanding of the functions of the suspension system. The suspension system must allow for the vertical movement of the tire and wheel assembly as the vehicle travels over irregular road surfaces while maintaining the tire's horizontal relationship to the road.

This requires that the steering knuckle be suspended between an upper and a lower control arm. The lower control arm attaches from the steering Knuckle at the outermost point of the control arm. The attachment is through a ball and socket type joint. The innermost end of the control arm attached at 2 points to the vehicle frame, through semi-rigid bushings. The upper control arm attaches to the frame in the same fashion. Between the lower control arm and a spring seat on the vehicle's frame, under tension, is a coil spring.

This up and down motion of the steering knuckle as the vehicle travels over bumps is absorbed predominantly by the coil spring. The vertical movement of the steering knuckle as the vehicle travels over irregular road surfaces will tend to compress the spring and spring tension will lead the spring to return to the original, at-rest state. This action isolates the vehicle from the road surface. The upper and lower control arms are allowed to pivot at the vehicle frame in a vertical fashion. The ball joint allows the steering knuckle to maintain the perpendicular relationship to the road surface.

A shock absorber is used in conjunction with this system in order to dampen out the oscillations of the coil spring. A shock absorber is a basic hydraulic cylinder. The shock is filled with oil and has a moveable shaft that connects to a piston inside the shock absorber. Valves inside the shock absorber offer resistance to oil flow and consequently inhibit rapid movement of the piston and shaft. Each end of the shock absorber is connected in such a fashion to utilize this recoil action of a spring alone.

Front suspensions systems utilize a stabilizer shaft. The stabilizer bar connects between the left and right lower control arm assemblies through the stabilizer link and stabilizer shaft insulators. This bar controls the amount of independent movement of the suspension when the vehicle turns. Limiting the independent movement defines the vehicle's handling characteristics on turns.

Torsion Bar

The front suspension has 2 primary purposes:

- Isolate the driver from irregularities in the road surface.
- Define the ride and handling characteristics of the vehicle.

The front suspension absorbs the impact of the tires travelling over irregular road surfaces and dissipates this energy throughout the suspension system. This process isolates the vehicle occupants from the road surface. The rate at which the suspension dissipates the energy and the amount of energy that is absorbed is how the suspension defines the vehicle's ride characteristics. Ride characteristics are designed into the suspension system and are not adjustable. The ride characteristics are mentioned in this description in order to aid in the understanding of the functions of the suspension system. The suspension system must allow for the vertical movement of the tire and wheel assembly as the vehicle travels over irregular road surfaces while maintaining the tire's horizontal relationship to the road.

This requires that the steering knuckle be suspended between an upper and a lower control arm. The lower control arm attaches from the steering knuckle at the outermost point of the control arm. The attachment is through a ball and socket type joint. The innermost end of the control arm is attached at 2 points to the vehicle frame through semi-rigid bushings. The upper control arm attaches to the frame in the same fashion. Attached to the lower control arm is a torsion bar. Torsion bars are steel or steel composite shaft that connects from the lower control arm an adjustable mount at the torsion bar crossmember. The torsion bar functions as a spring in this suspension system. The torsion bar absorbs energy from irregular road surfaces by twisting force along the center axis. The torsion bar has a resistance to this twisting motion and will return to the original, at-rest position similar to that of a spring.

A shock absorber is used in conjunction with this system in order to dampen out the oscillations of the torsion bar. A shock absorber is a basic hydraulic cylinder. The shock is filled with oil and has a moveable shaft that connects to a piston inside the shock absorber. Valves inside the shock absorber offer resistance to oil flow and consequently offer resistance to rapid movement of the piston and shaft. Each end of the shock absorber is connected in such a fashion in order to utilize this recoil action of a torsion bar alone.

Front suspension systems utilize a stabilizer shaft. The stabilizer bar connects between the left and right lower control arm assemblies through the stabilizer link and stabilizer shaft insulators. This bar controls the amount of independent movement of the suspension when the vehicle turns. Limiting the independent movement defines the vehicle's handling characteristics on turns.

Rear Suspension

These vehicles use a leaf spring and a solid rear axle suspension system.

The rear axle assembly is attached to multi-leaf springs with U-bolts. The front ends of the springs are attached to the frame at the front hangers with rubber bushings. The rear ends of the springs are attached to the frame with shackles that use rubber bushings. Shackles allow the springs to change position while the vehicle is in motion.

Two direct double-acting shock absorbers provide ride control. The shock absorbers are angle-mounted between the frame. The shock absorbers are attached with brackets. The brackets are attached to the anchor plate.

The rear spring steel stabilizing shaft helps minimize body roll and sway during cornering. The rear stabilizer shaft is connected to the rear axle and the frame with the following components:

- The rubber insulators
- The clamps
- The link assemblies

Automatic Level Control General Description

The function of the automatic level control system is to maintain a constant trim height at the rear suspension when the vehicle is loaded beyond a predetermined amount. An inflator system is included as part of the overall Automatic Level Control system. The function of the inflator system is to provide pressurized air up to 481 kPa (70 psi) to an inflator fill valve for inflating items other than the vehicles air shocks, such as sports balls, bicycle tires, automobile tires, etc. The system is operational when the ignition is in the RUN position only.

Loading The Vehicle

As a load is added to the vehicle, the vehicle body lowers causing the height sensor arm to rotate upward. If the body lowers enough such that the sensor arm rotates above the in-trim zone, the height sensor closes and activates the internal timing circuit. If the vehicle maintains this condition for more than the minimum delay of 7-14 seconds, the height sensor closes, completing the compressor relay circuit to ground. The compressor then supplies compressed air through the air dryer and air lines, to the air shocks.

As the air shocks inflate, the vehicle body raises, causing the height sensor arm to rotate downward. Once the height sensor arm reaches the in-trim zone, the height sensor opens, opening the compressor relay circuit, and shutting off the compressor.

Unloading The Vehicle

As a load is removed from the vehicle, the vehicle body raises, causing the height sensor arm to rotate downward. If the body raises enough such that the sensor arm rotates below the in-trim zone, the height sensor closes and energizes the internal timing circuit. If the vehicle maintains this condition for more than the minimum delay of 7-14 seconds, the height sensor energizes the exhaust solenoid. With the exhaust solenoid energized, compressed air exhausts from the shocks, through the airlines, air dryer, exhaust solenoid, and air filter, and the vehicle body begins to lower.

As the vehicle body lowers, the height sensor arm begins to rotate upward. If enough load remains in the vehicle, the height sensor arm may reach the in-trim zone. This de-energizes the exhaust solenoid and prevents further air from escaping the system. If very little or no load remains in the vehicle, the height sensor arm may not reach the in-trim zone. In this case, the height sensor de-energizes the exhaust solenoid after the electronic timer expires, approximately 5½ minutes. This timer prevents continuous energizing of the exhaust solenoid, and is reset by turning the ignition switch to OFF or RUN, or whenever the sensor arm remains above the in-trim zone for 7-14 seconds or more.

In case of a system leak, a similar timer prevents continuous operation of the compressor after $5\frac{1}{2}$ minutes. This timer is reset by turning the ignition switch to OFF or RUN, or whenever the ignition switch is in the RUN position and the sensor arm remains below the in-trim zone for 7-14 seconds or more.

Head Relief Function

Prior to every activation of the compressor motor, the height sensor energizes the exhaust solenoid for approximately 1 second to relieve the pressure in the compressor head. This prevents the compressor from trying to start against a high head pressure, drawing a high current, and potentially stalling and blowing the LD LEV fuse. This cycle is controlled by the height sensor and will not occur if the sensor is already in the exhaust mode (sensor arm below the in-trim zone).

Air Replenishment Cycle (ARC)

Approximately 40 seconds after the vehicle ignition switch is turned to RUN, the height sensor will energize the automatic level control air compressor for 3-5 seconds. If this rotates the height sensor arm below the in-trim zone, the height sensor will then energize the automatic level control air compressor until the arm is back in the in-trim zone. This cycle ensures that the minimum system pressure of 55-97 kPa (8-14 psi) is replenished in the air shocks. The air replenishment cycle is controlled by the height sensor and will not occur if the sensor arm position is above the in-trim zone, indicating that additional pressure is needed in the air shocks to raise the vehicle. In this case, the compressor runs after a 7-14 second delay, and will run as long as needed.

Inflator

A provision is made to use the compressor to inflate tires, etc. The inflation equipment consists of the automatic level control inflator relay, inflator air switch and auto level control inflator solenoid valve. When the inflator air switch is turned to ON, grounding the ground circuit. This energizes the inflation timer relay. The inflation timer relay then connects the automatic level control inflator solenoid valve supply voltage circuit to voltage, energizing the inflator solenoid, and grounds the automatic level control relay coil supply voltage circuit, energizing the compressor relay. These actions divert compressed air to the inflator fill valve rather than to the air shocks. The compressor will continue to run for up to 10 minutes or until the inflator OFF switch is depressed, opening the ground circuit and grounding the automatic level control reset signal circuit, resetting the timer. After approximately 10 minutes of run time, the inflation timer relay will automatically shut off the compressor by opening the ground circuit of the inflator switch and the automatic level control relay coil supply voltage circuit. The automatic level control inflator solenoid valve supply voltage circuit is then opened, de-energizing the inflator solenoid and reopening the air path to the air shocks. If the inflation timer relay timer shuts the compressor off in this manner, the system may be restarted by depressing the inflator ON switch.

Wheels and Tires

Fastener Tightening Specifications

Application	Specif	Specification	
		English	
Spare Tire Carrier Mounting Bolts (4WD Utility)	30 N·m	22 lb ft	
Spare Tire Carrier to Body Side Inner Panel Mounting Bolts (2-Door Utility)	30 N·m	22 lb ft	
Spare Tire Carrier to Frame Mounting Nuts (4-Door Utility)	37 N·m	27 lb ft	
Spare Tire Carrier to Rear Crossmenber Mounting Bolts (4-Door Utility)	11 N·m	100 lb in	
Spare Tire Carrier to Rear Crossmember Mounting Nuts (Pickup)	26 N·m	19 lb ft	
Spare Tire to Spare Tire Carrier Mounting Nuts (4WD Utility)	100 N·m	74 lb ft	
Wheel Nut	136 N·m	100 lb ft	

General Description

The factory installed tires are designed to operate satisfactorily with loads up to and including the full rated load capacity when these tires are inflated to the recommended pressures.


The following factors have an important influence on tire life:

- Correct tire pressures
- Correct wheel alignment
- Proper driving techniques
- Tire rotation

The following factors increase tire wear:

- Heavy cornering
- Excessively rapid acceleration
- Heavy braking

Tread Wear Indicators Description



The original equipment tires have tread wear indicators that show when you should replace the tires.

The location of these indicators are at 72 degree intervals around the outer diameter of the tire. The indicators appear as a 6 mm (0.25 in) wide band when the tire tread depth becomes 1.6 mm (2/32 in).

Metric Wheel Nuts and Bolts Description

Metric wheel/nuts and bolts are identified in the following way:

- The wheel/nut has the word Metric stamped on the face.
- The letter M is stamped on the end of the wheel bolt.

The thread sizes of metric wheel/nuts and the bolts are indicated by the following example: M12 x 1.5.

- M = Metric
- 12 = Diameter in millimeters
- 1.5 = Millimeters gap per thread

Tire Inflation Description

When you inflate the tires to the recommended inflation pressures, the factory-installed wheels and tires are designed in order to handle loads to the tire's rated load capacity. Incorrect tire pressures, or underinflated tires, can cause the following conditions:

- Vehicle handling concerns
- Poor fuel economy
- Shortened tire life
- Tire overloading

Inspect the tire pressure when the following conditions apply:

- The vehicle has been sitting at least 3 hours.
- The vehicle has not been driven for more than 1.6 km (1 mi).
- The tires are cool.

Inspect the tires monthly or before any extended trip. Adjust the tire pressure to the specifications on the tire label. Install the valve caps or the extensions on the valves. The caps or the extensions keep out dust and water.

The kilopascal (kPa) is the metric term for pressure. The tire pressure may be printed in both kilopascal (kPa) and psi. One psi equals 6.9 kPa.

Inflation Pressure Conversion (Kilopascals to PSI)

kPa	psi	kPa	psi
140	20	215	31
145	21	220	32
155	22	230	33
160	23	235	34
165	24	240	35
170	25	250	36
180	26	275	40
185	27	310	45
190	28	345	50
200	29	380	55
205	30	415	60
	Conversion: (i.9 kPa = 1 psi	

Tires with a higher than recommended pressure can cause the following conditions:

- A hard ride
- Tire bruising
- Rapid tread wear at the center of the tire


Tires with a lower than recommended pressure can cause the following conditions:

- A tire squeal on turns
- Hard steering
- Rapid wear and uneven wear on the edge of the tread
- Tire rim bruises and tire rim rupture
- Tire cord breakage
- High tire temperatures
- Reduced vehicle handling
- High fuel consumption
- Soft riding

Unequal pressure on the same axle can cause the following conditions:

- Uneven braking
- Steering lead
- Reduced vehicle handling

P-Metric Sized Tires Description



Most P-metric tire sizes do not have exact corresponding alphanumeric tire sizes. Replacement tires should be of the same tire performance criteria (TPC) specification number including the same size, the same load range, and the same construction as those originally installed on the vehicle. Consult a tire dealer if you must replace the P-metric tire with other sizes. Tire companies can best recommend the closest match of alphanumeric to P-metric sizes within their own tire lines.

Driveline System Description and Operation

Driveline/Axle - Propeller Shaft

The propeller shaft is a tube with universal joints at both ends which do not require periodic maintenance, that transmit power from the transfer case or transmission output shaft to the differential.

Front Propeller Shaft Description

The front propeller shaft transmits rotating force from the transfer case to the front differential when the transfer case is engaged. The front propeller shaft connects to the transfer case using a splined slip joint.

One Piece Propeller Shaft Description

A 1 piece propeller shaft uses a splined slip joint to connect the driveline to the transmission or transfer case.

Two Piece Propeller Shaft Description

There are 3 universal joints used on the two piece propeller shaft, A center bearing assembly is used to support the propeller shaft connection point, and help isolate the vehicle from vibration.

Propeller Shaft Phasing Description

The propeller shaft is designed and built with the yoke lugs (ears) in line with each other. This produces the smoothest running shaft possible. A propeller shaft designed with built in yoke lugs in line is known as in - phase. An out of phase propeller shaft often causes vibration. The propeller shaft generates vibration from speeding up and slowing down each time the universal joint goes around. The vibration is the same as a person snapping a rope and watching the wave reaction flow to the end. An in phase propeller shaft is similar to 2 persons snapping a rope at the same time and watching the waves meet and cancel each other out. A total cancellation of vibration produces a smooth flow of power in the drive line. All splined shaft slip yokes are keyed in order to ensure proper phasing.

Universal Joint Description

The universal joint is connected to the propeller shaft. The universal consist of 4 caps with needle bearings and grease seals mounted on the trunnions of a cross or spider. These bearings and caps are greased at the factory and no periodic maintenance is required. There are 2 universal joints used in a one piece propeller shaft and 3 used in two piece propeller shaft. The bearings and caps are pressed into the yokes and held in place with snap rings, except for 2 bearings on some models witch are strapped onto the pinion flange of the differential. Universal joints are designed to handle the effects of various loads and rear axle windup conditions during acceleration and braking. The universal joint operates efficiently and safely within the designed angle variations, when the design angles are exceeded, the operational life of the joint decreases.

Center Bearing Description

Center bearings support the driveline when using 2 or more propeller shafts. The center bearing is a ball bearing mounted in a rubber cushion that attaches to a frame crossmember. The manufacturer prelubricates and seals the bearing. The cushion allows vertical motion at the driveline and helps isolate the vehicle from vibration.

Wheel Drive Shafts Description and Operation

Front Wheel Drive Shafts are flexible assemblies which consist of the following components:

- · Front wheel drive shaft constant velocity joint outer joint.
- Front wheel drive shaft tri-pot joint inner joint.
- The front wheel drive shaft connects the front wheel drive shaft tri-pot joint and the front wheel drive shaft constant velocity joint.
- Wheel Drive Shaft Seal Cover 15 Series.

- The front wheel drive shaft tri-pot joint is completely flexible, and moves with an in and out motion.
- The front wheel drive shaft constant velocity joint is flexible but can not move in and out.

The Wheel Drive Shaft is a balanced shaft that transmits rotational force from the front differential to the front wheels when the transfer case is engaged. The wheel drive shaft is mounted to the front differential by bolting the flange of the wheel drive shaft to the flange on the inner output shaft of the front differential. The other end of the wheel drive shaft is splined to fit into and drive the hub assembly when the transfer case is engaged. The tri-pot joint and constant velocity joint on the wheel drive shaft allows the shaft to be flexible to move with the suspension travel of the vehicle.

Front Drive Axle Description and Operation

The Front Drive Axle consist of the following components:

- Differential Carrier Housing
- Differential Assembly
- Left and Right Output Shafts
- Inner Axle Shaft Housing
- Inner Axle Shaft

The front axle on the four-wheel-drive model vehicle does not have a central disconnect feature. The axle uses a conventional ring and pinion gear set in order to transmit the driving force of the engine to the wheels. The open differential allows the wheels to turn at different rates of speed while the axle continues to transmit the driving force. This prevents tire scuffing when going around corners and premature wear on internal axle parts. The ring and pinion set and the differential are contained within the carrier. The axle identification number on top of the differential carrier assembly or on a label on the right half of differential carrier assembly. The drive axles are completely flexible assemblies consisting of inner and outer constant velocity CV joints protected by thermoplastic boots and connected by a wheel drive shaft.

Rear Drive Axle Description and Operation

Rear Axles for this vehicle consist of the following components:

- Differential axle housing
- Differential carrier
- Right and left axle tubes
- Right and left axle shafts

A open differential has a set of 4 gears. Two are side gears and 2 are pinion gears. Some differentials have more than 2 pinion gears. Each side gear is splined to an axle shaft so each axle shaft; so that each axle shaft turns when its side gear rotates. The pinion gears are mounted on a differential pinion shaft, and the gears are free to rotate on this shaft. The pinion shaft is fitted into a bore in the differential case and is at right angles to the axle shafts. Power is transmitted through the differential as follows: the drive pinion rotates the ring gear. The ring gear being bolted to the differential case, rotates the case, The differential pinion, as it rotates the case, forces the pinion gears against the side gears. When both wheels have equal traction, the pinion gears do not rotate on the pinion shaft because of input force on the pinion gear is equally divided between the 2 side gears. Therefore, the pinion gears revolve with the pinion shaft, but do not rotate around the shaft itself. The side gears, being splined to the axle shafts and in mesh with the pinion gears rotate the axle shafts. If a vehicle were always driven in a straight line, the ring and pinion gears would be sufficient. The axle shaft could be solidly attached to the ring gear and both driving wheels would turn at equal speed. However, if it became necessary to turn a corner, the tires would scuff and slide because the differential allows the axle shafts to rotate at different speeds. When the vehicle turns a corner, the inner wheel turns slower than the out wheel and slows its rear axle side gear (as the shaft is splined to the side gear). The rear axle pinion gears will roll around the slowed rear axle side gear, driving the rear axle side gear wheel faster.

Locking Differential Description and Operation

The locking differential consists of the following components:

- Differential Carrier
- Locking Differential Spider
- 2 Clutch Disc Sets
- Locking Differential Side Gear
- Locking Differential Clutch Disc Guide
- Differential Side Gear Shim
- Locking Differential Governor
- Latching Bracket
- Cam Plate

The locking differential allows for normal differential function as indicated in the standard rear axle description. Additionally, the locking differential uses multi-disc clutch packs and a speed sensitive engagement mechanism that locks both wheels together if one wheel spins excessively during slow vehicle operation. Under light loads, the clutch plates alone tend to lock the axle shafts to the differential case, and therefore locking to each other. This is due primarily to the gear separating the load developed on the right clutch pack. This induced clutch torque capacity resists motion between the side gear and the axle differential case. The differential allows the wheels to turn at different speeds while the axle shafts continue to transmit the driving force. Heavier throttle application will cause an axle speed difference. This action starts the full-lock feature of the unit. You can accomplish full-lock through the use of a heavyweight governor mechanism, a cam system and a multi-disc pack. The flyweights on the governor mechanism move outward in order to engage a latching bracket whenever the wheel-to-wheel speed varies by approximately 100 RPM or more. This action retards a cam, which, in turn, compresses the multi-disc clutch packs, locking both of the side gears to the case. The 100 RPM wheel-to-wheel speed allows for cornering with the differential lockup. At vehicle speeds above approximately 32 km/h (20 mph), the latching bracket overcomes a spring preload and swings away from the flyweights. At this vehicle speed or greater, the differential is designed not to lock since added traction is generally not needed. The axle parts of the vehicles equipped with the locking differential are interchangeable with those equipped with the conventional differential, except for the case assembly.

Transfer Case Description – NVG233 (NP1)

The NVG 233 transfer case features a 3 button shift control switch, located on the instrument panel. When the ignition is in the RUN position, the transfer case shift control module starts monitoring the transfer case shift control switch, to determine if a new mode/gear position has been selected. At a single press of the transfer case shift control switch, the lamp of the new position begins flashing to inform the driver that the transfer case shift control module has received the request for a new mode/gear position. The lamp continues to flash until all shifting criteria has been met and the new mode/gear position has been reached, or has engaged. Once the new mode/gear position is fully active, the switch indicator lamp for the new position remains ON constantly.

The NVG 233 transfer case provides the driver with 3 manual mode/gear positions:

- 2HI 2 Wheel Drive high range
- 4HI 4 Wheel Drive high range
- 4LO 4 Wheel Drive low range

Any of these mode/gear positions may be selected while driving the vehicle. However, the transfer case will not allow a shift into, or out of, 4LO unless the following criteria has been met:

- The engine is running.
- The automatic transmission is in Neutral, or the clutch pedal is applied on manual transmissions.
- The vehicle speed is below 5 km/h (3 mph).

Below, is a list of major components that make up the automatic transfer case system:

Front Axle Indicator Switch

The front axle indicator switch is mounted to the front axle assembly. When 4WD is selected and all conditions have been met to complete the shift, the transfer case encoder motor shifts the transfer case. The front axle then engages via a cable, and the front axle switch closes. This sends ignition voltage from the 4WD fuse, through the switch, to the PCM. This input informs the PCM that the front axle has been engaged.

Transfer Case Encoder

The encoder is mounted to the transfer case encoder motor assembly and is replaced only as an assembly. The encoder converts the sector shaft position into electrical signal inputs to the transfer case shift control module. The module detects the position that the transfer case is in, by monitoring the 4 encoder channels, P, A, B, and C. These inputs translate into 2HI, 4HI, and 4LO, or whether the motor is still in transition between gears.

Transfer Case Encoder Motor

The transfer case encoder motor consists of a permanent magnet (PM) DC motor and gear reduction assembly. It is located on the left hand side of the transfer case. When activated, it turns the sector shaft of the transfer case clockwise or counter clockwise to shift the transfer case. The sector shaft also applies the clutch, which engages the front propshaft. The encoder motor is controlled with a pulse width modulated (PWM) circuit, provided by the transfer case shift control module. This circuit consists of a driver on both the Motor Control A and Motor Control B circuits. The encoder motor is bi-directional, to allow the motor to shift the transfer case from 2HI or 4HI, to 4LO positions.

Transfer Case Shift Control Module

The transfer case shift control module receives input signals, processes the signal information, develops output signals, and sends the output signal, in order to control the shifting of the transfer case.

The transfer case shift control module receives input signals from the transfer case control switch buttons, the park/neutral position (PNP) switch for vehicles with automatic transmissions, the clutch position switch for vehicles with manual transmissions, the powertrain control module (PCM) that supplies the vehicle speed signals, the encoder motor that provides actual mode and range information signals, the data link connector pin D3 that actuates diagnostic enable, power for the module and motor supplies, and the ground used for return lines at the module.

The transfer case shift control module sends signals to the transfer case encoder motor to initiate mode and range shifts, the transfer case control switch indicator lamps to provide transfer case status information, the diagnostic DTCs which are outputted via the shift control switch indicator lamps, and the encoder power.

In order to ensure the electronic shift system is operating properly, the transfer case shift control module continually performs diagnostics tests on itself, and other parts of the electronic shift system, when the ignition switch is in the RUN position.

Transfer Case Description – NVG236/246 (NP8)

The NVG 236/246 transfer case features a 4 button shift control switch located on the instrument panel. When the vehicle has the ignition key in the RUN position, the transfer case shift control module starts monitoring the transfer case shift control switch to determine if the driver desires a new mode/gear position. At a single press of the transfer case shift control switch, the lamp of the new desired position will begin flashing to inform the driver that the transfer case shift control module has received the request for a new mode/gear position. The lamp will continue to flash until all shifting criteria has been met and the new mode/gear position has been reached, or has been engaged. Once the new mode/gear position is fully active, the switch indicator lamp for the new position will remain ON constantly.

During normal driving situations the transfer case can operate in the Auto 4WD mode. In the Auto 4WD mode the transfer case shift control module monitors rear wheel slip speed, based on the inputs from both the front and rear propshaft speed sensors. When the vehicle experiences a rear wheel slip condition, the transfer case shift control module sends a pulse width modulated (PWM) signal to an electronic motor, which is the transfer case encoder motor. This motor rotates the transfer case sector shaft, applying a clutch pack. This clutch pack is designed to deliver a variable amount of torque, normally delivered to the rear wheels, and transfers it to the front wheels. Torque is then ramped up to the front wheels until the front propshaft speed sensor matches that of the rear propshaft speed sensor. Torque is then ramped down until torque is completely removed from the front wheels or until rear wheel slip is once again detected. The process would then repeat.

The NVG 236/246 transfer case has the added feature of also providing the driver with 3 manual mode/gear positions:

- 4HI 4 Wheel Drive high range
- 2HI 2 Wheel Drive high range
- 4LO 4 Wheel Drive low range

The driver may choose to select any of these mode/gear positions while driving the vehicle. However, the transfer case will not allow a shift into or out of 4LO unless the following criteria has been met:

- The engine is running.
- The automatic transmission is in Neutral, clutch depressed on manual transmissions.
- The vehicle speed is below 5 km/h (3 mph).

This transfer case also has a Neutral position. A shift to the Neutral position allows the vehicle to be towed without the rear axle rotating the transfer case main shaft and the transmission output shaft. Neutral position may be obtained only if the following criteria has been met:

- The key is ON.
- The automatic transmission is in Neutral, clutch depressed on manual transmissions.
- The vehicle speed is below 5 km/h (3 mph).
- The transfer case is in 2HI mode.

Once these conditions have been met, press and hold both the 2HI and 4LO buttons for 10 seconds. When the system completes the shift to neutral, the red neutral lamp will illuminate.

View the list of major components that make up the automatic transfer case (ATC) system below.

Transfer Case Shift Control Module

The transfer case shift control module uses the VIN information for calculations that are required for the different calibrations used based on axle ratio, transmission, tire size, and engine. The system does not know which calibration to use without this information. This information is provided to the transfer case shift control module via Class 2 data bus from the powertrain control module (PCM).

The transfer case shift control module monitors front and rear propshaft speed as well as controlling the operation of the transfer case encoder motor assembly and the engaging and disengaging of the front axle.

Transfer Case Encoder Motor

The transfer case encoder motor consists of a permanent magnet (PM) DC motor and gear reduction assembly. It is located on the left hand side of the transfer case. When activated it turns the sector shaft of the transfer case, clockwise or counterclockwise to shift the transfer case and to apply the clutch that applies the front propshaft. The encoder motor is controlled with a pulse width modulated (PWM) circuit provided by the transfer case shift control module. This circuit consists of a driver on both the Motor Control A and Motor Control B circuits. The encoder motor is bi-directional to allow the motor to shift the transfer case from 2HI or 4HI to NEUTRAL and 4LO positions.

The transfer case encoder motor can be turned ON and OFF using a scan tool. You may also monitor Motor Control A and B circuits using a scan tool.

Transfer Case Encoder

The encoder is mounted to the transfer case encoder motor assembly and is replaced only as an assembly. The encoder converts the sector shaft position, representing a mode or range, into electrical signal inputs to the transfer case shift control module. The module detects what position the transfer case is in by monitoring the 4 encoder channels (P, A, B, and C). These inputs translate into AUTO 4WD, 2HI, 4HI, NEUTRAL, and 4LO or whether the motor is still in transition between gears.

The transfer case encoder channel circuits may be monitored using a scan tool.

Transfer Case Motor Lock

The transfer case motor lock is used to prevent the transfer case from changing mode/gear positions or popping out of position when the vehicle is in 2HI, 4HI, and 4LO. When the lock circuit is energized, the transfer case encoder motor is allowed to rotate. When the transfer case is placed 2HI, 4HI, or 4LO the motor lock circuit has no voltage provided to it, applying the lock which assures that the transfer case remains in the current mode/gear position. When AUTO 4WD is selected the motor lock remains applied until an adaptive mode, torque being applied to the front propshaft is required. During an adaptive mode the motor lock circuit is energized, the locking mechanism is released, enabling the encoder motor to turn and apply torque to the front propshaft.

The transfer case motor lock circuit can be turned ON and OFF using a scan tool. You may also monitor the lock circuit using a scan tool.

Transfer Case Speed Sensors

There are three speed sensors mounted on the transfer case, two on the rear output shaft and one on the front output shaft. Each speed sensor is a permanent magnet (PM) generator. The PM generator produces a AC voltage. The AC voltage level and number of pulses increases as speed increases.

Vehicle Speed Sensor

One of the two speed sensors on the rear output shaft is the vehicle speed sensor (VSS) input to the powertrain control module (PCM). The PCM sends this information to the transfer case shift control module via the Class 2 serial data bus.

Rear Propshaft Speed Sensor

The transfer case shift control module converts the pulsating AC voltage from the rear transfer case speed sensor to a rear propshaft speed in RPM to be used for calculations. The rear propshaft speed can be displayed with a scan tool.

Front Propshaft Speed Sensor

The transfer case shift control module converts the pulsating AC voltage from the front transfer case speed sensor to front propshaft speed in RPM to be used for calculations, and to monitor the difference between the front and rear sensor speed. It is also used in the AUTO 4WD mode to determine the amount of slip and the percent of torque to apply to the front axle. The front propshaft speed can be displayed with a scan tool.

SERVICE 4WD Indicator

The SERVICE 4WD message is displayed on the driver information center and is an integral part of the cluster and cannot be serviced separately. This message is used to inform the driver of the vehicle of malfunctions within the automatic transfer case (ATC) system. The SERVICE 4WD message is controlled by the transfer case shift control module via a Class 2 message.

Braking System Description and Operation

Hydraulic Brake System Description and Operation

System Component Description

The hydraulic brake system consists of the following:

Hydraulic Brake Master Cylinder Fluid Reservoir

Contains supply of brake fluid for the hydraulic brake system.

Hydraulic Brake Master Cylinder

Converts mechanical input force into hydraulic output pressure.

Hydraulic output pressure is distributed from the master cylinder through two hydraulic circuits, supplying diagonally-opposed wheel apply circuits.

Hydraulic Brake Pressure Balance Control System

Regulates brake fluid pressure delivered to hydraulic brake wheel circuits, in order to control the distribution of braking force.

Pressure balance control is achieved through dynamic rear proportioning (DRP), which is a function of the ABS modulator.

Hydraulic Brake Pipes and Flexible Brake Hoses

Carries brake fluid to and from hydraulic brake system components.

Hydraulic Brake Wheel Apply Components

Converts hydraulic input pressure into mechanical output force.

System Operation

Mechanical force is converted into hydraulic pressure by the master cylinder, regulated to meet braking system demands by the pressure balance control system, and delivered to the hydraulic brake wheel circuits by the pipes and flexible hoses. The wheel apply components then convert the hydraulic pressure back into mechanical force which presses linings against rotating brake system components.

Brake Assist System Description and Operation

System Component Description

The brake assist system consists of the following:

Brake Pedal

Receives, multiplies and transfers brake system input force from driver.

Brake Pedal Pushrod

Transfers multiplied input force received from brake pedal to brake booster.

Vacuum Brake Booster

Uses source vacuum to decrease effort required by driver when applying brake system input force.

When brake system input force is applied, air at atmospheric pressure is admitted to the rear of both vacuum diaphragms, providing a decrease in brake pedal effort required. When input force is removed, vacuum replaces atmospheric pressure within the booster.

Vacuum Source

Supplies force used by vacuum brake booster to decrease brake pedal effort.

Vacuum Source Delivery System

Enables delivery and retention of source vacuum for vacuum brake booster.

System Operation

Brake system input force is multiplied by the brake pedal and transferred by the pedal pushrod to the hydraulic brake master cylinder. Effort required to apply the brake system is reduced by the vacuum brake booster.

Disc Brake System Description and Operation

System Component Description

The disc brake system consists of the following components:

Disc Brake Pads

Applies mechanical output force from the hydraulic brake calipers to friction surfaces of brake rotors.

Disc Brake Rotors

Uses mechanical output force applied to friction surfaces from the disc brake pads to slow speed of tire and wheel assembly rotation.

Disc Brake Pad Hardware

Secures disc brake pads firmly in proper relationship to the hydraulic brake calipers. Enables a sliding motion of brake pads when mechanical output force is applied.

Disc Brake Caliper Hardware

Provides mounting for hydraulic brake caliper and secures the caliper firmly in proper relationship to caliper bracket. Enables a sliding motion of the brake caliper to the brake pads when mechanical output force is applied.

System Operation

Mechanical output force is applied from the hydraulic brake caliper pistons to the inner brake pads. As the pistons press the inner brake pads outward, the caliper housings draw the outer brake pads inward. This allows the output force to be equally distributed. The brake pads apply the output force to the friction surfaces on both sides of the brake rotors, which slows the rotation of the tire and wheel assemblies. The correct function of both the brake pad and brake caliper hardware is essential for even distribution of braking force.

Drum Brake System Description and Operation

System Component Description

The drum brake system consists of the following:

Drum Brake Shoes

Applies mechanical output force (from hydraulic brake wheel cylinders) to friction surface of brake drums.

Brake Drums

Uses mechanical output force applied to friction surface from drum brake shoes to slow speed of tire and wheel assembly rotation.

Drum Brake Hardware

Secures drum brake shoes firmly in proper relationship to hydraulic brake wheel cylinders. Enables sliding motion of brake shoes needed to expand toward friction surface of drums when mechanical output force is applied; provides return of brake shoes when mechanical output force is relieved.

Drum Brake Adjusting Hardware

Provides automatic adjustment of brake shoes to brake drum friction surface whenever brake apply occurs during rearward motion of the vehicle.

System Operation

Mechanical output force is applied from the hydraulic brake wheel cylinder pistons to the top of the drum brake shoes. The output force is then distributed between the primary and secondary brake shoes as the shoes expand toward the friction surface of the brake drums. The brake shoes apply the output force to the friction surface of the brake drums, which slows the rotation of the tire and wheel assemblies. The proper function of both the drum brake hardware and adjusting hardware is essential to the proper distribution of braking force.

Park Brake System Description and Operation

System Component Description

The park brake system consists of the following:

Park Brake Lever Assembly

Receives, multiplies, and transfers park brake system apply input force from operator to park brake cable system.

Releases applied park brake system when lever is returned to at-rest, lowered, position.

Park Brake Cables

Transfers input force received from park brake lever, through park brake cable equalizer, to park brake apply levers.

Park Brake Cable Equalizer

Evenly distributes input force to both the left and right park brake units.

Park Brake Apply Lever

Multiplies and transfers input force to park brake actuator/adjuster.

Park Brake Actuator/Adjuster

Uses multiplied input force from apply lever to expand park brake shoe (rear disc, drum-in-hat system), or drum brake shoes toward the friction surface of the drum-in-hat of the rear brake rotor, or the brake drum.

Threaded park brake actuators/adjusters are also used to control clearance between the park brake shoe (rear disc, drum-in-hat system), or the drum brake shoes and the friction surface of the drum-in-hat (of the rear brake rotor), or the brake drum.

Park Brake Shoe (Rear Disc, Drum-In-Hat System)

Applies mechanical output force from park brake actuator to friction surface of the drum-in-hat (of the rear brake rotor).

System Operation

Park brake apply input force is received by the park brake pedal assembly being depressed, transferred and evenly distributed, through the park brake cables and the park brake cable equalizer, to the left and right park brake apply levers. The park brake apply levers multiply and transfer the apply input force to the park brake actuators/adjusters which expand the park brake shoe (rear disc, drum-in-hat system), or the drum brake shoes toward the friction surface of the drum-in-hat (of the rear brake rotor), or the brake drum in order to prevent the rotation of the rear tire and wheel assemblies. The park brake release handle assembly releases an applied park brake system when it is pulled rearward.

ABS Description and Operation

Antilock Brake System

When wheel slip is detected during a brake application, the ABS enters antilock mode. During antilock braking, hydraulic pressure in the individual wheel circuits is controlled to prevent any wheel from slipping. A separate hydraulic line and specific solenoid valves are provided for each wheel. The ABS can decrease, hold, or increase hydraulic pressure to each wheel brake. The ABS cannot, however, increase hydraulic pressure above the amount which is transmitted by the master cylinder during braking.

During antilock braking, a series of rapid pulsations is felt in the brake pedal. These pulsations are caused by the rapid changes in position of the individual solenoid valves as the EBCM responds to wheel speed sensor inputs and attempts to prevent wheel slip. These pedal pulsations are present only during antilock braking and stop when normal braking is resumed or when the vehicle comes to a stop. A ticking or popping noise may also be heard as the solenoid valves cycle rapidly. During antilock braking on dry pavement, intermittent chirping noises may be heard as the tires approach slipping. These noises and pedal pulsations are considered normal during antilock operation.

Vehicles equipped with ABS may be stopped by applying normal force to the brake pedal. Brake pedal operation during normal braking is no different than that of previous non-ABS systems. Maintaining a constant force on the brake pedal provides the shortest stopping distance while maintaining vehicle stability.

Engine Description and Operation

Engine Mechanical 2.2L

Mechanical Specifications

Application Specifications		
TO THE RESIDENCE OF THE PROPERTY OF THE PROPER	Metric	English
General Data		
Engine Type	L.	-4
Displacement	2.2 L	134 CID
RPO (Engine VIN Code)	L43/	LN2
Bore	89 mm	3.5 in
Stroke	88 mm	3.46 in
Compression Ratio	8.8	
Firing Order	1-3-	-4-2
Oil Pressure @ 65°C (150°F)	348 kpa	56 psi @ 3000 RPM
Cylinder Bore		
Diameter	88.991-89.009 mm	3.5036-3.5043 in
Out Of Round Maximum	0.013 mm	0.0005 in
Taper Thrust Side Maximum	0.013 mm	0.0005 in
Lubrication System		
Oil Capacity Without Filter Change	3.473 L	3.5 qts
 When Changing the Oil Filter, Up to an Additional 0.473 Liter or One Half Quart of Oil May Be Needed Filter Type or Equivalent 	. PF	-47
 Oil Pressure (3000 RPM @ 65°C (150°F) 	348 kPa	56 psi min.
Piston	1	Γ.
Clearance (42.7 mm from top of piston)	Herzelber erzelbar erselber erselbar erselbar erselber erselber erselber erselber erselber erselber erselber	
Factory Specification	0.015-0.047 mm	0.00059-0.00185 in
Service Specification	0.055-0.087 mm	0.0022-0.0034 in
Piston Ring Compression		
Top Groove Side Clearance	0.05-0.09 mm	0.0020-0.0035 in
Second Groove Side Clearance	0.04-0.08 mm	0.0016-0.0031 in
Top Ring Gap	0.25-0.50 mm	0.010-0.020 in
Second Ring Gap	0.30-0.45 mm	0.0012-0.0177 in
Piston Ring Oil		
Groove Clearance	0.013-0.220 mm	0.0005-0.0087 in
Gap	0.25-0.76 mm	0.010-0.030 in
Piston Pin		
Diameter	20.3200-20.3251 mm	0.8000-0.8002 in
Clearance In Piston	0.0079-0.018 mm	0.00031-0.00071 in
Interference Fit In Rod	0.021-0.0511 mm	0.0008-0.0020 in
Oil Pump		
Outer Gerotor Thickness	17.087-17.099 mm	0.6727-0.6731 in
Oil Pump Drive to Driven Gear Backlash	0.23-0.51 mm	0.0091-0.0201 in
Valve to Bore Clearance	0.038-0.089 mm	0.0015-0.0035 in
Gear Lash	0.094-0.195 mm	0.004-0.008 in
Gear Pocket Depth	30.36-30.44 mm	1.195-1.198 in

● Gear Length (Drive Gear) 38.18-38.25 mm 1.503-1.506 in ● Gear Length (Drive Gear) 30.45-30.48 mm 1.199-1.20 in ● Gear Length (Idler) 30.45-30.48 mm 1.199-1.20 in ● Gear Diameter (Drive Gear) 38.05-38.10 mm 1.498-1.50 in ● Gear Side Clearance (Drive Gear) 0.038-0.102 mm 0.001-0.004 in ● Gear Side Clearance (Idler) 0.038-0.102 mm 0.001-0.004 in ● End Clearance 0.05-0.18 mm 0.001-0.004 in ● End Clearance 0.05-0.18 mm 0.001-0.004 in ● Main Journal Diameter 63.360-63.384 mm 2.4945-2.4954 in ● Main Journal Taper 0.005 mm 0.00019 in ● Main Journal Taper 0.005 mm 0.00019 in ● Main Journal Out Of Round 0.005 mm 0.00019 in ● Rod Bearing Journal Diameter 50.758-50.784 mm 0.002-0.007 in ● Rod Bearing Journal Out Of Round 0.005 mm 0.002-0.007 in ● Rod Bearing Journal Out Of Round 0.005 mm 0.00019 in ● Rod Bearing Journal Out Of Round 0.005 mm 0.0009-0019 in ● Rod Bearing Journal Out Of Round				
● Gear Length (Drive Gear)	•		38.18-38.25 mm	1.503-1.506 in
● Gear Length (teller)	•		30.45-30.48 mm	
● Gear Diameter (Drive Gear)	•		30.45-30.48 mm	
■ Gear Diameter (Idler) 38.05–38.10 mm 1.498-1.5 in ■ Gear Side Clearance (Drive Gear) 0.038-0.102 mm 0.001-0.004 in ■ End Clearance 0.035-0.102 mm 0.001-0.004 in ■ End Clearance 0.05-0.18 mm 0.002-0.007 in Crankshaft 0.05-0.18 mm 0.002-0.007 in ■ Main Journal Diameter 63.360-63.384 mm 2.4945-2.4954 in ■ Main Journal Diameter 0.005 mm 0.00019 in ■ Main Journal Out Of Round 0.005 mm 0.00019 in ■ Main Bearing Clearance 0.015-0.047 mm 0.0006-0.0019 in ■ Crankshaft End Play 0.051-0.047 mm 0.0006-0.0019 in ■ Rod Bearing Journal Diameter 50.758-50.784 mm 1.9983-1.9994 in ■ Rod Bearing Journal Taper 0.005 mm 0.00019 in ■ Rod Bearing Journal Out Of Round 0.005 mm 0.00019 in ■ Rod Bearing Journal Clearance 0.025-0.079 mm 0.00098-0.031 in ■ Rod Side Clearance 0.025-0.079 mm 0.00098-0.031 in ■ Lobe Lift (Inlet and Exhaust) 6.687 mm 0.2633 in ■ Journal Diameter 47.453-47.478 mm	•	Gear Diameter (Drive Gear)	38.05-38.10 mm	
● Gear Side Clearance (Irlve Gear)	•	Gear Diameter (Idler)	38.05-38.10 mm	
● End Clearance (Idler) 0.038-0.102 mm 0.001-0.004 in ● End Clearance 0.05-0.18 mm 0.002-0.007 in Crankshaft • Main Journal Diameter 63.360-63.384 mm 2.4945-2.4954 in • Main Journal Diameter 0.005 mm 0.00019 in • Main Journal Out Of Round 0.005 mm 0.00019 in • Main Bearing Clearance 0.015-0.047 mm 0.0006-0.019 in • Crankshaft End Play 0.0511-0.1780 mm 0.002-0.007 in • Rod Bearing Journal Diameter 50.755-50.784 mm 1.9983-1.9994 in • Rod Bearing Journal Out Of Round 0.005 mm 0.00019 in • Rod Bearing Journal Out Of Round 0.005 mm 0.00019 in • Rod Side Clearance 0.025-0.079 mm 0.00098-0.0031 in • Rod Side Clearance 0.10-0.38 mm 0.0039-0.0149 in • Lobe Lift (Inlet and Exhaust) 6.687 mm 0.2633 in • Journal Diameter 47.453-47.478 mm 1.868-1.869 in • Journal Clearance 0.038-0.088 mm 0.0015-0.0035 in Valve System • Rocker Arm Ratio 40.64 mm 1.6 • Valve Margin (Exha	•		0.038-0.102 mm	
End Clearance 0.05-0.18 mm 0.002-0.007 in Crankshaft • Main Journal Diameter 63.360-63.384 mm 2.4945-2.4954 in • Main Journal Taper 0.005 mm 0.00019 in • Main Journal Out Of Round 0.005 mm 0.00019 in • Main Bearing Clearance 0.015-0.047 mm 0.0002-0.007 in • Rod Bearing Journal Diameter 50.758-50.784 mm 0.002-0.007 in • Rod Bearing Journal Taper 0.005 mm 0.00019 in • Rod Bearing Journal Clearance 0.025-0.079 mm 0.00019 in • Rod Bearing Journal Clearance 0.025-0.079 mm 0.00098-0.0031 in • Rod Side Clearance 0.10-0.38 mm 0.0039-0.0149 in Camshaft • Lobe Lift (Inlet and Exhaust) 6.687 mm 0.2633 in • Journal Diameter 47.453-47.478 mm 1.868-1.869 in • Journal Diameter 47.453-47.478 mm 1.868-1.869 in • Valve System • Rocker Arm Ratio 40.64 mm 1.6 • Valve Face Angle	•	Gear Side Clearance (Idler)	0.038-0.102 mm	
Crankshaft ■ Main Journal Diameter	•	End Clearance		
Main Journal Taper Main Journal Out Of Round Main Bearing Clearance Crankshaft End Play Rod Bearing Journal Diameter Rod Bearing Journal Diameter Rod Bearing Journal Diameter Rod Bearing Journal Diameter Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Clearance Rod Bearing Journal Clearance Rod Side Clearance (Inlet) Valve Hade Diameter (Exhaust) Valve Nation Side Side Clearance (Inlet) Valve Side Inlead Side Clearance (Inlet) Valve Side Inlearce Clearance (Inlet) Valve Sid	Crank	Shaft		
● Main Journal Taper 0.005 mm 0.00019 in ● Main Journal Out Of Round 0.005 mm 0.00019 in ● Main Bearing Clearance 0.015-0.047 mm 0.0006-0.0019 in ● Crankshaft End Play 0.0511-0.1780 mm 0.002-0.007 in ● Rod Bearing Journal Diameter 50.758-50.784 mm 1.9983-1.9994 in ● Rod Bearing Journal Taper 0.005 mm 0.00019 in ● Rod Bearing Journal Clearance 0.025-0.079 mm 0.00098-0.0031 in ● Rod Side Clearance 0.10-0.38 mm 0.0039-0.0149 in Camshaft - Lobe Lift (Inlet and Exhaust) 6.687 mm 0.2633 in ● Journal Diameter 47.453-47.478 mm 1.868-1.869 in ● Journal Diameter 47.453-47.478 mm 1.868-1.869 in ● Journal Clearance 0.038-0.088 mm 0.0015-0.0035 in Valve Face Arm Ratio 40.64 mm 1.6 ● Valve Face Runout 0.038 mm 0.0014 in ● Valve Margin (Exhaust) 2.21-1.79 mm 0.087-0.080 in ● Valve Margin (Inlet) 1.96-1.16 mm 0.061-0.04 in ● Valve Margin (Inlet) 1.96-1.16 mm </td <td>•</td> <td>Main Journal Diameter</td> <td>63.360-63.384 mm</td> <td>2 4945-2 4954 in</td>	•	Main Journal Diameter	63.360-63.384 mm	2 4945-2 4954 in
Main Journal Out Of Round Main Bearing Clearance Crankshaft End Play Rod Bearing Journal Diameter Rod Bearing Journal Diameter Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Clearance Rod Bearing Journal Clearance Rod Side Clearance (Inlet) Valve Face Runout Valve Margin (Inlet) Valve Margin (Inlet) Valve Margin (Inlet) Valve Margin (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Inlet) Valve Overall Length (Inlet) Valve Stem to Guide Clearance (Inlet) Valve Stem to Rouide Clearance (Inlet) Valve Stem to Rouide	•	Main Journal Taper		
Main Bearing Clearance Crankshaft End Play Rod Bearing Journal Diameter Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Clearance Rod Bearing Journal Clearance Rod Bearing Journal Clearance Rod Bearing Journal Clearance Rod Side Cle	•			
Crankshaft End Play Rod Bearing Journal Diameter Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Taper Rod Bearing Journal Clearance Rod Bearing Journal Clearance Rod Side Clearance (Inlet) Valve Margin (Exhaust) Valve Margin (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Inlet) Valve Sidem to Guide Clearance (Inlet) Valve Sidem to Guide Clearance (Inlet) Valve Sidem to Guide Clearance (Exhaust) Valve Sidem to Guide Clearance (Exhaust) Valve Sidem to Guide Clearance (Exhaust) Valve Sidem to Guide Clearance (Inlet) Valve Sidem to Guid	•			
• Rod Bearing Journal Diameter 50.788-50.784 mm 1.9983-1.9994 in Rod Bearing Journal Taper 0.005 mm 0.00019 in Rod Bearing Journal Out Of Round 0.005 mm 0.00019 in Rod Bearing Journal Clearance 0.025-0.079 mm 0.00098-0.031 in Rod Side Clearance 0.10-0.38 mm 0.0039-0.0149 in Rod Side Clearance 0.038-0.088 mm 0.0015-0.0035 in Rod System 0.038-0.088 mm 0.0014 in Rod System 0.038 mm 0.0014 in Rod System 0.0015 in Rod System 0.0014 in Rod System 0.0014 in Rod System 0.0014 in Rod System 0.0014 in Rod System 0.0015 in Rod System 0.0014 in Rod System 0.0015 in Rod System 0.0014 in Rod System 0.0015 i	•			
• Rod Bearing Journal Taper • Rod Bearing Journal Out Of Round • Rod Bearing Journal Clearance • Rod Side Clearance • Rod Rom • Rod Ro	•		~ 	
• Rod Bearing Journal Out Of Round • Rod Bearing Journal Clearance • Rod Side Rom • Rod S	•	Rod Bearing Journal Taper		
• Rod Bearing Journal Clearance 0.025-0.079 mm 0.00098-0.0031 in end of Rod Side Clearance 0.10-0.38 mm 0.0039-0.0149 in 0.0039-0.0149 in 0.0039-0.0149 in 0.0039-0.0149 in 0.0039-0.0149 in 0.0038-0.038 mm 0.0039-0.0149 in 0.0038-0.038 in 0.0039-0.0149 in 0.0038-0.038 in 0.0015-0.0035 in 0.0038-0.088 mm 0.0015-0.0035 in 0.0038 mm 0.0014 in 0.038 mm 0.0014 in 0.0014 i	•			
Camshaft 0.10-0.38 mm 0.0039-0.0149 in Camshaft Lobe Lift (Inlet and Exhaust) 6.687 mm 0.2633 in Journal Diameter 47.453-47.478 mm 1.868-1.869 in Journal Clearance 0.038-0.088 mm 0.0015-0.0035 in Valve System	•			
Camshaft Lobe Lift (Inlet and Exhaust) 6.687 mm 0.2633 in ■ Journal Diameter 47.453-47.478 mm 1.868-1.869 in ■ Journal Clearance 0.038-0.088 mm 0.0015-0.0035 in Valve System ● Rocker Arm Ratio 40.64 mm 1.6 ● Valve Face Angle	•			
■ Journal Diameter	Camst	naft:		0.0039-0.0149 111
■ Journal Diameter	<u> </u>	Lobe Lift (Inlet and Exhaust)	0.007	T 00000
■ Journal Clearance	•			
Valve System 40.64 mm 1.6 • Valve Face Angle 45° • Valve Face Runout 0.038 mm 0.0014 in • Valve Margin (Exhaust) 2.21-1.79 mm 0.087-0.080 in • Valve Margin (Inlet) 1.96-1.16 mm 0.061-0.04 in • Valve Head Diameter (Inlet) 44 mm 1.73 in • Valve Head Diameter (Exhaust) 37 mm 1.45 in • Valve Overall Length (Inlet) 134.23 mm 5.28 in • Valve Overall Length (Exhaust) 127 mm 5.00 in • Valve Stem to Guide Clearance (Inlet) 0.019-0.053 mm 0.0007-0.0020 in • Valve Stem to Guide Clearance (Exhaust) 0.035-0.075 mm 0.0014-0.0029 in • Valve Stem to Guide Clearance (Exhaust) 0.035-0.075 mm 0.0014-0.0029 in • Valve Guide Inside Diameter 7.000-7.020 mm 0.275-0.276 in • Valve Tip to Retainer Groove Centerline (Exhaust) 5.38-5.90 mm 0.212-0.232 in • Valve Springs Free Length 48.7 mm 1.91 in • Valve Seat Width (Inlet) 2.80 mm 0.110 in • Valve Springs Load (Closed) 361-325 N @ 40.64 mm				
 Rocker Arm Ratio Valve Face Angle Valve Face Runout Valve Face Runout Valve Margin (Exhaust) Valve Margin (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Springs Free Length Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 	2905300690580	ESCONIDIO DE CONTROLO DE C	U.038-0.088 mm	0.0015-0.0035 in
 Valve Face Angle	20003419409581			
 Valve Face Runout Valve Margin (Exhaust) Valve Margin (Inlet) Valve Margin (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 			40.64 mm	1.6
 Valve Margin (Exhaust) Valve Margin (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Inlet) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 				45°
 Valve Margin (Inlet) Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 				0.0014 in
 Valve Head Diameter (Inlet) Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Footal (Open) 				0.087-0.080 in
 Valve Head Diameter (Exhaust) Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 				0.061-0.04 in
 Valve Overall Length (Inlet) Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 				1.73 in
 Valve Overall Length (Exhaust) Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 				1.45 in
 Valve Stem to Guide Clearance (Inlet) Valve Stem to Guide Clearance (Exhaust) Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) Valve Springs Load (Open) Valve Seat Vident (Inlet) Valve Springs Load (Open) 				5:28 in
 Valve Stem to Guide Clearance (Exhaust) Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) Valve Springs Load (Open) 0.0014-0.0029 in 0.275-0.276 in 0.212-0.232 in 4.94-5.46 mm 0.194-0.215 in 1.91 in 0.110 in 0.138 in				
 Valve Guide Inside Diameter Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) 			0.019-0.053 mm	0.0007-0.0020 in
 Valve Tip to Retainer Groove Centerline (Exhaust) Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) 				0.0014-0.0029 in
 Valve Tip to Retainer Groove Centerline (Intake) Valve Springs Free Length Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) 4.94-5.46 mm 1.91 in 2.80 mm 0.110 in 0.138 in 361-325 N @ 40.64 mm 957-893 N @ 29.85 215-201 lb @ 1.175 				0.275-0.276 in
• Valve Springs Free Length 48.7 mm 1.91 in • Valve Seat Width (Inlet) 2.80 mm 0.110 in • Valve Seat Width (Exhaust) 3.51 mm 0.138 in • Valve Springs Load (Closed) 361-325 N @ 40.64 mm 81.2-73.1 lb @ 1.600 in • Valve Springs Load (Open) 957-893 N @ 29.85 215-201 lb @ 1.175		Valve Tip to Retainer Groove Centerline (Exhaust)	5.38-5.90 mm	0.212-0.232 in
 Valve Seat Width (Inlet) Valve Seat Width (Exhaust) Valve Springs Load (Closed) Valve Springs Load (Open) 2.80 mm 3.51 mm 3.51 mm 3.51 mm 3.51 mm 361-325 N @ 40.64 mm 957-893 N @ 29.85 215-201 lb @ 1.175 			4.94-5.46 mm	0.194-0.215 in
◆ Valve Seat Width (Exhaust) 3.51 mm 0.138 in • Valve Springs Load (Closed) 361-325 N @ 40.64 mm 81.2-73.1 lb @ 1.600 in • Valve Springs Load (Open) 957-893 N @ 29.85 215-201 lb @ 1.175				1.91 in
 Valve Springs Load (Closed) Valve Springs Load (Open) 361-325 N @ 40.64 mm in 215-201 lb @ 1.600 in 215-201 lb @ 1.175 				0.110 in
• Valve Springs Load (Open) mm in 957-893 N @ 29.85 215-201 lb @ 1.175	•	valve Seat Width (Exhaust)		
Valve Springs Load (Open) 957-893 N @ 29.85 215-201 lb @ 1.175	•	Valve Springs Load (Closed)	_	1.
	•	Valve Springs Load (Open)	_	215-201 lb @ 1.175

Fastener Tightening Specifications

	Specifi	cations
Application	Metric	English
Accelerator Cable Mounting Bracket	10 N·m	89 lb in
Accessory Bracket Bolts	50 N·m	37 lb ft
Battery Negative Cable Bolt To Engine	35 N·m	26 lb ft
Battery Positive Cable Retainer Bolt To Engine	35 N·m	26 lb ft
Camshaft Position Sensor to Block Bolt	10 N·m	89 lb in
Camshaft Rear Cover Bolts	12 N·m	106 lb in
Camshaft Sprocket Bolt	130 N·m	96 lb in
Camshaft Thrust Plate Bolts	12 N·m	106 lb in
Clutch Cover and Pressure Plate Assembly Bolts		10010111
First Pass	20 N·m	15 lb ft
Final Pass		5°
Connecting Rod Cap Nuts	52 N·m	38 lb ft
Crankshaft Bearing Cap Bolts - First Pass	50 N·m	31 lb ft
Crankshaft Bearing Cap Bolts - Second Pass	95 N·m	70 lb ft
Crankshaft Pulley Hub to Crankshaft Bolts	105 N·m	77 lb ft
Crankshaft Pulley to Hub Bolt	50 N·m	37 lb ft
Crankshaft Sensor Bolt	8 N·m	72 lb in
Cylinder Head Bolts Long	. 014111	12 10 111
First Pass	63 N·m	46 lb ft
Final Pass		0°
Cylinder Head Bolts Short	9	
First Pass	58 N·m	43 lb ft
Final Pass	90	
Direct Ignition System Coil Assembly	25 N·m	
Drive Belt Tensioner Bolt	50 N·m	18 lb ft
EGR Port Cover Bolts	11 N·m	37 lb ft
Engine Front Cover Bolts	11 N·m	97 lb in 97 lb in
Engine Front Cover Nuts	10 N·m	89 lb in
Engine Front Cover Studs	7 N·m	62 lb in
Engine Lift Bracket Nut	50 N·m	37 lb ft
Engine Mount Rear Bolt to Transmission	45 N·m	33 lb ft
Engine Mount Rear Nut to Crossmember	45 N·m	33 lb ft
Engine Mount Shield Bolt	11 N·m	97 lb in
Engine Mount Through Bolt And Studs	45 N·m	33 lb ft
Engine Mount to Engine Bolt	55 N·m	41 lb ft
Engine Wire Harness Bracket at Bolt to Rear of Cylinder Head	25 N·m	18 lb ft
Engine Wire Harness Bracket at Rear of Cylinder Head Bolts to Valve	10 N·m	
Cover	10 11111	89 lb in
Engine Wiring Harness Retaining Bolt To Intake Manifold	12 N·m	106 lb in
Exhaust Manifold Nuts	13 N·m	118 lb in
Fan Pully Bolts	30 N⋅m	22 lb ft
Flywheel Bolts	75 N·m	55 lb ft
Generator Output Wire Nut	17 N·m	13 lb ft
Generator Rear Brace Bolts	25 N·m	18 lb ft
Generator Rear Brace Nuts	25 N·m	18 lb ft
Ground Wires Bolt	35 N·m	26 lb ft
Heater Hose Bracket to Oil Fill Tube	14 N·m	10 lb ft
Intake Manifold Bolts	24 N·m	17 lb ft
Intake Manifold Nuts	24 N·m	17 lb ft
Intake Manifold Studs	12 N·m	105 lb in

19 N·m 26 lb ft 11 N·m 97 lb in Oil Filter 17 N·m 13 lb ft 13 lb ft 13 lb ft Oil Filter 35 N·m 26 lb ft 17 N·m 13 lb ft Oil Filter Adapter 35 N·m 26 lb ft Oil Gallery Plug - Large - Rear of Engine Block 33 N·m 24 lb ft Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plug - Side of Block Above Oil Filter 21 N·m 15 lb ft Oil Level Indicator Tube Nut 12 N·m 106 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Oxygen Sensor 42 N·m 31 lb ft Oxygen Steering Pump Lower Bolts 30 N·m 22 lb ft Oxygen Steering Pump Nuts 50 N·m 37 lb ft Oxy	Knock Sensor	40.11	7 22 11 21
Oil Filter 17 N·m 13 lb ft Oil Filter Adapter 35 N·m 26 lb ft Oil Gallery Plug - Large - Rear of Engine Block 33 N·m 24 lb ft Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plugs - Side of Block Above Oil Filter 21 N·m 15 lb ft Oil Level Indicator Tube Nut 12 N·m 10 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pump Cover Bolts 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Owey Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Roker Arm Bolts 25 N·m 19 lb ft			
Oil Filter Adapter 35 N·m 26 lb ft Oil Gallery Plug - Large - Rear of Engine Block 33 N·m 24 lb ft Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plugs - Side of Block Above Oil Filter 21 N·m 15 lb ft Oil Level Indicator Tube Nut 12 N·m 106 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m </td <td></td> <td></td> <td></td>			
Oil Gallery Plug - Large - Rear of Engine Block 33 N·m 24 lb ft Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plugs - Side of Block Above Oil Filter 21 N·m 15 lb ft Oil Level Indicator Tube Nut 12 N·m 106 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m<			
Oil Gallery Plug - Small - Rear of Engine Block 15 N·m 11 lb ft Oil Gallery Plugs - Side of Block Above Oil Filter 21 N·m 15 lb ft Oil Level Indicator Tube Nut 12 N·m 106 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 50 N·m			
Oil Gallery Plugs - Side of Block Above Oil Filter 21 N·m 15 lb ft Oil Level Indicator Tube Nut 12 N·m 106 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb	Oil Gallery Plug - Large - Rear of Engine Block		
Oil Level Indicator Tube Nut 12 N·m 106 lb in Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 50 N·m 10 N·m 89 lb in Water Pump Bolts 25 N·m 18 lb ft	Oil Gallery Pluga Side of Block Above Oil File		
Oil Pan Drain Plug 45 N·m 33 lb ft Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Pump Bolts 25 N·m 18 lb ft	Oil Lovel Indicates Tube Next		
Oil Pan Nuts and Bolts 10 N·m 89 lb in Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Inlet 25 N·m 18 lb ft			
Oil Pressure Sensor/Switch 12 N·m 106 lb in Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Bulley Bolts 25 N·m 18 lb ft	Oil Pan Nida and But		33 lb ft
Oil Pump Cover Bolts 10 N·m 89 lb in Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 24 N·m 17 lb ft Valve Rocker Arm Cover Bolts 50 N·m 37 lb ft Valve Rocket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Bulley Patter 25 N·m 18 lb ft		10 N·m	89 lb in
Oil Pump Drive Assembly Bolt 25 N·m 18 lb ft Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Inlet 25 N·m 18 lb ft		12 N·m	106 lb in
Oil Pump Mounting Bolt 44 N·m 32 lb ft Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pulley Polts 25 N·m 18 lb ft		10 N·m	89 lb in
Oxygen Sensor 42 N·m 31 lb ft Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 24 N·m 17 lb ft Valve Rocker Arm Cover Bolts 50 N·m 37 lb ft Valve Rocket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Dulloy Polte 25 N·m 18 lb ft	Oil Pump Drive Assembly Bolt	25 N·m	18 lb ft
Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Inlet 25 N·m 18 lb ft		44 N·m	32 lb ft
Power Steering Pump Front Bolts 30 N·m 22 lb ft Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pulloy Relte 25 N·m 18 lb ft		42 N·m	31 lb ft
Power Steering Pump Lower Bolts 50 N·m 37 lb ft Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pullow Polte 25 N·m 18 lb ft	Power Steering Pump Front Bolts	30 N·m	22 lb ft
Power Steering Pump Nuts 50 N·m 37 lb ft Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pullow Polte 25 N·m 18 lb ft	Power Steering Pump Lower Bolts	50 N·m	
Rocker Arm Bolts 25 N·m 19 lb ft Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Bullow Polte 25 N·m 18 lb ft	Power Steering Pump Nuts	50 N·m	
Spark Plugs 17 N·m 13 lb ft Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pullow Palte 25 N·m 18 lb ft		25 N·m	
Starter Positive Cable Retainer Bolt to Block 35 N·m 26 lb ft Throttle Body to Intake Manifold Bolts 10 N·m 89 lb in Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pullow Polte 25 N·m 18 lb ft		17 N·m	
Throttle Body to Intake Manifold Bolts 10 N⋅m 89 lb in Timing Chain Tensioner Bolts 24 N⋅m 17 lb ft Transmission Support Brace Bolts 50 N⋅m 37 lb ft Valve Rocker Arm Cover Bolts 10 N⋅m 89 lb in Water Jacket Drain Plug 15 N⋅m 11 lb ft Water Outlet Pipe 26 N⋅m 19 lb ft Water Pump Bolts 25 N⋅m 18 lb ft Water Pump Pulloy Polte 25 N⋅m 18 lb ft	Starter Positive Cable Retainer Bolt to Block	35 N·m	
Timing Chain Tensioner Bolts 24 N·m 17 lb ft Transmission Support Brace Bolts 50 N·m 37 lb ft Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pullow Polte 25 N·m 18 lb ft	Throttle Body to Intake Manifold Bolts		
Transmission Support Brace Bolts 50 N⋅m 37 lb ft Valve Rocker Arm Cover Bolts 10 N⋅m 89 lb in Water Jacket Drain Plug 15 N⋅m 11 lb ft Water Outlet Pipe 26 N⋅m 19 lb ft Water Pump Bolts 25 N⋅m 18 lb ft Water Pump Pullow Polte 25 N⋅m 18 lb ft			
Valve Rocker Arm Cover Bolts 10 N·m 89 lb in Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Inlet 25 N·m 18 lb ft			
Water Jacket Drain Plug 15 N·m 11 lb ft Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Pulley Polts 25 N·m 18 lb ft			
Water Outlet Pipe 26 N·m 19 lb ft Water Pump Bolts 25 N·m 18 lb ft Water Pump Inlet 25 N·m 18 lb ft			
Water Pump Bolts 25 N·m 18 lb ft Water Pump Inlet 25 N·m 18 lb ft			
Water Pump Pulley Polte Water Pump Pulley Polte 25 N·m 18 lb ft	Water Pump Bolts		
Mater Pump Pulloy Polto			
	Water Pump Pulley Bolts		

Engine Component Description

Engine Block

The engine block is cast iron. The engine block has four cylinders arranged in-line. The engine block is a one piece casting. The cylinders are encircled by coolant jackets.

Cylinder Head

The cylinder head is cast aluminum made in a lost-foam casting process. This results in a casting requiring very little final machining. The cylinder head has sintered powdered metal valve guides and valve seats.

Crankshaft

The crankshaft is cast nodular iron. Five crankshaft bearings support the crankshaft. The bearings are retained by bearing caps. Number four crankshaft bearing also serves as the crankshaft thrust bearing. The bearing caps are machined with the block for proper alignment and clearances. The bearing caps are retained by two bolts each. Four connecting rod journals are spaced 90 degrees apart. There is one connecting rod on each journal.

Piston and Connecting Rod Assemblies

The pistons are cast aluminum. The pistons use two compression rings and one oil control ring assembly. The piston is a low friction, lightweight design with a flat top and barrel shaped skirt. The piston pins are chromium steel. They have a floating fit in the piston and are retained by a press fit in the connecting rod. The connecting rods are forged steel. The connecting rods are machined with the rod cap installed for proper clearances and alignments.

Camshaft

The camshaft is steel. The camshaft is supported by five bearings pressed into the engine block. The camshaft is of an assembled design with each lobe, journal, and the oil pump drive gear assembled onto a hollow tube which is then expanded to hold the components in place. The camshaft timing chain sprocket mounted to the front of the camshaft is driven by the crankshaft sprocket thorough a camshaft timing chain.

Valve Train

The LN2 valve train utilizes cast steel rocker arms with a roller bearing fulcrum. Motion is transmitted from the camshaft through the hydraulic roller valve lifters and the tubular pushrods to the valve rocker arms. The valve rocker arm pivots on a roller bearing in order to open the valve. The valve train is of the netlash type without provision for manual adjustment. All valve train lash is taken up by hydraulic roller valve lifters.

The valve springs are of a conical type which reduce valve train harmonics and noise.

The valve seals are integral with the valve spring seats.

Intake Manifold and Fuel Rail

The intake manifold is constructed of a composite material incorporating metallic compression limiters at the mounting points for the throttle body, fuel rail, and the manifold to cylinder head flange. The fuel rail is of an assembled tubular design.

Exhaust Manifold

The exhaust manifold is cast iron.

Drive Belt System Description

The drive belt system consists of the following components:

- The drive belt
- The drive belt tensioner
- The drive belt idler pulley
- The crankshaft balancer pulley
- The accessory drive component mounting brackets
- The accessory drive components
 - The power steering pump, if belt driven
 - The generator
 - The A/C compressor, if equipped
 - The engine cooling fan, if belt driven
 - The water pump, if belt driven
 - The vacuum pump, if equipped
 - The air compressor, if equipped


The drive belt system may use 1 belt or 2 belts. The drive belt is thin so that it can bend backwards and has several ribs to match the grooves in the pulleys. There also may be a V-belt style belt used to drive certain accessory drive components. The drive belts are made of different types of rubbers -- chloroprene or EPDM -- and have different layers or plys containing either fiber cloth or cords for reinforcement.

Both sides of the drive belt may be used to drive the different accessory drive components. When the back side of the drive belt is used to drive a pulley, the pulley is smooth.

The drive belt is pulled by the crankshaft balancer pulley across the accessory drive component pulleys. The spring loaded drive belt tensioner keeps constant tension on the drive belt to prevent the drive belt from slipping. The drive belt tensioner arm will move when loads are applied to the drive belt by the accessory drive components and the crankshaft.

The drive belt system may have an idler pulley, which is used to add wrap to the adjacent pulleys. Some systems use an idler pulley in place of an accessory drive component when the vehicle is not equipped with the accessory.

Lubrication



Full pressure lubrication, through a full-flow oil filter is supplied by a gear-type oil pump. Oil is drawn up through the oil pump screen and passes through the pump to the oil filter. The oil filter is a full-flow paper element unit with an anti-drain back valve. An oil filter bypass valve is used to ensure adequate oil supply, in the event the filter becomes plugged or develops excessive pressure drop. Filtered oil flows into the main gallery and then to the camshaft, the balance shaft, the rear bearing, and the crankshaft bearings. The valve lifter oil gallery supplies oil to the valve lifters. Oil flows from the valve lifters through the hollow valve pushrods to the valve rocker arms. Oil drains back to the crankcase through the oil drain holes in the cylinder head. The camshaft timing chain is drip fed from the front camshaft bearing. The pistons and piston pins are lubricated by oil splash.

Engine Mechanical – 4.3L

General Specifications

Application	Specif Metric	ication English
General	meere	<u> Liigiisii </u>
Engine Type	90 dec	ree V6
Displacement	4.3 L	262 CID
• RPO		J3
• VIN		X
Bore	101.60 mm	4.012 in
Stroke	88.39 mm	3.480 in
Compression Ratio	9.2	
Firing Order	1-6-5	-4-3-2
Spark Plug Gap	1.52 mm	0.060 in
Balance Shaft		
Bearing Journal Diameter - Rear	38.085-38.100 mm	1.4994-1.500 in
Bushing Bore Diameter - Rear	0.050-0.088 mm	0.0020-0.0035 in
Block		
Crankshaft Main Bearing Bore Out-of-Round	0.050 mm	0.002 in
Cylinder Bore Diameter	101.618-101.643 mm	4.0007-4.0017 in
Cylinder Bore Out-of-Round - Production	0.017 mm	0.0007 in
Cylinder Bore Out-of-Round - Service	0.05 mm	0.0007 in
Cylinder Bore Taper - Production Relief Side	0.025 mm	0.0010 in
Cylinder Bore Taper - Production Thrust Side	0.012 mm	0.0005 in
Cylinder Bore Taper - Service	0.025 mm	0.0010 in
Cylinder Head Deck Surface Flatness	0.050-0.152 mm	0.002-0.006 in
Camshaft		
Camshaft End Play	0.0254-0.2286 mm	0.0010-0.0090 in
Camshaft Journal Diameter	47.440-47.490 mm	1.8677-1.8696 in
Camshaft Journal Out-of-Round	0.025 mm	0.001 in
Camshaft Lobe Lift - Exhaust	7.20-7.30 mm	0.283-0.287 in
Camshaft Lobe Lift - Intake	6.97-7.07 mm	0.274-0.278 in
Camshaft Runout	0.065 mm	0.0026 in
Connecting Rod		
Connecting Rod Bearing Clearance - Production	0.038-0.078 mm	0.0015-0.0031 in
Connecting Rod Bearing Clearance - Service	0.025-0.063 mm	0.0010-0.0025 in
Connecting Rod Side Clearance	0.15-0.44 mm	0.006-0.017 in
Crankshaft:		
Connecting Rod Journal Diameter	57.116-57.148 mm	2.2487-2.2497 in
Connecting Rod Journal Out-of-Round - Production	0.008 mm	0.0003 in
Connecting Rod Journal Out-of-Round - Service	0.025 mm	0.0010 in
 Connecting Rod Journal Taper - Production 	0.010 mm	0.0004 in
 Connecting Rod Journal Taper - Service 	0.025 mm	0.0010 in
Crankshaft End Play	0.050-0.20 mm	0.002-0.008 in
 Crankshaft Main Bearing Clearance #1 - Production 	0.02-0.05 mm	0.0008-0.0020 in

r			
•	Crankshaft Main Bearing Clearance #2, #3, and #4 - Production	0.028-0.058 mm	0.0011-0.0023 in
•	Crankshaft Main Bearing Clearance #1 - Service	0.0254-0.05 mm	0.0010-0.0020 in
•	Crankshaft Main Bearing Clearance #2, #3, and #4 - Service	0.025-0.063 mm	0.0010-0.0025 in
•	Crankshaft Main Journal Diameter #1	62.199-62.217 mm	2.4488-2.4495 in
•	Crankshaft Main Journal Diameter #2 and #3	62.191-62.215 mm	2.4485-2.4494 in
•	Crankshaft Main Journal Diameter #4	62.179-62.203 mm	2.4480-2.4489 in
•	Crankshaft Main Journal Out-of-Round - Production	0.005 mm	0.0002 in
•	Crankshaft Main Journal Out-of-Round - Service	0.025 mm	0.0010 in
•	Crankshaft Main Journal Taper	0.007 mm	0.0003 in
Exhau	st Manifold		
•	Surface Flatness - Flange to Flange	0.25 mm	0.010 in
•	Surface Flatness - Individual Flange	0.05 mm	0.002 in
Intake	Manifold	1 0.00 11111	0.002 111
•	Surface Flatness	0.40	
50000000000	ation System	0.10 mm	0.004 in
57555703495556763			
-	Oil Capacity for C/K, G/H with Filter	4.3 L	4.5 qt
•	Oil Capacity for C/K, G/H without Filter	3.8 L	4 qt
•	Oil Capacity for S/T, M/L with Filter	4.7 L	5 qt
•	Oil Capacity for S/T, M/L without Filter	4.3 L	4.5 qt
•	Oil Pressure - at 1,000 RPM	42 kPa	6 psi
•	Oil Pressure - at 2,000 RPM	125 kPa	18 psi
	Oil Pressure - at 4,000 RPM	166 kPa	24 psi
Piston			
•	Piston Ring End Gap - First Compression Ring - Production	0.25-0.40 mm	0.010-0.016 in
•	Piston Ring End Gap - Second Compression Ring - Production	0.38-0.58 mm	0.015-0.023 in
•	Piston Ring End Gap - Oil Control Ring - Production	0.25-0.76 mm	0.010-0.029 in
•	Piston Ring End Gap - First Compression Ring - Service	0.25-0.50 mm	0.010-0.020 in
•	Piston Ring End Gap - Second Compression Ring - Service	0.38-0.80 mm	0.015-0.031 in
•	Piston Ring End Gap - Oil Control Ring - Service	0.005-0.090 mm	0.0002-0.0035 in
•	Piston Ring to Groove Clearance - First Compression Ring - Production	0.030-0.070 mm	0.0012-0.0027 in
•	Piston Ring to Groove Clearance - Second Compression Ring - Production	0.076-0.280 mm	0.0030-0.0110 in
•	Piston Ring to Groove Clearance - Oil Control Ring - Production	0.046-0.196 mm	0.0018-0.0077 in
•	Piston Ring to Groove Clearance - First Compression Ring - Service	0.030-0.085 mm	0.0012-0.0033 in
•	Piston Ring to Groove Clearance - Second Compression Ring - Service	0.030-0.085 mm	0.0012-0.0033 in
•	Piston Ring to Groove Clearance - Oil Control Ring - Service	0.076-0.200 mm	0.0030-0.0079 in
Pistons	s and Pins		
•	Piston - Piston to Bore Clearance - Production	0.018-0.061 mm	0.0007-0.0024 in
•	Piston - Piston to Bore Clearance - Service	0.075 mm	0.0029 in
•	Pin - Piston Pin Clearance to Connecting Rod Bore -	0.012-0.048 mm	0.0005-0.0019 in

	Press Fit		
•	Pin - Piston Pin Clearance to Piston Pin Bore - Production	0.013-0.023 mm	0.0005-0.0009 in
•	Pin - Piston Pin Clearance to Piston Pin Bore - Service	0.025 mm	0.0010 in
•	Pin - Piston Pin Diameter	23.545-23.548 mm	0.9270-0.9271 in
Valve	System		
•	Valves - Valve Face Angle	45 de	grees
•	Valves - Valve Seat Angle	46 de	grees
•	Valves - Valve Seat Runout	0.05 mm	0.002 in
•	Valves - Valve Seat Width - Intake	1.016-1.651 mm	0.040-0.065 in
•	Valves - Valve Seat Width - Exhaust	1.651-2.489 mm	0.065-0.098 in
•	Valves - Valve Stem Oil Seal Installed Height	1-2 mm	0.03937-0.07874 in
•	Valves - Valve Stem-to-Guide Clearance - Intake - Production	0.025-0.069 mm	0.0010-0.0027 in
•	Valves - Valve Stem-to-Guide Clearance - Intake - Service	0.025-0.094 mm	0.0010-0.0037 in
•	Valves - Valve Stem-to-Guide Clearance - Exhaust - Production	0.025-0.069 mm	0.0010-0.0027 in
•	Valves - Valve Stem-to-Guide Clearance - Exhaust - Service	0.025-0.094 mm	0.0010-0.0037 in
•	Rocker Arms - Valve Rocker Arm Ratio	1.5:1	
•	Valve Springs - Valve Spring Free Length	51.3 mm	2.02 in
•	Valve Springs - Valve Spring Installed Height - Intake	42.92-43.43 mm	1.670-1.700 in
•	Valve Springs - Valve Spring Installed Height - Exhaust	42.92-43.43 mm	1.670-1.700 in
•	Valve Springs - Valve Spring Load - Closed	338-374 N @ 43.2 mm	76-84 lb @ 1.70 in
• 1	Valve Springs - Valve Spring Load - Open	832-903 N @ 32.3 mm	187-203 lb @ 1.27 in

Fastener Tightening Specifications

Application	Specification		
	Metric	English	
Accelerator Control Cable and Cruise Control Cable Bracket Nut	9 N·m	80 lb in	
Accelerator Control Cable Bracket Nut	12 N·m	106 lb in	
Accelerator Control Cable Bracket Stud to Intake Manifold	6 N⋅m	53 lb in	
Accelerator Control Cable Bracket Stud to Throttle Body	12 N·m	106 lb in	
Air Cleaner Adapter Stud	10 N·m	89 lb in	
Air Cleaner Outlet Duct Hose Clamp	4 N·m	32 lb in	
Air Cleaner Outlet Duct Wingnut	2 N·m	18 lb in	
Balance Shaft Driven Gear Bolt			
First Pass	20 N·m	15 lb ft	
Final Pass	35 de	grees	
Balance Shaft Retainer Bolt	12 N·m	106 lb in	
Battery Negative Cable Bolt to Engine	17 N·m	13 lb ft	
Belt Idler Pulley Bolt	50 N·m	37 lb ft	
Camshaft Retainer Bolt	12 N·m	106 lb in	
Camshaft Sprocket Bolt	25 N·m	18 lb ft	
Connecting Rod Nut			
First Pass	27 N·m	20 lb ft	
Final Pass	70 de	70 degrees	
Crankshaft Balancer Bolt	95 N·m	70 lb ft	
Crankshaft Balancer Remover/Installer Bolt	25 N·m	18 lb ft	

■ First Pass 20 N·m 15 lb ft ■ Final Pass 73 degrees Crankshaft Bearing Cap Bolt - Optional Strategy 105 N·m 77 lb ft Crankshaft Position Sensor Bolt 9 N·m 80 lb in Crankshaft Position Sensor Bolt 9 N·m 80 lb in Crankshaft Rear Oil Seal Housing Bolt and Nut 12 N·m 106 lb in Crankshaft Rear Oil Seal Housing Retainer Stud 6 N·m 53 lb in Cylinder Head Bolt - Preferred Method • All Bolts First Pass in Sequence 30 N·m 22 lb ft • Long Bolt Final Pass in Sequence 75 degrees • Medium Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 55 degrees Short Bolt Final Pass in Sequence 60 N·m 44 lb ft • First Pass in Sequence 90 N·m 66 lb ft 60 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Second Pass in Sequence 90 N·m 66	Crankshaft Bearing Cap Bolt - Preferred Method		
• Final Pass 73 degrees Crankshaft Position Sensor Bolt 9 N·m 80 bin 77 b ft Crankshaft Pulley Bolt 58 N·m 43 b ft 60 b in 43 b ft Crankshaft Pulley Bolt 58 N·m 43 b ft 43 b ft 76 b ft 77 b ft 80 b in 43 b ft 76 b ft 77 b ft 9 N·m 43 b ft 18 b ft <td></td> <td>20 N·m</td> <td>15 lb ft</td>		20 N·m	15 lb ft
Crankshaft Bearing Cap Bolt - Optional Strategy 105 N·m 77 lb ft Crankshaft Position Sensor Bolt 9 N·m 80 lb in Crankshaft Rear Oil Seal Housing Bolt and Nut 12 N·m 106 lb in Crankshaft Rear Oil Seal Housing Retainer Stud 6 N·m 53 lb in Cylinder Head Bolt - Preferred Method 30 N·m 22 lb ft • All Bolts First Pass in Sequence 75 degrees • Medium Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 55 degrees • Short Bolt Final Pass in Sequence 60 N·m • First Pass in Sequence 90 N·m • Second Pass in Sequence 90 N·m • Second Pass in Sequence 90 N·m • Second Pass in Sequence 90 N·m • Special Polt 20 N·m • Second Pass in Sequence 90 N·m • Special Polt 20 N·m • Second Pass in Sequence 90 N·m	Final Pass		
Crankshaft Position Sensor Bolt 9 N·m 80 lb in Crankshaft Rear Oil Seal Housing Bolt and Nut 12 N·m 43 lb ft Crankshaft Rear Oil Seal Housing Retainer Stud 6 N·m 53 lb in Crankshaft Rear Oil Seal Housing Retainer Stud Quinder Head Bolt - Preferred Method • All Bolts First Pass in Sequence 30 N·m 21 lb ft • All Bolts First Pass in Sequence 75 degrees 65 degrees • Medium Bolt Final Pass in Sequence 65 degrees • Medium Bolt Final Pass in Sequence 55 degrees • Short Bolt Final Pass in Sequence 55 degrees Cylinder Head Bolt - Optional On-Vehicle Strategy • First Pass in Sequence 60 N·m 44 lb ft • Final Pass in Sequence 90 N·m 66 lb ft 60 lf • Final Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 66 lb ft Cylinder Head Core Hole Plug 20 N·m 15 lb ft Distributor Cap Bolt 25 N·m 18 lb ft Distributor Cap Bolt 25 N·m 18 lb ft Dirive Belt Tensioner Bolt 50 N·m 37 lb ft <td>Crankshaft Bearing Cap Bolt - Optional Strategy</td> <td></td> <td></td>	Crankshaft Bearing Cap Bolt - Optional Strategy		
Crankshaft Pulley Bolt 58 N·m 43 lb ft Crankshaft Rear Oil Seal Housing Retainer Stud 6 N·m 53 lb in Cylinder Head Bolt - Preferred Method 8 ll Bolts First Pass in Sequence 30 N·m 22 lb ft • All Bolts First Pass in Sequence 65 degrees 65 degrees • Medium Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 65 degrees Cylinder Head Bolt - Optional On-Vehicle Strategy First Pass in Sequence 35 N·m 26 lb ft • Second Pass in Sequence 60 N·m 44 lb ft 6 lb ft • Second Pass in Sequence 90 N·m 66 lb ft 60 lb ft • Second Pass in Sequence 90 N·m 66 lb ft 60 lb ft • Second Pass in Sequence 90 N·m 66 lb ft 60 lb ft • Stributor Cap Bolt 20 N·m 15 lb ft 15 lb ft Distributor Cap Bolt 20 N·m 15 lb ft 15 lb ft Drive Belt Ider Pulley Bolt 20 N·m 15 lb ft 15 lb ft Engine Block Coolant Drain Hole Plug	Crankshaft Position Sensor Bolt		
Crankshaft Rear Oil Seal Housing Retainer Stud 6 N·m 53 lb in Cylinder Head Bolt - Preferred Method • All Bolts First Pass in Sequence 30 N·m 22 lb ft • Long Bolt Final Pass in Sequence 75 degrees • Medium Bolt Final Pass in Sequence 65 degrees • Medium Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 55 degrees • Short Bolt Final Pass in Sequence 60 N·m 26 lb ft • First Pass in Sequence 35 N·m 26 lb ft • First Pass in Sequence 90 N·m 46 lb ft • Final Pass in Sequence 90 N·m 46 lb ft • Final Pass in Sequence 90 N·m 46 lb ft • Final Pass in Sequence 90 N·m 46 lb ft Cylinder Head Core Hole Plug 20 N·m 15 lb ft Olistributor Cap Bolt 2.4 N·m 21 lb in Distributor Cap Bolt 2.5 N·m 18 lb ft Drive Belt Tensioner Bolt 50 N·m 37 lb ft Engine Block Colant Drain Hole Plug 20 N·m 15 lb ft Engine Block Col Gallery Plug 30 N·m <th< td=""><td>Crankshaft Pulley Bolt</td><td></td><td></td></th<>	Crankshaft Pulley Bolt		
Crankshaft Rear Oil Seal Housing Retainer Stud 6 N·m 53 lb in Cylinder Head Bolt - Preferred Method 30 N·m 22 lb ft • All Bolts First Pass in Sequence 30 N·m 22 lb ft • Long Bolt Final Pass in Sequence 65 degrees • Short Bolt Final Pass in Sequence 55 degrees Cylinder Head Bolt - Optional On-Vehicle Strategy 55 degrees • First Pass in Sequence 60 N·m 44 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Second Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 61 lb ft • Final Pass in Sequence 90 N·m 61 lb ft • Final Pass in Sequence 90 N·m 61 lb ft • Final Pass in Sequence 90 N·m 61 lb ft <t< td=""><td>Crankshaft Rear Oil Seal Housing Bolt and Nut</td><td></td><td></td></t<>	Crankshaft Rear Oil Seal Housing Bolt and Nut		
Cylinder Head Bolt - Preferred Method • All Bolts First Pass in Sequence 30 N·m 22 lb ft • Long Bolt Final Pass in Sequence 75 degrees • Medium Bolt Final Pass in Sequence 55 degrees • Short Bolt Final Pass in Sequence 55 degrees • Short Bolt Final Pass in Sequence 55 degrees • Cylinder Head Bolt - Optional On-Vehicle Strategy • First Pass in Sequence 35 N·m 26 lb ft • Final Pass in Sequence 60 N·m 44 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Final Pass in Sequence 90 N·m 61 lb ft • Final Pass in Sequence 90 N·m 15 lb ft • Final Pass in Sequence 90 N·m 90	Crankshaft Rear Oil Seal Housing Retainer Stud		
■ All Bolts First Pass in Sequence ■ Long Bolt Final Pass in Sequence ■ Medium Bolt Final Pass in Sequence ■ Stort Bolt Final Pass in Sequence □ Stort Bolt Final Pass in Sequence □ Second Pass in Sequence ■ Second Pass in Sequence □ Second Pass in Second Pa	Cylinder Head Bolt - Preferred Method	014111	33 15 111
Long Bolt Final Pass in Sequence Medium Bott Final Pass in Sequence Short Bolt Final Pass in Sequence Short Bolt Final Pass in Sequence Short Bolt Final Pass in Sequence Stodegrees Cylinder Head Bolt - Optional On-Vehicle Strategy First Pass in Sequence Second Pass in Sequence So N·m 44 lb ft Sib Interpretation Pass in Sequence Second Pass in Sequence So N·m 44 lb ft Second Pass in Sequence Second Pass in Se		30 N·m	22 lh ft
● Medium Bolt Final Pass in Sequence 55 degrees • Short Bolt Final Pass in Sequence 55 degrees Cylinder Head Bolt - Optional On-Vehicle Strategy • First Pass in Sequence 35 N·m 26 lb ft • Second Pass in Sequence 60 N·m 44 lb ft • Final Pass in Sequence 90 N·m 66 lb ft • Vinider Head Core Hole Plug 20 N·m 15 lb ft 15 lb ft Distributor Cap Bolt 2.4 N·m 21 lb in 15 lb ft Distributor Clamp Bolt 25 N·m 18 lb ft 18 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft 18 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft 15 lb ft Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft 15 lb ft Engine Block Left Rear Oil Gallery Plug 20 N·m 15 lb ft	Long Bolt Final Pass in Sequence		
● Short Bolt Final Pass in Sequence 55 degrees Cylinder Head Bolt - Optional On-Vehicle Strategy • Firist Pass in Sequence 35 N·m 26 lb ft • Second Pass in Sequence 60 N·m 44 lb ft • Final Pass in Sequence 90 N·m 66 lb ft Cylinder Head Core Hole Plug 20 N·m 15 lb ft Distributor Cap Bolt 2.4 N·m 21 lb in Distributor Clamp Bolt 25 N·m 18 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Drive Belt Rear Oil Gallery Bug 20 N·m 15 lb ft Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 2 N·m 18 lb in Engine Coolant Heater Bolt/Screw 2 N·m 15 lb ft Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Front Cover Bolt 10 N·m 74 lb ft	Medium Bolt Final Pass in Sequence		
Cylinder Head Bolt - Optional On-Vehicle Strategy ■ First Pass in Sequence 35 N·m 26 lb ft ■ Second Pass in Sequence 60 N·m 44 lb ft ● Final Pass in Sequence 90 N·m 66 lb ft Cylinder Head Core Hole Plug 20 N·m 15 lb ft Distributor Cap Bolt 2.4 N·m 21 lb in Distributor Cap Bolt 25 N·m 18 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Drive Belt Tensioner Bolt 50 N·m 37 lb ft Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Side Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 2 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 20 N·m 15 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft			
● First Pass in Sequence 35 N·m 26 lb ft ● Second Pass in Sequence 60 N·m 44 lb ft ● Final Pass in Sequence 90 N·m 66 lb ft Cylinder Head Core Hole Plug 20 N·m 15 lb ft Distributor Cap Bolt 2.4 N·m 21 lb in Distributor Clamp Bolt 25 N·m 18 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Drive Belt Tensioner Bolt 50 N·m 37 lb ft Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft Engine Block Leff Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Coli Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Bock Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Bock Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Coolant Temperature Gage Sensor 20 N·m 15 lb ft Engine		35 UE	egrees
● Second Pass in Sequence ● Final Pass in Sequence ● Qinder Head Core Hole Plug Distributor Cap Bolt Distributor Clamp Bolt Distributor Clamp Bolt Distributor Clamp Bolt Distributor Clamp Bolt Drive Belt Idler Pulley Bolt Drive Belt Idler Pulley Bolt Drive Belt Rear Oil Gallery Plug Distributor Clamp Bolt Drive Belt Idler Pulley Bolt Drive Bolt Bolt Bolt Bolt Bolt Drive Bolt Bolt Bolt Bolt Bolt Bolt Bolt Bolt	First Pass in Sequence	OF N	00 11 61
● Final Pass in Sequence 90 N·m 66 lb ft Cylinder Head Core Hole Plug 20 N·m 15 lb ft Distributor Cap Bolt 2.4 N·m 21 lb in Distributor Cap Bolt 25 N·m 18 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Side Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Temperature (ECT) Sensor 2 N·m 18 lb in Engine Coolant Temperature Gage Sensor 20 N·m 15 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft Engine Front Cover Bolt 12 N·m 16 lb in Engine Lift Front Bracket Stud 35 N·m 26 lb ft Engine Mount Bolt to Engine 54 N·m 55 lb ft Engine Mount Bolt to En			
Special Content Special Co			
Distributor Cap Bolt	Cylinder Head Core Hole Dive		
Distributor Clamp Bolt	Distributor Can Balt		
Drive Belt Idler Pulley Bolt 50 N·m 37 lb ft Drive Belt Tensioner Bolt 50 N·m 37 lb ft Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Side Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 2 N·m 18 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Plywheel Bolt 100 N·m 74 lb ft Engine Flywheel Bolt 12 N·m 106 lb in Engine Lift Bracket Bolt 12 N·m 106 lb in Engine Lift Front Bracket Stud 35 N·m 26 lb ft Engine Mount Bolt - Through-bolt 74 N·m 55 lb ft Engine Mount Bolt to Engine 54 N·m 40 lb ft Engine Mount Bott to Engine 54 N·m 30 lb ft Engine Mount Nut - Through-bolt 63 N·m 36 lb ft Engine Oil Cooler Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in			
Drive Belt Tensioner Bolt 50 N·m 37 lb ft Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Side Oil Gallery Plug 20 N·m 15 lb ft Engine Block Coil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 2 N·m 18 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Coolant Temperature Gage Sensor 20 N·m 15 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft Engine Finott Cover Bolt 12 N·m 106 lb in Engine Lift Bracket Bolt 15 N·m 11 lb ft Engine Lift Bracket Bolt 15 N·m 11 lb ft Engine Mount Bolt to Trnough-bolt 74 N·m 55 lb ft Engine Mount Bolt to Engine 54 N·m 40 lb ft Engine Mount Bolt to Frame 45 N·m 33 lb ft Engine Mount Bolt oil Paol to Oil Pan 9 N·m 80 lb in Engine Oil			
Engine Block Coolant Drain Hole Plug 20 N·m 15 lb ft Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Side Oil Gallery Plug 20 N·m 15 lb ft Engine Block Coil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 2 N·m 18 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft Engine Front Cover Bolt 100 N·m 74 lb ft Engine Front Cover Bolt 15 N·m 106 lb in Engine Lift Bracket Bolt 15 N·m 11 lb ft Engine Mount Bolt - Through-bolt 74 N·m 55 lb ft Engine Mount Bolt - Through-bolt 74 N·m 55 lb ft Engine Mount Bolt - Through-bolt 74 N·m 40 lb ft Engine Mount Bolt - Through-bolt 63 N·m 46 lb ft Engine Oil Cooler Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Engine Oil Cooler Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle 15 N·m 11 lb ft Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head 35 N·m 26 lb ft Engine Wiring Harness Bracket Nut to Intake Manifold 12 N·m 106 lb in Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold 15 N·m 11 lb ft Pipe Pipe Pipe Silve Purge Solenoid Valve Nut to Intake Manifold 15 N·m 11 lb ft Pipe Pipe Pipe Pipe Silve Purge Solenoid Valve Nut to Intake Manifold 15 N·m 11 lb ft Pipe Pipe Pipe Pipe Silve Purge Solenoid Valve Nut to Intake Manifold 15 N·m 11 lb ft Pipe Pipe Pipe Pipe Silve Purge Solenoid Valve Nut to Intake Manifold 15 N·m 11 lb ft Pipe Pipe Pipe Pipe Silve P			
Engine Block Left Rear Oil Gallery Plug 30 N·m 22 lb ft Engine Block Left Side Oil Gallery Plug 20 N·m 15 lb ft Engine Block Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Block Right Rear Oil Gallery Plug 20 N·m 15 lb ft Engine Coolant Heater Bolt/Screw 2 N·m 18 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Coolant Temperature Gage Sensor 20 N·m 15 lb ft Engine Flywheel Bolt Engine Front Cover Bolt 100 N·m 74 lb ft Engine Front Cover Bolt 12 N·m 106 lb in Engine Lift Bracket Bolt 15 N·m 11 lb ft Engine Lift Front Bracket Stud 35 N·m 26 lb ft Engine Mount Bolt to Engine 54 N·m 55 lb ft Engine Mount Bolt to Engine 54 N·m 40 lb ft Engine Mount Bracket Bolt to Frame 45 N·m 33 lb ft Engine Oil Cooler Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Engine Oil Level Sensor 13 N·m 11 lb ft Engine Oil Pressure Gage Sensor 13 N·m 11 lb ft Engine Oil Pressure Gage Sensor 57 Sensor 15 N·m 11 lb ft Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head 35 N·m 26 lb ft Engine Wiring Harness Bracket Nut to Intake Manifold 12 N·m 106 lb in Exhaust Manifold Bolt/Stud • First Pass 15 N·m 11 lb ft • Final Pass 30 N·m 22 lb ft Final Pass 30 N·m 22 lb ft Final Pass 30 N·m 22 lb ft			
Engine Block Left Side Oil Gallery Plug			
Engine Block Oil Gallery Plug	Engine Block Left Rear Oil Gallery Plug		
Engine Block Right Rear Oil Gallery Plug	Engine Block Oil College Block		
Engine Coolant Heater Bolt/Screw 2 N·m 18 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft			
Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Engine Coolant Temperature Gage Sensor 20 N·m 15 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft Engine Front Cover Bolt 12 N·m 106 lb in Engine Lift Bracket Bolt 15 N·m 11 lb ft Engine Lift Front Bracket Stud 35 N·m 26 lb ft Engine Mount Bolt - Through-bolt 74 N·m 55 lb ft Engine Mount Bolt to Engine 54 N·m 40 lb ft Engine Mount Bracket Bolt to Frame 45 N·m 33 lb ft Engine Mount Nut - Through-bolt 63 N·m 46 lb ft Engine Oil Cooler Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Engine Oil Level Sensor 13 N·m 115 lb in Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle 15 N·m 11 lb ft Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner 25 N·m 18 lb ft Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head 35 N·m 26 lb ft Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head 10 N·m 89 lb in Evaporative Em	Engine Coolont Hoster Beld/Carey		
Engine Coolant Temperature Gage Sensor 20 N·m 15 lb ft Engine Flywheel Bolt 100 N·m 74 lb ft Engine Front Cover Bolt 12 N·m 106 lb in Engine Lift Bracket Bolt 15 N·m 11 lb ft Engine Lift Front Bracket Stud 35 N·m 26 lb ft Engine Mount Bolt - Through-bolt 74 N·m 55 lb ft Engine Mount Bolt to Engine 54 N·m 40 lb ft Engine Mount Bracket Bolt to Frame 45 N·m 33 lb ft Engine Mount Nut - Through-bolt 63 N·m 46 lb ft Engine Oil Cooler Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Engine Oil Level Sensor 13 N·m 115 lb in Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle 15 N·m 11 lb ft Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner 25 N·m 18 lb ft Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head 35 N·m 26 lb ft Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head 10 N·m 89 lb in Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake 10 N·m 89 lb in			
Engine Flywheel Bolt Engine Front Cover Bolt Engine Front Cover Bolt Engine Lift Bracket Bolt Engine Lift Bracket Bolt Engine Lift Bracket Stud Indicate Lift Bracket Bolt to End Indicate Lift Bracket Indicate Lift Bracket Bolt to Frame Indicate Lift Bracket Bolt Indicate Lift Bracket Indicate Lift Bracket Bracket Bolt to Oil Pan Indicate Lift Bracket Bracket Bracket Bolt to Generator and Drive Belt Tensioner Indicate Lift Bracket Bracket Bracket Bolt to Rear of Cylinder Head Indicate Lift Bracket	Engine Coolant Temperature (ECT) Sensor		
Engine Front Cover Bolt Engine Lift Bracket Bolt Engine Lift Bracket Bolt Engine Lift Bracket Stud 35 N·m 26 lb ft Engine Mount Bolt - Through-bolt T4 N·m 55 lb ft Engine Mount Bolt to Engine 54 N·m 40 lb ft Engine Mount Bracket Bolt to Frame 45 N·m 33 lb ft Engine Mount Nut - Through-bolt Engine Oil Cooler Pipe Clip Bolt to Oil Pan Engine Oil Level Sensor Engine Oil Pressure Gage Sensor Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold First Pass 15 N·m 11 lb ft 10 N·m 89 lb in Exhaust Manifold Bolt/Stud First Pass 15 N·m 11 lb ft 10 N·m 11 lb ft 11 lb ft 12 N·m 10 lb in 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 14 lb ft 15 N·m 15 lb in 15 N·m 16 lb in 17 N·m 17 lb ft 18 lb ft 18 lb ft 19 N·m 10 lb in 10 N·m 10 lb in 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft	Engine Coolant Temperature Gage Sensor		
Engine Lift Bracket Bolt Engine Lift Front Bracket Stud Engine Mount Bolt - Through-bolt Engine Mount Bolt to Engine Engine Mount Bolt to Engine Engine Mount Bracket Bolt to Frame Engine Mount Bracket Bolt to Frame Engine Mount Nut - Through-bolt Engine Oil Cooler Pipe Clip Bolt to Oil Pan Engine Oil Level Sensor Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold Exhaust Manifold Bolt/Stud Engine Plass Engin			
Engine Lift Front Bracket Stud Engine Mount Bolt - Through-bolt Engine Mount Bolt to Engine Engine Mount Bolt to Engine Engine Mount Bracket Bolt to Frame Engine Mount Bracket Bolt to Frame Engine Mount Nut - Through-bolt Engine Mount Nut - Through-bolt Engine Oil Cooler Pipe Clip Bolt to Oil Pan Engine Oil Level Sensor Engine Oil Pressure Gage Sensor Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Bolt to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold Exhaust Manifold Bolt/Stud First Pass 15 N·m 11 lb ft 15 N·m 11 lb ft 16 N·m 17 lb ft 17 N·m 18 lb ft 18 lb ft 19 N·m 10 lb in 10 N·m 10 lb in 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 14 lb ft 15 N·m 15 N·m 16 lb in 17 N·m 17 lb ft 18 lb ft 18 lb ft 18 lb ft 19 N·m 10 lb lb in 10 N·m 10 lb lb in 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 14 lb ft 15 N·m 15 N·m 16 lb in 17 N·m 17 lb ft 18 lb ft 18 lb ft 19 N·m 10 lb lb in 10 N·m 10 lb lb in 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 14 lb ft 15 N·m 15 N·m 16 lb in 17 N·m 17 lb ft 18 lb ft 18 lb ft 19 N·m 10 lb lb in 10 N·m 10 lb lb in 10 N·m 11 lb ft 10 N·m 11 lb ft 11 lb ft			
Engine Mount Bolt - Through-bolt Engine Mount Bolt to Engine Engine Mount Bolt to Engine Engine Mount Bracket Bolt to Frame Engine Mount Bracket Bolt to Frame Engine Mount Nut - Through-bolt Engine Mount Nut - Through-bolt Engine Oil Cooler Pipe Clip Bolt to Oil Pan Engine Oil Level Sensor Engine Oil Pressure Gage Sensor Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold Exhaust Manifold Bolt/Stud First Pass 15 N·m 11 lb ft 15 N·m 22 lb ft 16 N·m 17 lb ft 18 lb ft 19 N·m 10 lb in 10 N·m 11 lb ft 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 14 lb ft 15 N·m 16 lb in 17 N·m 18 lb ft 18 lb ft 19 N·m 10 lb in 10 N·m 10 lb in 10 N·m 11 lb ft 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 14 lb ft 15 N·m 15 N·m 16 lb in 17 N·m 17 lb ft 18 lb ft 18 lb ft 19 N·m 10 lb in 10 N·m 10 lb in 10 N·m 11 lb ft 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 N·m 11 lb ft 15 N·m 11 lb ft 15 N·m 11 lb ft 15 N·m 11 lb ft			
Ingine Mount Bolt to Engine Ingine Mount Bracket Bolt to Frame Ingine Mount Nut - Through-bolt Ingine Oil Cooler Pipe Clip Bolt to Oil Pan Ingine Oil Level Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Fitting - Plus Required Angle Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Rear of Cylinder Head Ingine Wiring Harness Bracket Nut to Intake Manifold Ingine Wiring Harness Brack			
Ingine Mount Bracket Bolt to Frame Ingine Mount Nut - Through-bolt Ingine Oil Cooler Pipe Clip Bolt to Oil Pan Ingine Oil Level Sensor Ingine Oil Pressure Gage Sensor Fitting - Plus Required Angle Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Rear of Cylinder Head Ingine Wiring Harness Bracket Nut to Intake Manifold Ingine Wiring Harness Bracket Nut Nut to Intake Manifold Ingine Wiring Harness Bracket Nut Nut to Intake Manifold Ingine Wiring Harness Bracket Nut Nut to Intake Manifold Ingine Wiring Harness Bracket Nut Nut to Intake Manifold Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Generator and Drive B			
Ingine Mount Nut - Through-bolt Ingine Oil Cooler Pipe Clip Bolt to Oil Pan Ingine Oil Level Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Fitting - Plus Required Angle Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Rear of Cylinder Head Ingine Wiring Harness Bracket Nut to Intake Manifold Ingin			
Ingine Oil Cooler Pipe Clip Bolt to Oil Pan Ingine Oil Level Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Fitting - Plus Required Angle Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Rear of Cylinder Head Ingine Wiring Harness Bracket Nut to Intake Manifold Ingine Wiring Harness Bracket Nut to I			
Ingine Oil Level Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Ingine Oil Pressure Gage Sensor Fitting - Plus Required Angle Ingine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Ingine Wiring Harness Bracket Bolt to Rear of Cylinder Head Ingine Wiring Harness Bracket Bolt to Rear of Cylinder Head Ingine Wiring Harness Bracket Nut to Intake Manifold Ingine			
Engine Oil Pressure Gage Sensor Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold First Pass Final Pass Final Pass 30 N·m 11 lb ft 12 N·m 106 lb in 10 N·m 11 lb ft 11 lb ft 12 N·m 11 lb ft 13 lb ft 14 lb ft 15 N·m 11 lb ft			
Engine Oil Pressure Gage Sensor Fitting - Plus Required Angle Engine Wiring Harness Bracket Bolt to Generator and Drive Belt Tensioner Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold Exhaust Manifold Bolt/Stud First Pass Final Pass Expand West Parts			
In a series of the series of t	Engine Oil Pressure Gage Sensor Fitting Divo Poquined Angle		
Bracket Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold First Pass Final Pass Final Pass 18 lb ft 26 lb ft 10 N·m 89 lb in 11 lb ft 30 N·m 12 lb ft	Engine Wiring Harness Bracket Bolt to Congretor and Drive Bolt Torgions	15 N·m	11 lb ft
Engine Wiring Harness Bracket Nut to Intake Manifold Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold Manifold First Pass Final Pass The Part Part Part Part Part Part Part Part	Bracket		18 lb ft
Evaporative Emission (EVAP) Canister Purge Solenoid Valve Nut to Intake Manifold Exhaust Manifold Bolt/Stud First Pass Final Pass The Part Part Part Part Part Part Part Part	Engine Wiring Harness Bracket Bolt to Rear of Cylinder Head		
Manifold 89 lb in Synapsis In State In	Engine vyining marness Bracket Nut to Intake Manifold	12 N·m	106 lb in
● First Pass 15 N·m 11 lb ft ● Final Pass 30 N·m 22 lb ft	Manifold	10 N·m	89 lb in
• Final Pass 30 N·m 22 lb ft			
• Final Pass 30 N·m 22 lb ft		15 N·m	11 lb ft
on and Water Duma Dullan Dull			
	Fan and Water Pump Pulley Bolt	25 N·m	18 lb ft
uel Meter Body Bracket Bolt 10 N·m 89 lb in	Fuel Meter Body Bracket Bolt		

Fuel Pipe Bracket Bolt to Rear of Cylinder Head	Fuel Pipe Bracket Bolt	- ON	
Fuel Pipe Retainer Nut		6 N·m	53 lb in
Fuel Supply Pipe Nut - Fuel Tank Side 30 N-m 22 is ft			
Generator and Drive Belt Tensioner Bracket Bolt to Engine 41 N.m 30 lb ft			
Generator and Drive Belt Tensioner Bracket Stud Nut	Concretor and Drive Polt Tonsion of Drive Delt Tonsion of Drive De		
Generator and Drive Belt Tensioner Bracket Stud to Engine 20 N·m 15 ib ft	Concretor and Drive Belt Tensioner Bracket Bolt to Engine		
Ground Wire or Strap Bolt to Rear of Cylinder Head Heater Inlet Hose Fitting 25 N·m 18 lb ft Ignition Coil Stud 12 N·m 106 lb in Knock Sensor 25 N·m 18 lb ft Ignition Coil Stud 12 N·m 106 lb in Knock Sensor 25 N·m 18 lb ft Oil Filter Pass in Sequence 3 N·m 27 lb in • First Pass in Sequence 12 N·m 106 lb in • First Pass in Sequence 12 N·m 106 lb in • First Pass in Sequence 15 N·m 11 lb ft Oil Filter Adapter Bolt 21 N·m 15 lb ft Oil Filter Fitting 35 N·m 22 lb ft Oil Filter Fitting 35 N·m 26 lb ft Oil Pan Bolt and Nut in Sequence 25 N·m 106 lb in Oil Pan Bolt and Nut in Sequence 25 N·m 18 lb ft Oil Pan Bolt and Nut in Sequence 25 N·m 18 lb ft Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 60 lb in Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump Bracket 20 N·m 37 lb ft Power Steering Pump Bracket Stud Nut 10 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Power Steering Pump 50 N·m 27 lb ft Radiator Inlet Hose Support Bracket Nut to Power Steering Pump 50 N·m 27 lb ft Remote Oil Filter Pipe Clip Bolt to Oil Pan 9 N·m 89 lb in Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt ft 10 N·m 20 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt ft 10 N·m 10 lb ft Power Steering Pump Rear Bracket Nut to Power Steering Pump 9 N·m 80 lb in Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 22 lb ft Spark P	Concretor and Drive Belt Tensioner Bracket Stud Nut		
Heater Inlet Hose Fitting 25 N·m 18 lb ft Ignition Coil Stud 12 N·m 106 lb in Knock Sensor 25 N·m 18 lb ft Ignition Coil Stud 12 N·m 106 lb in Knock Sensor 25 N·m 18 lb ft Ignition Coil Stud 12 N·m 106 lb in Isl bft	Generator and Drive Belt Tensioner Bracket Stud to Engine		
Ignition Coil Stud	Heater late the Fifth		
Nonck Sensor			18 lb ft
Lower Intake Manifold Bolt ● First Pass in Sequence ■ Second Pass in Sequence ■ Final Pass in Sequence ■ Final Pass in Sequence ■ 12 N·m 11 lb ft Oil Filter □ Gil Filter Adapter Bolt □ Filter Fitting □ Servent Adapter Mounting Bracket Bolt to Engine □ Filter Fitting □ Filter Fitting □ Servent Steering Pump Bracket Stud to Engine □ Filter Fitting □ Filter Filting □ Filter Filti			
First Pass in Sequence 12 N·m 106 ib in Final Pass in Sequence 12 N·m 11b ft 15 N·m 11 lb ft 15 N·m 11 lb ft 16 lb in 15 N·m 11 lb ft 16 lb in 17 N·m 15 lb ft 17 lb ft 18 N·m 11 lb ft 18 N·m 11 lb ft 18 N·m 11 lb ft 19 lb ft 19 N·m 15 lb ft 19 lb		25 N·m	18 lb ft
Second Pass in Sequence Final Pass in Sequence Is N·m Il lib ft Oil Filter Is N·m Il lib ft Oil Filter Adapter Bolt Oil Filter Adapter Bolt Oil Filter Fitting Is N·m Is lib ft Oil Filter Fitting Is N·m Is lib ft Oil Filter Fitting Is N·m Is lib ft Oil Level Indicator Tube Bolt Oil Pan Baffle Bolt Oil Pan Baffle Bolt Oil Pan Baffle Bolt Oil Pan Bott and Nut in Sequence Is N·m Is lib ft Oil Pan Bott and Nut in Sequence Oil Pan Drain Plug Is N·m Is lib ft Oil Pump Bolt to Rear Crankshaft Bearing Cap Oil Pump Bott to Rear Crankshaft Bearing Cap Oil Pump Bracket Oil Pump Bracket Sud to Engine Flower Steering Pump Bracket Sud to Engine Ower Steering Pump Bracket Stud Nut Ower Steering Pump Bracket Stud to Engine Ower Steering Pump Nut to Engine Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut to Engine Stud Ower Steering Pump Rear Bracket Nut Sequent Nut Ower Steering Pump Rear Bracket Nut Sequent Nut Ower Steering Pump Rear Bracket Nut Seque			
Final Pass in Sequence Final		3 N·m	27 lb in
● Final Pass in Sequence		12 N·m	106 lb in
Dil Filter 30 N·m 22 lb ft	Final Pass in Sequence	15 N·m	
Oil Filter Adapter Bolt 21 N·m 15 lb ft Oil Filter Fitting 35 N·m 26 lb ft Oil Level Indicator Tube Bolt 12 N·m 106 lb in Oil Pan Baffle Bolt 12 N·m 106 lb in Oil Pan Baffle Bolt 12 N·m 106 lb in Oil Pan Boit and Nut in Sequence 25 N·m 18 lb ft Oil Pan Drain Plug 25 N·m 18 lb ft Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 66 lb ft Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump 20 N·m 15 lb ft Power Steering Pump Bolt 50 N·m 37 lb ft Power Steering Pump Bracket Bolt to Engine 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Bracket Stud to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Power Steering Pump 50 N·m 37 lb ft Redictor Inlet Hose Support Bracket Nut to Exhaust Manifold Stud <td< td=""><td>Oil Filter</td><td></td><td></td></td<>	Oil Filter		
Oil Filter Fitting 35 N·m 26 lb ft Oil Level Indicator Tube Bolt 12 N·m 106 lb in Oil Pan Baffle Bolt 12 N·m 106 lb in Oil Pan Bolt and Nut in Sequence 25 N·m 18 lb ft Oil Pan Drain Plug 25 N·m 18 lb ft Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 66 lb ft Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump 20 N·m 15 lb ft Power Steering Pump Bolt 50 N·m 37 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Power Steering Pump 50 N·m 37 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Adapter Nut			
Oil Level Indicator Tube Bolt 12 N·m 106 lb in Oil Pan Baffle Bolt 12 N·m 106 lb in Oil Pan Bolt and Nut in Sequence 25 N·m 18 lb ft Oil Pan Drain Plug 25 N·m 18 lb ft Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 66 lb ft Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump 20 N·m 15 lb ft Power Steering Pump Bolt 50 N·m 37 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Bracket Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 36 N·m 27 lb ft Remote Oil F	Oil Filter Fitting		
Oil Pan Baffle Bolt 12 N·m 106 lb in Oil Pan Bolt and Nut in Sequence 25 N·m 18 lb ft Oil Pan Drain Plug 25 N·m 18 lb ft Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 66 lb ft Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump Bracket Stud Steering Pump Bolt 50 N·m 37 lb ft Power Steering Pump Bolt 50 N·m 37 lb ft 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Inlet and Outlet Hose Clip Bolt 10 N·m </td <td>Oil Level Indicator Tube Bolt</td> <td></td> <td></td>	Oil Level Indicator Tube Bolt		
Oil Pan Drain Plug 25 N·m 18 lb ft Oil Pan Drain Plug 25 N·m 18 lb ft Oil Pump Bolt to Rear Crankshaft Bearing Cap 90 N·m 66 lb ft Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump 20 N·m 15 lb ft Power Steering Pump Bolt 50 N·m 37 lb ft Power Steering Pump Bracket Bolt to Engine 41 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Bracket Stud to Engine 41 N·m 30 lb ft Power Steering Pump Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Evaluate Manifold Stud 36 N·m 37 lb ft Rediator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt 35 N·m	Oil Pan Baffle Bolt		
Oil Pam Drain Plug Oil Pump Bolt to Rear Crankshaft Bearing Cap Oil Pump Bolt to Rear Crankshaft Bearing Cap Oil Pump Cover Bolt Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump Bracket Power Steering Pump Bolt Power Steering Pump Bracket Bolt to Engine Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud to Engine Power Steering Pump Rear Bracket Nut to Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut to Evaluate Manifold Stud Nover Steering Pump Rear Bracket Nut Steering Pump Nut Steering Pump Rear Rear Nut Steering Pump Nut Steering Pump Rear Rear Rear Nut Steering Pump Rear Rear Rear Rear Rear Rear Rear Rear	Oil Pan Bolt and Nut in Sequence		
Oil Pump Bolt to Rear Crankshaft Bearing Cap Oil Pump Cover Bolt Oil Pump Cover Bolt 12 N·m 106 lb in Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump Bracket Power Steering Pump Bolt Power Steering Pump Bolt Power Steering Pump Bracket Bolt to Engine Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Nut to Engine Power Steering Pump Nut to Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud So N·m So	Oil Pan Drain Plug		
Oil Pump Cover Bolt Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump Bracket Power Steering Pump Bolt Power Steering Pump Bolt Power Steering Pump Bracket Bolt to Engine Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud to Engine Power Steering Pump Rear Bracket Stud Stud Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Power Steering Pump Rear Bracket Nut Power Steering Pump Power Steering Pump Rear Bracket Nut Power Steering Pump Power Steering Pump Rear Bracket Nut Power Steering Pump Power Steering Pump Rear Bracket Nut Power Steering Pump Power Steering Pump Rear Bracket Pump Power Steering Pump Power Pum			
Power Steering Fluid Reservoir Filler Neck Bolt to Power Steering Pump Bracket Power Steering Pump Bolt Power Steering Pump Bracket Bolt to Engine Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Rear Bracket Nut to Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Power Steering Pump Power Steering Pump Rear Bracket Nut to Power Steering Pump Power Steering Pump Rear Bracket Nut to Power Steering Pump Power Steering Pump Rear Bracket Nut to Power Steering Pump Power Steering Pump Rear Bracket Nut to Power Steering Pump Power Steering Pump Rear Bracket Nut Steeping Pump Power Steering Pump Rear Bracket Bolt to Oil Pum Steeping Pump Rear Pump Pump Stud Nut Steeping Pump Rear Pump Pump Pump Pump Pump Pump Pump Pump			
Bracket Power Steering Pump Bolt Power Steering Pump Bracket Bolt to Engine Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Rear Bracket Nut to Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Power Steering Pump Rear Bracket Bolt to Engine Power Steering Pump Rear Bracket Nut Power Steering Pump Rear Bracket Nut Power Steering Pump Rear Bracket Rolt to Engine Power Steering Pump Rear Bracket Nut Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt to Oil Pan Power Steering Pump Rear Bracket Rolt Soli Pin Rolt Rolt Rolt Rolt Rolt Rolt Rolt Rolt		12 11111	100 1011
Power Steering Pump Bracket Bolt to Engine 41 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud 36 N·m 37 lb ft Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Adapter Nut 25 N·m 18 lb ft Remote Oil Filter Inlet and Outlet Hose Clip Bolt 10 N·m 89 lb in Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Reactor Pipe Bracket Nut 25 N·m 18 lb ft Spark Plug • Initial Installation - NEW Cylinder Head 30 N·m 22 lb ft Spark Plug • Initial Installation - NEW Cylinder Head 30 N·m 106 lb in Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pn 80 lb in Throttle Body Stud 9 N·m 80 lb in Transmission Bolt to Oil Pan 47 N·m 35 lb ft	Bracket	20 N·m	15 lb ft
Power Steering Pump Bracket Bolt to Engine 41 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud Nut 41 N·m 30 lb ft Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud 36 N·m 37 lb ft Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Adapter Nut 25 N·m 18 lb ft Remote Oil Filter Inlet and Outlet Hose Clip Bolt 10 N·m 89 lb in Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Reactor Pipe Bracket Nut 25 N·m 18 lb ft Spark Plug • Initial Installation - NEW Cylinder Head 30 N·m 22 lb ft Spark Plug • Initial Installation - NEW Cylinder Head 30 N·m 106 lb in Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pn 80 lb in Throttle Body Stud 9 N·m 80 lb in Transmission Bolt to Oil Pan 47 N·m 35 lb ft	Power Steering Pump Bolt	50 N·m	37 lh ft
Power Steering Pump Bracket Stud Nut Power Steering Pump Bracket Stud to Engine Power Steering Pump Bracket Stud to Engine Power Steering Pump Nut to Engine Power Steering Pump Nut to Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Power Steering Pump Power Steering Pump Rear Bracket Nut to Exhaust Manifold Stud Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Nut Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Power Initial Installation - NEW Cylinder Head Power Pow			
Power Steering Pump Bracket Stud to Engine 20 N·m 15 lb ft Power Steering Pump Nut to Engine 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Power Steering Pump 50 N·m 37 lb ft Rediator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Adapter Nut 25 N·m 18 lb ft Remote Oil Filter Inlet and Outlet Hose Clip Bolt 10 N·m 89 lb in Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Check Valve Pipe Stud Nut 25 N·m 18 lb ft Secondary Air Injection (AIR) Reactor Pipe Bracket Nut 41 N·m 37 lb ft Spark Plug • Initial Installation - NEW Cylinder Head 30 N·m 22 lb ft • All Subsequent Installations 15 N·m 11 lb ft Spark Plug Wire Support Bolt 51 N·m 106 lb in Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan 80 lb in Throttle Body Stud 9 N·m 80 lb in Transmission Bolt to Oil Pan 47 N·m 35 lb ft	Power Steering Pump Bracket Stud Nut		
Power Steering Pump Nut to Engine Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Engine Stud Power Steering Pump Rear Bracket Nut to Power Steering Pump So N·m 37 lb ft Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Nut Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Transmission Bolt to Oil Pan	Power Steering Pump Bracket Stud to Engine		
Power Steering Pump Rear Bracket Nut to Engine Stud 41 N·m 30 lb ft Power Steering Pump Rear Bracket Nut to Power Steering Pump 50 N·m 37 lb ft Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Nut 25 N·m 18 lb ft Remote Oil Filter Inlet and Outlet Hose Clip Bolt 10 N·m 89 lb in Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter 35 N·m 26 lb ft 80 lb in Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Check Valve Pipe Stud Nut 50 N·m 18 lb ft 10 N·m 10 lb ft 11 N·m 12 lb ft 12 N·m 13 lb ft 14 N·m 15 N·m 11 lb ft 15 N·m 11 lb ft 15 N·m 11 lb ft Spark Plug Wire Support Bolt 15 N·m 10 lb in	Power Steering Pump Nut to Engine		
Power Steering Pump Rear Bracket Nut to Power Steering Pump 50 N·m 37 lb ft Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud 36 N·m 27 lb ft Remote Oil Filter Adapter Mounting Bracket Bolt 30 N·m 22 lb ft Remote Oil Filter Adapter Nut 25 N·m 18 lb ft Remote Oil Filter Inlet and Outlet Hose Clip Bolt 10 N·m 89 lb in Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt 35 N·m 26 lb ft Remote Oil Filter Pipe Clip Bolt to Oil Pan 9 N·m 80 lb in Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine 40 N·m 29 lb ft Secondary Air Injection (AIR) Check Valve Pipe Stud Nut 25 N·m 18 lb ft Secondary Air Injection (AIR) Reactor Pipe Bracket Nut 41 N·m 37 lb ft Spark Plug • Initial Installation - NEW Cylinder Head 30 N·m 22 lb ft All Subsequent Installations 15 N·m 11 lb ft Spark Plug Wire Support Bolt 12 N·m 106 lb in Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan 80 lb in Transmission Bolt to Oil Pan 47 N·m 35 lb ft			
Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Nut Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Pine Manifold Stud An N·m Tansmission Bolt to Oil Pan 30 N·m 22 lb ft 12 N·m 106 lb in 80 lb in 70 N·m 80 lb in 71 N·m 72 lb ft 73 lb ft	Power Steering Pump Rear Bracket Nut to Power Steering Pump		
Remote Oil Filter Adapter Mounting Bracket Bolt Remote Oil Filter Adapter Nut Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan 47 N·m 35 lb ft	Radiator Inlet Hose Support Bracket Nut to Exhaust Manifold Stud		
Remote Oil Filter Adapter Nut Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head Initial Installation - NEW Cylinder Head All Subsequent Installations Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan 18 lb ft 10 N·m 80 lb in 18 lb ft 10 N·m 80 lb in 18 lb ft 10 N·m 80 lb in 18 lb ft 18 lb ft 19 N·m 10 lb in 10 N·m 80 lb in 10 N·m 80 lb in 10 N·m 80 lb in 11 lb ft 12 N·m 10 lb in 12 N·m 10 lb in 13 lb ft	Remote Oil Filter Adapter Mounting Bracket Bolt		
Remote Oil Filter Inlet and Outlet Hose Clip Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan 10 N·m 80 lb in 11 lb ft 12 N·m 80 lb in 15 N·m 80 lb in 17 N·m 80 lb in 18 lb ft 19 N·m 80 lb in 18 lb ft 19 N·m 80 lb in 18 lb ft 19 N·m 80 lb in 19 N·m 80 lb in 10 N·m 80 lb in 11 lb ft 12 N·m 80 lb in	Remote Oil Filter Adapter Nut		
Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Adapter Bolt Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head Initial Installation - NEW Cylinder Head Installation - New Cylinder Hea			
Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pipe Adapter Bolt Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan 26 lb ft 80 lb in 75 N·m 11 lb ft 12 N·m 80 lb in 80 lb in 76 N·m 80 lb in 77 N·m 80 lb in			
Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Townsission Bolt to Oil Pan	Remote Oil Filter Inlet and Outlet Hose to Remote Oil Filter Pine Adapter	33 14-111	20 ID IL
Remote Oil Filter Pipe Clip Bolt to Oil Pan Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan So Ib in Transmission Bolt to Oil Pan So Ib it	Bolt	35 N⋅m	26 lb ft
Secondary Air Injection (AIR) Check Valve Pipe Bracket Bolt to Engine Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Pan Transmission Bolt to Oil Pan Throttle Pan Throt		Q Ni.m	90 lb in
Secondary Air Injection (AIR) Check Valve Pipe Stud Nut Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan 18 lb ft 41 N·m 37 lb ft 42 lb ft 12 N·m 106 lb in 9 N·m 80 lb in 7 N·m 15 N·m 17 N·m 106 lb in 17 N·m 17 N·m 18 lb ft 18 lb ft 19 N·m 10 lb ft			
Secondary Air Injection (AIR) Reactor Pipe Bracket Nut Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Transmission Bolt to Oil Pan At N·m 37 lb ft 41 N·m 37 lb ft 37 lb ft	Secondary Air Injection (AIR) Check Valve Pine Stud Nut		
Spark Plug Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan The Initial Installation - NEW Cylinder Head 30 N·m 11 lb ft 12 N·m 106 lb in 80 lb in 7 N·m 11 lb ft 12 N·m 106 lb in 11 lb ft 12 N·m 106 lb in 12 N·m 107 lb in 108 lb in 109 N·m 109 N·m 109 lb in	Secondary Air Injection (AIR) Reactor Pine Bracket Nut		
 Initial Installation - NEW Cylinder Head All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Initial Installation - NEW Cylinder Head Initial Installation - New Medical Initial Initia	Spark Plug	41 11/111	37 ID π
All Subsequent Installations Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan All Subsequent Installations 15 N·m 11 lb ft 106 lb in 9 N·m 80 lb in 47 N·m 35 lb ft		20 N m	00.15.6
Spark Plug Wire Support Bolt Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan			
Starter Motor Wiring Harness/Transmission Cooler Pipe Bracket Bolt to Oil Pan Throttle Body Stud Transmission Bolt to Oil Pan To District Harness/Transmission Cooler Pipe Bracket Bolt to Oil 9 N·m 80 lb in 47 N·m 35 lb ft			
Pan 80 lb in Throttle Body Stud 9 N·m 80 lb in Transmission Bolt to Oil Pan 47 N·m 35 lb ft		12 N·m	106 lb in
Transmission Bolt to Oil Pan 47 N·m 35 lb ft	Pan		80 lb in
Transmission Bolt to Oil Pan 47 N·m 35 lb ft		9 N·m	80 lb in
Towns and the Control of the Control		47 N·m	
	I ransmission Cover Bolt	12 N·m	

Upper Intake Manifold Stud		
First Pass	5 N·m	44 lb in
Final Pass	9 N·m	80 lb in
Valve Lifter Pushrod Guide Bolt	16 N·m	12 lb ft
Valve Rocker Arm Bolt	30 N·m	22 lb ft
Valve Rocker Arm Cover Bolt	12 N·m	106 lb in
Water Outlet Stud	25 N·m	18 lb ft
Water Pump Bolt	45 N·m	33 lb ft

Engine Component Description 4.3L

Balance Shaft

The cast iron balance shaft is mounted in the crankcase above and in-line with the camshaft. A camshaft gear drives the gear attached to the balance shaft. The front end of the balance shaft is supported by a ball-type bearing. The rear end of the balance shaft uses a sleeve-type bearing.

Camshaft

The steel camshaft is supported by four bearings pressed into the engine block. The camshaft timing chain sprocket mounted to the front of the camshaft is driven by the crankshaft sprocket through a camshaft timing chain.

Crankshaft

The cast nodular iron crankshaft is supported by four crankshaft bearings. The number four crankshaft bearing at the rear of the engine is the end thrust bearing. The crankshaft bearings are retained by bearing caps that are machined with the engine block for proper alignment and clearances. The crankshaft position sensor reluctor ring has three lugs used for crankshaft timing and is constructed of powdered metal. The crankshaft position sensor reluctor ring has a slight interference fit onto the crankshaft and an internal keyway for correct positioning.

Cylinder Heads

The cast iron cylinder heads have one intake and one exhaust valve for each cylinder. A spark plug is located between the valves in the side of the cylinder head. The valve guides and seats are integral to the cylinder head. The 4.3L heavy duty applications have pressed in exhaust valve seats. The valve rocker arms are positioned on the valve rocker arm supports and retained by a bolt.

Engine Block

The cast iron engine block has six cylinders arranged in a V shape with three cylinders in each bank. Starting at the front side of the engine block, the cylinders in the left bank are numbered 1-3-5 and cylinders in the right bank are numbered 2-4-6 (when viewed from the rear). The firing order of the cylinders is 1-6-5-4-3-2. The cylinders are encircled by coolant jackets.

Exhaust Manifolds

The cast iron exhaust manifolds direct exhaust gases from the combustion chambers to the exhaust system. The left side exhaust manifold has a port for the EGR valve inlet pipe.

Intake Manifold

The intake manifold is a two-piece design. The upper portion is made from a composite material and the lower portion is cast aluminum. The throttle body attaches to the upper manifold. The lower manifold has an exhaust gas recirculation (EGR) port cast into the manifold for mixture. The (EGR) valve bolts into the lower intake manifold. The Central Sequential Multiport Fuel Injection system uses multiple fuel injectors to meter and distribute fuel to each engine cylinder. The Central (SFI) is retained by a bracket bolted to the lower intake manifold. The fuel meter body also houses the pressure regulator. Metal inlet and outlet fuel lines and nylon delivery tubes connect to the Central (SFI) unit. The delivery tubes independently distribute fuel to each cylinder through nozzles located at the port entrance of each manifold runner where the fuel is atomized.

Piston and Connecting Rod Assemblies

The cast aluminum pistons use two compression rings and one oil control assembly. The piston is a low friction, lightweight design with a flat top and barrel shaped skirt. The piston pins are offset 0.9 mm (0.0354 in) toward the major thrust side (right side) to reduce piston slap as the connecting rod travels from one side of the piston to the other side after a stroke. The piston pins have a floating fit in the piston and are retained by a press fit in the connecting rod. The connecting rods are forged steel. The connecting rods are machined with the rod cap installed for proper clearances and alignments.

Valve Train

Motion is transmitted from the camshaft through the hydraulic roller valve lifters and the tubular valve pushrods to the roller type valve rocker arms. The roller type valve rocker arm pivots on a needle type bearing in order to open the valve. The valve rocker arms for each bank of cylinders are mounted to a one piece valve rocker arm support. Each valve rocker arm is retained on the valve rocker arm support and the cylinder head by a bolt. The hydraulic valve lifters keep all the parts of the valve train in constant contact. Each hydraulic valve lifter acts as an automatic adjuster and maintains zero lash in the valve train. This eliminates the need for periodic valve adjustment.

Engine Cooling

Fastener Tightening Specifications

Application	Specif	ication
	Metric	English
Coolant Recovery Reservoir Nuts	8-11 N·m	6-8 lb ft
Engine Coolant Heater Cord Bolt	8 N·m	71 lb in
Engine Coolant Heater Mounting Screw	1.9 N·m	17 lb in
Engine Oil Cooler Line Clamp Bolt	10 N·m	89 lb in
Engine Oil Cooler Line to Adapter Bolt	35 N·m	26 lb ft
Engine Oil Cooler Line to Radiator Connectors	31 N·m	23 lb ft
Engine Oil Cooler Lines to Oil Filter Adapter Retaining Bolt	35 N·m	26 lb ft
Fan Clutch Assembly Nut to Water Pump Pulley Stud	56 N·m	40 lb ft
Fan Clutch Mounting Bolts	33 N·m	24 lb ft
Fan Shroud Bolts	10 N·m	89 lb in
Intake Air Duct Clamp	5 N·m	44 lb in
Remote Filter Housing Bracket to Radiator Core Support	30 N·m	22 lb ft
Remote Filter Housing to Bracket Nuts	25 N·m	18 lb ft
Steering Linkage Shield Bolts	32 N·m	24 lb ft
Throttle Body Bracket Nuts	10 N·m	89 lb in
Water Outlet Housing Bolt 2.2 L	10 N·m	89 in lb
Water Outlet Housing Bolts 4.3 L	19 N·m	14 lb ft
Water Pump Bolt 2.2L	25 N·m	18 lb ft
Water Pump Bolt and Stud 4.3L	41 N·m	30 lb ft
Water Pump Pulley Bolts	25 N·m	18 lb ft

Cooling System Description and Operation

Coolant Heater

The optional engine coolant heater (RPO K05) operates using 110-volt AC external power and is designed to warm the coolant in the engine block area for improved starting in very cold weather -29°C (-20°F). The coolant heater helps reduce fuel consumption when a cold engine is warming up. The unit is equipped with a detachable AC power cord. A weather shield on the cord is provided to protect the plug when not in use.

Cooling System

The cooling system's function is to maintain an efficient engine operating temperature during all engine speeds and operating conditions. The cooling system is designed to remove approximately one-third of the heat produced by the burning of the air-fuel mixture. When the engine is cold, the coolant does not flow to the radiator until the thermostat opens. This allows the engine to warm quickly.

Cooling Cycle

Coolant flows from the radiator outlet and into the water pump inlet. Some coolant flows from the water pump, to the heater core, then back to the water pump. This provides the passenger compartment with heat and defrost capability as the coolant warms up.

Coolant also flows from the water pump outlet and into the engine block. In the engine block, the coolant circulates through the water jackets surrounding the cylinders where it absorbs heat.

The coolant then flows through the cylinder head gasket openings and into the cylinder heads. In the cylinder heads, the coolant flows through the water jackets surrounding the combustion chambers and valve seats, where it absorbs additional heat.

From the cylinder heads, the coolant flows to the thermostat. The flow of coolant will either be stopped at the thermostat until the engine reaches normal operating temperature, or it will flow through the thermostat and into the radiator where it is cooled. At this point, the coolant flow cycle is completed.

Efficient operation of the cooling system requires proper functioning of all cooling system components. The cooling system consists of the following components:

Coolant

The engine coolant is a solution made up of a 50-50 mixture of DEX-COOL and suitable drinking water. The coolant solution carries excess heat away from the engine to the radiator, where the heat is dissipated to the atmosphere.

Radiator

The radiator is a heat exchanger. It consists of a core and two tanks. The aluminum core is a tube and fin crossflow design that extends from the inlet tank to the outlet tank. Fins are placed around the outside of the tubes to improve heat transfer to the atmosphere.

The inlet and outlet tanks are a molded, high temperature, nylon reinforced plastic material. A high temperature rubber gasket seals the tank flange edge to the aluminum core. The tanks are clamped to the core with clinch tabs. The tabs are part of the aluminum header at each end of the core.

The radiator also has a drain cock located in the bottom of the left hand tank. The drain cock unit includes the drain cock and drain cock seal.

The radiator removes heat from the coolant passing through it. The fins on the core transfer heat from the coolant passing through the tubes. As air passes between the fins, it absorbs heat and cools the coolant.

Pressure Cap

The pressure cap seals the cooling system. It contains a blow off or pressure valve and a vacuum or atmospheric valve. The pressure valve is held against its seat by a spring, which protects the radiator from excessive cooling system pressure. The vacuum valve is held against its seat by a spring, which permits opening of the valve to relieve vacuum created in the cooling system as it cools off. The vacuum, if not relieved, might cause the radiator and/or coolant hoses to collapse.

The pressure cap allows cooling system pressure to build up as the temperature increases. As the pressure builds, the boiling point of the coolant increases. Engine coolant can be safely run at a temperature much higher than the boiling point of the coolant at atmospheric pressure. The hotter the coolant is, the faster the heat transfers from the radiator to the cooler, passing air.

The pressure in the cooling system can get too high. When the cooling system pressure exceeds the rating of the pressure cap, it raises the pressure valve, venting the excess pressure.

As the engine cools down, the temperature of the coolant drops and a vacuum is created in the cooling system. This vacuum causes the vacuum valve to open, allowing outside air into the surge tank. This equalizes the pressure in the cooling system with atmospheric pressure, preventing the radiator and coolant hoses from collapsing.

Coolant Recovery System

The coolant recovery system consists of a plastic coolant recovery reservoir and overflow tube. The recovery reservoir is also called a recovery tank or expansion tank. It is partially filled with coolant and is connected to the radiator fill neck with the overflow tube. Coolant can flow back and forth between the radiator and the reservoir.

In effect, a cooling system with a coolant recovery reservoir is a closed system. When the pressure in the cooling system gets too high, it will open the pressure valve in the pressure cap. This allows the coolant, which has expanded due to being heated, is allowed to flow through the overflow tube and into the recovery reservoir. As the engine cools down, the temperature of the coolant drops and a vacuum is created in the cooling system. This vacuum opens the vacuum valve in the pressure cap, allowing some of the coolant in the reservoir to be siphoned back into the radiator. Under normal operating conditions,

no coolant is lost. Although the coolant level in the recovery reservoir goes up and down, the radiator and cooling system are kept full. An advantage to using a coolant recovery reservoir is that it eliminates almost all air bubbles from the cooling system. Coolant without bubbles absorbs heat much better than coolant with bubbles.

Air Baffles and Seals

The cooling system uses deflectors, air baffles and air seals to increase cooling system capability. Deflectors are installed under the vehicle to redirect airflow beneath the vehicle and through the radiator to increase engine cooling. Air baffles are also used to direct airflow through the radiator and increase cooling capability. Air seals prevent air from bypassing the radiator and A/C condenser, and prevent recirculation of hot air for better hot weather cooling and A/C condenser performance.

Water Pump

The water pump is a centrifugal vane impeller type pump. The pump consists of a housing with coolant inlet and outlet passages and an impeller. The impeller is mounted on the pump shaft and consists of a series of flat or curved blades or vanes on a flat plate. When the impeller rotates, the coolant between the vanes is thrown outward by centrifugal force.

The impeller shaft is supported by one or more sealed bearings. The sealed bearings never need to be lubricated. Grease cannot leak out, dirt and water cannot get in as long as the seal is not damaged or worn.

The purpose of the water pump is to circulate coolant throughout the cooling system. The water pump is driven by the crankshaft via the drive belt.

Thermostat

The thermostat is a coolant flow control component. It's purpose is to help regulate the operating temperature of the engine. It utilizes a temperature sensitive wax-pellet element. The element connects to a valve through a small piston. When the element is heated, it expands and exerts pressure against the small piston. This pressure forces the valve to open. As the element is cooled, it contracts. This contraction allows a spring to push the valve closed.

When the coolant temperature is below the rated thermostat opening temperature, the thermostat valve remains closed. This prevents circulation of the coolant to the radiator and allows the engine to warm up. After the coolant temperature reaches the rated thermostat opening temperature, the thermostat valve will open. The coolant is then allowed to circulate through the thermostat to the radiator where the engine heat is dissipated to the atmosphere. The thermostat also provides a restriction in the cooling system, after it has opened. This restriction creates a pressure difference which prevents cavitation at the water pump and forces coolant to circulate through the engine block.

Engine Oil Cooler

The engine oil cooler is a heat exchanger. It is located inside the left side end tank of the radiator. The engine oil temperature is controlled by the temperature of the engine coolant that surrounds the oil cooler in the radiator.

The engine oil pump, pumps the oil through the engine oil cooler line to the oil cooler. The oil then flows through the cooler where the engine coolant absorbs heat from the oil. The oil is then pumped through the oil cooler return line, to the oil filter, to the engine block oil system.

Transmission Oil Cooler

The transmission oil cooler is a heat exchanger. It is located inside the right side end tank of the radiator. The transmission fluid temperature is regulated by the temperature of the engine coolant in the radiator.

The transmission oil pump, pumps the fluid through the transmission oil cooler line to the transmission oil cooler. The fluid then flows through the cooler where the engine coolant absorbs heat from the fluid. The fluid is then pumped through the transmission oil cooler return line, to the transmission.

Engine Electrical

Fastener Tightening Specifications

Application	Specif	Specification		
	Metric	English		
Battery Hold Down Retainer Nut	17 N·m	13 lb ft		
Battery Negative Cable to Engine (2.2L)	12 N·m	106 lb in		
Battery Negative Cable to Engine Block Bolt (4.3L)	17 N·m	13 lb ft		
Battery Negative Cable to Engine Block Bolt (2.2L)	17 N·m	13 lb ft		
Battery Negative Cable to Frame (2.2L)	6 N·m	53 lb in		
Battery Negative Cable to Frame (4.3L)	9 N·m	80 lb in		
Battery Negative Cable to Radiator Support (2.2L)	6 N·m	53 lb in		
Battery Negative Cable to Radiator Support (4.3L)	9 N·m	80 lb in		
Battery Positive Cable Harness to Engine (4.3L)	9 N·m	80 lb in		
Battery Positive Cable Nut	6 N·m	80 lb in		
Battery Positive Cable to Generator Nut	17 N·m	13 lb ft		
Battery Positive Cable to Starter Nut	9 N·m	80 lb in		
Battery Positive Cable to Underhood Fuse Block Bolt	10 N·m	89 lb in		
Battery Terminal Bolt	15 N·m	11 lb ft		
Battery Tray Bolt	25 N·m	18 lb ft		
Differential Carrier Shield Bolt	25 N·m	18 lb ft		
Engine to Transmission Brace Bolt and Nut	50 N·m	37 lb ft		
Engine Wiring Harness to Starter	1.9 N·m	17 lb in		
Engine Wiring Harness Bracket to Generator Mounting Bracket Bolt	25 N·m	18 lb ft		
Fan Pulley Bolt (2.2L)	30 N·m	22 lb ft		
Generator Mounting Bolt (4.3L)	50 N·m	37 lb ft		
Generator Mounting Bolt - Front (2.2L)	25 N·m	18 lb ft		
Generator Mounting Bolt - Rear (2.2L)	50 N·m	37 lb ft		
Generator Mounting Brace to Air Intake Plenum Stud Nut (2.2L)	25 N·m	18 lb ft		
Generator Mounting Brace to Engine Stud Nut (2.2L)	50 N·m	37 lb ft		
Generator Mounting Brace to Generator Bolt (2.2L)	25 N·m	18 lb ft		
Generator Mounting Bracket Bolt (2.2L)	50 N⋅m	37 lb ft		
Generator Mounting Bracket Bolt and Nut (4.3L)	41 N·m	30 lb ft		
Generator Output (Bat) Terminal Nut	17 N·m	12 lb ft		
Ground Strap to Cowl Bolt	17 N·m	12 lb ft		
Ground Strap to Cowl Bolt/Nut	50 N·m	37 lb ft		
Heater Hose Bracket to Generator Bolt (4.3L)	25 N·m	18 lb ft		
Starter Motor Mounting Bolt (2.2L)	43 N m	32 lb ft		
Starter Motor Mounting Bolt (4.3L)	50 N m	37 lb ft		

Battery Usage

Орион	Catalog No.	Cold Cranking Amps (CCA)	Reserve Capacity (Minutes)	Load Test (A)	Recommended Replacement
Std (Except Bravada)	670	525	90	260	75-60
UA1 (Std Bravada - Option All Others)	674	690	90	340	75B-84

Battery Temperature vs Minimum Voltage

Estimated Temperature °F	Estimated Temperature °C	Minimum Voltage
70 or above	21 or above	9.6
50	10	9.4
32	0	9.1
15	-10	8.8
0	-18	8.5
Below 0	Below -18	8.0

Starter Motor Usage

Applications	Starter Type
2.2L (L43)	PG-260F
4.3L (L35)	PG-260G

Generator Usage


Engine	Generator Model	Option Code	Rated Output AMPS	Load Test Output AMPS
Gasoline Engine	CS130D	K60	100 A	70 A

Battery Description and Operation

Caution

Batteries produce explosive gases, contain corrosive acid, and supply levels of electrical current high enough to cause burns. Therefore, to reduce the risk of personal injury when working near a battery:

- Always shield your eyes and avoid leaning over the battery whenever possible.
- Do not expose the battery to open flames or sparks.
- Do not allow the battery electrolyte to contact the eyes or the skin. Flush immediately and thoroughly any contacted areas with water and get medical help.
- Follow each step of the jump starting procedure in order.
- Treat both the booster and the discharged batteries carefully when using the jumper cables.



The maintenance free battery is standard. There are no vent plugs in the cover. The battery is completely sealed except for two small vent holes in the side. These vent holes allow the small amount of gas that is produced in the battery to escape.

The battery has three functions as a major source of energy:

- Engine cranking
- Voltage stabilizer
- Alternate source of energy with generator overload.

The battery specification label (example below) contains information about the following:

- The test ratings
- The original equipment catalog number
- The recommended replacement model number

CATALOG NO.

1819

CCA LOAD TEST
770 380

REPLACEMENT MODEL
100 – 6YR

A battery has 2 ratings:

- Reserve capacity
- Cold cranking amperage

When a battery is replaced use a battery with similar ratings. Refer to the battery specification label on the original battery or refer to Battery Usage .

Reserve Capacity

Reserve capacity is the amount of time in minutes it takes a fully charged battery, being discharged at a constant rate of 25 amperes and a constant temperature of 27°C (80°F) to reach a terminal voltage of 10.5 V. Refer to Battery Usage for the reserve capacity rating of the original equipment battery.

Cold Cranking Amperage

The cold cranking amperage is an indication of the ability of the battery to crank the engine at cold temperatures. The cold cranking amperage rating is the minimum amperage the battery must maintain for 30 seconds at -18°C (0°F) while maintaining at least 7.2 volts. Refer to Battery Usage for the cold cranking amperage rating for this vehicle.

Circuit Description

The battery positive terminal supplies Battery Positive voltage to the under hood fuse block and the rear fuse block. The under hood fuse block provides a cable connection for the generator and a cable connection for the starter.

The battery negative terminal is connected to chassis ground G305 and supplies ground for the AD converter in the DIM.

Starting System Description and Operation

The PG-260 is a non-repairable starter motor. It has pole pieces that are arranged around the armature within the starter housing. When the solenoid windings are energized, the pull-in winding circuit is completed to ground through the starter motor. The hold-in winding circuit is completed to ground through the solenoid. The windings work together magnetically to pull in and hold in the plunger. The plunger moves the shift lever. This action causes the starter drive assembly to rotate on the armature shaft spline as it engages with the flywheel ring gear on the engine. At the same time, the plunger closes the solenoid switch contacts in the starter solenoid. Full battery voltage is then applied directly to the starter motor and it cranks the engine.

As soon as the solenoid switch contacts close, current stops flowing thorough the pull-in winding as battery voltage is now applied to both ends of the windings. The hold-in winding remains energized; its magnetic field is strong enough to hold the plunger, shift lever, starter drive assembly, and solenoid switch contacts in place to continue cranking the engine. When the engine starts, the pinion gear overrun sprag protects the armature from excessive speed until the switch is opened.

When the ignition switch is released from the CRANK position, voltage is removed from the starter solenoid S terminal. Current flows from the motor contacts through both windings to ground at the end of the hold-in winding. However, the direction of the current flow through the pull-in winding is now in the opposite direction of the current flow when the winding was first energized.

The magnetic fields of the pull-in and hold-in windings now oppose one another. This action of the windings, along with the help of the return spring, cause the starter drive assembly to disengage and the solenoid switch contacts to open simultaneously. As soon as the contacts open, the starter motor is turned off.

Charging System Description and Operation

Generator

The generator features the following major components:

- · The delta stator
- The rectifier bridge
- The rotor with slip rings and brushes
- A conventional pulley
- Dual internal fans
- The regulator

The pulley and the fan cool the slip ring and the frame.

The generator features permanently lubricated bearings. Service should only include tightening of mount components. Otherwise, replace the generator as a complete unit.

Regulator

The voltage regulator controls the rotor field current in order to limit the system voltage. When the field current is on, the regulator switches the current on and off at a rate of 400 cycles per second in order to perform the following functions:

- Radio noise control
- Obtain the correct average current needed for proper system voltage control

At high speeds, the on-time may be 10 percent with the off-time at 90 percent. At low speeds, the on-time may be 90 percent and the off-time 10 percent.

Circuit Description

The generator provides voltage to operate the vehicle's electrical system and to charge its battery. A magnetic field is created when current flows through the rotor. This field rotates as the rotor is driven by the engine, creating an AC voltage in the stator windings. The AC voltage is converted to DC by the rectifier bridge and is supplied to the electrical system at the battery terminal.

When the engine is running, the generator turn-on signal is sent to the generator from the PCM, turning on the regulator. The generator's voltage regulator controls current to the rotor, thereby controlling the output voltage. The rotor current is proportional to the electrical pulse width supplied by the regulator. When the engine is started, the regulator senses generator rotation by detecting AC voltage at the stator through an internal wire. Once the engine is running, the regulator varies the field current by controlling the pulse width. This regulates the generator output voltage for proper battery charging and electrical system operation. The generator F terminal is connected internally to the voltage regulator and externally to the PCM. When the voltage regulator detects a charging system problem, it grounds this circuit to signal the PCM that a problem exists. The PCM monitors the generator field duty cycle signal circuit. The

system voltage sense circuit receives battery positive voltage that is Hot At All Times through a fuse link that is connected to the starter motor. This voltage is used by the regulator as the reference for system voltage control.

Engine Controls

Engine Controls – 4.3L

Ignition System Specifications

Application	Specif	ication
Аррисации	Metric	English
Firing Order	1-6-5-	-4-3-2
Spark Plug Wire Resistance	1,000 oh	ms per ft
Spark Plug Torque	15 N·m	11 lb ft
Spark Plug Gap	1.52 mm	0.060 in
Spark Plug Type	R41-932 [A	

Fastener Tightening Specifications

Accelerator Cable Routing Bracket Mounting Nuts Accelerator Control Cable Bracket Mounting Studs and Nuts 12 N·m 106 lb in Accelerator Pedal Mounting Nuts Air Cleaner Adapter Stud Air Cleaner Housing Mounting Nut Air Cleaner Housing Mounting Nut Air Cleaner Housing Mounting Nut Air Cleaner Outlet Duct Hose Clamp Air Cleaner Outlet Duct Hose Clamp Air Cleaner Outlet Duct Hose Clamp Air Cleaner Outlet Duct Retaining Wingnut Camshaft Position (CMP) Sensor Screws Coolant Hose Nipple 17 N·m 13 lb in Crankshaft Position (CKP) Sensor Mounting Bolt Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt Distributor Mounting Clamp Bolt Distributor Mounting Clamp Bolt Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor Evaporative emissions (EVAP) Canister Mount Bolt Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket To Frame Bolt Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Shield Nut-Pickup 25 N·m 27 lb in Fuel Tank Shield Bolts-2-Door 11 N·m 97 lb in Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 50 N·m 18 lb ft Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 25 N·m 18 lb ft Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 50 N·m 50 N·	Application Specif		ication	
Accelerator Cable Routing Bracket Mounting Nuts Accelerator Control Cable Bracket Mounting Studs and Nuts 12 N·m 106 lb in Accelerator Pedal Mounting Nuts 9 N·m 80 lb in Air Cleaner Adapter Stud 9 N·m 80 lb in Air Cleaner Housing Mounting Nut Air Cleaner Outlet Duct Hose Clamp Air Cleaner Outlet Duct Retaining Wingnut 2 N·m 18 lb in Camshaft Position (CMP) Sensor Screws 2.2 N·m 19 lb in Coolant Hose Nipple Crankshaft Position (CKP) Sensor Mounting Bolt Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor Evaporative emissions (EVAP) Canister Mount Bolt Fuel Fill Hose Clamp Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear Fuel Pipe Bracket to Frame Bolt Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Nuts 5 N·m 31 lb in Fuel Pipe Retainer Nuts 5 N·m 11 lb ft Fuel Pipe Retainer Shield Nut-Pickup 225 N·m 18 lb ft Fuel Tank Shield bolts-2-Door Fuel Tank Shield to Frame Bolts-Pickup 11 N·m 97 lb in Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Bolts-Pickup 10 N·m 11 N·m 11 N·m 11 N·m 11 N·m 11 N·m 11 N·m 12 N·m 13 N·m 14 N·m 15 N·m 16 N·m 17 N·m 17 N·m 18 N·m 18 N·m 19 N·m 10 N·m 10 N·m 10 N·m 10 N·m 10 N·m 11 N·m 11 N·m 11 N·m 11 N·m 11 N·m 12 N·m 13 N·m 14 N·m 15 N·m 16 N·m 17 N·m 17 N·m 18 N·m 18 N·m 19 N·m 10 N·m 10 N·m 10 N·m 10 N·m 10 N·m 11 N·m			1	
Accelerator Control Cable Bracket Mounting Studs and Nuts	Accelerator Cable Routing Bracket Mounting Nuts	9 N·m		
Accelerator Pedal Mounting Nuts 9 N·m 80 lb in	Accelerator Control Cable Bracket Mounting Studs and Nuts	12 N·m		
Air Cleaner Adapter Stud 9 N·m 80 lb in Air Cleaner Outlet Duct Hose Clamp 4 N·m 35 lb in Air Cleaner Outlet Duct Retaining Wingnut 2 N·m 18 lb in Camshaft Position (CMP) Sensor Screws 2.2 N·m 19 lb in Coolant Hose Nipple 17 N·m 13 lb ft Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 2.5 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft		9 N·m		
Air Cleaner Housing Mounting Nut 10 N·m 89 lb in Air Cleaner Outlet Duct Hose Clamp 4 N·m 35 lb in Air Cleaner Outlet Duct Retaining Wingnut 2 N·m 18 lb in Camshaft Position (CMP) Sensor Screws 2.2 N·m 19 lb in Coolant Hose Nipple 17 N·m 13 lb ft Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 25 N·m 21 lb in Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb		9 N·m		
Air Cleaner Outlet Duct Hose Clamp 4 N·m 35 lb in Air Cleaner Outlet Duct Retaining Wingnut 2 N·m 18 lb in Camshaft Position (CMP) Sensor Screws 2.2 N·m 19 lb in Coolant Hose Nipple 17 N·m 13 lb ft Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Retainer Clip Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe Retainer Nuts 3 N·m 27 lb in <t< td=""><td>Air Cleaner Housing Mounting Nut</td><td>10 N·m</td><td></td></t<>	Air Cleaner Housing Mounting Nut	10 N·m		
Air Cleaner Outlet Duct Retaining Wingnut 2 N·m 18 lb in Camshaft Position (CMP) Sensor Screws 2.2 N·m 19 lb in Coolant Hose Nipple 17 N·m 13 lb ft Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 25 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Solt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 30 N·m 27 lb in Fuel Pipe Retainer Nuts 30 N·m 27 lb in		4 N·m		
Camshaft Position (CMP) Sensor Screws 2.2 N·m 19 lb in Coolant Hose Nipple 17 N·m 13 lb ft Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 25 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in	Air Cleaner Outlet Duct Retaining Wingnut			
Coolant Hose Nipple 17 N·m 13 lb ft Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 25 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket Teme Bolt 15 N·m 11 lb ft Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in	Camshaft Position (CMP) Sensor Screws			
Crankshaft Position (CKP) Sensor Mounting Bolt 9 N·m 80 lb in Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 25 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft	Coolant Hose Nipple			
Distributor Cap Screws 2.4 N·m 21 lb in Distributor Mounting Clamp Bolt 25 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-4-Door 33 N·m 24 lb ft Fuel Tank	Crankshaft Position (CKP) Sensor Mounting Bolt			
Distributor Mounting Clamp Bolt 25 N·m 18 lb ft Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Bracket to Frame Bolt 15 N·m 20 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 30 N·m 27 lb in Fuel Pipe Retainer Nuts 30 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 30 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-4-Door 30 N·m 24 lb ft	Distributor Cap Screws			
Distributor Rotor Hold Down Screws 1.9 N·m 17 lb in Engine Coolant Temperature (ECT) Sensor 20 N·m 15 lb ft Evaporative emissions (EVAP) Canister Mount Bolt 12 N·m 106 lb in Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N·m 97 lb in Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N·m 17 lb ft </td <td>Distributor Mounting Clamp Bolt</td> <td></td> <td></td>	Distributor Mounting Clamp Bolt			
Engine Coolant Temperature (ECT) Sensor Evaporative emissions (EVAP) Canister Mount Bolt Fuel Fill Hose Clamp Fuel Fill Pipe to Fill Pipe Housing Attaching Screws Fuel Pipe Bracket Bolt-Rear Fuel Pipe Bracket to Frame Bolt Fuel Pipe Bracket to Frame Bolt Fuel Pipe Fittings Fuel Pipe Ground Strap Bolt Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe to Fuel Rail Retaining Screw Fuel Pressure Regulator Bracket Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-2-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Frame Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Palt and Nut-Pickup				
Evaporative emissions (EVAP) Canister Mount Bolt Fuel Fill Hose Clamp Fuel Fill Pipe to Fill Pipe Housing Attaching Screws Fuel Pipe Bracket Bolt-Rear Fuel Pipe Bracket to Frame Bolt Fuel Pipe Bracket to Frame Bolt Fuel Pipe Fittings Fuel Pipe Ground Strap Bolt Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe to Fuel Rail Retaining Screw Fuel Pipe to Fuel Rail Retaining Screw Fuel Pressure Regulator Bracket Fuel Rail Attaching Bolts Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bult-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Put-Pickup Fuel Tank Shield Tank Shield Tank Shield to Frame Put-Pickup Fuel Tank Shield	Engine Coolant Temperature (ECT) Sensor			
Fuel Fill Hose Clamp 2.5 N·m 22 lb in Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Rail Attaching Bolts 10 N·m 89 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-4-Door 33 N·m 24 lb ft Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N·m 17 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N·m 97 lb in Fuel Tank Shield to Frame Bolts-Pickup 25 N·m 18 lb ft	Evaporative emissions (EVAP) Canister Mount Bolt			
Fuel Fill Pipe to Fill Pipe Housing Attaching Screws 1.9 N·m 17 lb in Fuel Pipe Bracket Bolt-Rear 6 N·m 53 lb in Fuel Pipe Bracket to Frame Bolt 15 N·m 11 lb ft Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N·m 97 lb in Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N·m 17 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N·m 97 lb in Fuel Tank Shield to Frame Bolts-Pickup 25 N·m 18 lb ft	Fuel Fill Hose Clamp			
Fuel Pipe Bracket Bolt-Rear Fuel Pipe Bracket to Frame Bolt Fuel Pipe Bracket to Frame Bolt Fuel Pipe Fittings Fuel Pipe Ground Strap Bolt Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe to Fuel Rail Retaining Screw Fuel Pressure Regulator Bracket Fuel Rail Attaching Bolts Fuel Rail Attaching Bolts Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-2-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup	Fuel Fill Pipe to Fill Pipe Housing Attaching Screws			
Fuel Pipe Bracket to Frame Bolt Fuel Pipe Fittings Fuel Pipe Ground Strap Bolt Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe to Fuel Rail Retaining Screw Fuel Pressure Regulator Bracket Fuel Rail Attaching Bolts Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup	Fuel Pipe Bracket Bolt-Rear			
Fuel Pipe Fittings 27 N·m 20 lb ft Fuel Pipe Ground Strap Bolt 15 N·m 11 lb ft Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Rail Attaching Bolts 10 N·m 89 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N·m 97 lb in Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N·m 24 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N·m 97 lb in Fuel Tank Shield to Frame Nut-Pickup 25 N·m 18 lb ft				
Fuel Pipe Ground Strap Bolt Fuel Pipe Retainer Clip Bolt Fuel Pipe Retainer Nuts Fuel Pipe Retainer Nuts Fuel Pipe to Fuel Rail Retaining Screw Fuel Pressure Regulator Bracket Fuel Rail Attaching Bolts Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-2-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup				
Fuel Pipe Retainer Clip Bolt 30 N·m 22 lb ft Fuel Pipe Retainer Nuts 3 N·m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Rail Attaching Bolts 10 N·m 89 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N·m 97 lb in Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N·m 17 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N·m 97 lb in Fuel Tank Shield to Frame Nut-Pickup 25 N·m 18 lb ft	Fuel Pipe Ground Strap Bolt			
Fuel Pipe Retainer Nuts 3 N⋅m 27 lb in Fuel Pipe to Fuel Rail Retaining Screw 3 N⋅m 27 lb in Fuel Pressure Regulator Bracket 3.5 N⋅m 31 lb in Fuel Rail Attaching Bolts 10 N⋅m 89 lb in Fuel Tank Front Shield Nut-Pickup 25 N⋅m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N⋅m 97 lb in Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N⋅m 17 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N⋅m 97 lb in Fuel Tank Shield to Frame Nut-Pickup 25 N⋅m 18 lb ft	Fuel Pipe Retainer Clip Bolt			
Fuel Pipe to Fuel Rail Retaining Screw 3 N·m 27 lb in Fuel Pressure Regulator Bracket 3.5 N·m 31 lb in Fuel Rail Attaching Bolts 10 N·m 89 lb in Fuel Tank Front Shield Nut-Pickup 25 N·m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N·m 97 lb in Fuel Tank Shield Bolts-4-Door 33 N·m 24 lb ft Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N·m 17 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N·m 97 lb in Fuel Tank Shield to Frame Nut-Pickup 25 N·m 18 lb ft	Fuel Pipe Retainer Nuts			
Fuel Pressure Regulator Bracket 3.5 N⋅m 31 lb in Fuel Rail Attaching Bolts 10 N⋅m 89 lb in Fuel Tank Front Shield Nut-Pickup 25 N⋅m 18 lb ft Fuel Tank Shield Bolts-2-Door 11 N⋅m 97 lb in Fuel Tank Shield Bolts-4-Door 33 N⋅m 24 lb ft Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup 23 N⋅m 17 lb ft Fuel Tank Shield to Frame Bolts-Pickup 11 N⋅m 97 lb in Fuel Tank Shield to Frame Nut-Pickup 25 N⋅m 18 lb ft				
Fuel Rail Attaching Bolts Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-2-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup	Fuel Pressure Regulator Bracket			
Fuel Tank Front Shield Nut-Pickup Fuel Tank Shield Bolts-2-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Streep Bolts and Nut-Pickup				
Fuel Tank Shield Bolts-2-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Stree Bolts and Nut-Pickup Fuel Tank Street Bolts and Nut-Pickup Fuel Tank Street Bolts and Nut-Pickup	Fuel Tank Front Shield Nut-Pickup			
Fuel Tank Shield Bolts-4-Door Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Street Bolts and Nut-Pickup	Fuel Tank Shield Bolts-2-Door			
Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Street Bolts and Nut-Pickup Fuel Tank Street Bolts and Nut-Pickup Fuel Tank Street Bolts and Nut-Pickup	Fuel Tank Shield Bolts-4-Door			
Fuel Tank Shield to Frame Bolts-Pickup Fuel Tank Shield to Frame Nut-Pickup Fuel Tank Shield to Frame Nut-Pickup 25 N·m 18 lb ft	Fuel Tank Shield to Crossmember Bolts and Nuts-Pickup			
Fuel Tank Shield to Frame Nut-Pickup 25 N·m 18 lb ft	Fuel Tank Shield to Frame Bolts-Pickup			
Fuel Took Stron Bolt and Not Did.	Fuel Tank Shield to Frame Nut-Pickup			
I TO NOTE I TO THE PARTY OF THE	Fuel Tank Strap Bolt and Nut-Pickup and 4-Door Utility	18 N·m	13 lb ft	

91 N·m	67 lb ft
	15 lb in
	31 lb ft
	27 lb in
	97 lb in
	31 lb in
	18 lb ft
	35 lb in
8 N·m	71 lb in
13 N·m	115 lb in
9.5 N·m	84 lb in
8 N·m	71 lb in
	24 lb ft
	80 lb in
25 N·m	18 lb ft
2 N·m	18 lb in
8 N·m	71 lb in
8 N·m	71 lb in
8 N·m	71 lb in
	13 N·m 9.5 N·m 8 N·m 33 N·m 9 N·m 25 N·m 2 N·m 8 N·m 8 N·m

Fuel System Specifications

Use regular unleaded gasoline rated at 87 octane or higher. It is recommended that the gasoline meet specifications which have been developed by the American Automobile Manufacturers Association (AAMA) and endorsed by the Canadian Motor Vehicle Manufacturers Association for better vehicle performance and engine protection. Gasoline meeting the AAMA specification could provide improved driveability and emission control system performance compared to other gasolines. For more information, write to: American Automobile Manufacturer's Association, 7430 Second Ave, Suite 300, Detroit MI 48202.

Be sure the posted octane is at least 87. If the octane is less than 87, you may get a heavy knocking noise when you drive. If the knocking is bad enough, the knocking can damage your engine.

If you are using fuel rated at 87 octane or higher and you hear heavy knocking, your engine needs service. But do not worry if you hear a little pinging noise when you are accelerating or driving up a hill. That is normal, and you do not have to buy a higher octane fuel to get rid of the pinging. However, if there is a heavy, constant knock, that means you have a problem.

Notice

Your vehicle was not designed for fuel that contains methanol. Do not use methanol fuel which can corrode metal parts in your fuel system and also damage plastic and rubber parts. This kind of damage would not be covered under your warranty.

If your vehicle is certified to meet California Emission Standards, indicated on the under hood emission control label, your vehicle is designed to operate on fuels that meet California specifications. If such fuels are not available in states adopting California emissions standards, your vehicle will operate satisfactorily on fuels meeting federal specifications, but emission control system performance may be affected. The malfunction indicator lamp on your instrument panel may turn ON and/or your vehicle may fail a smogcheck test. If this occurs, return to your authorized dealer for diagnosis to determine the cause of failure. In the event there is a determination that the cause of the condition is the type of fuels used, repairs may not be covered by your warranty.

Some gasolines that are not reformulated for low emissions may contain an octane-enhancing additive called methylcyclopentadienyl manganese tricarbonyl (MMT). Ask your service station operator whether or not the fuel contains MMT.

Exhaust System

Fastener Tightening Specifications

Application	Specif	Specification	
	Metric	English	
Accessory Mounting Bracket Bolts (2.2L)	30 N·m	22 lb ft	
Accessory Mounting Bracket Lower Bolt (2.2L)	50 N·m	37 lb ft	
Accessory Mounting Bracket to Cylinder Head Stud Nuts (2.2L)	50 N·m	37 lb ft	
Air Injection Pipe Nut to Exhaust Manifold Stud (2.2L)	10 N·m	89 lb in	
Catalytic Converter to Exhaust Manifold Stud Nuts (4.3L)	53 N·m	39 lb ft	
Catalytic Converter to Muffler Flange nuts (2.2L)	35 N·m	26 lb ft	
Catalytic Converter to Muffler Flange nuts (4.3L)	40 N·m	30 lb ft	
Exhaust Manifold Bolts and Stud (4.3L)		00 10 10	
First Pass	15 N·m	11 lb ft	
Final Pass	30 N·m	22 lb ft	
Exhaust Manifold Heat Shield Bolts	12 N·m	106 lb in	
Exhaust Manifold Nuts (2.2L)	13 N·m	115 lb in	
Exhaust Manifold Pipe to Catalytic Converter Flange Nuts (2.2L)	35 N·m	26 lb ft	
Exhaust Manifold Pipe to Exhaust Manifold Bolts (2.2L)	30 N·m	22 lb ft	
Hanger to Frame Bolts	17 N·m	13 lb ft	
Oil Level Indicator Tube Bolt (4.3L)	12 N·m	106 lb in	
Radiator Inlet Hose Support Bracket Nut (4.3L)	36 N·m	27 lb ft	

Exhaust System Description

Important

Use of non-OEM parts may cause driveability concerns.

The exhaust system design varies according to the model designation and the intended use of the vehicle.

In order to secure the exhaust pipe to the exhaust manifold, the exhaust system utilizes a flange and seal joint coupling. A flange and gasket coupling secures the catalytic converter assembly to the muffler assembly.

Hangers suspend the exhaust system from the underbody, allowing some movement of the exhaust system and disallowing the transfer of noise and vibration into the vehicle.

Heat shields protect the vehicle from the high temperatures generated by the exhaust system.

Resonator

Some exhaust systems are equipped with a resonator. The resonator, located either before or after the muffler, allows the use of mufflers with less back pressure. Resonators are used when vehicle characteristics require specific exhaust tuning.

Catalytic Converter

The catalytic converter is an emission control device added to the engine exhaust system in order to reduce hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx) pollutants from the exhaust gas.

The catalytic converter is comprised of a ceramic monolith substrate, supported in insulation and housed within a sheet metal shell. The substrate may be washcoated with 3 noble metals:

- Platium (Pt)
- Palladium (Pd)
- Rhodium (Rh)

The catalyst in the converter is not serviceable.

Muffler

The exhaust muffler reduces the noise levels of the engine exhaust by the use of tuning tubes. The tuning tubes create channels inside the exhaust muffler that lower the sound levels created by the combustion of the engine.

Transmission/Transaxle Description and Operation

Manual Transmission - NV 1500


Fastener Tightening Specifications

Application	Specif	Specification		
	Metric	English		
Backup Lamp Switch	37 N·m	28 lb ft		
Bearing Retainer Bolts	29 N·m	21 lb ft		
Clutch Actuator Bolt	8 N·m	71 lb in		
Clutch Housing Cover Bolts	14 N·m	10 lb ft		
Oil Drain and Fill Plugs	30 N·m	22 lb ft		
Shift Boot Screws	2 N·m	18 lb in		
Shift Housing to Transmission Bolts	20 N·m	15 lb ft		
Shift Lever Nut	48 N·m	35 lb ft		
Vehicle Speed Sensor	16 N·m	12 lb ft		
Transmission-to-Engine Studs and Bolts	47 N·m	35 lb ft		
Transmission Mount to Cross Member Nut	57 N·m	42 lb ft		
Transmission Mount to Transmission Bolts (2.2L)	45 N·m	33 lb ft		
Transmission Mount to Transmission Bolts (4.3L)	50 N·m	37 lb ft		

Lubrication Specifications

Application	Specif Metric	ication English
 Synchro-Mesh Transmission Fluid With Friction Modifier GM P/N 12377916 	2.7 l	2.9 qt

Description and Operation



NV 1500, a rugged, durable and reliable manual transmission, has 5 forward gears and 1 reverse gear. The 5th gear is an overdrive ratio.

2003 Chevrolet S-10 Restoration Kit

All gears have synchronization for clash-free shifting. To reduce gear noise, the gears are in constant helical mesh.

The NV 1500 was designed for quality in lightweight applications (175 lb ft torque and 6,000 lbs GCW). The NV 1500 also features:

- 76 mm center distance center of input shaft to center of countershaft
- Single rail shift system
- Hydrodynamic bearing for speed gears, no needle bearings

The gear and shift systems are enclosed in a 2 piece aluminum housing which consists of the following components:

- The input shaft
- The mainshaft
- The mainshaft gears
- The countershaft
- The reverse idler gear
- The shift forks
- The shift shaft components

The NV 1500 transmission is used in trucks with the 2.2L engine.

Manual Transmission - NV 3500


Fastener Tightening Specifications

Application	Specif	Specification	
• • • • • • • • • • • • • • • • • • • •	Metric	English	
Backup Lamp Switch	37 N·m	27 lb ft	
Clutch Actuator Bolt	8 N·m	71 lb in	
Clutch Housing Cover Bolts	14 N·m	10 lb ft	
Front Bearing Retainer Bolts	14 N·m	10 lb ft	
Oil Drain and Fill Plugs	30 N·m	22 lb ft	
Shift Boot Screws	2 N·m	18 lb in	
Shift Housing to Transmission Bolts	20 N·m	15 lb ft	
Shift Lever Adjusting Nut	48 N·m	35 lb ft	
Transmission-to-Engine Studs and Bolts	47 N·m	35 lb ft	
Transmission Mount Bolt	50 N·m	37 lb ft	
Transmission Mount Nut	50 N·m	33 lb ft	
Transmission Mount to Crossmember Nut	57 N·m	42 lb ft	
Transmission Mount to Transmission Bolt	50 N·m	37 lb ft	
Vehicle Speed Sensor Bolt	16 N·m	12 lb ft	

Lubrication Specifications

Application	Specif Metric	ication English
New Venture Gear NV3500 Manual Transmission Recommended Lubricant: Synchromesh Transmission Fluid GM P/N 12345349		2.2 quarts

Description



The New Venture Gear NV 3500 is a 5 speed manual transmission used on light duty trucks with the 4.3L engine. The NV 3500 is identified by RPO M50 and RPO MG5. The difference between the RPO codes is the first speed gear ratios that the transmission has. The shift assembly design inside the NV 3500 transmission installed on C/K trucks is different than the NV 3500 transmissions installed in smaller S/T trucks. The distance between the input shaft and the countershaft is 85 mm (0.132 in). The transmission is available in rear wheel drive and four wheel drive.

The transmission has the following features:

- Constant mesh helical gearing for reduced noise
- A 2 piece aluminum housing
- Synchronized shifting in all forward gears
- A shift tower mounted shift lever
- Single rail shift system

Hydraulic Clutch

Fastener Tightening Specifications

Application	Specification	
	Metric	English
Clutch Housing Cover Bolts	14 N·m	10 lb ft
Clutch Pedal Bolt and nut	25 N·m	19 lb ft
Clutch Plate to Flywheel Bolts NV 1500	44 N·m	33 lb ft
Clutch Plate to Flywheel Bolts NV 3500	40 N·m	29 lb ft
Concentric Slave Cylinder Bolts	8 N·m	71 lb in

Hydraulic Clutch Description

The S/T model vehicle uses two different clutch variations.

4.3L Clutch

The 4.3L clutch system is described as the following:

- Size 280 mm (11 in)
- Clutch pressure plate Diaphragm spring plate, non-self adjusting
- Clutch disc Damper spring style
- Hydraulic system

2.2L Clutch

The 2.2L clutch system is described as the following:

- Size 232 mm (9 in)
- Clutch pressure plate Diaphragm spring plate, non-self adjusting
- Clutch disc Damper spring style
- Hydraulic system

Clutch Driving Members

The clutch driving members are 2 flat surfaces machined to a smooth finish:

- The rear face of the engine flywheel
- The front face of the clutch pressure plate

Clutch Driven Members

The driven member is the clutch driven plate. The clutch driven plate has a splined hub. The splined hub slides lengthwise along the splines of the input shaft. The splined hub drives the input shaft through these same splines. The driving and driven members are held together with a spring pressure. This pressure is exerted by a diaphragm spring in the clutch pressure plate.

Hydraulic Clutch Fluid

Notice: Do not use mineral or paraffin-base oil in the clutch hydraulic system. These fluids may damage the rubber parts in the cylinders.

When refilling the system or adding fluid after service, use GM Delco Supreme No. 2 Brake Fluid, or equivalent that meets DOT 3 specifications.

Hydraulic Clutch Operating Members

The clutch system consists of the following components:

- A master cylinder with a reservoir
- A switch
- A concentric slave cylinder connected to hydraulic tubing
- A pressure plate
- A clutch cover
- Diaphragm springs
- A release bearing
- A clutch disc
- Torsional springs

With the depression of the clutch pedal, the clutch master cylinder becomes pressurized from the force of the push rod into the master cylinder. This forces hydraulic fluid into the tubing from the master cylinder to the concentric slave cylinder. The concentric slave cylinder then engages by pushing the releasing bearing into the diaphragm spring and release the clutch. A hole in the cowl panel accommodates the master cylinder. A quick connect coupling helps route the hydraulic tubing, the concentric slave cylinder is inside the transmission and on the input bearing retainer. The hydraulic control system can be replaced without having to gain access to the clutch system internal components, simply engage the quick connect coupling mounted through the transmission housing. No adjustments to the clutch system are necessary. As the clutch wears, the fluid level in the master cylinder reservoir changes to compensates for clear wear. A new system will have fluid in the reservoir. An electrical switch on the push rod has 2 functions. One function is a clutch interlock, ensuring the engine does not start unless the clutch pedal is engaged (positioned to the floor). The second function is to cut off the cruise-control system (if so equipped) when the clutch pedal is engaged.

Automatic Transmission - 4L60-E

Fastener Tightening Specifications

Application	Specification	
	Metric	English
Accumulator Cover to Case Bolt	8.0-14.0 N·m	6-10 lb ft
Case Extension to Case Bolt	42.0-48.0 N·m	31-35 lb ft
Case Extension to Case Bolt (4WD Shipping)	11.2-22.6 N·m	8.3-16.7 lb ft
Converter Cover Bolt	10 N·m	89 lb in
Converter Housing to Case Screw	65.0-75.0 N·m	48-55 lb ft
Cooler Pipe Connector	35.0-41.0 N·m	26-30 lb ft
Detent Spring to Valve Body Bolt	20.0-27.0 N·m	15-20 lb ft
Floorshift Control Bolt	10 N·m	89 lb in
Flywheel to Torque Converter Bolt	63 N·m	46 lb ft
Forward Accumulator Cover to Valve Body Bolt	8.0-14.0 N·m	6-10 lb ft
Heat Shield to Transmission Bolt	17 N·m	13 lb ft
Line Pressure Plug	8.0-14.0 N·m	6-10 lb ft
Manual Shaft to Inside Detent Lever Nut	27.0-34.0 N·m	20-25 lb ft
Negative Battery Cable Bolt	15 N·m	11 lb ft
Oil Level Indicator Bolt	47 N·m	35 lb ft
Oil Pan to Transmission Case Bolt	11 N·m	97 lb in
Oil Passage Cover to Case Bolt	8-14.0 N·m	6-10 lb ft
Park Brake Bracket to Case Bolt	27.0-34.0 N·m	20-25 lb ft
Park/Neutral Position Switch Screw	3 N·m	27 lb in
Plate to Case Bolt (Shipping)	27.0-34.0 N·m	20-25 lb ft
Plate to Converter Bolt (Shipping)	27.0-34.0 N·m	20-25 lb ft
Plug Assembly, Automatic Transmission Oil Pan (C/K)	30-40 N·m	22.1-29.5 lb ft
Plug Assembly, Automatic Transmission Oil Pan (Y)	28-32 N·m	20.7-23.6 lb ft
Pressure Control Solenoid Bracket to Valve Body Bolt 8 0-14 0 N·m 6-10 IV		6-10 lb ft
Pump Assembly to Case Bolt	26.0-32.0 N·m	19-24 lb ft
Pump Cover to Pump Body Bolt	20.0-27.0 N·m	15-20 lb ft
Shift Cable Grommet Screw	1.7 N·m	15 lb in
Shift Control Cable Attachment	20 N·m	15 lb ft
Speed Sensor Retainer Bolt	10.5-13.5 N·m	7.7-10 lb ft
Stud, Automatic Transmission Case Extension (Y-car)	18.0-22.0 N·m	13-16 lb ft
TCC Solenoid Assembly to Case Bolt	8.0-14.0 N·m	6-10 lb ft
Trans Mount to Transmission Bolt	25 N·m	18 lb ft
Transmission Fluid Pressure Manual Valve Position Switch to		
Valve Body Bolt	8.0-14.0 N·m	6-10 lb ft
Transmission Oil Cooler Pipe Fitting	35.0-41.0 N·m	26-30 lb ft
Transmission Oil Pan to Case Bolt	9.5-13.8 N·m	7-10 lb ft
Transmission to Engine Bolt	47 N·m	35 lb ft
Valve Body to Case Bolt	8.0-14.0 N·m	6-10 lb ft

Transmission General Specifications

- Tanelineolon Concrat Opcomodations			
Name	Hydra-matic 4L60-E		
RPO Codes	M30		
	Toledo, Ohio		
Production Location	Romulus, MI		
	Ramos Arizpe, Mexico		
Vehicle Platform (Engine/Transmission) Usage	S/T		
Transmission Drive	Longitudinally-Mounted Rear Wheel		
	Drive		
1st Gear Ratio	3.059:1		
2nd Gear Ratio	1.625:1		
3rd Gear Ratio	1.000:1		
4th Gear Ratio	0.696:1		
Reverse	2.294:1		
Torque Converter Size (Diameter of Torque Converter Turbine)	245 mm		
	298 mm		
Pressure Taps	Line Pressure		
Transmission Fluid Type	DEXRON® III		
	245 mm Converter		
Transmission Fluid Capacity (Approximate)	Dry: 8.3 I (8.8 qt)		
Transmission Fluid Capacity (Approximate)	298 mm Converter		
	Dry: 11.25 l (11.9 qt)		
Transmission Type: 4	Four Forward Gears		
Transmission Type: L	Longitudinal Mount		
Transmission Type: 60	Product Series		
Transmission Type: E	Electronic Controls		
Position Quadrant	P, R, N, Overdrive, D, 2, 1		
	P, R, N, Overdrive, 3, 2, 1		
Case Material	Die Cast Aluminum		
	245 mm Converter		
Transmission Weight Dry (Approximate)	65.4 kg (144.30 lb)		
Transmission Weight Dry (Approximate)	298 mm Converter		
	70.5 kg (155.70 lb)		
	245 mm Converter		
Transmission Weight Wet (Approximate)	72.4 kg (159.55 lb)		
The second troight trot (reproximate)	298 mm Converter		
	80.5 kg (176.16 lb)		
Maximum Trailer Towing Capacity	6 130 kg (13,500 lb)		
Maximum Gross Vehicle Weight (GVW)	3 900 kg (8,600 lb)		

Fluid Capacity Specifications

Application	Specification	
Application	Metric	English
Bottom Pan Removal	4.7 liters	5 quarts
Complete Overhaul	10.6 liters	11 quarts
(measurements are approximation)	ate)	

Transmission Component and System Description

The 4L60E transmission consists primarily of the following components:

- Torque converter assembly
- Servo assembly and 2-4 band assembly
- Reverse input clutch and housing
- Overrun clutch
- Forward clutch
- 3-4 clutch
- Forward sprag clutch assembly
- Lo and reverse roller clutch assembly
- Lo and reverse clutch assembly
- Two planetary gear sets: Input and Reaction
- Oil pump assembly
- Control valve body assembly

The electrical components of the 4L60-E are as follows:

- 1-2 and 2-3 shift solenoid valves
- 3-2 shift solenoid valve assembly
- Transmission pressure control (PC) solenoid
- Torque converter clutch (TCC) solenoid valve
- TCC pulse width modulation (PWM) solenoid valve
- Automatic transmission fluid pressure (TFP) manual valve position switch
- Automatic transmission fluid temperature (TFT) sensor
- Vehicle speed sensor assembly

Adapt Function

Transmission Adapt Function

The 4L60-E transmission uses a line pressure control system, which has the ability to continuously adapt the system's line pressure. This compensates for normal wear of the following parts:

- The clutch fiber plates
- The seals
- The springs

The PCM maintains the Upshift Adapt parameters for the transmission The PCM monitors the AT ISS sensor and the AT OSS during commanded shifts in order to determine if a shift is occurring too fast or too slow. The PCM adjusts the signal from the transmission pressure control solenoid in order to maintain a set shift feel.

Transmission adapts must be reset whenever the transmission is overhauled or replaced.

Automatic Transmission Shift Lock Control Description

The automatic transmission shift lock control is a safety device that prevents an inadvertent shift out of PARK when the ignition is ON. The driver must press the brake pedal before moving the shift lever out of the PARK position. The system consist of the following components:

- The automatic transmission shift lock control solenoid.
- The automatic transmission shift lock control switch.
- The park/neutral position switch.

With the ignition in the ON position battery positive voltage is supplied to the park/neutral position switch. With the transmission in the PARK position the contacts in the park/neutral position switch are closed. This allows current to flow through the switch to the automatic transmission shift lock control switch. The circuit continues through the normally-closed switch to the automatic transmission shift lock control

solenoid. The automatic transmission shift lock control solenoid is permanently grounded. This energizes the automatic transmission shift lock control solenoid, locking the shift linkage in the PARK position. When the driver presses the brake pedal the contacts in the automatic transmission shift lock control switch open, causing the automatic transmission shift lock control solenoid to release. This allows the shift lever to move from the PARK position.

This page intentionally left blank.

Abbreviations and Meanings

Abbreviation	Meaning
	A
Α	Ampere(s) .
ABS	Antilock Brake System
A/C	Air Conditioning
AC	Alternating Current
ACC	Accessory, Automatic Climate Control
ACL	Air Cleaner
ACR4	Air Conditioning Refrigerant, Recovery, Recycling, Recharging
AD	Automatic Disconnect
A/D	Analog to Digital
ADL	Automatic Door Lock
A/F	Air/Fuel Ratio
AH	Active Handling
AIR	Secondary Air Injection
ALC	Automatic Level Control, Automatic Lamp Control
AM/FM	Amplitude Modulation/Frequency Modulation
Ant	Antenna
AP	Accelerator Pedal
APCM	Accessory Power Control Module
API	American Petroleum Institute
APP	Accelerator Pedal Position
APT	Adjustable Part Throttle
ASM	Assembly, Accelerator and Servo Control Module
ASR	Acceleration Slip Regulation
A/T	Automatic Transmission/Transaxle
ATC	Automatic Transfer Case, Automatic Temperature Control
ATDC	After Top Dead Center
ATSLC	Automatic Transmission Shift Lock Control
Auto	Automatic
avg	Average
A4WD	Automatic Four-Wheel Drive
AWG	American Wire Gage
	B
B+	Battery Positive Voltage
BARO	Barometric Pressure
BATT	Battery
BBV	Brake Booster Vacuum
BCA	Bias Control Assembly
BCM	Body Control Module
BHP	Brake Horsepower
BLK	Black
BLU	Blue
BP	Back Pressure
BPCM	Battery Pack Control Module
BPMV	Brake Pressure Modulator Valve
BPP	Brake Pedal Position
BRN	Brown

BTDC	Before Top Dead Center
BTM	Battery Thermal Module
BTSI	Brake Transmission Shift Interlock
Btu	British Thermal Units
	C
°C	Degrees Celsius
CAC	Charge Air Cooler
CAFE	Corporate Average Fuel Economy
Cal	Calibration
Cam	Camshaft
CARB	California Air Resources Board
CC	Coast Clutch
cm ³	Cubic Centimeters
CCM	Convenience Charge Module, Chassis Control Module
CCOT	Cycling Clutch Orifice Tube
CCP	Climate Control Panel
CD	Compact Disc
CE	Commutator End
CEAB	Cold Engine Air Bleed
CEMF	Counter Electromotive Force
CEX	Cabin Exchanger
cfm	Cubic Feet per Minute
cg	Center of Gravity
CID	Cubic Inch Displacement
CKP	Crankshaft Position
CKT	Circuit
C/Ltr	Cigar Lighter
CL	Closed Loop
CLS	Coolant Level Switch
CMC	Compressor Motor Controller
CMP	Camshaft Position
CNG	Compressed Natural Gas
СО	Carbon Monoxide
CO2	Carbon Dioxide
Coax	Coaxial
СОММ	Communication
Conn	Connector
CPA	Connector Position Assurance
CPP	Clutch Pedal Position
CPS	Central Power Supply
CPU	Central Processing Unit
CRT	Cathode Ray Tube
CRTC	Cathode Ray Tube Controller
CS	Charging System
CSFI	Central Sequential Fuel Injection
CTP	Closed Throttle Position
cu ft	Cubic Foot/Feet
cu in	Cubic Inch/Inches
CV	Constant Velocity Joint
CVRSS	Continuously Variable Road Sensing Suspension

Cyl	Cylinder(s)
	D
DAB	Delayed Accessory Bus
dB	Decibels
dBA	Decibels on A-weighted Scale
DC	Direct Current, Duty Cycle
DCM	Door Control Module
DE	Drive End
DEC	Digital Electronic Controller
DERM	Diagnostic Energy Reserve Module
DI	Distributor Ignition
dia	Diameter
DIC	Driver Information Center
Diff	Differential
DIM	Dash Integration Module
DK	Dark
DLC	Data Link Connector
DMCM	Drive Motor Control Module
DMM	Digital Multimeter
DMSDS	Drive Motor Speed and Direction Sensor
DMU	Drive Motor Unit
DOHC	Dual Overhead Camshafts
DR, Drvr	Driver
DRL	Daytime Running Lamps
DTC	Diagnostic Trouble Code
	E
EBCM	Electronic Brake Control Module
EBTCM	Electronic Brake and Traction Control Module
EC	Electrical Center, Engine Control
ECC	Electronic Climate Control
ECI	Extended Compressor at Idle
ECL	Engine Coolant Level
ECM	Engine Control Module, Electronic Control Module
ECS	Emission Control System
ECT	Engine Coolant Temperature
EEPROM	Electrically Erasable Programmable Read Only Memory
EEVIR	Evaporator Equalized Values in Receiver
EFE	Early Fuel Evaporation
EGR	Exhaust Gas Recirculation
EGR TVV	Exhaust Gas Recirculation Thermal Vacuum Valve
EHPS	Electro-Hydraulic Power Steering
El	Electronic Ignition
ELAP	Elapsed
ELC	Electronic Level Control
E/M	English/Metric
EMF	Electromotive Force
EMI	Electromagnetic Interference
Eng	Engine
EOP	Engine Oil Pressure
EOT	Engine Oil Temperature

EPA	Environmental Protection Assured
EPR	Environmental Protection Agency
EPROM	Exhaust Pressure Regulator
ESB	Erasable Programmable Read Only Memory
	Expansion Spring Brake
ESC	Electronic Suspension Control
ESD	Electrostatic Discharge
ESN	Electronic Serial Number
ETC	Electronic Throttle Control, Electronic Temperature Control, Electronic Timing
FTOO	Control
ETCC	Electronic Touch Climate Control
ETR	Electronically Tuned Receiver
ETS	Enhanced Traction System
EVAP	Evaporative Emission
EVO	Electronic Variable Orifice
Exh	Exhaust
	F
°F	Degrees Fahrenheit
FC	Fan Control
FDC	Fuel Data Center
FED	Federal All United States except California
FEDS	Fuel Enable Data Stream
FEX	Front Exchanger
FF	Flexible Fuel
FFH	Fuel-Fired Heater
FI	Fuel Injection
FMVSS	Federal U.S. Motor Vehicle Safety Standards
FP	Fuel Pump
ft	Foot/Feet
FT	Fuel Trim
F4WD	Full Time Four-Wheel Drive
4WAL	Four-Wheel Antilock
4WD	Four-Wheel Drive
FW	Flat Wire
FWD	Front Wheel Drive, Forward
1 44 5	
	G
g CA	Grams, Gravitational Acceleration
GA	Gage, Gauge
gal	Gallon
gas	Gasoline
GCW	Gross Combination Weight
Gen	Generator
GL	Gear Lubricant
GM	General Motors
GM SPO	General Motors Service Parts Operations
gnd	Ground
gpm	Gallons per Minute
GRN	Green
GRY	Gray
GVWR	Gross Vehicle Weight Rating

	H
Н	Hydrogen
H2O	Water
Harn	Harness
HC	Hydrocarbons
H/CMPR	High Compression
HD	Heavy Duty
HDC	Heavy Duty Cooling
hex	Hexagon, Hexadecimal
Hg	Mercury
Hi Alt	High Altitude
HO2S	Heated Oxygen Sensor
hp	Horsepower
HPL	High Pressure Liquid
HPS	High Performance System
HPV	High Pressure Vapor
HPVS	Heat Pump Ventilation System
Htd	Heated
HTR	Heater
HUD	Head-up Display
HVAC	Heater-Ventilation-Air Conditioning
HVACM	Heater-Vent-Air Conditioning Module
HVIL	High Voltage Interlock Loop
HVM	Heater Vent Module
Hz	Hertz
	1
IAC	Idle Air Control
IAT	Intake Air Temperature
IC	Integrated Circuit, Ignition Control
ICCS	Integrated Chassis Control System
ICM	Ignition Control Module
ID	Identification, Inside Diameter
IDI	Integrated Direct Ignition
IGBT	Insulated Gate Bi-Polar Transistor
ign	Ignition
ILC	Idle Load Compensator
in	Inch/Inches
INJ	Injection
inst	Instantaneous, Instant
IP	Instrument Panel
IPC	Instrument Panel Cluster
IPM	Instrument Panel Module
I/PEC	Instrument Panel Electrical Center
ISC	Idle Speed Control
ISO	International Standards Organization
ISS	Input Speed Shaft, Input Shaft Speed
POOR SERVICE OF SERVIC	Impar opeca orian, input orian opeca
	ra erre reas de reas de la compacta del la compacta de la compacta del la compacta de la compacta del la compacta de la compacta del la compacta del la compacta del la com
KAM	
KAM KDD	Keep Alive Memory Keyboard Display Driver

kHz	Kilohertz
km	Kilometer
km/h	Kilometers per Hour
km/l	Kilometers per Liter
kPa	Kilopascals
KS	Knock Sensor
kV	Kilovolts
L	Liter
L4	Four Cylinder Engine, In-Line
L6	Six-Cylinder Engine, In-Line
lb	Pound
lb ft	Pound Feet Torque
lb in	Pound Inch Torque
LCD	Liquid Crystal Display
LDCL	Left Door Closed Locking
LDCM	Left Door Control Module
LDM	Lamp Driver Module
LED	Light Emitting Diode
LEV	Low Emissions Vehicle
LF	Left Front
lm	Lumens
LR	Left Rear
LT	Left
LT	Light
LT	Long Term
LTPI	Low Tire Pressure Indicator
LTPWS	Low Tire Pressure Warning System
	M
MAF	Mass Air Flow
Man	Manual
MAP	Manifold Absolute Pressure
MAT	Manifold Absolute Temperature
max	Maximum
M/C	Mixture Control
MDP	Manifold Differential Pressure
MFI	Multiport Fuel Injection
mi	Miles
MIL	Malfunction Indicator Lamp
min	Minimum
MIN	Mobile Identification Number
mL mm	Milliter
mm	Millimeter
mpg	Miles per Gallon
mph	Miles per Hour
ms MST	Millisecond Manifold Surface Temporature
MSVA	Manifold Surface Temperature
M/T	Magnetic Steering Variable Assist, Magnasteer® Manual Transmission/Transaxle
MV	Megavolt
141 A	INCHARCE

NAES North American Export Sales NC Normally Closed NEG Negative Neu Neutral NI Neutral Idle NiMH Nickel Metal Hydride NLGI National Lubricating Grease Institute N'm Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORS ORD Orange ORV Orange ORVR On-Board Refueling Vapor Recovery OZ Ounce(s)	mV	Millivolt
NC Normally Closed NEG Negative Neu Neutral NI Neutral Idle NiMH Nickel Metal Hydride NLGI National Lubricating Grease Institute N-m Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed		$oldsymbol{N}$
NC Normally Closed NEG Negative Neu Neutral NI Neutral Idle NiMH Nickel Metal Hydride NLGI National Lubricating Grease Institute N·m Newton-meter Torque NO Normally Open NOC Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NAES	North American Export Sales
Neu Neutral Idle NI Neutral Idle NiMH Nickel Metal Hydride NLGI National Lubricating Grease Institute N·m Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD II On-Board Diagnostics OBD III On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NC	
Neu Neutral Idle NII Neutral Idle NIMH Nickel Metal Hydride NLGI National Lubricating Grease Institute N-m Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohm Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NEG	
NiMH Nickel Metal Hydride NLGI National Lubricating Grease Institute N·m Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	Neu	
NLGI National Lubricating Grease Institute N·m Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NI	Neutral Idle
N·m Newton-meter Torque NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O Oxygen O2 Oxygen O3 Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NiMH	Nickel Metal Hydride
NO Normally Open NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O Oxygen O2 Oxygen O3 Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NLGI	National Lubricating Grease Institute
NOX Oxides of Nitrogen NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	N·m	Newton-meter Torque
NPTC National Pipe Thread Coarse NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic	NO	Normally Open
NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NOx	Oxides of Nitrogen
NPTF National Pipe Thread Fine NOVRAM Non-Volatile Random Access Memory O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NPTC	National Pipe Thread Coarse
O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NPTF	
O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	NOVRAM	
O2 Oxygen O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed		
O2S Oxygen Sensor OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	02	
OBD On-Board Diagnostics OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	O2S	
OBD II On-Board Diagnostics Second Generation OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OBD	
OC Oxidation Converter Catalytic OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OBD II	
OCS Opportunity Charge Station OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OC	
OD Outside Diameter ODM Output Drive Module ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft Ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	ocs	
ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OD	
ODO Odometer OE Original Equipment OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	ODM	Output Drive Module
OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	ODO	
OEM Original Equipment Manufacturer OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OE	Original Equipment
OHC Overhead Camshaft ohms Ohm OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OEM	
OL Open Loop, Out of Limits ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OHC	
ORC Oxidation Reduction Converter Catalytic ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	ohms	Ohm
ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	OL	Open Loop, Out of Limits
ORN Orange ORVR On-Board Refueling Vapor Recovery OSS Output Shaft Speed	ORC	Oxidation Reduction Converter Catalytic
OSS Output Shaft Speed	ORN	
OSS Output Shaft Speed	ORVR	On-Board Refueling Vapor Recovery
oz Ounce(s)	OSS	Output Shaft Speed
	OZ	Ounce(s)
P		P
PAG Polyalkylene Glycol	PAG	Polyalkylene Glycol
PAIR Pulsed Secondary Air Injection	PAIR	
PASS, PSGR Passenger	PASS, PSGR	
PASS-Key® Personalized Automotive Security System		
P/B Power Brakes	P/B	
PC Pressure Control	PC	Pressure Control
PCB Printed Circuit Board	PCB	Printed Circuit Board
PCM Powertrain Control Module	PCM	Powertrain Control Module
PCS Pressure Control Solenoid	PCS	Pressure Control Solenoid
PCV Positive Crankcase Ventilation	PCV	Positive Crankcase Ventilation
PEB Power Electronics Bay	PEB	Power Electronics Bay
PID Parameter Identification	PID	Parameter Identification
PIM Power Inverter Module	PIM	Power Inverter Module
PM Permanent Magnet Generator	PM	Permanent Magnet Generator

P/N	Part Number
PNK	Pink
PNP	Park/Neutral Position
PRNDL	Park, Reverse, Neutral, Drive, Low
POA	Pilot Operated Absolute Valve
POS	Positive, Position
POT	Potentiometer Variable Resistor
PPL	Purple
ppm	Parts per Million
PROM	Programmable Read Only Memory
P/S, PS	Power Steering
PSCM	
PSD	Power Steering Control Module, Passenger Seat Control Module Power Sliding Door
PSP	Power Steering Pressure
psi	Pounds per Square Inch
psia	Pounds per Square Inch Pounds per Square Inch Absolute
psig	Pounds per Square Inch Absolute Pounds per Square Inch Gauge
pt	Pint
PTC	Positive Temperature Coefficient
PWM	Pulse Width Modulated
QDM	Q
qt	Quad Driver Module
- qı	Quart(s)
D 40	R
R-12 R-134a	Refrigerant-12
R-134a RAM	Refrigerant-134a
RAIVI	Random Access Memory, Non-permanent memory device, memory contents are lost
RAP	when power is removed. Retained Accessory Power
RAV	Remote Activation Verification
RCDLR	Remote Control Door Lock Receiver
RDCM	Right Door Control Module
Ref	Reference
Rev	Reverse
REX	Rear Exchanger
RIM	Rear Integration Module
RF	Right Front, Radio Frequency
RFA	Remote Function Actuation
RFI	Radio Frequency Interference
RH	Right Hand
RKE	Remote Keyless Entry
Rly	Relay
ROM	Read Only Memory, Permanent memory device, memory contents are retained when
	power is removed.
RPM	Revolutions per Minute Engine Speed
RPO	Regular Production Option
RR	Right Rear
RSS	Road Sensing Suspension
RTD	Real Time Damping
RT	Right

RTV	Room Temperature Vulcanizing Sealer
RWAL	Rear Wheel Antilock
RWD	Rear Wheel Drive
	S
S	Second(s)
SAE	Society of Automotive Engineers
SC	Supercharger
SCB	Supercharger Bypass
SCM	Seat Control Module
SDM	Sensing and Diagnostic Module
SEO	Special Equipment Option
SFI	Sequential Multiport Fuel Injection
SI	System International Modern Version of Metric System
SIAB	Side Impact Air Bag
SIR	Supplemental Inflatable Restraint
SLA	Short/Long Arm Suspension
sol	Solenoid
SO2	Sulfur Dioxide
SP	Splice Pack
S/P	Series/Parallel
SPO	Service Parts Operations
SPS	Service Programming System, Speed Signal
sq ft, ft²	Square Foot/Feet
sq in, in²	Square Inch/Inches
SRC	Service Ride Control
SRI	Service Reminder Indicator
SRS	Supplemental Restraint System
SS	Shift Solenoid
ST	Scan Tool
STID	Station Identification Station ID
S4WD	Selectable Four-Wheel Drive
Sw	Switch
SWPS	Steering Wheel Position Sensor
syn	Synchronizer
	T
TAC	Throttle Actuator Control
Tach	Tachometer
TAP	Transmission Adaptive Pressure, Throttle Adaptive Pressure
TBI	Throttle Body Fuel Injection
TC	Turbocharger, Transmission Control
TCC	Torque Converter Clutch
TCS	Traction Control System
TDC	Top Dead Center
TEMP	Temperature
Term	Terminal
TFP	Transmission Fluid Pressure
TFT	Transmission Fluid Temperature
THM	Turbo Hydro-Matic
TIM	Tire Inflation Monitoring, Tire Inflation Module
TOC	Transmission Oil Cooler

TD	
TP	Throttle Position
TPA	Terminal Positive Assurance
TPM	Tire Pressure Monitoring, Tire Pressure Monitor
TR	Transmission Range
TRANS	Transmission/Transaxle
TT	Tell Tail Warning Lamp
TV	Throttle Valve
TVRS	Television and Radio Suppression
TVV	Thermal Vacuum Valve
TWC	Three Way Converter Catalytic
TWC+OC	Three Way + Oxidation Converter Catalytic
TXV	Thermal Expansion Valve
	U
UART	Universal Asynchronous Receiver Transmitter
U/H	Underhood
U/HEC	Underhood Electrical Center
U-joint	Universal Joint
UTD	Universal Theft Deterrent
UV	Ultraviolet
	· ·
V	Volt(s), Voltage
V6	Six-Cylinder Engine, V-Type
V8	Eight-Cylinder Engine, V-Type
Vac	Vacuum
VAC	Vehicle Access Code
VATS	Vehicle Anti-Theft System
VCIM	Vehicle Communication Interface Mode
VCM	Vehicle Control Module
V dif	Voltage Difference
VDOT	Variable Displacement Orifice Tube
VDV	Vacuum Delay Valve
vel	Velocity
VES	Variable Effort Steering
VF	Vacuum Fluorescent
VIO	Violet
VIN	Vehicle Identification Number
VLR	Voltage Loop Reserve
VMV	Vacuum Modulator Valve
VR	Voltage Regulator
V ref	Voltage Reference
VSES	Vehicle Stability Enhancement System
VSS	Vehicle Speed Sensor
	W
w/	With
W/B	Wheel Base
WHL	Wheel
WHT	White
w/o	Without
WOT	Wide Open Throttle
W/P	Water Pump
**/1	Tracor Fullip

W/S	Windshield
WSS	Wheel Speed Sensor
WU-OC	Warm Up Oxidation Converter Catalytic
WU-TWC	Warm Up Three-Way Converter Catalytic
	X^{-1}
X-valve	Expansion Valve
yd	Yard(s)
YEL	Yellow

This page intentionally left blank.

Conversion - English/Metric

English	Multiply/ Divide by	Metric	
order to calculate English mea	surement, divide by the number in the	center column.	
order to calculate metric meas	urement, multiply by the number in the	center column.	
	Length		
in	25.4	mm	
ft	0.3048	m	
yd	0.9144		
mi	1.609	km	
	Area		
sq in	645.2	sq mm	
	6.45	sq cm	
sq ft	0.0929	sq m	
sq yd	0.8361	. 94 III	
	Volume		
	16,387.00	cu mm	
cu in	16.387	cu cm	
	0.0164		
qt	0.9464	L	
gal	3.7854		
cu yd	0.764	cu m	
	Mass		
lb	0.4536	l	
ton	907.18	kg	
ton	0.907	tonne (t)	
	Force		
Kg F	9.807		
oz F	0.278	newtons (N)	
lb F	4.448		
	Acceleration		
ft/s²	0.3048	1-3	
In/s²	0.0254	m/s²	
	Torque		
Lb in	0.11298		
lb ft	1.3558	N·m	
	Power		
hp	0.745	kW	
	Pressure (Stress)		
inches of H2O	0.2488		
lb/sq in	6.895	kPa	
	Energy (Work)		
Btu	1055		
lb ft	1.3558	J (J= one Ws)	
kW hour	3,600,000.00		
	Light		
Foot Candle	10.764	lm/m²	

mph	1.6093	km/h
	Temperature	
(°F - 32) 5/9	=	°C
°F	=	(9/5 °C + 32)
	Fuel Performance	
235.215/mpg	=	100 km/L

Equivalents - Decimal and Metric

Fraction (in)	Decimal (in)	Metric (mm)
1/64	0.015625	0.39688
1/32	0.03125	0.79375
3/64	0.046875	1.19062
1/16	0.0625	1.5875
5/64	0.078125	1.98437
3/32	0.09375	2.38125
7/64	0.109375	2.77812
1/8	0.125	3.175
9/64	0.140625	3.57187
5/32	0.15625	3.96875
11/64	0.171875	4.36562
3/16	0.1875	4.7625
13/64	0.203125	5.15937
7/32	0.21875	5.55625
15/64	0.234375	5.95312
1/4	0.25	6.35
17/64	0.265625	6.74687
9/32	0.28125	7.14375
19/64	0.296875	7.54062
5/16	0.3125	7.9375
21/64	0.328125	8.33437
11/32	0.34375	8.73125
23/64	0.359375	9.12812
3/8	0.375	9.525
25/64	0.390625	9.92187
13/32	0.40625	10.31875
27/64	0.421875	10.71562
7/16	0.4375	11.1125
29/64	0.453125	11.50937
15/32	0.46875	11.90625
31/64	0.484375	12.30312
1/2	0.5	12.7
33/64	0.515625	13.09687
17/32	0.53125	13.49375
35/64	0.546875	13.89062
9/16	0.5625	14.2875
37/64	0.578125	14.68437
19/32	0.59375	15.08125
39/64	0.609375	15.47812
5/8	0.625	15.875
41/64	0.640625	16.27187

Fraction (in)	Decimal (in)	Metric (mm)
21/32	0.65625	16.66875
43/64	0.671875	17.06562
11/16	0.6875	17.4625
45/64	0.703125	17.85937
23/32	0.71875	18.25625
47/64	0.734375	18.65312
3/4	0.75	19.05
49/64	0.765625	19.44687
25/32	0.78125	19.84375
51/64	0.796875	20.24062
13/16	0.8125	20.6375
53/64	0.828125	21.03437
27/32	0.84375	21.43125
55/64	0.859375	21.82812
7/8	0.875	22.225
57/64	0.890625	22.62187
29/32	0.90625	23.01875
59/64	0.921875	23.41562
15/16	0.9375	23.8125
61/64	0.953125	24.20937
31/32	0.96875	24.60625
63/64	0.984375	25.00312
1	1.0	25.4

This page intentionally left blank.

Fasteners


Metric Fasteners

This vehicle provides fastener dimensions using the metric system. Most metric fasteners are approximate in diameter to equivalent English fasteners. Make replacements using fasteners of the same nominal diameter, thread pitch, and strength.

A number marking identifies the OE metric fasteners except cross-recess head screws. The number also indicates the strength of the fastener material. A Posidrive® or Type 1A cross-recess identifies a metric cross-recess screw. For best results, use a Type 1A cross-recess screwdriver, or equivalent, in Posidrive® recess head screws.

GM Engineering Standards and North American Industries have adopted a portion of the ISO-defined standard metric fastener sizes. The purpose was to reduce the number of fastener sizes used while retaining the best thread qualities in each thread size. For example, the metric M6.0 X 1 screw, with nearly the same diameter and 25.4 threads per inch replaced the English 1/4-20 and 1/4-28 screws. The thread pitch is midway between the English coarse and fine thread pitches.

Fastener Strength Identification



- 1. English Bolt, Grade 2 (Strength Class)
- 2. English Bolt, Grade 5 (Strength Class)
- 3. English Bolt, Grade 7 (Strength Class)
- 4. English Bolt, Grade 8 (Strength Class)
- 5. Metric Nut, Strength Class 9
- 6. Metric Bolts, Strength Class Increases as Numbers Increase

The most commonly used metric fastener strength property classes are 9.8 and 10.9. The class identification is embossed on the head of each bolt. The English, inch strength classes range from grade 2 to grade 8. Radial lines are embossed on the head of each bolt in order to identify the strength class. The number of lines on the head of the bolt is 2 lines less than the actual grade. For example, a grade 8 bolt will have 6 radial lines on the bolt head. Some metric nuts are marked with a single digit strength identification number on the nut face.

The correct fasteners are available through GM SPO. Many metric fasteners available in the aftermarket parts channels are designed to metric standards of countries other than the United States, and may exhibit the following:

- Lower strength
- No numbered head marking system
- Wrong thread pitch

The metric fasteners on GM products are designed to new, international standards. The following are the common sizes and pitches, except for special applications:

- M6.0 X 1
- M8 X 1.25
- M10 X 1.5
- M12 X 1.75
- M14 X 2.00
- M16 X 2.00

Prevailing Torque Fasteners

Prevailing torque fasteners create a thread interface between the fastener and the fastener counterpart in order to prevent the fastener from loosening.

All Metal Prevailing Torque Fasteners


These fasteners accomplish the thread interface by a designed distortion or deformation in the fastener.

Nylon Interface Prevailing Torque Fasteners

These fasteners accomplish the thread interface by the presence of a nylon material on the fastener threads.

Adhesive Coated Fasteners

These fasteners accomplish the thread interface by the presence of a thread-locking compound on the fastener threads. Refer to the appropriate repair procedure in order to determine if the fastener may be reused and the applicable thread-locking compound to apply to the fastener.



- 1. Prevailing Torque Nut, Center Lock Type
- 2. Prevailing Torque Nut, Top Lock Type
- 3. Prevailing Torque Nut, Nylon Patch Type
- 4. Prevailing Torque Nut, Nylon Washer Insert Type
- 5. Prevailing Torque Nut, Nylon Insert Type

- 6. Prevailing Torque Bolt, Dry Adhesive Coating Type
- 7. Prevailing Torque Bolt, Thread Profile Deformed Type
- 8. Prevailing Torque Bolt, Nylon Strip Type
- 9. Prevailing Torque Bolt, Out-of-Round Thread Area Type

A prevailing torque fastener may be reused ONLY if:

- The fastener and the fastener counterpart are clean and not damaged
- There is no rust on the fastener
- The fastener develops the specified minimum torque against its counterpart prior to the fastener seating

Metric Prevailing Torque Fastener Minimum Torque Development

Hilliam Torque Deven	- [
Specific	cation
Metric	English
l Prevailing Torque Fasteners	C
0.4 N·m	4 lb in
0.8 N·m	7 lb in
1.4 N·m	12 lb in
	19 lb in
3 N·m	27 lb in
4.2 N·m	37 lb in
7 N·m	62 lb in
10.5 N·m	93 lb in
ace Prevailing Torque Fasten	
	3 lb in
	5 lb in
	10 lb in
	13 lb in
	20 lb in
	30 lb in
	49 lb in
***	75 lb in
	Metric

English Prevailing Torque Fastener Minimum Torque Development

	onor minimum rorque beve	Siopinicité
Application	Specifi	cation
принания	Metric	English
All Meta	al Prevailing Torque Fastener	S
1/4 in	0.5 N·m	4.5 lb in
5/16 in	0.8 N·m	7.5 lb in
3/8 in	1.3 N·m	11.5 lb in
7/16 in	1.8 N·m	16 lb in
1/2 in	2.3 N·m	20 lb in
9/16 in	3.2 N·m	28 lb in
5/8 in	4 N·m	36 lb in
3/4 in	7 N·m	54 lb in
Nylon Inter	face Prevailing Torque Faster	ners
1/4 in	0.3 N·m	3 lb in
5/16 in	0.6 N·m	5 lb in
3/8 in	1 N·m	9 lb in
7/16 in	1.3 N·m	12 lb in
1/2 in	1.8 N·m	16 lb in
9/16 in	2.5 N·m	22 lb in
5/8 in	3.4 N·m	30 lb in
3/4 in	5 N·m	45 lb in

I = Included with another feature

■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
		Air bags, frontal, driver and right front passenger, includes passenger side deactivation switch	S	S	S	S
		Assist handle, front passenger	S	S	S	s
		Door trim, with integral padded armrest, driver and passenger side map pockets	S	S	S	S
	BG9	Floor covering, rubberized vinyl	S	n/a	n/a	n/a
		Instrumentation, analog, includes speedometer, odometer with trip odometer, fuel level, voltmeter, engine temperature, oil pressure and tachometer 1 - (U16) Instrumentation, tachometer included with (MW2) Transmission, 5- speed manual and (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	S ¹	S	S	S
	DC4	Mirror, inside rearview, manual day/night, includes dual reading lights	S	S	S	S
		Power outlets, auxiliary, covered, 2, 12-volt 1 - One power outlet.	S ¹	S	S	S
		Seat, passenger side rear jump (Extended Cab)	S	S	S	S
		Steering wheel, 4-spoke, deluxe, steel sleeve, includes theft-deterrent locking feature, Black	S	n/a	n/a	n/a
		Theft-deterrent system, PASSlock	S	S	S	S
	D34	Visors, padded, color-keyed	S	n/a	n/a	n/a
		Visors, padded, color-keyed and vanity mirror, passenger-side	n/a	S	S	S
		Warning tones, headlamp on, key-in-ignition, driver safety belt unfasten, turn signal on	S	S	S	S
		Windows, rear quarter swing-out (Extended Cab Models)	S	s	S	S
		Air dam, body-color 1 - Standard with (YC5) LS Trim with Exterior Appearance Package.	n/a	S ¹	n/a	S
		Air dam, Gray 1 - Air dam, body-color standard with (YC5) LS trim with Exterior Appearance Package.	S	S ¹	S	n/a
	T61	Daytime running lamps, includes automatic exterior lamp control	S	S	S	S

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and

STANDARD EQUIPMENT - 2WD

Free Flow	Ref. Only	Description .	Base		SLE	
RPO Code	RPO Code	1 - Equipment groups 1SA and 1SB available on CS10603,	1SA ¹	1SB ¹	1SC ²	1SX ²
		Door, 3rd, driver-side 1 - Standard on CS10653 Extended Cab only.	S ¹	S ¹	S¹	S¹
	ANL	Fog lamps, front, halogen, integrated into front bumper with (V4A) Xtreme Package	n/a	n/a	n/a	S
		Grille, Monochromatic, color-keyed 1 - Included with (V4A) Xtreme sport appearance package.	n/a	n/a	n/a	S ¹
		Wipers, intermittent, front, includes pulse washers	S	s	S	S .
-	K60	Alternator, 100 amps	S	S	s	s
		Battery, heavy-duty, 525 cold-cranking amps, includes rundown protection	S	S	s	S
		Brakes, 4-wheel antilock, front disc/rear drum	S	s	S	S
	C5T	GVWR , 4200 lbs. (1905 kg) (CS10603 Regular Cab, short box)	S	S	S	S
	СЗА	GVWR , 4400 lbs. (1996 kg) (CS10653 Extended Cab)	n/a	n/a	S	S
	C5D	GVWR , 4600 lbs. (2087 kg) (CS10653 Extended Cab)	S	S	n/a	n/a
	C5D	GVWR, 4600 lbs. (2087 kg) (CS10803 Regular Cab, long box with (LN2))	S	S	n/a	n/a

I = Included with another feature

■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref.	Description	Base	SLE			
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
		Air bags, frontal, driver and right front passenger, includes passenger side deactivation switch 1 - Deactivation switch not available with Crew Cab Models.	S	S	S	S ¹	
····		Assist handle, front passenger	S	S	S	S	
	DK7	Console, overhead custom, includes 2 storage compartments, garage door opener compartment, 4 map lights, dome lamp, electronic compass and outside temperature display	n/a	n/a	n/a	S	
		Door locks, child security, rear	n/a	n/a	n/a	S	
		Door trim, with integral padded armrest, driver and passenger side map pockets	S	S	S	S	
	BG9	Floor covering, rubberized vinyl	S	n/a	n/a	n/a	
		Instrumentation, analog, includes speedometer, odometer with trip odometer, fuel level, voltmeter, engine temperature, oil pressure and tachometer 1 - (U16) Instrumentation, tachometer included with (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	S¹	S	S	S	
	DC4	Mirror, inside rearview, manual day/night, includes dual reading lights 1 - Dual reading lamps are located in overhead console on Crew Cab.	S	S	S	S ¹	
		Power outlets, auxiliary, covered, 2, 12-volt 1 - One power outlet.	S ¹	S	S	S	
		Seat, passenger side rear jump (Extended Cab)	S	S	S	n/a	
		Seats, rear bench, full width, 3-passenger	n/a	n/a	n/a	S	
		Steering wheel, 4-spoke, deluxe, steel sleeve, includes theft-deterrent locking feature, Black	S	n/a	n/a	n/a	
		Theft-deterrent system, PASSlock	s	S	S	S	
	D34	Visors, padded, color-keyed	s	n/a	n/a	n/a	
		Visors, padded, color-keyed and vanity mirror, passenger-side 1 - Upgradeable to (DH6) Visors, padded, color-keyed, illuminated vanity mirrors, passenger- and driver-side.	n/a	S	S	S¹	
		Warning tones , headlamp on, key-in-ignition, driver safety belt unfasten, turn signal on	S	S	S	S	

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

STANDARD EQUIPMENT - 4WD

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
		Windows, rear quarter swing-out (Extended Cab)	S	S	S	n/a
		Air dam, body-color 1 - Air dam Spectra Gray with (ZR5) Appearance Package.	n/a	n/a	n/a	S¹
		Air dam, Gray	S	s	s	n/a
	T61	Daytime running lamps, includes automatic exterior lamp control	S	S	s	s
		Door, 3rd, driver-side 1 - Requires CT10653 Extended Cab Model.	S ¹	S ¹	S¹	n/a
		Grille, color-keyed and chrome with composite headlamps	n/a	n/a	n/a	S
		Grille, Gray and chrome with composite headlamps	S	s	s	n/a
	DK2	Mirrors, outside rearview, foldaway, power, heated 1 - Included with (ZQ6) Convenience Package.	n/a	l ¹	l ¹	S
		Pickup bed liner	n/a	n/a	n/a	S
		Wipers, intermittent, front, includes pulse washers	S	S	S	S
	K60	Alternator, 100 amps	S	S	S	S
		Battery, heavy-duty, 525 cold-cranking amps, includes rundown protection	S	S	S	S
	JC1	Brakes, 4-wheel antilock, 4-wheel disc	s	S	S	S
	C5A	GVWR , 4900 lbs. (2223 kg)	n/a	n/a	S	n/a
	C6F	GVWR , 5150 lbs. (2336 kg)	S	S	n/a	S
		Steering, power	S	S	S	S
		Suspension, front, independent torsion bar, and stabilizer bar	S	S	S	S
		Suspension, rear, semi-floating axle with 2-stage multi-leaf springs	S	S	S	S
	NP1	Transfer case, electronic shift, includes dash-mounted controls	S	S	s	S

I = Included with another feature

■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

No deletions allowed to Equipment Groups. Additional options may be added; check ordering information section for compatibility.

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and

Free Flow	Ref.	Only Description —	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	15B ¹	1SC ²	1SX ²
	C60	Air conditioning, front manual				
		Base Decor		n/a	n/a	n/a
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α		•	
	B30	Floor covering, color-keyed carpeting	n/a			
U16		Instrumentation, tachometer 1 - Included with (MW2) Transmission, 5- speed manual and (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	A ¹			
		LS decor 1 - Upgradeable to (YC5) LS trim with exterior appearance package.	n/a	_ 1		
	AM6	Seats, front 60/40 split bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders (CS10603 Regular Cab, short box and CS10803 Regular Cab, long box) 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.		<u> </u>	ם1	o ¹
	AM6	Seats, front 60/40 split-bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders (CS10653 Extended Cab) 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.	□ 1	_1	□ ¹	□ ¹
	UM7	Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	□ ¹	n/a	n/a	n/a
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	Α,	_1	_1	<u>1</u>
	NP5	Steering wheel, leather-wrapped rim, Black, steel sleeve, includes theft-deterrent locking feature	n/a			•

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	VF6	Bumpers , front and rear, body color, step, includes step pad	n/a		-	•
		Bumpers, front and rear, Dark Gray, rear step includes pad		n/a	n/a	n/a
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	А	Α	
	D44	Mirrors, outside rearview, foldaway, manual, Black, below eye-line, adjustable 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated with (ZQ6) Convenience Package.	•	_1	_1	□ ¹
	E63	Pickup bed, Fleetside, all-welded steel with double wall construction and corrosion protection with 8 cargo tie-downs and tailgate, locking, 2-position 1 - Upgradeable to (E62) Pickup bed, sportside except for CS10803.		₋₁	<u>-1</u>	_1
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZCE) Tire, spare P205/75R15 all-season, blackwall or (ZCA) Tire, spare P205/75R15, all-season, White outlined-letter.	□ ¹	_1	•	•
	QCE	Tires, P205/75R15, all-season, blackwall 1 - Upgradeable to (QCA) Tires, P205/75R15, all-season, White outlined-letter.	□ ¹	₋₁	n/a	n/a
	QCB	Tires, P235/55R16, all-season, blackwall	n/a	n/a	•	
	N60	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, includes center caps	n/a		n/a	n/a
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps		n/a	n/a	n/a
	N96	Wheels, 4 - 16" x 7" (40.6 cm x 17.8 cm) aluminum, 5-spoke, includes center caps	n/a	n/a		•
	V4A	Xtreme Sport Appearance Package, includes (ZQ8) Suspension Package, Sport, consisting of a 2" (5.1 cm) lowered ride height and monotube shocks, 16" x 8" (40.6 cm x 20.3 cm) aluminum wheels, (QCB) Tires, P235/55R16 all-season blackwall, body-colored grille with gold bowtie as well as body-colored front and rear bumpers	n/a	n/a	n/a	•
	LN2	Engine, Vortec 2200 L4 MFI, (120 HP [89.5 kW] @ 5000 rpm, 140 lbft. [189.0 N-m] @ 3600 rpm) 1 - Upgradeable to (LU3) Engine, Vortec 4300 V6 MFI.	1	₋₁	₋₁	_1
	GT4	Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Upgradeable to (GT5) Rear axle, 4.10 ratio with (M30) Transmission, 4-speed automatic Required with (LN2) Engine, Vortec 2200 L4 MFI and (MW2) Transmission, 5 - speed manual.	_1	. 🗆 1	₁	₀ 1

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	GT5	Rear axle, 4.10 ratio (CS10803 Regular Cab, long box) 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI. Required with (M30) Transmission, 4-speed automatic and (LN2) Engine, Vortec 2200 L4 MFI.	□ ¹	1	n/a	n/a
-	GT5	Rear axle, 4.10 ratio (CS10653 Extended Cab) 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (M30) Transmission, 4-speed automatic or (GU4) Rear axle, 3.08 ratio with (M50) Transmission, 5-speed manual and (LU3) Engine, Vortec 4300 V6 MFI.	_1	1	₁	₋₁
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar (CS10653 Extended Cab only)		•	n/a	n/a
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar (CS10803 Regular Cab, long box only) 1 - (Z85) Suspension Package, Increased Capacity includes RPO (C5A) GVWR, 4900 lbs. (2223 kg) with (LU3) Engine, Vortec 4300 V6 MFI; includes (C5D) GVWR, 4600 lbs. (2087 kg) with (LN2) Engine, Vortec 2200 L4 MFI.	■ 1	1	n/a	n/a
	Z83	Suspension Package, Solid Smooth Ride (CS10603 Regular Cab, short box) 1 - Upgradeable to (Z85) Suspension package, Increased Capacity.	₀ 1	□ 1	n/a	n/a
	ZQ8	Suspension Package, Sport, includes (N96) 16" (40.6 cm) aluminum, 5-spoke and (QCB) Tires, P235/55R16, all-season, blackwall (CS10603 Regular Cab, short box and CS10653 Extended Cab)	n/a	n/a		•
	M30	Transmission, 4-speed automatic, electronically controlled with overdrive (CS10803 Regular Cab, long box) 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio or (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI.	■ ¹	1	n/a	n/a
	MW2	Transmission, 5-speed manual with overdrive (CS10603 Regular Cab, short box) 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT4) Rear axle, 3.73 ratio.	□ ¹	₋₁	_1	_1
	MW2	Transmission, 5-speed manual with overdrive (CS10653 Extended Cab) 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio.	□ ¹	o ¹	_1	1

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

No deletions allowed to Equipment Groups. Additional options may be added; check ordering information section for compatibility.

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
	C60	Air conditioning, front manual		•		
		Base Decor	•	n/a	n/a	n/a
ZQ6		Convenience Package, power windows and door locks, programmable, with lighted switches and driver's express-down window, (DK2) Mirrors, outside rearview, foldaway, power, heated and Keyless entry, remote	n/a	A	A	
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α		•	
B30		Floor covering, color-keyed carpeting 1 - Requires a Fleet or Governmental Order type.	A ¹			
U16		Instrumentation, tachometer 1 - Available with (M30) Transmission, 4-speed automatic and included with (M50) Transmission, 5-speed manual.	A ¹			•
		LS decor 1 - May be upgraded to (YC5) LS trim with Exterior Appearance Package.	n/a	₋₁		•
	AV5	Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console and (Storage pockets on Crew Cab Models) 1 - May be substituted with (AM6) Seats, front 60/40 split bench with (M30) Transmission, 4-speed automatic. 2 - Upgradeable to (AN3) Seats, front leather seating surfaces high-back reclining buckets.	□ 1	□1		□²
	UM7	Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	_1	n/a	n/a	n/a
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	Α	_1	_ ¹	_1
	NP5	Steering wheel, leather-wrapped rim, Black, steel sleeve, includes theft-deterrent locking feature	n/a	=	.	•
		Bumpers, front and rear, body-color, rear step includes pad	n/a	•	n/a	

Free Flow	Ref. Only	Description -	Base		SLE	
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
		Bumpers, front and rear, Dark Gray, rear step includes pad	-	n/a		n/a
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	А	А	
	D44	Mirrors, outside rearview, foldaway, manual, Black, below eye-line, adjustable 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated.		₋₁	_□ 1	n/a
	E63	Pickup bed, Fleetside, all-welded steel with double wall construction and corrosion protection with 8 cargo tie-downs and tailgate, locking, 2-position 1 - May be upgraded to (E62) Pickup bed, sportside.	-	□ ¹		-
	ZWU	Tire, spare, P265/75R15, on-/off-road, blackwall, located at rear underbody of vehicle 1 - Included with (QWU) Tires, P265/75R15, on-/off-road, blackwall.	n/a	n/a	1	n/a
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZEB) Tire, spare P235/75R15, on-/off-road, white outline-letter or (ZBF) Tire, spare P235/70R15, all-season, blackwall.	_ 1	□ ¹	n/a	₀ 1
	QBF	Tires, P235/70R15, all-season, blackwall 1 - Includes (ZAA)Tire, spare, compact, located at rear underbody of vehicle - Upgradeable to (QEB) Tires, P235/75R15,on-/off-road, white outlined-letter.	_1	. 🗖 1	n/a	_1
	QWU	Tires, P265/75R15, on-/off-road, blackwall 1 - Includes (ZWU) Tire, spare, P265/75R15, on-/off-road, blackwall.	n/a	n/a	■ 1	n/a
V76		Recovery hooks, 2 front, frame-mounted	A			
	N90	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, cast, includes center caps	n/a		n/a	
	PA3	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) bright aluminum, includes gray accent, center caps	n/a	n/a	•	n/a
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps		n/a	n/a	n/a
G80		Differential, locking, heavy-duty, rear 1 - Required with (GT4) Rear axle, 3.73 ratio and (LU3) Engine, Vortec 4300 V6 MFI Optional with (GU6) Rear axle, 3.42 ratio.	A ¹	A ¹		A ¹
·	LU3	Engine, Vortec 4300 V6 MFI (2WD - 180 HP [134.3 kW] @ 4400 rpm, 245 lbft. [330.7 N-m] @ 2800 rpm) (4WD - 190 HP [141.7 kW] @ 4400 rpm, 250 lbft. [339.5 N-m] @ 2800 rpm)		•		
	GU6	Rear axle, 3.42 ratio 1 - Upgradeable to (GT4) Rear axle, 3.73 ratio.	. п 1	□ ¹	n/a	_ 1

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653, 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1\$A ¹	1SB ²	1SC ²	1SA ³
GT4		Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Requires (G80) Differential, locking, heavy-duty, rear - Not available with (M50) Transmission, 5-speed manual and (Z85) Suspension package, Increased Capacity.	A ¹	A ¹		A ¹
ZM5		Skid Plate Package	Α	Α		n/a
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar			n/a	
	ZR2	Suspension Package, Wide Stance, includes decal, revised wide-tread frame, strengthened front differential gears and drive axles, large bearings and longer, large rear axle shafts, revised multi-leaf springs and added rear axle track bar, front stabilizer bar, Bilstein gas-pressurized shock absorbers, shield package and chrome grille, front fenders and pickup box outer panels with extra wide wheel flares, modified jack and spare tire stowage winch	n/a	n/a	•	n/a
M30		Transmission, 4-speed automatic, electronically controlled with overdrive 1 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	A ¹	A ¹	A ¹	■ 1
	M50	Transmission, 5-speed manual with overdrive 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (GU6) rear axle 3.42 ratio with (Z85) Suspension Package, increased capacity Not available with (AM6) Seats, front 60/40 split bench. 2 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	o ¹	□ ¹	_ 2	n/a

I = Included with another feature ■ = Included in Equipment Group

■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

No deletions allowed to Equipment Groups. Additional options may be added; check ordering information section for compatibility.

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	C60	Air conditioning, front manual			-	
		Base Decor		n/a	n/a	n/a
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α			
	B30	Floor covering, color-keyed carpeting	n/a			
U16		Instrumentation, tachometer 1 - Included with (MW2) Transmission, 5- speed manual and (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	A ¹	•	•	-
		LS decor 1 - Upgradeable to (YC5) LS trim with exterior appearance package.	n/a	₋₁	-	-
	AM6	Seats, front 60/40 split bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders (CS10603 Regular Cab, short box and CS10803 Regular Cab, long box) 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.		ם1	1	ם1
	AM6	Seats, front 60/40 split-bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders (CS10653 Extended Cab) 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.	_ ¹	□ ¹	₋₁	□ ¹
	UM7	Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	□ ¹	n/a	n/a	n/a
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	A	_1	1	_ 1
	NP5	Steering wheel, leather-wrapped rim, Black, steel sleeve, includes theft-deterrent locking feature	n/a			

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Ecspholi Full Temperature Full Tempera	1SA ¹	1SB ¹	1SC ²	1SX ²
	VF6	Bumpers, front and rear, body color, step, includes step pad	n/a	-		=
		Bumpers, front and rear, Dark Gray, rear step includes pad		n/a	n/a	n/a
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	А	А	
	D44	Mirrors, outside rearview, foldaway, manual, Black, below eye-line, adjustable 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated with (ZQ6) Convenience Package.		_1	1	- D ¹
	E63	Pickup bed, Fleetside, all-welded steel with double wall construction and corrosion protection with 8 cargo tie-downs and tailgate, locking, 2-position 1 - Upgradeable to (E62) Pickup bed, sportside except for CS10803.	•	1	_1	□ ¹
-	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZCE) Tire, spare P205/75R15 all-season, blackwall or (ZCA) Tire, spare P205/75R15, all-season, White outlined-letter.	□ ¹	1	. •	•
	QCE	Tires, P205/75R15, all-season, blackwall 1 - Upgradeable to (QCA) Tires, P205/75R15, all-season, White outlined-letter.	□ ¹	_1	n/a	n/a
	QCB	Tires, P235/55R16, all-season, blackwall	n/a	n/a	•	
	N60	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, includes center caps	n/a		n/a	n/a
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps		n/a	n/a	n/a
	N96	Wheels, 4 - 16" x 7" (40.6 cm x 17.8 cm) aluminum, 5-spoke, includes center caps	n/a	n/a		=
	V4A	Xtreme Sport Appearance Package, includes (ZQ8) Suspension Package, Sport, consisting of a 2" (5.1 cm) lowered ride height and monotube shocks, 16" x 8" (40.6 cm x 20.3 cm) aluminum wheels, (QCB) Tires, P235/55R16 all-season blackwall, body-colored grille with gold bowtie as well as body-colored front and rear bumpers	n/a	n/a	n/a	
	LN2	Engine, Vortec 2200 L4 MFI, (120 HP [89.5 kW] @ 5000 rpm, 140 lbft. [189.0 N-m] @ 3600 rpm) 1 - Upgradeable to (LU3) Engine, Vortec 4300 V6 MFI.	□ ¹	__ _1	□ ¹	_1
	GT4	Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Upgradeable to (GT5) Rear axle, 4.10 ratio with (M30) Transmission, 4-speed automatic Required with (LN2) Engine, Vortec 2200 L4 MFI and (MW2) Transmission, 5 - speed manual.	□ ¹	_1	₁	₋₁

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	GT5	Rear axle, 4.10 ratio (CS10803 Regular Cab, long box) 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI. Required with (M30) Transmission, 4-speed automatic and (LN2) Engine, Vortec 2200 L4 MFI.	п ¹	o 1	n/a	n/a
	GT5	Rear axle, 4.10 ratio (CS10653 Extended Cab) 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (M30) Transmission, 4-speed automatic or (GU4) Rear axle, 3.08 ratio with (M50) Transmission, 5-speed manual and (LU3) Engine, Vortec 4300 V6 MFI.	□ ¹	₋₁	_ 1	_ 1
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar (CS10653 Extended Cab only)		•	n/a	n/a
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar (CS10803 Regular Cab, long box only) 1 - (Z85) Suspension Package, Increased Capacity includes RPO (C5A) GVWR, 4900 lbs. (2223 kg) with (LU3) Engine, Vortec 4300 V6 MFI; includes (C5D) GVWR, 4600 lbs. (2087 kg) with (LN2) Engine, Vortec 2200 L4 MFI.	1	■1	n/a	n/a
	Z83	Suspension Package, Solid Smooth Ride (CS10603 Regular Cab, short box) 1 - Upgradeable to (Z85) Suspension package, Increased Capacity.	□ ¹	□ ¹	n/a	n/a
	ZQ8	Suspension Package, Sport , includes (N96) 16" (40.6 cm) aluminum, 5-spoke and (QCB) Tires, P235/55R16, all-season, blackwall (CS10603 Regular Cab, short box and CS10653 Extended Cab)	n/a	n/a	•	•
	M30	Transmission, 4-speed automatic, electronically controlled with overdrive (CS10803 Regular Cab, long box) 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio or (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI.	■ ¹	■ 1	n/a	n/a
	MW2	Transmission, 5-speed manual with overdrive (CS10603 Regular Cab, short box) 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT4) Rear axle, 3.73 ratio.	□ ¹	<u> </u>	□ ¹	_1
	MW2	Transmission, 5-speed manual with overdrive (CS10653 Extended Cab) 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio.	_ 1	_ 1	_1	1

		ADDITIONAL OPTIONS				
Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
ZQ6		Convenience Package, power windows and door locks, programmable, with lighted switches and driver's express-down window, (DK2) Mirrors, outside rearview, foldaway, power, heated and Keyless entry, remote	n/a	A	A	А
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α		•	•
B32		Floormats, includes front rubberized vinyl floormats on Regular and Extended Cab Models 1 - Requires (B30) Floor covering, color-keyed carpeting.	n/a	A ¹	A ¹	A ¹
U16		Instrumentation, tachometer 1 - Included with (MW2) Transmission, 5- speed manual and (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	A ¹	•	•	
AV5		Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console (CS10603 Regular Cab, short box and CS10803 Regular Cab, long box)	n/a	A	A	A
AV5		Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console (CS10653 Extended Cab)	Α	A	А	А
UP0		Sound system, ETR AM/FM stereo with CD player and cassette, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)	n/a	А	А	А
UC6		Sound system, ETR AM/FM stereo with 6-disc CD changer, includes seek-and-scan, digital clock and auto-tone control, speed-compensated volume, TheftLock, Radio Data System (RDS) and 6-speakers	n/a	А	. А	A
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	, A	<u> </u>	_1 _	_ 1
CF5		Sunroof, power, tilt-sliding 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI on (CS10603).	A ¹	A ¹	A ¹	A ¹
A28		Window, rear sliding	Α	Α	Α	A
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	Α	Α	
ANL		Fog lamps, front, halogen, incorporated into headlamp assembly	n/a	Α	Α	n/a

	ADDITIONAL OPTIONS								
Free Flow	Ref. Only	Description	Base		SLE				
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²			
B94		Gold Package, includes Gold exterior emblems, stripe and wheels 1 - Not available with (74U) Victory red exterior paint, (43U) Yellow exterior paint or Red Flames decals. Dealer must order (54A) Gold stripe, which requires (894) Gold Package.	n/a	n/a	n/a	A ¹			
YC5		LS trim, with exterior appearance package, includes (V37) Bumpers, front and rear, chrome, step and bodyside moldings with chrome insert 1 - Not available with (E62) Pickup bed, sportside or CS10803 Regular Cab, long box.	n/a	A ¹	n/a	n/a			
E62		Pickup bed, Sportside 1 - Not available with (YC5) LS trim with exterior appearance package or CS10803.	n/a	A ¹	A ¹	A ¹			
PCX		Special Equipment Package, bed extender	Α	Α	Α	А			
PDA		Special Equipment Package, Black anodized bed rails 1 - Not available with (YC5) LS trim with exterior appearance package, (V4A) Xtreme sport appearance package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment Package, hard lockable tonneau cover, (PCZ) Special Equipment Package, Chrome bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails or Model CS10803.	A ¹	A ¹	A ¹	n/a			
PCZ		Special Equipment Package, chrome bed rails 1 - Not available with (PDW) Special equipment package, soft tonneau cover, (V4A) Xtreme Sport Appearance Package, (PDU) Special Equipment Package, hard lockable tonneau cover, (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PDA) Special Equipment Package, Black anodized bed rails or CS10803.	A ¹	A ¹	A ¹	n/a			
PDU		Special Equipment Package, hard lockable tonneau	A ¹	A ¹	A ¹	A ¹			
		COVER 1 - Not available with (PDW) Special Equipment Package, soft tonneau cover, (PDA) Special Equipment Package, Black anodized bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails or CS10803.							
PDB		Special Equipment Package, natural brushed aluminum bed rails 1 - Not available with (YC5) LS trim with Exterior Appearance Package, (V4A) Xtreme Sport Appearance Package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment Package, hard lockable tonneau cover, (PCZ) Special Equipment Package, Chrome bed rails, (PDA) Special Equipment Package, black anodized bed rails or CS10803.	A ¹	A ¹	A ¹	n/a			
WDY		Special Equipment Package, soft tonneau cover 1 - Not available with (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails, (PDA) Special Equipment Package, Black anodized bed rails, (PDU) Special Equipment Package, hard lockable tonneau cover or Model CS10803.	A ¹	A ¹	A ¹	A ¹			

		ADDITIONAL OPTIONS				
Free Flow	Ref.	Description	Base		SLE	
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
PDZ		Special Equipment Package, trailer hitch 1 - Requires (LU3) Engine, Vortec 4300 V6 MFI. Not available with (E62) Pickup bed, sportside or (V4A) Xtreme Sport Appearance Package.	A ¹	A ¹	A ¹	n/a
ZCA		Tire, spare P205/75R15, all season, White outlined-letter. 1 - Requires (QCA) Tires, P205/75R15, all-season, white outlined-letter.	A ¹	A ¹	n/a	n/a
ZCE		Tire, spare P205/75R15, all-season, blackwall 1 - Requires (QCE) Tires, P205/75R15, all-season, blackwall.	A ¹	A ¹	n/a	n/a
QCA		NEW! Tires , P205/75R15, all-season, White outlined-letter	Α	Α	n/a	n/a
D98		Xtreme accent stripe, for hood or Flame side decal, roof and tailgate (Dealer must specify 13A, 41A, 59A, 70A if stripes are desired or 38A if Red Flame side decals are desired)	n/a	n/a	n/a	А
BZY		Xtreme specific bed liner 1 - Requires (V4A) Xtreme Sport Appearance Package.	n/a	n/a	n/a	A ¹
V10		Cold Climate Package, includes engine block heater and Battery, heavy-duty 690 cold-cranking amps 1 - Required in Alaska, Minnesota, Montana, North Dakota, and South Dakota Includes heavy-duty battery and (K05) Engine block heater.	A ¹	A ¹	A ¹	A ¹
G80		Differential, locking, heavy-duty, rear 1 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual Not available with (LN2) Engine, Vortec 2200 L4 MFI. 2 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual Required with (ZQ8) Suspension, Sport Not available with (LN2) Engine, Vortec 2200 L4 MFI.	A ¹	A ¹	A ²	A ²
FE9		Emissions, Federal requirements	Α	Α	Α	Α
NG1		Emissions, New York or Vermont state requirements	Α	Α	Α	Α
NE1		Emissions, Maine or Massachusetts state requirements	Α	А	Α	Α
YF5		Emissions, California state requirements	Α	Α	Α	Α

ADDITIONAL OPTIONS								
Free Flow	Ref. Only	Description	Base	SLE				
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	15X ²		
VCL		Emissions, Federal Clean Air (for use by central fueled fleets in federally mandated non-attainment areas) Note: Option (VCL) Emissions, Federal Clean Air must be ordered to receive the (LEV) Emissions, California emission compliance - HD certification. If (VCL) Emissions, Federal Clean Air is not ordered, the vehicle will be produced with the base (FE9) Emissions, Federal requirements and will not be (LEV) Emissions, California emission compliance - HD certified 1 - Requires (CS10653) 2WD Extended Cabs with (LU3) Engine, Vortec 4300 V6 MFI and (M30) Transmission, 4-speed automatic or (CS10603/CS10653) models with (LN2) Engine, Vortec 2200 L4 MFI and (M30) Transmission, 4-speed automatic.	A ¹	A ¹	A ¹	A ¹		
NB8		Emissions override, California, Maine, Massachusetts, New York or Vermont (for vehicles ordered by dealers in states of California, New York, Vermont, Massachusetts or Maine with Federal emissions) 1 - Requires (FE9) Emissions, Federal requirements.	A ¹	A ¹	A ¹	A ¹		
NC7		Emissions override, Federal (for vehicles ordered by dealers in Federal emission states with California, New York, Vermont, Massachusetts or Maine emissions; may also be used by dealers in states of California, New York, Vermont, Massachusetts or Maine to order different state-specific emissions) 1 - Requires (YF5) Emissions, California requirements, (NG1) Emissions, New York or Vermont state requirements or (NE1) Emissions, Massachusetts or Maine state requirements.	A ¹	A ¹	A ¹	A ¹		
LU3		Engine, Vortec 4300 V6 MFI (2WD - 180 HP [134.3 kW] @ 4400 rpm, 245 lbft. [330.7 N-m] @ 2800 rpm) (4WD - 190 HP [141.7 kW] @ 4400 rpm, 250 lbft. [339.5 N-m] @ 2800 rpm)	Α	А	А	А		
C5A		GVWR , 4900 lbs. (2223 kg) (CS10803 Regular Cab, long box with (LU3))	Α	Α	n/a	n/a		
GU4		Rear axle, 3.08 ratio (CS10603 Regular Cab, short box) 1 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual. Requires (G80) Differential, locking, heavy duty, rear. Not available with (M30) Transmission, 4-speed automatic.	n/a	A ¹	A ¹	A ¹		
GU4		Rear axle, 3.08 ratio (CS10653 Extended Cab) 1 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual. Requires (G80) Differential, locking, heavy duty, rear. Not available with (M30) Transmission, 4-speed automatic.	A ¹	A ¹	A ¹	A ¹		

ADDITIONAL OPTIONS								
Free Flow	Ref. Only	Description	Base		SLE			
RPO Code	RPO Code	1 - Equipment groups 1SA and 1SB available on CS10603,	1SA ¹	1SB ¹	1SC ²	1SX ²		
GU6		Rear axle, 3.42 ratio (CS10603 Regular Cab, short box, CS10803 Regular Cab, long box and CS10653 Extended Cab) 1 - Required with (M30) Transmission, 4-speed automatic and (LU3) Engine, Vortec 4300 V6 MFI.	A ¹	A ¹	A ¹	A ¹		
GT5		Rear axle, 4.10 ratio (CS10603 Regular Cab, short box) 1 - Required with (LN2) Engine, Vortec 2200 L4 MFI and (M30) Transmission, 4-speed automatic.	A ¹	A ¹	A ¹	A ¹		
M30		Transmission, 4-speed automatic, electronically controlled with overdrive (CS10603 Regular Cab, short box and CS10653 Extended Cab) 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio or (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI.	A ¹	A ¹	A ¹	A ¹		
M50		Transmission, 5-speed manual with overdrive (CS10653 Extended Cab) 1 - Requires (LU3) Engine, Vortec 4300 V6 MFI and (GU4) Rear axle, 3.08 ratio. (G80) Differential, locking, heavy-duty, rear required with (M50) Transmission, 5-speed manual. Not available with (AM6) Seats, front 60/40 split bench.	A ¹	A ¹	A ¹	A ¹		
M50		Transmission, 5-speed manual with overdrive (CS10603 Regular Cab, short box) 1 - Requires (LU3) Engine, Vortec 4300 V6 MFI and (GU4) Rear axle, 3.08 ratio. (G80) Differential, locking, heavy-duty, rear required with (M50) Transmission, 5-speed manual. Not available with (AM6) Seats, front 60/40 split bench.	n/a	A ¹	A ¹	A ¹		

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

No deletions allowed to Equipment Groups. Additional options may be added; check ordering information section for compatibility.

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
	C60	Air conditioning, front manual				
<u> </u>		Base Decor		n/a	n/a	n/a
ZQ6		Convenience Package, power windows and door locks, programmable, with lighted switches and driver's express-down window, (DK2) Mirrors, outside rearview, foldaway, power, heated and Keyless entry, remote	n/a	А	A	
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α			
B30		Floor covering, color-keyed carpeting 1 - Requires a Fleet or Governmental Order type.	A ¹			
U16		Instrumentation, tachometer 1 - Available with (M30) Transmission, 4-speed automatic and included with (M50) Transmission, 5-speed manual.	A ¹	•		
		LS decor 1 - May be upgraded to (YC5) LS trim with Exterior Appearance Package.	n/a	□ ¹		
	AV5	Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console and (Storage pockets on Crew Cab Models) 1 - May be substituted with (AM6) Seats, front 60/40 split bench with (M30) Transmission, 4-speed automatic. 2 - Upgradeable to (AN3) Seats, front leather seating surfaces high-back reclining buckets.	- 1	₋₁		□ ²
	UM7	Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	_1	n/a	n/a	n/a
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	A	_1	-1	□ 1
	NP5	Steering wheel, leather-wrapped rim, Black, steel sleeve, includes theft-deterrent locking feature	n/a			
		Bumpers , front and rear, body-color, rear step includes pad	n/a		n/a	•

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
		Bumpers, front and rear, Dark Gray, rear step includes pad		n/a		n/a
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	A	А	
	D44	Mirrors, outside rearview, foldaway, manual, Black, below eye-line, adjustable 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated.	=	₋₁	₋₁	n/a
	E63	Pickup bed, Fleetside, all-welded steel with double wall construction and corrosion protection with 8 cargo tie-downs and tailgate, locking, 2-position 1 - May be upgraded to (E62) Pickup bed, sportside.		1	# · _	
	ZWU	Tire, spare, P265/75R15, on-/off-road, blackwall, located at rear underbody of vehicle 1 - Included with (QWU) Tires, P265/75R15, on-/off-road, blackwall.	n/a	n/a	■ 1	n/a
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZEB) Tire, spare P235/75R15, on-/off-road, white outline-letter or (ZBF) Tire, spare P235/70R15, all-season, blackwall.	□ ¹	o 1	n/a	1
	QBF	Tires, P235/70R15, all-season, blackwall 1 - Includes (ZAA)Tire, spare, compact, located at rear underbody of vehicle - Upgradeable to (QEB) Tires, P235/75R15,on-/off-road, white outlined-letter.	_1	□ ¹	n/a	_ 1
	QWU	Tires, P265/75R15, on-/off-road, blackwall 1 - Includes (ZWU) Tire, spare, P265/75R15, on-/off-road, blackwall.	n/a	n/a	■ ¹	n/a
V76		Recovery hooks, 2 front, frame-mounted	Α			•
	N90	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, cast, includes center caps	n/a		n/a	
	PA3	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) bright aluminum, includes gray accent, center caps	n/a	n/a		n/a
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps		n/a	n/a	n/a
G80		Differential, locking, heavy-duty, rear 1 - Required with (GT4) Rear axle, 3.73 ratio and (LU3) Engine, Vortec 4300 V6 MFI Optional with (GU6) Rear axle, 3.42 ratio.	A ¹	A ¹	•	A ¹
-	LU3	Engine, Vortec 4300 V6 MFI (2WD - 180 HP [134.3 kW] @ 4400 rpm, 245 lbft. [330.7 N-m] @ 2800 rpm) (4WD - 190 HP [141.7 kW] @ 4400 rpm, 250 lbft. [339.5 N-m] @ 2800 rpm)		-		
	GU6	Rear axle, 3.42 ratio 1 - Upgradeable to (GT4) Rear axle, 3.73 ratio.	_1	₀ 1	n/a	_1

Free Flow	Ref.	Description	Base		SLE	
RPO Code	Only RPO Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
GT4		Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Requires (G80) Differential, locking, heavy-duty, rear - Not available with (M50) Transmission, 5-speed manual and (Z85) Suspension package, Increased Capacity.	A ¹	A ¹		A ¹
ZM5		Skid Plate Package	Α	А		n/a
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar			n/a	•
	ZR2	Suspension Package, Wide Stance, includes decal, revised wide-tread frame, strengthened front differential gears and drive axles, large bearings and longer, large rear axle shafts, revised multi-leaf springs and added rear axle track bar, front stabilizer bar, Bilstein gas-pressurized shock absorbers, shield package and chrome grille, front fenders and pickup box outer panels with extra wide wheel flares, modified jack and spare tire stowage winch	n/a	n/a		n/a
M30		Transmission, 4-speed automatic, electronically controlled with overdrive 1 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	A ¹	A ¹	A ¹	1
	M50	Transmission, 5-speed manual with overdrive 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (GU6) rear axle 3.42 ratio with (Z85) Suspension Package, increased capacity Not available with (AM6) Seats, front 60/40 split bench. 2 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	_ ¹	₋₁	□ ²	n/a
		ADDITIONAL OPTIONS		l	-	I .
Free	Ref.	, ESTIONAL OF HONS	Base		SLE	
Flow RPO Code	Only RPO Code	Description 1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
ZQ6		Convenience Package, power windows and door locks, programmable, with lighted switches and driver's express-down window, (DK2) Mirrors, outside rearview, foldaway, power, heated and Keyless entry, remote	n/a	A	Α	•
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α			
B30		Floor covering, color-keyed carpeting 1 - Requires a Fleet or Governmental Order type.	A ¹			
B32		Floormats, includes front rubberized vinyl floormats on Regular and Extended Cab Models, front and rear carpeted floormats on Crew Cab Models 1 - Requires a Fleet or Governmental Order type.	A ¹	А	Α	А

		ADDITIONAL OPTIONS	3			
Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
U16		Instrumentation, tachometer 1 - Available with (M30) Transmission, 4-speed automatic and included with (M50) Transmission, 5-speed manual.	A ¹	•		•
AM6		Seats, front 60/40 split-bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders 1 - Not available with (M50) Transmission, 5-speed manual.	A ¹	A ¹	n/a	n/a
AN3		Seats, front leather seating surfaces high-back reclining buckets, 8-way power, heated, adjustable head restraints and storage pockets 1 - Requires (122) Seats, front high-back reclining buckets, Leather seating surfaces.	n/a	n/a	n/a	A ¹
UP0		Sound system, ETR AM/FM stereo with CD player and cassette, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Requires a Fleet or Governmental Order type.	A ¹	Α	Α	А
UC6		Sound system, ETR AM/FM stereo with 6-disc CD changer, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)	n/a	А	А	А
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	A	o ¹	<u> </u>	□ ¹
CF5		Sunroof, power, tilt-sliding	Α	Α	Α	n/a
DH6		Visors, padded, color-keyed, illuminated vanity mirrors, passenger- and driver-side	n/a	n/a	n/a	Α
A28		Window, rear sliding	n/a	Α	Α	Α
E95		Cargo cover, soft tonneau, Black 1 - Requires (ZR5) Appearance Package. Not available with (PCX) Special Equipment Package, bed extender.	n/a	n/a	n/a	A ¹
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	Α	Α	
ANL		Fog lamps, front, halogen, incorporated into headlamp assembly	n/a	Α	Α	Α

		ADDITIONAL OPTIONS	3				
Free Flow	Ref. Only Description	Description	Base	SLE			
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
YC5		LS trim, with exterior appearance package, includes (V37) Bumpers, front and rear, chrome, step and bodyside moldings with chrome insert 1 - Not available with (E62) Pickup bed, sportside.	n/a	· A¹	n/a	n/a	
E62		Pickup bed, Sportside	n/a	Α	n/a	n/a	
PCX		Special Equipment Package, bed extender	Α	Α	Α	А	
PDA		Special Equipment Package, Black anodized bed rails 1 - Not available with (YC5) LS trim with Exterior Appearance Package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment Package, hard lockable tonneau cover, (PDB) Special Equipment Package, natural brushed aluminum bed rails or (PCZ) Special Equipment Package, Chrome bed rails.	A ¹	A ¹	A ¹	n/a	
PCZ		Special Equipment Package, chrome bed rails 1 - Not available with (PDA) Special Equipment Package, Black anodized bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails, or (PDW) Special Equipment Package, soft tonneau cover or (PDU) Special Equipment Package, black anodized bed rails.	A ¹	A ¹	A ¹	n/a	
PDU		Special Equipment Package, hard lockable tonneau cover 1 - Not available with (PDW) Special Equipment Package, soft tonneau cover, (PDA) Special Equipment Package, Black anodized bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails or Crew Cab (ZR5) Appearance Package.	A ¹	A ¹	A ¹	A ¹	
PDB		Special Equipment Package, natural brushed aluminum bed rails 1 - Not available with (YC5) LS trim with Exterior Appearance Package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment package, hard lockable tonneau cover, (PCZ) Special Equipment Package, Chrome bed rails or (PDA) Special Equipment package, Black anodized bed rails.	A ¹	A ¹	A ¹	n/a	
PDW		Special Equipment Package, soft tonneau cover 1 - Not available with (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails, (PDA) Special Equipment Package, Black anodized bed rails, (PDU) Special Equipment Package, hard lockable tonneau cover or (ZR5) Appearance Package.	A ¹	A ¹	A ^{1.}	A ¹	
PDZ		Special Equipment Package, trailer hitch 1 - Not available with (E62) Pickup bed, sportside.	А	A ¹	Α	Α	
ZEB		Tire, spare P235/75R15, on-/off-road, White outlined-letter, located at rear underbody of vehicle 1 - Available with (QEB) Tires, P235/75R15,on-/off-road, White outlined-letter.	A ¹	A ¹	n/a	A ¹	

ADDITIONAL OPTIONS								
Free Ref. Flow Only	Description	Base	SLE					
RPO RPO Code Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	15A ¹	1SB ²	1SC ²	1SA ³			
ZBF	Tire, spare P235/70R15, all-season, blackwall, located at rear underbody of vehicle 1 - Available with (QBF) Tires, P235/70R15, all-season, blackwall Upgradeable to (ZEB) Tire, spare P235/75R15, on-/off-road, white outline-letter.	A ¹	A ¹	n/a	A ¹			
QEB	Tires, P235/75R15, on-/off-road, White outlined-letter 1 - Includes (ZAA)Tire, spare, compact, located at rear underbody of vehicle.	A ¹	A ¹	n/a	A ¹			
V76	Recovery hooks, 2 front, frame-mounted	Α						
ZR5	NEW! Appearance Package, includes Black roof rack, side steps, bed rails, specific aluminum wheels with Spectra Gray accents, Spectra Gray wheel flares and bumpers and (2) ZR5 decals 1 - Not available with (PDU) Special Equipment Package, hard lockable tonneau cover or (PDW) Special Equipment Package, soft tonneau cover.	n/a	n/a	n/a	A ¹			
V10	Cold Climate Package, includes engine block heater and Battery, heavy-duty 690 cold-cranking amps 1 - Required in Alaska, Minnesota, Montana, North Dakota, and South Dakota Includes heavy-duty battery and (K05) Engine block heater.	A ¹	A ¹	A ¹	A ¹			
G80	Differential, locking, heavy-duty, rear 1 - Required with (GT4) Rear axle, 3.73 ratio and (LU3) Engine, Vortec 4300 V6 MFI Optional with (GU6) Rear axle, 3.42 ratio.	A ¹	A ¹		A ¹			
FE9	Emissions, Federal requirements	Α	Α	Α	Α			
NG1	Emissions, New York or Vermont state requirements	Α	Α	Α	Α			
NE1	Emissions, Maine or Massachusetts state requirements	Α	Α	Α	Α			
YF5	Emissions, California state requirements	Α	Α	Α	Α			
VCL	Emissions, Federal Clean Air (for use by central fueled fleets in federally mandated non-attainment areas) Note: Option (VCL) Emissions, Federal Clean Air must be ordered to receive the (LEV) Emissions, California emission compliance - HD certification. If (VCL) Emissions, Federal Clean Air is not ordered, the vehicle will be produced with the base (FE9) Emissions, Federal requirements and will not be (LEV) Emissions, California emission compliance - HD certified 1 - Requires (CT10653) 4WD Extended Cabs with (LU3)	A ¹	A¹	A ¹	n/a			

ADDITIONAL OPTIONS								
Free Flow	Ref.	Description	Base		SLE			
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³		
NB8		Emissions override, California, Maine, Massachusetts, New York or Vermont (for vehicles ordered by dealers in states of California, New York, Vermont, Massachusetts or Maine with Federal emissions) 1 - Requires (FE9) Emissions, Federal requirements.	A ¹	A ¹	A ¹	A ¹		
NC7		Emissions override, Federal (for vehicles ordered by dealers in Federal emission states with California, New York, Vermont, Massachusetts or Maine emissions; may also be used by dealers in states of California, New York, Vermont, Massachusetts or Maine to order different state-specific emissions) 1 - Requires (YF5) Emissions, California requirements, (NG1) Emissions, New York or Vermont state requirements or (NE1) Emissions, Massachusetts or Maine state requirements.	A ¹	A ¹	A ¹	A ¹		
GT4		Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Requires (G80) Differential, locking, heavy-duty, rear - Not available with (M50) Transmission, 5-speed manual and (Z85) Suspension package, Increased Capacity.	A ¹	A ¹	-	A ¹		
ZM5		Skid Plate Package	Α	Α		n/a		
M30		Transmission, 4-speed automatic, electronically controlled with overdrive 1 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	A ¹	A ¹	A ¹	■ 1		

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

No deletions allowed to Equipment Groups. Additional options may be added; check ordering information section for compatibility.

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base	SLE			
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²	
	C60	Air conditioning, front manual		. =		-	
	LN2	Engine, Vortec 2200 L4 MFI 1 - Upgradeable to (LU3) Engine, Vortec 4300 V6 MFI.	□ 1	□¹	□ 1	□ ¹	
	D44	Mirrors, outside rearview, foldaway, manual, Black 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated with (ZQ6) Convenience Package.	. ■	_ 1	□ ¹	□ ¹	
-	E63	Pickup bed, Fleetside 1 - Upgradeable to (E62) Pickup bed, sportside except for CS10803.		_1 ·	□ ¹	_1	
	GT4	Rear axle, 3.73 ratio 1 - Upgradeable to (GT5) Rear axle, 4.10 ratio with (M30) Transmission, 4-speed automatic Required with (LN2) Engine, Vortec 2200 L4 MFI and (MW2) Transmission, 5 - speed manual.	□¹	□ ¹	₀ 1	□ ¹	
	GT5	Rear axle, 4.10 ratio 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (M30) Transmission, 4-speed automatic or (GU4) Rear axle, 3.08 ratio with (M50) Transmission, 5-speed manual and (LU3) Engine, Vortec 4300 V6 MFI.	_1	□ 1	_1	<u>1</u>	
	AM6	Seats, front 60/40 split bench 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.		□ ¹	₋₁	₀ 1	
	AM6	Seats, front 60/40 split-bench 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.	□ ¹	_1	₁	₋₁	
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZCE) Tire, spare P205/75R15 all-season, blackwall or (ZCA) Tire, spare P205/75R15, all-season, White outlined-letter.	_1	o ¹			
	MW2	Transmission, 5-speed manual 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT4) Rear axle, 3.73 ratio.	□ ¹	□ ¹ .	_ ¹	₁	
	MW2	Transmission, 5-speed manual 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio.	_1	_ 1	_ ¹	_1	

Free Flow	Ref. Only	Description	Base	SLE		
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	GT5	Rear axle, 4.10 ratio 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI. Required with (M30) Transmission, 4-speed automatic and (LN2) Engine, Vortec 2200 L4 MFI.	□¹	o¹		
	Z85	Suspension Package, Increased Capacity				
	Z85	Suspension Package, Increased Capacity				
	Z83	Suspension Package, Solid Smooth Ride 1 - Upgradeable to (Z85) Suspension package, Increased Capacity.	□ ¹	₋₁		
	QCE	Tires, P205/75R15, all-season, blackwall 1 - Upgradeable to (QCA) Tires, P205/75R15, all-season, White outlined-letter.	□ 1	□ ¹	,	
	M30	Transmission, 4-speed automatic				
		Base Decor				
		Bumpers, front and rear, Dark Gray				
	UM7	Sound system, ETR AM/FM stereo 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	₋₁			
	PH1	Wheels , 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray	=			
	VF6	Bumpers, front and rear			•	-
ZQ3		Convenience Package				•
	B30	Floor covering, color-keyed carpeting				
U16		Instrumentation, tachometer				
		LS decor 1 - Upgradeable to (YC5) LS trim with exterior appearance package.		₋₁		
UN0		Sound system, ETR AM/FM stereo with CD player 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.		□ ¹	□ ¹	_ ₁ 1
	NP5	Steering wheel, leather-wrapped rim		•		
	N60	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum				
	ZQ8	Suspension Package, Sport				
	QCB	Tires, P235/55R16, all-season, blackwall				
	N96	Wheels, 4 - 16" x 7" (40.6 cm x 17.8 cm) aluminum, 5-spoke			■'	
AJ1		Glass, Solar-Ray deep tinted				
	V4A	Xtreme Sport Appearance Package			-	

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

No deletions allowed to Equipment Groups. Additional options may be added; check ordering information section for compatibility.

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base	SLE			
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
	C60	Air conditioning, front manual			•	•	
	LU3	Engine, Vortec 4300 V6 MFI					
	E63	Pickup bed, Fleetside 1 - May be upgraded to (E62) Pickup bed, sportside.		п¹		•	
	AV5	Seats, front high-back reclining buckets 1 - May be substituted with (AM6) Seats, front 60/40 split bench with (M30) Transmission, 4-speed automatic. 2 - Upgradeable to (AN3) Seats, front leather seating surfaces high-back reclining buckets.	_1	_1	•	□ ²	
	D44	Mirrors, outside rearview, foldaway, manual, Black 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated.		_1	□ ¹		
	GU6	Rear axle, 3.42 ratio 1 - Upgradeable to (GT4) Rear axle, 3.73 ratio.	□ ¹	□¹		_ 1	
	Z85	Suspension Package, Increased Capacity					
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZEB) Tire, spare P235/75R15, on-/off-road, white outline-letter or (ZBF) Tire, spare P235/70R15, all-season, blackwall.	_1	_1		_1	
	QBF	Tires, P235/70R15, all-season, blackwall 1 - Includes (ZAA)Tire, spare, compact, located at rear underbody of vehicle - Upgradeable to (QEB) Tires, P235/75R15,on-/off-road, white outlined-letter.	1	₀ 1		□ 1	
	M50	Transmission, 5-speed manual 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (GU6) rear axle 3.42 ratio with (Z85) Suspension Package, increased capacity Not available with (AM6) Seats, front 60/40 split bench. 2 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	_1	□ 1	□ ²		
		Bumpers, front and rear, Dark Gray					
		Base Decor					
	UM7	Sound system, ETR AM/FM stereo 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	□ ¹				
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray					
ZQ3		Convenience Package					

PEG STAIRSTEP - 4WD

Free Flow	Ref. Only	Description	Base	SLE		
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
B30		Floor covering, color-keyed carpeting		•	-	
U16		Instrumentation, tachometer				
		LS decor 1 - May be upgraded to (YC5) LS trim with Exterior Appearance Package.		1		=
V76		Recovery hooks, 2 front, frame-mounted		. •		
UN0		Sound system, ETR AM/FM stereo with CD player 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.		□ ¹ '	_ 1	_1
	NP5	Steering wheel, leather-wrapped rim				
		Bumpers, front and rear, body-color				
	N90	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, cast				
G80		Differential, locking, heavy-duty, rear				
GT4		Rear axle, 3.73 ratio				
ZM5		Skid Plate Package				
	ZR2	Suspension Package, Wide Stance				
	ZWU	Tire, spare				
	QWU	Tires , P265/75R15				
	PA3	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) bright aluminum				
ZQ6		Convenience Package				
AJ1		Glass, Solar-Ray deep tinted				
M30		Transmission, 4-speed automatic				

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref. Only	Description -	Base	SLE			
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²	
		Air bags, frontal, driver and right front passenger, includes passenger side deactivation switch	S	S	S	S	
	C60	Air conditioning, front manual			•		
		Assist handle, front passenger	s	s	S	S	
		Base Decor		n/a	n/a	n/a	
ZQ6		Convenience Package, power windows and door locks, programmable, with lighted switches and driver's express-down window, (DK2) Mirrors, outside rearview, foldaway, power, heated and Keyless entry, remote	n/a	А	A	А	
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α			•	
		Door trim, with integral padded armrest, driver and passenger side map pockets	S	S	S	S	
	B30	Floor covering, color-keyed carpeting	n/a			•	
	BG9	Floor covering, rubberized vinyl	S	n/a	n/a	n/a	
B32		Floormats, includes front rubberized vinyl floormats on Regular and Extended Cab Models 1 - Requires (B30) Floor covering, color-keyed carpeting.	n/a	A ¹	A ¹	A ¹	
U16		Instrumentation, tachometer 1 - Included with (MW2) Transmission, 5- speed manual and (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	A ¹		•	•	
		Instrumentation, analog, includes speedometer, odometer with trip odometer, fuel level, voltmeter, engine temperature, oil pressure and tachometer 1 - (U16) Instrumentation, tachometer included with (MW2) Transmission, 5- speed manual and (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	S¹	S	S	S	
		LS decor 1 - Upgradeable to (YC5) LS trim with exterior appearance package.	n/a	□ 1			
	DC4	Mirror, inside rearview, manual day/night, includes dual reading lights	S	S	S	S	
		Power outlets, auxiliary, covered, 2, 12-volt 1 - One power outlet.	S¹	S	S	S	
		Seat, passenger side rear jump (Extended Cab)	S	S	S	S	

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free	Ref.		Base		SLE	
Flow RPO Code	Only RPO Code	Description 1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	AM6	Seats, front 60/40 split bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders (CS10603 Regular Cab, short box and CS10803 Regular Cab, long box) 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.		□ ¹	_1	1
	AM6	Seats, front 60/40 split-bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders (CS10653 Extended Cab) 1 - Upgradeable to (AV5) Seats, front high-back reclining buckets Not available with (M50) Transmission, 5-speed manual.	□ ¹	□ ¹	□1	□ ¹
AV5		Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console (CS10603 Regular Cab, short box and CS10803 Regular Cab, long box)	n/a	А	А	А
AV5		Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console (CS10653 Extended Cab)	Α	А	А	А
	UM7	Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	_ 1	n/a	n/a	n/a
UP0		Sound system, ETR AM/FM stereo with CD player and cassette, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)	n/a	Α	Α	А
UC6		Sound system, ETR AM/FM stereo with 6-disc CD changer, includes seek-and-scan, digital clock and auto-tone control, speed-compensated volume, TheftLock, Radio Data System (RDS) and 6-speakers	n/a	A	A	A
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	A	_1	_1	₋₁
		Steering wheel, 4-spoke, deluxe, steel sleeve, includes theft-deterrent locking feature, Black	S	n/a	n/a	n/a
	NP5	Steering wheel, leather-wrapped rim, Black, steel sleeve, includes theft-deterrent locking feature	n/a			
CF5		Sunroof, power, tilt-sliding 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI on (CS10603).	A ¹	A ¹	A ¹	A ¹

INTERIOR - 2WD

Free Flow	Ref. Only	Description 1 - Equipment groups 1SA and 1SB available on CS10603,	Base 1SA ¹	SLE		
RPO RPO	RPO Code			1SB ¹	1SC ²	1SX ²
		Theft-deterrent system, PASSlock	S	s	s	s
	D34	Visors, padded, color-keyed	S	n/a	n/a	n/a
		Visors, padded, color-keyed and vanity mirror, passenger-side	n/a	S	S	S
		Warning tones, headlamp on, key-in-ignition, driver safety belt unfasten, turn signal on	S	S	S	S
		Windows, rear quarter swing-out (Extended Cab Models)	s	S	S	S
A28		Window, rear sliding	Α .	Α	Α	Α

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref. Only	Description	Base	SLE		
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Fequipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
<u> </u>		Air bags, frontal, driver and right front passenger, includes passenger side deactivation switch 1 - Deactivation switch not available with Crew Cab Models.	S	S	S	S ¹
	C60	Air conditioning, front manual				-
		Assist handle, front passenger	S	S	S	S
		Base Decor		n/a	n/a	n/a
	DK7	Console, overhead custom, includes 2 storage compartments, garage door opener compartment, 4 map lights, dome lamp, electronic compass and outside temperature display	n/a	n/a	n/a	S
ZQ6		Convenience Package, power windows and door locks, programmable, with lighted switches and driver's express-down window, (DK2) Mirrors, outside rearview, foldaway, power, heated and Keyless entry, remote	n/a	Α .	А	
ZQ3		Convenience Package, Tilt-Wheel and cruise control	Α .			
		Door locks, child security, rear	n/a	n/a	n/a	S
		Door trim, with integral padded armrest, driver and passenger side map pockets	S	S	S	s
B30		Floor covering, color-keyed carpeting 1 - Requires a Fleet or Governmental Order type.	A ¹			
	BG9	Floor covering, rubberized vinyl	S	n/a	n/a	n/a
B32		Floormats, includes front rubberized vinyl floormats on Regular and Extended Cab Models, front and rear carpeted floormats on Crew Cab Models 1 - Requires a Fleet or Governmental Order type.	A ¹	Α	Α	А
U16		Instrumentation, tachometer 1 - Available with (M30) Transmission, 4-speed automatic and included with (M50) Transmission, 5-speed manual.	A ¹			
		Instrumentation, analog, includes speedometer, odometer with trip odometer, fuel level, voltmeter, engine temperature, oil pressure and tachometer 1 - (U16) Instrumentation, tachometer included with (M50) Transmission, 5-speed manual. Optional with (M30) Transmission, 4-speed automatic.	S ¹	S	S	S

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free	Ref.	Description 1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	Base	SLE		
RPO Code	RPO Code		1SA ¹	1SB ²	1SC ²	1SA ³
		LS decor 1 - May be upgraded to (YC5) LS trim with Exterior Appearance Package.	n/a	_1		-
	DC4	Mirror, inside rearview, manual day/night, includes dual reading lights 1 - Dual reading lamps are located in overhead console on Crew Cab.	S	S	S	S ¹
		Power outlets, auxiliary, covered, 2, 12-volt 1 - One power outlet.	S ¹	S	S	S
		Seat, passenger side rear jump (Extended Cab)	S	S	S	n/a
		Seats, rear bench, full width, 3-passenger	n/a	n/a	n/a	S
AM6		Seats, front 60/40 split-bench, manual reclining, integral outboard head restraints, armrests with integral storage, dual cupholders 1 - Not available with (M50) Transmission, 5-speed manual.	A ¹	A ¹	n/a	n/a
	AV5	Seats, front high-back reclining buckets, includes manual driver and passenger recliners, integral head restraints, floor console and (Storage pockets on Crew Cab Models) 1 - May be substituted with (AM6) Seats, front 60/40 split bench with (M30) Transmission, 4-speed automatic. 2 - Upgradeable to (AN3) Seats, front leather seating surfaces high-back reclining buckets.	_1	₁		□ ²
AN3		Seats, front leather seating surfaces high-back reclining buckets, 8-way power, heated, adjustable head restraints and storage pockets 1 - Requires (122) Seats, front high-back reclining buckets, Leather seating surfaces.	n/a	n/a	n/a	A ¹
	UM7	Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock 1 - Upgradeable to (UN0) Sound system, ETR AM/FM stereo with CD player.	_1	n/a	n/a	n/a
UP0		Sound system, ETR AM/FM stereo with CD player and cassette, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Requires a Fleet or Governmental Order type.	A ¹	A	Α	А
UC6		Sound system, ETR AM/FM stereo with 6-disc CD changer, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)	n/a	A	A	A

Free Flow	Ref. Only	Description	Base	SLE			
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
UN0		Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS) 1 - Upgradeable to (UP0) Sound system, ETR AM/FM stereo with CD player and cassette or (UC6) Sound system, ETR AM/FM stereo with 6-disc CD changer.	Α	_1	□ ¹	_1	
		Steering wheel, 4-spoke, deluxe, steel sleeve, includes theft-deterrent locking feature, Black	s	n/a	n/a	n/a	
	NP5	Steering wheel, leather-wrapped rim, Black, steel sleeve, includes theft-deterrent locking feature	n/a	•			
CF5		Sunroof, power, tilt-sliding	Α	Α	Α	n/a	
		Theft-deterrent system, PASSlock	S	S	S	S	
	D34	Visors, padded, color-keyed	S	n/a	n/a	n/a	
		Visors, padded, color-keyed and vanity mirror, passenger-side 1 - Upgradeable to (DH6) Visors, padded, color-keyed, illuminated vanity mirrors, passenger- and driver-side.	n/a	S	S	S ¹	
DH6		Visors, padded, color-keyed, illuminated vanity mirrors, passenger- and driver-side	n/a	n/a	n/a	A	
		Warning tones, headlamp on, key-in-ignition, driver safety belt unfasten, turn signal on	S	S	S	S	
		Windows, rear quarter swing-out (Extended Cab)	S	S	S	n/a	
A28		Window, rear sliding	n/a	Α	Α	Α	

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref. Only	Description	Base	Base SLE				
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²		
		Air dam, body-color 1 - Standard with (YC5) LS Trim with Exterior Appearance Package.	n/a	S¹	n/a	S		
		Air dam, Gray 1 - Air dam, body-color standard with (YC5) LS trim with Exterior Appearance Package.	S	S ¹	S	n/a		
	VF6	Bumpers, front and rear, body color, step, includes step pad	n/a					
		Bumpers, front and rear, Dark Gray, rear step includes pad		n/a	n/a	n/a		
	T61	Daytime running lamps, includes automatic exterior lamp control	S	S	S	S		
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	Α	Α			
		Door, 3rd, driver-side 1 - Standard on CS10653 Extended Cab only.	S¹	S¹	S ¹	S¹		
ANL		Fog lamps, front, halogen, incorporated into headlamp assembly	n/a	Α	Α	n/a		
	ANL	Fog lamps, front, halogen, integrated into front bumper with (V4A) Xtreme Package	n/a	n/a	n/a	S		
B94		Gold Package, includes Gold exterior emblems, stripe and wheels 1 - Not available with (74U) Victory red exterior paint, (43U) Yellow exterior paint or Red Flames decals. Dealer must order (54A) Gold stripe, which requires (B94) Gold Package.	n/a	n/a	n/a	A ¹		
		Grille, Monochromatic, color-keyed 1 - Included with (V4A) Xtreme sport appearance package.	n/a	n/a	n/a	S¹		
YC5		LS trim, with exterior appearance package, includes (V37) Bumpers, front and rear, chrome, step and bodyside moldings with chrome insert 1 - Not available with (E62) Pickup bed, sportside or CS10803 Regular Cab, long box.	n/a	A ¹	n/a	n/a		
	D44	Mirrors, outside rearview, foldaway, manual, Black, below eye-line, adjustable 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated with (ZQ6) Convenience Package.		_1	_1	_ ¹		

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref.	Description 1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	Base	SLE			
RPO Code	RPO Code		1SA ¹	1SB ¹	1SC ²	1SX ²	
	DK2	Mirrors, outside rearview, foldaway, power, heated 1 - Included with (ZQ6) Convenience Package.	n/a	l ¹	l ¹	l ¹	
	E63	Pickup bed, Fleetside, all-welded steel with double wall construction and corrosion protection with 8 cargo tie-downs and tailgate, locking, 2-position 1 - Upgradeable to (E62) Pickup bed, sportside except for CS10803.	-	_1	_1	1	
E62		Pickup bed, Sportside 1 - Not available with (YC5) LS trim with exterior appearance package or CS10803.	n/a	A ¹	A ¹	A ¹	
PCX		Special Equipment Package, bed extender	Α	Α	Α	Α	
PDA		Special Equipment Package, Black anodized bed rails 1 - Not available with (YC5) LS trim with exterior appearance package, (V4A) Xtreme sport appearance package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment Package, hard lockable tonneau cover, (PCZ) Special Equipment Package, Chrome bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails or Model CS10803.	A ¹	A ¹	A ¹	n/a	
PCZ		Special Equipment Package, chrome bed rails 1 - Not available with (PDW) Special equipment package, soft tonneau cover, (V4A) Xtreme Sport Appearance Package, (PDU) Special Equipment Package, hard lockable tonneau cover, (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PDA) Special Equipment Package, Black anodized bed rails or CS10803.	A ¹	A ¹	A ¹	n/a	
PDU		Special Equipment Package, hard lockable tonneau cover 1 - Not available with (PDW) Special Equipment Package, soft tonneau cover, (PDA) Special Equipment Package, Black anodized bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails or CS10803.	A ¹	A ¹	A ¹	A ¹	
PDB		Special Equipment Package, natural brushed aluminum bed rails 1 - Not available with (YC5) LS trim with Exterior Appearance Package, (V4A) Xtreme Sport Appearance Package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment Package, hard lockable tonneau cover, (PCZ) Special Equipment Package, Chrome bed rails, (PDA) Special Equipment Package, black anodized bed rails or CS10803.	A ¹	A ¹	A ¹	n/a	
PDW		Special Equipment Package, soft tonneau cover 1 - Not available with (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails, (PDA) Special Equipment Package, Black anodized bed rails, (PDU) Special Equipment Package, hard lockable tonneau cover or Model CS10803.	A ¹	A ¹	A ¹	A ¹	
PDZ		Special Equipment Package, trailer hitch 1 - Requires (LU3) Engine, Vortec 4300 V6 MFI. Not available with (E62) Pickup bed, sportside or (V4A) Xtreme Sport Appearance Package.	A ¹	A ¹	A ¹	n/a	

Free Flow	Ref. Only	Description	Base	SLE			
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²	
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZCE) Tire, spare P205/75R15 all-season, blackwall or (ZCA) Tire, spare P205/75R15, all-season, White outlined-letter.	□¹	₋₁		-	
ZCA		Tire, spare P205/75R15, all season, White outlined-letter. 1 - Requires (QCA) Tires, P205/75R15, all-season, white outlined-letter.	A ¹	A ¹	n/a	n/a	
ZCE		Tire, spare P205/75R15, all-season, blackwall 1 - Requires (QCE) Tires, P205/75R15, all-season, blackwall.	A ¹	A ¹	n/a	n/a	
	QCE	Tires, P205/75R15, all-season, blackwall 1 - Upgradeable to (QCA) Tires, P205/75R15, all-season, White outlined-letter.	□ 1	□ ¹	n/a	n/a	
QCA		NEW! Tires, P205/75R15, all-season, White outlined-letter	Α	Α	n/a	n/a	
	QCB	Tires, P235/55R16, all-season, blackwall	n/a	n/a			
	N60	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, includes center caps	n/a		n/a	n/a	
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps	•	n/a	n/a	n/a	
	N96	Wheels, 4 - 16" x 7" (40.6 cm x 17.8 cm) aluminum, 5-spoke, includes center caps	n/a	n/a	=		
		Wipers, intermittent, front, includes pulse washers	S	S	S	S	
D98		Xtreme accent stripe, for hood or Flame side decal, roof and tailgate (Dealer must specify 13A, 41A, 59A, 70A if stripes are desired or 38A if Red Flame side decals are desired)	n/a	n/a	n/a	А	
BZY		Xtreme specific bed liner 1 - Requires (V4A) Xtreme Sport Appearance Package.	n/a	n/a	n/a	A ¹	
	V4A	Xtreme Sport Appearance Package, includes (ZQ8) Suspension Package, Sport, consisting of a 2" (5.1 cm) lowered ride height and monotube shocks, 16" x 8" (40.6 cm x 20.3 cm) aluminum wheels, (QCB) Tires, P235/55R16 all-season blackwall, body-colored grille with gold bowtie as well as body-colored front and rear bumpers	n/a	n/a	n/a		

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref.	Description	Base	SLE		
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653, 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	18C ²	1SA ³
		Air dam, body-color 1 - Air dam Spectra Gray with (ZR5) Appearance Package.	n/a	n/a	n/a	S ¹
		Air dam, Gray	s	S	S	n/a
		Bumpers, front and rear, body-color, rear step includes pad	n/a		n/a	
		Bumpers, front and rear, Dark Gray, rear step includes pad	=	n/a	•	n/a
E95		Cargo cover, soft tonneau, Black 1 - Requires (ZR5) Appearance Package. Not available with (PCX) Special Equipment Package, bed extender.	n/a	n/a	n/a	A ¹
	T61	Daytime running lamps, includes automatic exterior lamp control	S	s	S	S
AJ1		Glass, Solar-Ray deep tinted (all windows except light tinted glass on windshield, driver and front passenger)	n/a	А	А	-
		Door, 3rd, driver-side 1 - Requires CT10653 Extended Cab Model.	S ¹	S¹	S ¹	n/a
ANL		Fog lamps, front, halogen, incorporated into headlamp assembly	n/a	A	A	А
		Grille, color-keyed and chrome with composite headlamps	n/a	n/a	n/a	S
		Grille, Gray and chrome with composite headlamps	S	S	S	n/a
YC5		LS trim, with exterior appearance package, includes (V37) Bumpers, front and rear, chrome, step and bodyside moldings with chrome insert 1 - Not available with (E62) Pickup bed, sportside.	n/a	A ¹	n/a	n/a
	D44	Mirrors, outside rearview, foldaway, manual, Black, below eye-line, adjustable 1 - Upgradeable to (DK2) Mirrors, outside rearview, foldaway, power, heated.	=	_1	□ ¹	n/a
	DK2	Mirrors, outside rearview, foldaway, power, heated 1 - Included with (ZQ6) Convenience Package.	n/a	l ¹	l ¹	S
		Pickup bed liner	n/a	n/a	n/a	S

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
	E63	Pickup bed, Fleetside, all-welded steel with double wall construction and corrosion protection with 8 cargo tie-downs and tailgate, locking, 2-position 1 - May be upgraded to (E62) Pickup bed, sportside.		₋₁		
E62		Pickup bed, Sportside	n/a	А	n/a	n/a
PCX		Special Equipment Package, bed extender	Α	Α	Α	Α
PDA		Special Equipment Package, Black anodized bed rails 1 - Not available with (YC5) LS trim with Exterior Appearance Package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment Package, hard lockable tonneau cover, (PDB) Special Equipment Package, natural brushed aluminum bed rails or (PCZ) Special Equipment Package, Chrome bed rails.	A ¹	A ¹	A ¹	n/a
PCZ		Special Equipment Package, chrome bed rails 1 - Not available with (PDA) Special Equipment Package, Black anodized bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails, or (PDW) Special Equipment Package, soft tonneau cover or (PDU) Special Equipment Package, black anodized bed rails.	A ¹	A ¹	A ¹	n/a
PDU		Special Equipment Package, hard lockable tonneau cover 1 - Not available with (PDW) Special Equipment Package, soft tonneau cover, (PDA) Special Equipment Package, Black anodized bed rails, (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails or Crew Cab (ZR5) Appearance Package.	A ¹	A ¹	A ¹	A ¹
PDB		Special Equipment Package, natural brushed aluminum bed rails 1 - Not available with (YC5) LS trim with Exterior Appearance Package, (PDW) Special Equipment Package, soft tonneau cover, (PDU) Special Equipment package, hard lockable tonneau cover, (PCZ) Special Equipment Package, Chrome bed rails or (PDA) Special Equipment package, Black anodized bed rails.	A ¹	A ¹	A ¹	n/a
PDW		Special Equipment Package, soft tonneau cover 1 - Not available with (PDB) Special Equipment Package, natural brushed aluminum bed rails, (PCZ) Special Equipment Package, Chrome bed rails, (PDA) Special Equipment Package, Black anodized bed rails, (PDU) Special Equipment Package, hard lockable tonneau cover or (ZR5) Appearance Package.	A ¹	A ¹	A ¹	A ¹
PDZ		Special Equipment Package, trailer hitch 1 - Not available with (E62) Pickup bed, sportside.	Α	A ¹	Α	Α
ZEB		Tire, spare P235/75R15, on-/off-road, White outlined-letter, located at rear underbody of vehicle 1 - Available with (QEB) Tires, P235/75R15,on-/off-road, White outlined-letter.	A ¹	A ¹	n/a	A ¹
	ZWU	Tire, spare, P265/75R15, on-/off-road, blackwall, located at rear underbody of vehicle 1 - Included with (QWU) Tires, P265/75R15, on-/off-road, blackwall.	n/a	n/a	1	n/a

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
	ZAA	Tire, spare, compact, located at rear underbody of vehicle. 1 - Upgradeable to (ZEB) Tire, spare P235/75R15, on-Joff-road, white outline-letter or (ZBF) Tire, spare P235/70R15, all-season, blackwall.	_1	¹	n/a	_ 1
ZBF		Tire, spare P235/70R15, all-season, blackwall, located at rear underbody of vehicle 1 - Available with (QBF) Tires, P235/70R15, all-season, blackwall Upgradeable to (ZEB) Tire, spare P235/75R15, on-/off-road, white outline-letter.	A ¹	A ¹	n/a	A ¹
	QBF	Tires, P235/70R15, all-season, blackwall 1 - Includes (ZAA)Tire, spare, compact, located at rear underbody of vehicle - Upgradeable to (QEB) Tires, P235/75R15,on-/off-road, white outlined-letter.	_1	□ ¹	n/a	□ ¹
QEB		Tires, P235/75R15, on-/off-road, White outlined-letter 1 - Includes (ZAA)Tire, spare, compact, located at rear underbody of vehicle.	A ¹	A ¹	n/a	A ¹
	QWU	Tires, P265/75R15, on-/off-road, blackwall 1 - Includes (ZWU) Tire, spare, P265/75R15, on-/off-road, blackwall.	n/a	n/a	■ 1	n/a
V76		Recovery hooks, 2 front, frame-mounted	Α			
	N90	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, cast, includes center caps	n/a		n/a	
	PA3	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) bright aluminum, includes gray accent, center caps	n/a	n/a	•	n/a
	PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps		n/a	n/a	n/a
		Wipers, intermittent, front, includes pulse washers	S	S	S	S
ZR5		NEW! Appearance Package, includes Black roof rack, side steps, bed rails, specific aluminum wheels with Spectra Gray accents, Spectra Gray wheel flares and bumpers and (2) ZR5 decals 1 - Not available with (PDU) Special Equipment Package, hard lockable tonneau cover or (PDW) Special Equipment Package, soft tonneau cover.	n/a	n/a	n/a	A ¹

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only RPO Code	Description 1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	Base	SLE		
RPO Code			1SA ¹	1SB ¹	1SC ²	1SX ²
	K60	Alternator, 100 amps	S	s	s	S
		Battery, heavy-duty, 525 cold-cranking amps, includes rundown protection	S	S	S	S
		Brakes, 4-wheel antilock, front disc/rear drum	S	s	S	S
V10		Cold Climate Package, includes engine block heater and Battery, heavy-duty 690 cold-cranking amps 1 - Required in Alaska, Minnesota, Montana, North Dakota, and South Dakota Includes heavy-duty battery and (K05) Engine block heater.	A ¹	A ¹	A ¹	A ¹
G80		Differential, locking, heavy-duty, rear 1 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual Not available with (LN2) Engine, Vortec 2200 L4 MFI. 2 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual Required with (ZQ8) Suspension, Sport Not available with (LN2) Engine, Vortec 2200 L4 MFI.	A ¹	A ¹	A²	A ²
FE9		Emissions, Federal requirements	Α	Α	А	А
NG1		Emissions, New York or Vermont state requirements	Α	Α	Α	Α
NE1		Emissions, Maine or Massachusetts state requirements	Α	Α	А	Α
YF5		Emissions, California state requirements	Α	А	А	Α
VCL		Emissions, Federal Clean Air (for use by central fueled fleets in federally mandated non-attainment areas) Note: Option (VCL) Emissions, Federal Clean Air must be ordered to receive the (LEV) Emissions, California emission compliance - HD certification. If (VCL) Emissions, Federal Clean Air is not ordered, the vehicle will be produced with the base (FE9) Emissions, Federal requirements and will not be (LEV) Emissions, California emission compliance - HD certified 1 - Requires (CS10653) 2WD Extended Cabs with (LU3) Engine, Vortec 4300 V6 MFI and (M30) Transmission, 4-speed automatic or (CS10603/CS10653) models with (LN2) Engine, Vortec 2200 L4 MFI and (M30) Transmission,	A ¹	A ¹	A ¹	A ¹

Free Flow	Ref.	Description 1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	Base	SLE		
RPO Code	RPO Code		1SA ¹	1SB ¹	1SC ²	1SX ²
NB8		Emissions override, California, Maine, Massachusetts, New York or Vermont (for vehicles ordered by dealers in states of California, New York, Vermont, Massachusetts or Maine with Federal emissions) 1 - Requires (FE9) Emissions, Federal requirements.	A ¹	A ¹	A ¹	A ¹
NC7		Emissions override, Federal (for vehicles ordered by dealers in Federal emission states with California, New York, Vermont, Massachusetts or Maine emissions; may also be used by dealers in states of California, New York, Vermont, Massachusetts or Maine to order different state-specific emissions) 1 - Requires (YF5) Emissions, California requirements, (NG1) Emissions, New York or Vermont state requirements or (NE1) Emissions, Massachusetts or Maine state requirements.	A ¹	A ¹	A ¹	A ¹
	LN2	Engine, Vortec 2200 L4 MFI, (120 HP [89.5 kW] @ 5000 rpm, 140 lbft. [189.0 N-m] @ 3600 rpm) 1 - Upgradeable to (LU3) Engine, Vortec 4300 V6 MFI.	□ ¹	□ 1	□1	□ ¹
LU3		Engine, Vortec 4300 V6 MFI (2WD - 180 HP [134.3 kW] @ 4400 rpm, 245 lbft. [330.7 N-m] @ 2800 rpm) (4WD - 190 HP [141.7 kW] @ 4400 rpm, 250 lbft. [339.5 N-m] @ 2800 rpm)	A	А	А	A
	C5T	GVWR , 4200 lbs. (1905 kg) (CS10603 Regular Cab, short box)	S	S	S	S
	СЗА	GVWR , 4400 lbs. (1996 kg) (CS10653 Extended Cab)	n/a	n/a	S	S
	C5D	GVWR , 4600 lbs. (2087 kg) (CS10653 Extended Cab)	S	S	n/a	n/a
	C5D	GVWR, 4600 lbs. (2087 kg) (CS10803 Regular Cab, long box with (LN2))	S	S	n/a	n/a
C5A		GVWR , 4900 lbs. (2223 kg) (CS10803 Regular Cab, long box with (LU3))	Α	А	n/a	n/a
GU4		Rear axle, 3.08 ratio (CS10603 Regular Cab, short box) 1 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual. Requires (G80) Differential, locking, heavy duty, rear. Not available with (M30) Transmission, 4-speed automatic.	n/a	A ¹	A ¹	A ¹
GU4		Rear axle, 3.08 ratio (CS10653 Extended Cab) 1 - Required with (LU3) Engine, Vortec 4300 V6 MFI and (M50) Transmission, 5-speed manual. Requires (G80) Differential, locking, heavy duty, rear. Not available with (M30) Transmission, 4-speed automatic.	A ¹	A ¹	A ¹	A ¹
GU6		Rear axle, 3.42 ratio (CS10603 Regular Cab, short box, CS10803 Regular Cab, long box and CS10653 Extended Cab) 1 - Required with (M30) Transmission, 4-speed automatic and (LU3) Engine, Vortec 4300 V6 MFI.	A ¹	A ¹	A ¹	A ¹

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	GT4	Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Upgradeable to (GT5) Rear axle, 4.10 ratio with (M30) Transmission, 4-speed automatic Required with (LN2) Engine, Vortec 2200 L4 MFI and (MW2) Transmission, 5 - speed manual.	o¹	1	_ ¹	₀ 1
GT5		Rear axle, 4.10 ratio (CS10603 Regular Cab, short box) 1 - Required with (LN2) Engine, Vortec 2200 L4 MFI and (M30) Transmission, 4-speed automatic.	A ¹	A ¹	A ¹	A ¹
	GT5	Rear axle, 4.10 ratio (CS10803 Regular Cab, long box) 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI. Required with (M30) Transmission, 4-speed automatic and (LN2) Engine, Vortec 2200 L4 MFI.	□ ¹	□1	n/a	n/a
	GT5	Rear axle, 4.10 ratio (CS10653 Extended Cab) 1 - Upgradeable to (GU6) Rear axle, 3.42 ratio with (M30) Transmission, 4-speed automatic or (GU4) Rear axle, 3.08 ratio with (M50) Transmission, 5-speed manual and (LU3) Engine, Vortec 4300 V6 MFI.	□ ¹	□ ¹	₁	_1
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar (CS10653 Extended Cab only)		· =	n/a	n/a
	Z 85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar (CS10803 Regular Cab, long box only) 1 - (Z85) Suspension Package, Increased Capacity includes RPO (C5A) GVWR, 4900 lbs. (2223 kg) with (LU3) Engine, Vortec 4300 V6 MFI; includes (C5D) GVWR, 4600 lbs. (2087 kg) with (LN2) Engine, Vortec 2200 L4 MFI.	1	1	n/a	n/a
	Z83	Suspension Package, Solid Smooth Ride (CS10603 Regular Cab, short box) 1 - Upgradeable to (Z85) Suspension package, Increased Capacity.	□1	□¹	n/a	n/a
	ZQ8	Suspension Package, Sport , includes (N96) 16" (40.6 cm) aluminum, 5-spoke and (QCB) Tires, P235/55R16, all-season, blackwall (CS10603 Regular Cab, short box and CS10653 Extended Cab)	n/a	n/a		=
M30		Transmission, 4-speed automatic, electronically controlled with overdrive (CS10603 Regular Cab, short box and CS10653 Extended Cab) 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio or (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI.	A ¹	A ¹	A ¹	A ¹
	M30	Transmission, 4-speed automatic, electronically controlled with overdrive (CS10803 Regular Cab, long box) 1 - Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio or (GU6) Rear axle, 3.42 ratio with (LU3) Engine, Vortec 4300 V6 MFI.	■ ¹	■ 1	n/a	n/a

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
	MW2	Transmission, 5-speed manual with overdrive (CS10603 Regular Cab, short box) 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT4) Rear axle, 3.73 ratio.	· □1	1	₋₁	□ ¹
	MW2	Transmission, 5-speed manual with overdrive (CS10653 Extended Cab) 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (LN2) Engine, Vortec 2200 L4 MFI and (GT5) Rear axle, 4.10 ratio.	□ ¹	1	<u> </u>	_1
M50		Transmission, 5-speed manual with overdrive (CS10653 Extended Cab) 1 - Requires (LU3) Engine, Vortec 4300 V6 MFI and (GU4) Rear axle, 3.08 ratio. (G80) Differential, locking, heavy-duty, rear required with (M50) Transmission, 5-speed manual. Not available with (AM6) Seats, front 60/40 split bench.	A ¹	A ¹	A ¹	A ¹
M50		Transmission, 5-speed manual with overdrive (CS10603 Regular Cab, short box) 1 - Requires (LU3) Engine, Vortec 4300 V6 MFI and (GU4) Rear axle, 3.08 ratio. (G80) Differential, locking, heavy-duty, rear required with (M50) Transmission, 5-speed manual. Not available with (AM6) Seats, front 60/40 split bench.	n/a	A ¹	A ¹	A ¹

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	1 - Equipment group 1SA available on CT10653. 2 - Equipment groups 1SB and 1SC available on CT10653 3 - Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
	K60	Alternator, 100 amps	. S	s	s	S
		Battery, heavy-duty, 525 cold-cranking amps, includes rundown protection	S	S	s	s
	JC1	Brakes, 4-wheel antilock, 4-wheel disc	s	S	S	S
V10		Cold Climate Package, includes engine block heater and Battery, heavy-duty 690 cold-cranking amps 1 - Required in Alaska, Minnesota, Montana, North Dakota, and South Dakota Includes heavy-duty battery and (K05) Engine block heater.	A ¹	A ¹	A ¹	A ¹
G80		Differential, locking, heavy-duty, rear 1 - Required with (GT4) Rear axle, 3.73 ratio and (LU3) Engine, Vortec 4300 V6 MFI Optional with (GU6) Rear axle, 3.42 ratio.	A ¹	A ¹	•	A ¹
FE9		Emissions, Federal requirements	Α	А	Α	Α
NG1		Emissions, New York or Vermont state requirements	Α	А	Α	А
NE1		Emissions, Maine or Massachusetts state requirements	Α	Α	Α	Α
YF5		Emissions, California state requirements	Α	А	Α	А
VCL		Emissions, Federal Clean Air (for use by central fueled fleets in federally mandated non-attainment areas) Note: Option (VCL) Emissions, Federal Clean Air must be ordered to receive the (LEV) Emissions, California emission compliance - HD certification. If (VCL) Emissions, Federal Clean Air is not ordered, the vehicle will be produced with the base (FE9) Emissions, Federal requirements and will not be (LEV) Emissions, California emission compliance - HD certified 1 - Requires (CT10653) 4WD Extended Cabs with (LU3) Engine, Vortec 4300 V6 MFI and (M30) Transmission, 4-speed automatic.	A ¹	A ¹	A ¹	n/a
NB8		Emissions override, California, Maine, Massachusetts, New York or Vermont (for vehicles ordered by dealers in states of California, New York, Vermont, Massachusetts or Maine with Federal emissions) 1 - Requires (FE9) Emissions, Federal requirements.	A ¹	A ¹	A ¹	A ¹

^{*}Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base		SLE	
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³
NC7		Emissions override, Federal (for vehicles ordered by dealers in Federal emission states with California, New York, Vermont, Massachusetts or Maine emissions; may also be used by dealers in states of California, New York, Vermont, Massachusetts or Maine to order different state-specific emissions) 1 - Requires (YF5) Emissions, California requirements, (NG1) Emissions, New York or Vermont state requirements or (NE1) Emissions, Massachusetts or Maine state requirements.	A ¹	A ¹	A ¹	A ¹
	LU3	Engine, Vortec 4300 V6 MFI (2WD - 180 HP [134.3 kW] @ 4400 rpm, 245 lbft. [330.7 N-m] @ 2800 rpm) (4WD - 190 HP [141.7 kW] @ 4400 rpm, 250 lbft. [339.5 N-m] @ 2800 rpm)				
	C5A	GVWR , 4900 lbs. (2223 kg)	n/a	n/a	S	n/a
	C6F	GVWR , 5150 lbs. (2336 kg)	S	S	n/a	S
	GU6	Rear axle, 3.42 ratio 1 - Upgradeable to (GT4) Rear axle, 3.73 ratio.	□ 1	_1	n/a	_1
GT4		Rear axle, 3.73 ratio (CS10603 Regular Cab, short box) 1 - Requires (G80) Differential, locking, heavy-duty, rear - Not available with (M50) Transmission, 5-speed manual and (Z85) Suspension package, Increased Capacity.	A ¹	A ¹		A ¹
ZM5		Skid Plate Package	Α	Α		n/a
		Steering, power	S	s	S	S
	Z85	Suspension Package, Increased Capacity, includes 1.26" (32 mm) twin-tube shocks and a 1.14" (29 mm) stabilizer bar			n/a	=
	ZR2	Suspension Package, Wide Stance, includes decal, revised wide-tread frame, strengthened front differential gears and drive axles, large bearings and longer, large rear axle shafts, revised multi-leaf springs and added rear axle track bar, front stabilizer bar, Bilstein gas-pressurized shock absorbers, shield package and chrome grille, front fenders and pickup box outer panels with extra wide wheel flares, modified jack and spare tire stowage winch	n/a	n/a		n/a
		Suspension , front, independent torsion bar, and stabilizer bar	S	S	S	S
		Suspension, rear, semi-floating axle with 2-stage multi-leaf springs	S	S	S	S
	NP1	Transfer case , electronic shift, includes dash-mounted controls	S	S	S	S

MECHANICAL - 4WD

Free Flow	Ref. Only	Description	Base	SLE			
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
M30		Transmission, 4-speed automatic, electronically controlled with overdrive 1 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	A ¹	A ¹	A ¹	■1	
	M50	Transmission, 5-speed manual with overdrive 1 - Upgradeable to (M30) Transmission, 4-speed automatic Requires (GU6) rear axle 3.42 ratio with (285) Suspension Package, increased capacity Not available with (AM6) Seats, front 60/40 split bench. 2 - Requires (G80) Differential, locking, heavy-duty, rear with (GT4) Rear axle, 3.73 ratio.	□ ¹	□ ¹	□ ²	n/a	

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

	1		Transmissions			A	xles		GVWR lbs. (kg)			
Model	Engine	MW2 5-Speed Manual with OD	M50 5-Speed Manual with OD	M30 4-Speed Automatic with OD	GU4 3.08	GU6 3.42	GT4 3.73	GT5 4.10	C5T 4200 (1905)	C3A 4400 (1996)	C5D 4600 (2087)	C5A 4900 (2223)
CS10603	LU3 Vortec 4300 V6 MFI	n/a	n/a	Α	n/a	S	n/a	n/a	n/a	n/a	S	n/a
	LU3 Vortec 4300 V6 MFI	n/a	S	S	S ¹	n/a	n/a	n/a	S	n/a	Α	n/a
	LN2 Vortec 2200 MFI	n/a	n/a	Α	n/a	n/a	n/a	S	S	n/a	Α	n/a
	LN2 Vortec 2200 MFI	S	n/a	n/a	n/a	n/a	S	Α	S	n/a	Α	n/a
CS10803	LU3 Vortec 4300 V6 MFI	n/a	n/a	S	n/a	S	n/a	n/a	n/a	n/a	n/a	S
	LN2 Vortec 2200 MFI	n/a	n/a	S	n/a	n/a	n/a	S	n/a	n/a	S	n/a
CS10653	LU3 Vortec 4300 V6 MFI	n/a	n/a	Α	n/a	S	n/a	n/a	n/a	А	S	n/a
	LU3 Vortec 4300 V6 MFI	n/a	S	n/a	S ¹	n/a	n/a	n/a	n/a	А	S	n/a
	LN2 Vortec 2200 MFI	n/a	n/a	А	n/a	n/a	n/a	S	n/a	А	S	n/a
	LN2 Vortec 2200 MFI	S	n/a	n/a	n/a	n/a	n/a	S	n/a	А	S	n/a

I = Included with another feature
= Included in Equipment Group
= Included in Equipment Group but upgradeable

Model		Transm	Transmissions			GVWR lbs. (kg)	
	Engine	M50 5-Speed Manual with OD	M30 4-Speed Automatic with OD	GU6 3.42	GT4 3.73	C5A 4900 (2223)	C6F 5150 (2336)
CT10653	LU3 Vortec 4300 V6 MFI	S	n/a	S	A ¹	A ²	S
	LU3 Vortec 4300 V6 MFI	n/a	Α	Α	A ¹	A ²	Α
CT10643	LU3 Vortec 4300 V6 MFI	n/a	S	S	A ¹	n/a	S

^{1 -} Requires (G80) Differential, locking, heavy-duty, rear.

^{2 -} Included with (ZR2) Suspension Package, Wide Stance.

I = Included with another feature

■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

				Interior		
Decor Level	Seat Type	Seat Code	Seat Trim	Medium Gray	Graphite	
Base	60/40 reclining split-bench	AM6	Deluxe Cloth	92H	12H	
Base	Reclining high-back buckets	AV5	Deluxe Cloth	92H	12H	
LS	60/40 reclining split-bench	AM6	Deluxe Cloth	92H	12H	
LS	Reclining high-back buckets	AV5	Deluxe Cloth	92H	12H	

Exterior Solid Paint	Color Code		Interior		XTREME ACCENT STRIPE COLORS AND FLAME DECALS Available Accent Stripe Colors						
		WA- Number	Medium Gray	Graphite	13A Sparkle Silver	38A Red Flames	41A Black	70A Torch Red	59A Competition Yellow	54A Gold Package ¹	
Light Pewter Metallic	11U	WA-382E	Α	A	n/a	n/a	n/a	n/a	n/a	n/a	
Indigo Blue Metallic ²	39U	WA-9792	Α	Α	Α	Α	Α	Α	Α	Α	
Black Onyx ²	41U	WA-8555	Α	Α	Α	Α	n/a	Α	Α	* A	
NEW! Yellow ²	43U	WA-5456	Α	Α	Α	Α	Α	Α	n/a	n/a	
Dark Green Metallic	47U	WA-9539	Α	Α	n/a	n/a	n/a	n/a	n/a	n/a	
Summit White ²	50U	WA-8624	Α	Α	Α	Α	Α	Α	n/a	Α	
Sandalwood Metallic	58U	WA-711J	Α	Α	n/a	n/a	n/a	n/a	n/a	n/a	
Victory Red ²	74U	WA-9260	Α	Α	Α	Α	Α	n/a	А	n/a	
Dark Cherry Red Metallic ²	94U	WA-9088	A	А	Α	Α	A	n/a	n/a	Α	

^{1 -} Requires (B94) Gold package. Not available with (74U) Victory Red or (43U) Yellow. (B94) Gold package includes Gold stripe(must specify 54A), badges and wheels.

^{2 -} Available (V4A) Xtreme Sport Appearance Package colors.

COLOR AND TRIM - 4WD Solid Paint

S = Standard Equipment A = Available n/a = Not Available

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

				Interior		
Decor Level	Seat Type	Seat Code	Seat Trim	Medium Gray	Graphite	
Base/LS	60/40 reclining split-bench	AM6	Deluxe Cloth	92H	12H	
Base/LS	Reclining high-back buckets	AV5	Deluxe Cloth	92H	12H	
Crew Cab	Reclining high-back buckets	AV5	Deluxe Cloth	n/a	12H	
Crew Cab	Leather reclining high-back buckets (8-way power, heated)	AN3	Deluxe Leather seating surfaces	n/a	122	

		WA- Number	Interior			
Exterior Solid Paint	Color Code		Medium Gray	Graphite		
Light Pewter Metallic	11U	WA-382E	Α	Α		
Indigo Blue Metallic	39U	WA-9792	Α	A		
Black Onyx	41U	WA-8555	Α	Α		
Yellow	43U	WA-5456	Α	Α		
Dark Green Metallic	47U	WA-9539	Α	A		
Summit White	50U	WA-8624	Α	Α		
Sandalwood Metallic	58U	WA-711J	А	Α		
Victory Red	74U	WA-9260	Α	Α		
Dark Cherry Red Metallic	94U	WA-9088	Α	Α		

COLOR AND TRIM - 4WD SEO Solid Paint

S = Standard Equipment A = Available n/a = Not Available

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

				Interior		
Decor Level	Seat Type	Seat Code	Seat Trim	Medium Gray	Graphite	
Base/LS	60/40 reclining split-bench	AM6	Deluxe Cloth	92H	12H	
Base/LS	Reclining high-back buckets	AV5	Deluxe Cloth	92H	12H	
Crew Cab	Reclining high-back buckets	AV5	Deluxe Cloth	n/a	12H	
Crew Cab	Leather reclining high-back buckets (8-way power, heated)	AN3	Deluxe Leather seating surfaces	n/a	122	

			Interior		
Exterior Solid Paint	Color Code	WA- Number	M edium Gray	Graphite	
Light Stellar Blue	none	WA-146B	A	A	
Yellow	none	WA-9411	Α	A	
Yellow	none	WA-9414	Α	Α	
Wheatland Yellow	9W3	WA-253A	Α	Α	
Green	none	WA-7941	Α	Α	
Green, Woodland	9V5	WA-9015	Α	Α	
Tangier Orange	9W4	WA-9417	Α	Α	
Doeskin Tan	9V9	WA-9403	Α	А	

COLOR AND TRIM - 2WD SEO Solid Paint

S = Standard Equipment A = Available n/a = Not Available

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

				Interior		
Decor Level	Seat Type	Seat Code	Seat Trim	Medium Gray	Graphite	
Base	60/40 reclining split-bench	AM6	Deluxe Cloth	92H	12H	
Base	Reclining high-back buckets	AV5	Deluxe Cloth	92H	12H	
LS	60/40 reclining split-bench	AM6	Deluxe Cloth	92H	12H	
LS	Reclining high-back buckets	AV5	Deluxe Cloth	92H	12H	

			Interior		
Exterior Solid Paint	Color Code	WA- Number	Medium Gray	Graphite	
Light Stellar Blue	none	WA-146B	Α	A	
Yellow	none	WA-9411	Α	Α	
Yellow	none	WA-9414	Α	Α	
Wheatland Yellow	9W3	WA-253A	Α	Α	
Green	none	WA-7941	Α	Α	
Green, Woodland	9V5	WA-9015	Α	Α	
Tangier Orange	9W4	WA-9417	Α	Α	
Doeskin Tan	9V9	WA-9403	Α	Α	

I = Included with another feature ■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref.	Description	Base	SLE			
RPO Code	RPO Code	Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	15B ¹	1SC ²	1SX ²	
		Interior					
9J6		Steering column, tilt (MSRP = \$145.00) Tilt-steering column without cruise control. 1 - Requires RPO (M30) Transmission, 4-speed automatic. Not available with T10643 model, RPO (ZQ3) Convenience Package.	A ¹	n/a	n/a	n/a	
		Exterior					
8X1		Label, fasten safety belts (MSRP = \$2.00) "Fasten Safety Belts" reminder label on side door window glass.	А	A	А	А	
8F2		Tailgate ornamentation delete (MSRP = No Charge) Deletes decals and nameplates on truck exterior. 1 - Not available with RPO (V4A) Xtreme Sport Appearance Package.	A ¹	n/a	n/a	n/a	
8E1		Fuel, additional 3 gallons (MSRP = \$8.00) 3 gallons in addition to normal assembly plant fill. 1 - Requires a Fleet or Government sales order.	A ¹	A ¹	A ¹	A ¹	
9V5		Paints, solid (MSRP = No Charge), Woodland Green 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	
9V9		Paints, solid (MSRP = No Charge), Doeskin Tan 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (VAA) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	
9W3		Paints, solid (MSRP = No Charge), Wheatland Yellow 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	

SEO OPTIONS/SHIP THRU CODES - 2WD

Free Flow	Ref. Only	Description _	Base		SLE	
RPO Code	RPO Code	1 - Equipment groups 1SA and 1SB available on CS10603, CS10803 and CS10653. 2 - Equipment groups 1SC and 1SX available on CS10603 and CS10653.	1SA ¹	1SB ¹	1SC ²	1SX ²
9W4		Paints, solid (MSRP = No Charge), Tangier Orange 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a
		Mechanical				
8U4		Engine block heater (MSRP = \$35.00) Engine block heater with hook-up cord. 1 - Not available with T10643 Model, RPO (V10) Cold Climate Package.	A ¹	A ¹	A ¹	A ¹

I = Included with another feature ■ = Included in Equipment Grou

■ = Included in Equipment Group □ = Included in Equipment Group but upgradeable

*Indicates availability of feature on multiple models. For example, it indicates feature availability on 2WD and 4WD Models or Rear wheel drive and All-wheel drive Models.

Free Flow	Ref. Only	Description	Base	SLE			
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
		Interior	·				
9J6		Steering column, tilt (MSRP = \$145.00) Tilt-steering column without cruise control. 1 - Requires RPO (M30) Transmission, 4-speed automatic. Not available with T10643 model, RPO (ZQ3) Convenience Package.	A ¹	n/a	n/a	n/a	
		Exterior					
8X1		Label, fasten safety belts (MSRP = \$2.00) "Fasten Safety Belts" reminder label on side door window glass.	А	А	А	A	
8F2		Tailgate ornamentation delete (MSRP = No Charge) Deletes decals and nameplates on truck exterior. 1 - Not available with RPO (V4A) Xtreme Sport Appearance Package.	A ¹	n/a	n/a	n/a	
8E1		Fuel, additional 3 gallons (MSRP = \$8.00) 3 gallons in addition to normal assembly plant fill. 1 - Requires a Fleet or Government sales order.	A ¹	A ¹	A ¹	A ¹	
9V5		Paints, solid (MSRP = No Charge), Woodland Green 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	
9V9		Paints, solid (MSRP = No Charge), Doeskin Tan 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	
9W3		Paints, solid (MSRP = No Charge), Wheatland Yellow 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	

SEO OPTIONS/SHIP THRU CODES - 4WD

Free Flow	Ref. Only Description		Base	SLE			
RPO Code	RPO Code	Equipment group 1SA available on CT10653. Equipment groups 1SB and 1SC available on CT10653 Equipment group 1SA available on CT10643.	1SA ¹	1SB ²	1SC ²	1SA ³	
9W4		Paints, solid (MSRP = No Charge), Tangier Orange 1 - Includes dark gray or black front and rear face components in lieu of color keyed. Requires SEO (TGK), Special Paint, one color, to be ordered. Not available with T10643 model, RPO (YC5) LS trim, with exterior appearance package, RPO (V4A) Xtreme Sport Appearance Package and RPO (ANL) Fog lamps, front.	A ¹	n/a	n/a	n/a	
		Mechanical					
8U4		Engine block heater (MSRP = \$35.00) Engine block heater with hook-up cord. 1 - Not available with T10643 Model, RPO (V10) Cold Climate Package.	A ¹	A ¹	A ¹	A ¹	

All dimensions in inches (mm) unless otherwise	stated.	`	·
		Specifications	Regular Cab
			Short Box 2WD CS10603
	 	Wheelbace	108.30
BBC CA	_ A	Wheelbase	(2751)
	B	Overall length	190.00
6/3/4/4/3/4,	Ĭ <u> </u>		(4826)
Y(,)\—	- c	Body width	67.90
-BA - I	┸├──	•	(1725)
8	D	Overall height	62.00 (1575)
	-	Head room, front	39.50
	_	neau room, front	(1003)
▞▀▘▍▝ ▝ ▀▘▍▝▜▘▘▍▋		Shoulder room, front	56.90
d www.iwe	<u>-</u>	,	(1445)
		Hip room, front	53.60
	↓		(1361)
		Leg room, front	42.40 (1077)
		Tallmata width Occupie	(1077) 41.40
		Tailgate width, Sportside	(1052)
		Tailgate width, Fleetside	54.90
		,	(1394)
	CA	Cab to axle	37.40
			(950)
	BA	Front bumper to axle	35.20
		5	(894)
	İ	Rear bumper to back of cab	106.00 (2692)
	GF	Cround to ton of word load	25.90
	"	Ground to top of rear load floor	(658)
	IBL	Inside length, at floor	72.40
		morae length, at hoor	(1839)
		Inside height	16.80
			(427)
	IWR	Inside width, at floor,	51.00
		Sportside	(1295)
	IWR	Inside width, at floor,	54.90 (1394)
	Dena:	Fleetside	
	Iww	Inside width, between wheelhousing, Sportside	39.50 (1003)
	IWW		40.30
	10000	Inside width, between wheelhousing, Fleetside	(1024)
	-	Inside width, rear at top,	51.00
		Sportside	(1295)

Specifications	Regular Cab Short Box 2WD CS10603
Inside width, rear at top, Fleetside	56.60 (1438)
Ground clearance, front	9.10 (231)
Ground clearance, rear	7.20 (183)
Sign panel area	9.5 (241) x 46.25 (1175)

Published dimensions indicated are without optional equipment or accessories. Additional accessories or equipment ordered at the customer's request can result in a minor change in these dimensions.

		Specifications	Regular Cab
			Long Box 2WD CS10803
—BBC——CA—	A	Wheelbase	117.90 (2995)
	В	Overall length	206.00 (5232)
	С	Body width	67.90 (1725)
A B	D	Overall height	62.90 (1598)
		Head room, front	39.50 (1003)
WW IWR		Shoulder room, front	56.90 (1445)
-101.		Hip room, front	53.60 (1361)
		Leg room, front	42.40 (1077)
		Tailgate width	54.90 (1394)
	CA	Cab to axle	47.10 (1196)
	ВА	Front bumper to axle	35.20 (894)
		Rear bumper to back of cab	106.00 (2692)
	GF	Ground to top of rear load floor	28.10 (714)
	IBL	Inside length, at floor	88.30 (2243)
		Inside height	16.80 (427)
	IWR	Inside width, at floor	54.90 (1394)
	IWW	Inside width, between wheelhousing	40.30 (1024)
		Inside width, rear at top	56.60 (1438)
		Ground clearance, front	8.70 (221)
		Ground clearance, rear	6.70
		Sign panel area	(170) 9.5 (241) x 46.25 (1175)

2003 Chevrolet Truck S10

DIMENSIONS - 2WD REGULAR CAB, LONG BOX

	Specifications	Regular Ca Long Box 2V CS10803	VD

All dimensions in inches (mm) unless otherwise	stated.			
		Specifications	Extended Cab 2WD CS10653	Extended Cab 4WD CT10653
	A	Wheelbase	122.90 (3122)	122.90 (3122)
	В	Overall length	205.30 (5215)	205.30 (5215)
	с	Body width	67.90 (1725)	67.90 (1725)
BA B	D	Overall height	62.70 (1593)	63.40 (1610)
,		Head room, front	39.50 (1003)	39.50 (1003)
WW IWA		Shoulder room, front	56.90 (1445)	56.90 (1445)
-IBL + I		Hip room, front	51.60 (1311)	51.60 (1311)
	····	Leg room, front	42.40 (1077)	42.40 (1077)
		Tailgate width, Sportside	41.40 (1052)	41.40 (1052)
		Tailgate width, Fleetside	54.90 (1394)	54.90 (1394)
	CA	Cab to axle	37.40 (950)	37.40 (950)
	ВА	Front bumper to axle	35.20 (894)	35.20 (894)
		Rear bumper to back of cab	120.70 (3066)	120.70 (3066)
	GF	Ground to top of rear load floor	27.20 (691)	27.70 (704)
	IBL	Inside length, at floor	72.80	72.80
		Inside height	(1849) 16.80 (427)	(1849) 16.80
	IWR	Inside width, at floor, Sportside	51.00 (1295)	(427) 51.00 (1295)
	IWR	Inside width, at floor, Fleetside	54.90 (1394)	54.90 (1394)
	IWW	Inside width, between wheelhousing, Sportside	39.50 (1003)	39.50 (1003)
	IWW		40.30 (1024)	40.30 (1024)
		Inside width, rear at top,	51.00 (1295)	51.00 (1295)

Specifications	Extended Cab 2WD CS10653	Extended Cab 4WD CT10653
Inside width, rear at top, Fleetside	56.60 (1438)	56.60 (1438)
Ground clearance, front	8.50 (216)	9.10 (231)
Ground clearance, rear	7.20 (183)	7.50 (190)
Sign panel area	9.5 (241) x 66.5 (1689)	9.5 (241) x 66 (1689)

Published dimensions indicated are without optional equipment or accessories. Additional accessories or equipment ordered at the customer's request can result in a minor change in these dimensions.

All dimensions in inches (mm) unless otherwise s	tated.		
		Specifications	Grew Cab 4WD CT10643
TEA-	A	Wheelbase	122.90 (3122)
	В	Overall length	205.30 (5215)
	С	Body width	67.90 (1725)
-BA-B-	D	Overall height	63.40 (1610)
		Head room, front	39.50 (1003)
IWWWWH I		Head room, rear	38.20 (970)
		Shoulder room, front	56.90 (1445)
	*	Shoulder room, rear	57.20 (1453)
		Hip room, front	51.60 (1311)
		Hip room, rear	49.50 (1257)
		Leg room, front	42.40 (1077)
		Leg room, rear	34.60 (879)
		Tailgate width	54.90 (1394)
	CA	Cab to axle	19.90 (505)
	ВА	Front bumper to axle	35.20 (894)
		Rear bumper to back of cab	138.10 (3508)
	GF	Ground to top of rear load	27.20 (691)
	IBL	Inside length, at floor	55.20 (1402)
		Inside height	16.80 (427)
	IWR	Inside width, at floor	54.90
	iww	Inside width, between	(1394) 40.30 (1034)
	<u></u>	wheelhousing	(1024)

All dimensions in inches (mm) unless otherwise stated.				
	Specifications	Crew Cab 4WD CT10643		
	Inside width, rear at top	56.60 (1438)		
	Ground clearance, front	8.50 (216)		
	Ground clearance, rear	7.50 (190)		
	Sign panel area	9.5 (241) x 66.5 (1689)		

Published dimensions indicated are without optional equipment or accessories. Additional accessories or equipment ordered at the customer's request can result in a minor change in these dimensions.

	Regular Cab 2WD CS10603	Regular Cab, Long Box 2WD CS10803	Extended Cab 2WD CS10653
Specifications			
Front shock absorber diameter, in. (mm)	1.26 (32)	1.26 (32)	1.26 (32)
Front stabilizer bar diameter, in. (mm)	1.00 (25)	1.00 (25)	1.00 (25)
Rear shock absorber diameter, in. (mm)	1.26 (32)	1.26 (32)	1.26 (32)
Rear stabilizer bar diameter, in. (mm)	1.00 (25)	1.00 (25)	1.00 (25)
Turning diameter, curb-to-curb, ft. (m)	37.0 (11.3)	39.8 (12.1)	41.3 (12.6)
Capacities		· · · · · · · · · · · · · · · · · · ·	
Front axle, lbs. (kg)	2500 (1134)	2500 (1134)	2500 (1134)
Front spring capacity, lbs. (kg)	2500 (1134)	2500 (1134)	2500 (1134)
Rear axle, lbs. (kg)	2900 (1315)	2900 (1315)	2900 (1315)
Rear spring capacity, lbs. (kg)	2300 (1043)	2300 (1043)	2700 (1225)
Curb weight, lbs. (kg)	3016 (1368)	3112 (1412)	3198 (1451)
Cargo volume, cargo box, cu. ft. (liters)	39.4 (1115.8)	48.1 (1362.2)	39.4 (1115.8)
Payload ¹ , lbs. (kg)	1184 (537)	1488 (675)	1202 (545)
Gross Vehicle Weight Rating (GVWR), lbs. (kg)	4200 (1905)	4600 (2087)	4400 (1996)
Front Gross Axle Weight Rating (GAWR), bs. (kg)	2500 (1134)	2500 (1134)	2500 (1134)
Rear Gross Axle Weight Rating (GAWR), bs. (kg)	2300 (1043)	2700 (1225)	2300 (1043)
uel capacity, approximate, gallon (liters)	18 (68)	18 (68)	18 (68)
Seating capacity (front/rear)	3/0	3/0	3/1

	Extended Cab 4WD CT10653	Crew Cab 4WD CT10643
Specifications		
Front shock absorber diameter, in. (mm)	1.26 (32)	1.26 (32)
Front stabilizer bar diameter, in. (mm)	1.10 (28)	1.10 (28)
Rear shock absorber diameter, in. (mm)	1.26 (32)	1.26 (32)
Rear stabilizer bar diameter, in. (mm)	1.10 (28)	1.10 (28)
Turning diameter, curb-to-curb, ft. (m)	41.6 (12.7)	41.6 (12.7)
Capacities		1
Front axle, lbs. (kg)	2800 (1270)	2800 (1270)
Front spring capacity, lbs. (kg)	2800 (1270)	2800 (1270)
Rear axle, lbs. (kg)	2900 (1315)	2900 (1315)
Rear spring capacity, lbs. (kg)	2700 (1225)	2700 (1225)
Curb weight, lbs. (kg)	3761 (1706)	4039 (1832)
Cargo volume, cargo box, cu. ft. (liters)	39.4 (1115.8)	30.2 (855.3)
Payload ² , lbs. (kg)	1389 (630)	1111 (504)
Gross Vehicle Weight Rating (GVWR), Ibs. (kg)	5150 (2336)	5150 (2336)
Front Gross Axle Weight Rating (GAWR), lbs. (kg)	2800 (1270)	2800 (1270)
Rear Gross Axle Weight Rating (GAWR), lbs. (kg)	2700 (1225)	2700 (1225)
Fuel capacity, approximate, gallon (liters)	18 (68)	17 (64)
Seating capacity (front/rear)	3/1	2/3

	N60 Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, includes center caps
Image to come	N90 Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, cast, includes center caps
\$503 \$100 \$100 \$100 \$100 \$100 \$100 \$100 \$1	N96 Wheels, 4 - 16" x 7" (40.6 cm x 17.8 cm) aluminum, 5-spoke, includes center caps
	PA3 Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) bright aluminum, includes gray accent, center caps
	PH1 Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray, includes Black center caps



UC6

Sound system, ETR AM/FM stereo with 6-disc CD changer, includes seek-and-scan, digital clock and auto-tone control, speed-compensated volume, TheftLock, Radio Data System (RDS) and 6-speakers



UM7

Sound system, ETR AM/FM stereo, includes seek-and-scan and digital clock




UNO

Sound system, ETR AM/FM stereo with CD player, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)



UP0

Sound system, ETR AM/FM stereo with CD player and cassette, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)



UC

Sound system, ETR AM/FM stereo with 6-disc CD changer, includes seek-and-scan, digital clock, auto-tone control, speed-compensated volume, TheftLock and Radio Data System (RDS)

Deletions

- Beige cloth interior deleted
- Glove box lamp deleted
- Cigarette lighter element deleted (covered 12 volt outlet remains)
- Coin holder deleted from 60/40 bench seat arm rest
- Tow hooks (V76 4X4 only) from standard to optional (included LS uplevel equipment groups)
- Floor mats (B32) from standard LS to optional
- Chrome wheel lip moldings are no longer available as part of the YC5 Exterior Appearance Package
- Tachometer (U16) optional with automatic transmission (included with LS equipment groups), standard with manual transmission
- On Crew cab, under hood lamp and glove box lamp deleted
- On Crew cab, cigarette lighter element deleted (covered 12 volt remains)
- On Crew Cab, lift out center console tray deleted
- NOTE: all equipment groups have been revised to allow for more ordering flexibility

New Features

- 60/40 split-bench seat (AM6) standard on Regular Cab
- ZR5 Appearance Package available on Crew Cab includes (interim 2002): Black roof rack, side steps and bed rails, specific aluminum wheels with Spectra Gray accents, Spectra gray wheel flares and bumpers and (2) ZR5 decals.
- Regular Production Accessories (interim 2002): Bed extender (PCX), chrome bed rails (PCZ), natural brushed aluminum bed rails (PCZ), black anodized bed rails (PDA), soft tonneau cover (PDW), hard lockable tonneau cover (PDU) and trailer hitch (PDZ)
- CS10803 Regular Cab, Long box model
- Yellow exterior color (43U)
- New cloth interior seating surfaces
- Available Flame / Heat decals (38A) on Xtreme models
- Available bedliner with Xtreme logo on Xtreme models (interim availability)
- Available soft tonneau cover for ZR5 Crew Cab with ZR5 logo (interim availability)
- Available (QCA) Tires, P205/75R15, all-season, white outlined-letter
- Equipment Groups have been completely revised to allow for greater ordering flexibility

Changes

- On Crew Cab, full size spare (ZBF/ZEB) is now optional as opposed to standard
- On Crew Cab, illuminated visor vanity mirrors (DH6) are now optional as opposed to standard
- On Crew Cab, fog lamps (ANL) are now optional as opposed to standard
- On Crew Cab, floor mats (B32) are now optional as opposed to standard
- On Crew Cab, sliding rear window (A28) is now optional as opposed to required
- On Crew Cab, rear locking differential (G80) is now optional as opposed to required
- On Crew Cab, P235/75R15 On-off Road white outlined tires (QEB) is now optional as opposed to required
- On Crew Cab, Dual play CD and Cassette Radio (UP0) is now optional as opposed to required
- NOTE: all options are free flow over the 1SA equipment group to allow for more ordering flexibility (1SH from 2002 MY has been dropped)

RPO CODES

Option Code	Description
8E1	Fuel, additional 3 gallons (MSRP = \$8.00)
8F2	Tailgate ornamentation delete (MSRP = No Charge)
8U4	Engine block heater (MSRP = \$35.00)
8X1	Label, fasten safety belts (MSRP = \$2.00)
9J6	Steering column, tilt (MSRP = \$145.00)
9V5	Paints, solid (MSRP = No Charge), Woodland Green
9V9	Paints, solid (MSRP = No Charge), Doeskin Tan
9W3	Paints, solid (MSRP = No Charge), Wheatland Yellow
9W4	Paints, solid (MSRP = No Charge), Tangier Orange
A28	Window, rear sliding
AJ1	Glass, Solar-Ray deep tinted
AM6	Seats, front 60/40 split-bench
AM6	Seats, front 60/40 split bench
AM6	Seats, front 60/40 split-bench
AN3	Seats, front leather seating surfaces high-back reclining buckets
ANL	Fog lamps, front
ANL	Fog lamps, front
AV5	Seats, front high-back reclining buckets
AV5	Seats, front high-back reclining buckets
AV5	Seats, front high-back reclining buckets
B30	Floor covering, color-keyed carpeting
B32	Floormats
B32	Floormats
B94	Gold Package
BG9	Floor covering, rubberized vinyl
BZY	Xtreme specific bed liner
C3A	GVWR, 4400 lbs. (1996 kg)
C5A	GVWR, 4900 lbs. (2223 kg)
C5A	GVWR, 4900 lbs. (2223 kg)
C5D	GVWR, 4600 lbs. (2087 kg)
C5D	GVWR, 4600 lbs. (2087 kg)
C5T	GVWR, 4200 lbs. (1905 kg)
C60	Air conditioning, front manual
C6F	GVWR, 5150 lbs. (2336 kg)
CF5	Sunroof, power
D34	Visors, padded
D44	Mirrors, outside rearview, foldaway, manual, Black
D98	Xtreme accent stripe, for hood or Flame side decal, roof and tailgate
DC4	Mirror, inside rearview
DH6	Visors, padded
DK2	Mirrors, outside rearview, foldaway, power, heated
DK7	Console, overhead custom
E62	Pickup bed, Sportside
E63	Pickup bed, Fleetside
E95	Cargo cover, soft tonneau
FE9	Emissions, Federal requirements
G80	Differential, locking, heavy-duty, rear
GT4	Rear axle, 3.73 ratio
GT5	Rear axle, 4.10 ratio

Option Code	Description
GT5	Rear axle, 4.10 ratio
GT5	Rear axle, 4.10 ratio
GU4	Rear axle, 3.08 ratio
GU4	Rear axle, 3.08 ratio
GU6	Rear axle, 3.42 ratio
GU6	Rear axle, 3.42 ratio
JC1	Brakes, 4-wheel antilock, 4-wheel disc
K60	Alternator, 100 amps
LN2	Engine, Vortec 2200 L4 MFI
LU3	Engine, Vortec 4300 V6 MFI
M30	Transmission, 4-speed automatic
M30	Transmission, 4-speed automatic
M30	Transmission, 4-speed automatic
M50	Transmission, 5-speed manual
M50	Transmission, 5-speed manual
M50	Transmission, 5-speed manual
MW2	Transmission, 5-speed manual
MW2	Transmission, 5-speed manual
N60	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum
N90	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) aluminum, cast
N96	Wheels, 4 - 16" x 7" (40.6 cm x 17.8 cm) aluminum, 5-spoke
NB8	Emissions override, California, Maine, Massachusetts, New York or Vermont
NC7	Emissions override, Federal
NE1	Emissions, Maine or Massachusetts state requirements
NG1	Emissions, New York or Vermont state requirements
NP1	Transfer case, electronic shift
NP5	Steering wheel, leather-wrapped rim
PA3	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) bright aluminum
PCX	Special Equipment Package, bed extender
PCZ	Special Equipment Package, chrome bed rails
PDA	Special Equipment Package, Black anodized bed rails
PDB	Special Equipment Package, natural brushed aluminum bed rails
PDU	Special Equipment Package, hard lockable tonneau cover
PDW	Special Equipment Package, soft tonneau cover
PDZ	Special Equipment Package, trailer hitch
PH1	Wheels, 4 - 15" x 7" (38.1 cm x 17.8 cm) steel painted Gray
QBF	Tires, P235/70R15, all-season, blackwall
QCA	Tires, P205/75R15, all-season, White outlined-letter
QCB	Tires, P235/55R16, all-season, blackwall
QCE	Tires, P205/75R15, all-season, blackwall
QEB	Tires, P235/75R15, on-/off-road, White outlined-letter
QWU	Tires, P265/75R15
T61	Daytime running lamps
U16	Instrumentation, tachometer
UC6	Sound system, ETR AM/FM stereo with 6-disc CD changer
UC6	Sound system, ETR AM/FM stereo with 6-disc CD changer
UM7	Sound system, ETR AM/FM stereo
UN0	Sound system, ETR AM/FM stereo with CD player
UP0	Sound system, ETR AM/FM stereo with CD player and cassette

RPO CODES

Option Code	Description
V10	Cold Climate Package
V4A	Xtreme Sport Appearance Package
V76	Recovery hooks, 2 front, frame-mounted
VCL	Emissions, Federal Clean Air
VF6	Bumpers, front and rear
YC5	LS trim, with exterior appearance package
YF5	Emissions, California state requirements
Z83	Suspension Package, Solid Smooth Ride
Z85	Suspension Package, Increased Capacity
Z85	Suspension Package, Increased Capacity
Z85	Suspension Package, Increased Capacity
ZAA	Tire, spare, compact, located at rear underbody of vehicle.
ZBF	Tire, spare P235/70R15, all-season, blackwall
ZCA	Tire, spare P205/75R15, all season, White outlined-letter.
ZCE	Tire, spare P205/75R15, all-season, blackwall
ZEB	Tire, spare P235/75R15, on-/off-road, White outlined-letter
ZM5	Skid Plate Package
ZQ3	Convenience Package
ZQ6	Convenience Package
ZQ8	Suspension Package, Sport
ZR2	Suspension Package, Wide Stance
ZR5	Appearance Package
ZWU	Tire, spare

2003 Chevrolet Truck S10

TRAILERING SPECS - Automatic Transmission Ratings with Ball Hitch

Maximum trailer ratings are calculated assuming standard equipped vehicle, driver and required trailering equipment. The weight of optional equipment, passengers and cargo will reduce the maximum trailer weight your vehicle can tow. 10 to 15% of the trailer weight is the recommended trailer tongue load.

Automatic Transmission Ratings with Ball Hitch					
Model	(LN2) Va	rtec 2200 L4 MFI	(LU3) Vortec 4300 V6 MFI		
	Axle Ratio	Maximum Trailer Weight lbs. (kg)	Axle Ratio	Maximum Trailer Weight lbs. (kg)	
CS10603	4.10	3100 (1406)	3.42	6000 (2722)	
CS10653	4.10	3000 (1361)	3.42	5600 (2540)	
CS10803			3.42	5900 (2676)	
CT10653 w/o ZR2			3.42	5500 (2495)	
			3.73	5500 (2495)	
CT10653 w/ZR2			3.73	4700 (2132)	
CT10643			3.42	5200 (2359)	
			3.73	5200 (2359)	

Note: S-10 pickups equipped with Xtreme Sport Appearance Package are not designed, nor intended, to tow a trailer.

Engine	(GCWR) Gross Combination Weight Ratings lbs. (kg)		
	6500 (2948)	9500 (4309)	
(LN2) Vortec 2200 L4 MFI	4.10		
(LU3) Vortec 4300 V6 MFI		3.42 /3.731	

TRAILERING SPECS - Manual Transmission Ratings with Ball Hitch

Maximum trailer ratings are calculated assuming standard equipped vehicle, driver and required trailering equipment. The weight of optional equipment, passengers and cargo will reduce the maximum trailer weight your vehicle can tow. 10 to 15% of the trailer weight is the recommended trailer tongue load.

Manual Transmission Ratings with Ball Hitch				
	(LN2) Vortec 2200 L4 MFI		(LU3) Vortec 4300 V6 MFI	
Model	Axle Ratio	Maximum Trailer Weight lbs. (kg)	Axle Ratio	Maximum Trailer Weight lbs. (kg)
CS10603	3.73	1600 (726)	3.08	3900 (1769)
CS10653	4.10	2000 (907)	3.08	3800 (1724)
CS10803			3.08	3900 (1769)
CT10653 w/o ZR2			3.42	4000 (1814)
CT10653 w/ZR2			3.73	4200 (1905)

Note: S-10 pickups equipped with Xtreme Sport Appearance Package are not designed, nor intended, to tow a trailer.

GCWR For Engine/Rear Axle Ratio Combination with Manual Transmission					
Engine		(GCWR) Gross Combination Weight Ratings lbs. (kg)			
	5000 (2268)	5500 (2495)	7500 (3402)	8000 (3629)	8500 (3856)
(LN2) Vortec 2200 L4 MFI	3.73	4.10			
(LU3) Vortec 4300 V6 MFI			3.08	3.42	3.73